1 TEPT

Encyclopedia

Figure 10 pedia

Figure 10 pedia

Technica

History and Basic Operation of the Sol



The Complete Guide to Processor Technology Corporation Products

Published by

Proteus
The Processor Technology Users' Group
1690 Woodside Road, Suite 219
Redwood City, California 94061

ed Abila Coughy' 114

reng 1 - 1 everni "L'Anclos, uzava" drug 1917 - 201de hotol Burtu 213

ENCYCLOPEDIA PROCESSOR TECHNICA

The complete guide to Processor Technology Corporation's Products

Edited by Stanley M. Sokolow, B.A., D.D.S. Sonya Sokolow, Ph.D.

Published by Proteus, Processor Technology Users Copyright (C) 1982 Proteus

CONTENTS Revised 4/19/82

Volume 1 -- History and basic operation of the Sol. Preface to the Encyclopedia Processor Technica. Includes the semi-technical Sol Users Manual that came with later Sols, functions of the Sol's buttons and switches, hookups to common printers, cassette operations, use as a dumb terminal, minor troubleshooting. Also a historical scrapbook of Processor Technology Corporation and of the Sol: reprints of articles which describe the way the Sol came to be, copies of old advertising, product catalogs, price lists, dealer list, historical accounts from insiders, Personal Computer Retailer newsletter for dealers, all issues of Access newsletter.

Volume 2 -- Technical manual on the Sol computer. It incorporates material from the big black looseleaf notebook that came with early Sol's, plus material taken from the PTC Sol Service Manual, from Access (PTC's newsletter to users), from Proteus, and from other sources. Covers topics such as: theory of operation, schematics, assembly drawings, parts lists, troubleshooting, testing, hardware updating (rev D to rev R), constructing and using the ParaSol Debugger, input/output hookups, timing diagrams, testpoint voltages, hardware interfacing, user-originated modifications.

Volume 3 -- Programming the Sol. Solos user's manual, the 8080 microprocessor from the programmer's view, the 8080 instruction set, assembly language programming, communications interface programs, the Sol system architecture.

Volume 4 -- PTC Programming Manuals.

Volume 5 -- ALS-8, Assembly Language System. Including the user's manual, users' group newsletters, internal routines.

Volume 6 -- PTC memory boards. From the 2KRO ROM board to the 64KRA-1 RAM board. Schematics, assembly drawings, theory of operation, switch settings, engineering changes, upgrades, troubleshooting, ROM listings, parts lists, etc.

Volume 7 -- PTC input/output interfaces. The 3P+S, the CUTS board, the VDM.

Volume 8 -- Helios Disk System Manual. Installation, testing, light maintenance, theory of operation, drawings.

Volume 9 -- Helios Service Manual. Sol/Helios System troubleshooting. Updates, Controller/formatter troubleshooting, PerSci Drive Maintenance.

Volume 10 -- Programming the Helios disk system. Users' manuals on the following: PTDOS 1.5, Extended Disk BASIC, Optional Precision BASIC, Level I Business BASIC (Demoversion), Disk Basic/5.

Volume 11 -- SolPrinters and Hytype interface.

Volume 12 -- Sol a la carte. Using the Sol with other equipment, such as interfacing to other disks, modifying memory boards to work properly in Sol, customizations for the Sol with CP/M, NorthStar, Micropolis, etc. (This volume to be published at a later date.)

ENCYCLOPEDIA PROCESSOR TECHNICA

Foreword to the Encyclopedia

by Stanley M. Sokolow, B.A., D.D.S.

Since August, 1977, I have been the de facto Executive Director of the organization for owners of Processor Technology Corporation Sol computers. Originally, we called ourselves "Solus" (pronounced like "solice"), a name coined by Bill Burns, the founder of the group. The name represented "SOL Users Society," but it really had a double meaning since the early Sol users actually needed a lot of solice to cope with Processor Technology Corporation's growing pains.

Later, I changed the name to "Proteus" (for PROcessor TEchnology USers) to indicate a broader scope, covering all of the Processor Technology product line, not just the Sol. Proteus has continued to be the primary focal point for communication among Sol owners, mainly through our newsletter.

This Encyclopedia represents the accumulation of information which Proteus has been able to gather on Processor Technology products. It is envisioned as a living resource which will be updated as new information becomes available. Any reader who has information or literature on any Processor Technology hardware or software product is requested to submit this material to Proteus for inclusion into future editions of the Encyclopedia and its supplements. (The original documents will be returned to you if requested.)

I also urge all owners of Sol computers to subscribe to our newsletter, called Proteus News. This has been an invaluable source of practical information about the Sol and other Processor Technology products. Our hope is that the organization will continue to keep the Sol a viable computer as long as there is interest in it, and even far into the future when it is an antique.

Proteus's address is Proteus, c/o Stanley M. Sokolow, 1690 Woodside Road, Suite 219, Redwood City, California 94061.

EXPLANATION OF PAGE NUMBERING

Since the material in the Encyclopedia has come from many

sources, the original page numbering is out of sequence. Instead, we refer to new page numbers at the top of each page. They have this form:

5 EPT 7 - 123

where "EPT" means Encyclopedia Processor Technica, the number before it means the volume number, the number following is the chapter number, and the number after the hyphen is the new page number. We left the old page numbers intact so that references to them in the body of the text could be found.

property and which was been and the first that the standard of the standards

ENCYCLOPEDIA PROCESSOR TECHNICA

Copyright (C) 1982 Proteus 1690 Woodside Road Redwood City, California 94061

DISCLAIMER

The information presented in this and other volumes of the Encyclopedia Processor Technica is published in the interest of the owners of Processor Technology Corporation products. The publisher assumes no liability for the accuracy of the content presented, although we have done our reasonable best to include only accurate information. It is assumed that the reader will use due care in utilizing the information, especially with regard to suggested modifications to products.

ever and unifor (C) engaginged a read objections for t table encoded for the Colonia

ada in manufor mode on a cir ma manuer que l'arraciat e il no l'arraciat e il no depende di composito e il norma del producto del composito e il norma del producto del composito e il norma del composito e il norma del producto del composito e il norma del composito e il

ENCYCLOPEDIA PROCESSOR TECHNICA

Volume 1

History and Basic Operation of the Sol

CONTENTS

	Page
Foreword to the Encyclopedia.	
Preface to Volume 1.	
Chapter 1. Historical Scrapbook of Processor Technology. "VDM-1" (Jan 1976)	2 4 6 8 10 11.1 11.6 12
Compatible Circuitry," by Lee Felsenstein and Robert Marsh (Feb 1977)	
Personal Computer Retailer, Vol. 1 No. 1 (March 1977) The Small Computer Catalog, May 1977 "Sol: The Inside Story," by Lee Felsenstein (July 1977)	31
"The Sol-20 Computer Terminal," by Rudolf Hirschmann (Aug 1977)	
Sol System Suggested Retail Price List (Sept 1, 1977) "Why Sol Should be your Small Computer Choice." "Helios II Disk Memory System." (Product description)	61
Sol Small Computer Systems (Catalog)	70 78
1978)	84
Personal Computer Retailer, July 18, 1978	87 93
Personal Computer Retailer, Sept 7, 1978	
Sol System Suggested U.S. Retail Price List (Oct 1, 1978)	
Retailer Memo, October 12, 1978	.109 .113

A compart of the acceptance of the following section of

1 sentist

the education relatively to take one protects

5 17831 603

nya4

allenger word and the Ecoverage of the

.i employ or england i.

Personal Cor Processor Te Personal Cor "Processor 5 6/25/75 "A User's Re Bumpous "User's Repo	aputer Retailer, Decemputer Retailer, January 190 Day Liminguter Retailer, April Technology Goes Under Retailer, January 1978 December 1978.	ited Warranty, 2 ited Warranty, 2 it 18, 1979 r," by Tom Willi Computer" by Farranty, 2 item of the second s	125 2/6/79.129 130 iams 136 Robert 137
Chapter 2. Proc Vol 1, No 1, Vol 1, No 2, Vol 1, No 3, Vol 1, No 4	cessor Technology ACC February 1977 April 1977 June 1977 November 1977 March 1978	CESS Newsletter	2 14 30
Appendix 2. Select: Interco Appendix 3. Appendix 4.	Users Manual. Exploring the Sol Sy At the Controls Introduction to Soft Loading Programs from At the Keyboard (Key Unpacking and Install TLC for Your Sol (Lie Products Available of Cassette Recorder Stang a Cassette Reco	tware	18 22 28 36 45 29 65 65 66 68

The second of th

The second of Table Control to the second of the second of

VOLUME 1

PREFACE

This first volume of the Encyclopedia Processor Technica is intended to provide a general introduction to the Sol computer and its manufacturer, Processor Technology Corporation. The history is sketchy because when the corporation went out of business the records were mostly all discarded and the employees scattered as they went on to new projects. As more information is uncovered, we will publish it in our annual supplements to the Encyclopedia. We hope that readers who have something of value to add will contact Proteus and help us fill in the gaps.

In addition to this volume, historical information can be gleaned from back issues of Proteus News, the newsletter of the Processor Technology Users, publisher of this Encyclopedia. These back issues are available in a separate volume.

Stanley M. Sokolow, Editor

35.00

age to the control of the control of

, But a particular

1 EPT 1 - 1

Chapter 1. Historical Scrapbook of Processor Technology 1	
"VDM-1" (Jan 1976)	
"BYTE's Audio Cassette Standards Symposium (Feb 1976) 4	
"4KRA" (March 1976)	
"Altair" (April 1976)	
"8080 Expansion" (June 1976)	
"Popular Electronics" (July 1976)	
"8080 Compatible" (Sept 1976)	
"Sol-20" (Nov 1976)	
"Sol" (Dec 1976)	
"Intelligent-Terminal Designers Opt for 8080-	
Compatible Circuitry," by Lee Felsenstein and	
Robert Marsh (Feb 1977)	
Personal Computer Retailer, Vol. 1 No. 1 (March 1977)23	
The Small Computer Catalog, May 197731	
"Sol: The Inside Story," by Lee Felsenstein (July	
1977)53	
"The Sol-20 Computer Terminal," by Rudolf Hirschmann	
(Aug 1977)59	
Sol System Suggested Retail Price List (Sept 1, 1977)61	
"Why Sol Should be your Small Computer Choice."63	
"Helios II Disk Memory System." (Product description) 64	
Sol Small Computer Systems (Catalog)70	
Personal Computer Retailer, May 3, 1978	
"Build an all-in-one home computer," by J. Free (June	
1978)	
Sol System Suggested U.S. Retail Price List	
(July 1, 1978)85	
Personal Computer Retailer, July 18, 197887	
Technical Training Seminars Diploma93	
Sol Dealer List, August 197894	
Personal Computer Retailer, Sept 7, 197895	
Product Description: "WordWizard Electronic Typing	
System"101	
Sol System Suggested U.S. Retail Price List	
(Oct 1, 1978)105	
Retailer Memo, October 12, 1978109	
Personal Computer Retailer, November 20, 1978113	
Personal Computer Retailer, December 18, 1978119	
Personal Computer Retailer, January 26, 1979125	
Processor Technology 90 Day Limited Warranty, 2/6/79129	
Personal Computer Retailer, April 18, 1979130	
"Processor Technology Goes Under," by Tom Williams	
6/25/79	

BYTE January 1976 pp. 20,21

1 EPT 1 - 2

features-

- ultra high speed intelligent display
- generates 16, 64 character lines of alpha-numeric data
- displays upper and lower case characters
- full 128 ascii characters
- single printed circuit card
- standard video output

- \$160.00-

SPECIAL FREE OFFER! Scientific Notation Software Package with Formatted Output


The floating point math package features 12 decimal digits with exponents from +127 to -127; handles assigned and unassigned humbers. With it is a 5 function calculator package: $+ - \times \div &$ sq. root. It includes 3 storage and 3 operating memories and will handle chain and column calculations.

With the purchase of (1) VDM-1 and (1) 4KRA-4 Memory:

Just \$299.00 (Offer expires 2-1-76)

from-Processor Technology

VIDEO DSPIAY MODULE



COPPOPATION D 2465 Fourth Street Berkeley, Ca. 94710



Report:

BYTE's Audio Cassette Standards Symposium

Manfred and Virginia Peschke

BYTE Magazine sponsored a symposium on November 7 and 8, 1975 in Kansas City MO regarding the interchange of data on inexpensive consumer quality audio cassette drives. These drives may be used as one of the mass storage devices in the first generation of personal computers, and will retain importance for some time to come as a means of interchange of software between computer enthusiasts who purchase products of the small systems industry. In order to promote the growth of the industry, BYTE sought to achieve an industry standard on audio cassette data interchange through a working conference.

We extend our greatest appreciation to the 18 people who worked very hard until late Friday night and Saturday morning to discuss the multitude of problems and solutions associated with digital recording on auto cassettes. The names of the participants are listed in table 1. In spite of the short time available, the participants were able to draft a set of provisional standards which seems to promise great reliability and is rather inexpensive to implement; implementations may be entirely in hardware, or may require a mix of software and some minimal hardware. Considerations were given to the problems of speed variation among recorders and playback equipment, start and stop delays, recording density (or speed) versus reliability, and recording frequencies to avoid interference with the telephone network in case some users plan to transmit the tones of the cassette over the phone lines.

On Saturday afternoon, Mr. Felsenstein and Mr. Mauch volunteered to write up the consensus among the participants as to a provisional standard which has been reproduced below.

Provisional Audio Cassette Data Interchange Standard

The consensus among the participants of the audio cassette standards symposium at Kansas City MO sponsored by BYTE Magazine is as follows: The proposed standard centers around the use of a frequency shift modulation method from which serial clock data can be extracted at rates of up to 300 baud. The system is intended to be used with low to medium cost cassette recorders incorporating electrical stop and start capability which may be operated under program control.

The technique proposed provides for long and short term tape speed variation, limitations in bandwidth due to effects such as tape misalignment, and the necessity to retain low cost and low complexity of the hardware. The technique allows for potential operation at higher tape speed than the nominal 1.875 inch/s (4.75 cm/s).

A mark (logical one) bit consists of eight cycles at a frequency of 2400 Hz.

A space (logical zero) bit consists of four cycles at a frequency of 1200 Hz.

A recorded character consists of a space as a start bit, eight data bits, and two or more marks as stop bits.

The interval between characters consists of an unspecified amount of time at the mark frequency. In this respect the data format is similar to that of asynchronous data communication.

The eight data bits are organized least significant bit first, most significant bit last, and followed (optionally) by a parity bit. The total number of significant bits and the parity bit cannot exceed 8.

Where less than eight data bits are used, the unused bits (following the optional parity bit) at the end of the character are mark bits (2400 Hz).

Data will be organized in blocks of arbitrary and optionally variable length, preceded by a minimum of five seconds of marks

To avoid errors due to splice and wrinkle problems common at the begining of tape, the beginning of the first data block will occur no sooner than 30 seconds from the beginning of clear leader.

The contents of the data block are not specified.

The data block ends after the stop bits of the final character.

Bit clocking information may be extracted from the recorded waveform, which is always an integer multiple of the bit rate, regardless of tape speed. This permits the recovery and retiming of data by means of a UART, which requires a clock of sixteen times the bit rate, although other simple circuitry may be used.

A reliable bandwidth of 3000 Hz was assumed in choosing mark and space frequencies due to the head misalignment expected between various cassette recorders. The recording technique is a redundant form of Manchester or bifrequency code which has a long history of reliability in the computer industry. In its present form it was proposed by three independent manufacturers at the conference. One cited reliability rates of one error in 10**7 characters for 200 passes.

Table 1: Participants at Audio Cassette Symposium.

Ray Borrill, 1218 Prairie Dr, Bloomington IN

Hal Chamberlin, The Computer Hobbyist, P O Box 5985, Raleigh NC 27607

Tom Durston, MITS, 6328 Linn NE, Albuquerque NM

Lee Felsenstein, LGC Engineering, 1807 Delaware St, Berkeley CA 94703

Joe Frappier, Mikra-D, 32 Maple St, Bellingham MA

Bill Gates, MITS

Gary Kay, Southwest Technical Products Corp, 219 W Rhapsody, San Antonio TX 78216

Bob Marsh, Processor Technology, 2465 Fourth St, Berkeley CA 94710

Harold A Mauch, Pronetics, 4021 Windsor, Garland TX 75042

Bob Nelson, PCM, San Ramon CA

George Perrine, HAL Communications Corp, Box 365, Urbana IL 61801

Ed Roberts, MITS

Richard Smith, The Computer Hobbyist, P O Box 5882, Raleigh NC 27607

Les Solomon, Popular Electronics, 1 Park Av, New York NY 10016

Michael Stolowitz, Godbout Electronics, Box 2355, Oakland Airport CA 94614

Paul Tucker, HAL Communications Corp

Mike Wise, Sphere, 791 S 500 W, Bountiful UT 84010

Bob Zaller, MITS

1K 475 ns STATIC RAM \$4.25 for one \$4.00 each for eight

SIGNETICS 2602-1 all orders shipped postpaid and insured. Mass residents add 3% sales tax

\$3.75 each for 32

WHY PAY FOR BEING SMALL?

Centi-Byte is a new source of memory components and other necessary items for the computer hardware builder. Our function is to be a voice to the manufacturing companies representing you, the modest volume consumer of special purpose components. Centi-Byte brings you this special introductory offer of fast memory chips, chips fast enough to run an MC6800 or 8080 at maximum speed. These 2602-1's are new devices purchased in quantity and fully guaranteed to manufacturer's specifications.

Centi-Byte works by concentrating your purchasing power into quantity buys of new components. Let us know what you need in the way of specialized components and subsystems for future offenings. With your purchasing power concentrated through us, together we will lower the cost of home computing.



PO BOX 312 BELMONT, MASS. 02178

OSI MODEL 300 COMPUTER TRAINER

THE MODEL 300 IS A COMPLETELY ASSEMBLED AND TESTED, READY TO USE, COMPUTER DESIGNED TO "BOOTSTRAP" THE STUDENT, HOBBYIST, AND ENGINEER INTO THE MICROPROCESSOR WORLD. THE UNIT IS BUILT AROUND THE MOS 6502 B BIT MICROPROCESSOR AND USES A 128 WORD RAM. ITS CONTROLS INCLUDE B DATA SWITCHES, 7 ADDRESS SWITCHES, MEMORY LOAD, PROCESSOR RESET, PROCESSOR RUN. INTERRUPT, AND MEMORY WRITE PROTECT. THE DISPLAYS INDICATE DATA, ADDRESS, AND PROGRAM EXECUTION TWO INPUT LINES AND ONE OUTPUT LATCH ARE PROVIDED FOR 1/O PROGRAMMING. THE MODEL 300 COMES COMPLETE WITH A LABBRATORY MANUAL WITH 20 EXPERIMENTS STARTING WITH SIMPLY LOADING AND READING MEMORY AND FINISHING WITH OUTPUTING TO A TELETYPE.

THE 6000 SERIES COMPUTER FAMILY (SUPERBOARD)

A COMPLETE MINICOMPUTER PC BOARD (DOUBLE SIDED EPOXY) WHICH ACCEPTS ANY 6000 SERIES PROCESSOR, SYSTEM CLOCK, 2- 1702 TYPE ROMS, 1K X 8 RAM (2102 TYPE), 1 PIA, 1ACIA, CURRENT LOOP AND PARALLEL INTERFACES AND HAS BUS EXPANSION CAPABILITIES. EACH SUPERBOARD COMES COMPLETE WITH DOCUMENTATION.

SIPER	BOARD BARE WITH	MANUAL	29.00
5800	MICROPROCESSOR	MANUAL AND SUPERBOARD AND SUPERBOARD AND SUPERBOARD FEATURES	69.00
6502	MICROPROCESSOR	AND SUPERBOARD FEATURES	49.00
	INTERNAL CLOCK		54.00

ALSO AVAILABLE:
ALL SYSTEM SUPPORT PARTS
RAM - ROM MEMORY EXPANDER BOARD
SUPERI/O BOARD CONTAINING CASSETTE INTERFACE; X, Y DISPLAY
AND A/D CONVERTER.
VIDEO GRAPHIC BOARD

COMING SOON: FIRMWARE $\underline{\mathsf{BASIC}}$ BOARD (USES ROM AND CALCULATOR CHIP)

CALL (216) 653-6484 OR WRITE TODAY FOR OUR COMPLETE INFORMATION PACKAGE




OHIO SCIENTIFIC INSTRUMENTS

P.O BOX 374 HUDSON, OHIO 44236

Harch 1876 pp. 48,49 BYTE

LOW POWER MEMORIES AT A NEW LOW PR



Vant Details?

The Processor Technology 4KRA-4 is the fastest, most reliable and yet, least expensive read/write memory module on the market today. The 4KRA-4 is the only memory available of any kind that can be powered by two "D" size batteries for up to ten (10) hours. (Ask for our TB-101 technical bulletin on back-up battery operation of the 4KRA-4).

Don't be mislead by "undirected" statements on the subject of memory power consumption. All RAM's used in the 4KRA-4 consume typically 1/3 the power of 8101 or 2102 type memories. Under absolute worst case conditions our RAM's require only 30% more power than the "typical" consumption of any 4K dynamic memory. Remember that dynamic memories use three power supplies, but static memories only one.

It's time to clear the air of any confusion anyone might have about memory speed. In any 8080 system, all memories with access times between 50 and 520 nanoseconds are the same speed! Access time alone is not a valid indicator of speed unless it is greater than 550 nanoseconds, thereby requiring slow-down "wait" states. However, two other factors affect overall system speed.

1) Dynamic memories must refresh themselves periodically, slowing down the micro processor. In a well designed dynamic memory system refresh slows the processor by a few percent. Static memories do not require any refreshing. When our 4KRA-4 memories are used in the Altair 8800 the "wait" light goes out, indicating maximum speed operation.

2) Long cycle times can slow the system down during critical operations such as Direct Memory Access. DMA is used by most disk memories and by such devices as a soon to be announced color graphics generator. Most dynamic memories now on the market have a 1500 nanosecond cycle time, about three times that of our 4KRA-4. This longer cycle time can slow down the DMA device by at least 33%!

Most important, our 4KRA-4 Static Memories work, and keep on working! Processor Technology has four 8800 computers, each using at least 32K Bytes of 4KRA-4 memory. We use these machines heavily for program development and product testing. We have yet to lose a single bit in normal operation! Reports from our customers confirm our experience and indicate that we have one of the lowest failure rates in the industry.

Frankly, we have done everything we could to make the best read/write memory around, because, after all, memory is the most important part of any computer.

SPECIFICATIONS: 4KRA-4

Maximum capacity: 4096 eight bit bytes

Operating mode: Static

Access time: 520 nano-seconds, worst case maximum Cycle time: 520 nano-seconds maximum, read or write Bus Pinout: Plug-in compatible with Altair 8800 Bus Edge contacts: Gold plated, 100 pins (dual 50) on .125" centers


Power requirements, operating: +7.5 to +10VDC at 1.0A maximum (0°C), 0.8A typ ical at 25°C.

> standby: +1.6 to +2.5VDC at 0.5A maximum worst case, 0.4A

typical

Dimensions: 5.3" x 10.0" (13.46cm x 25.4cm)

VIDEO DISPLAY MODULE



Please don't think of the VDM-1 as an ordinary TV typewriter! The VDM-1 is an intelligent display whose capabilities are limited only by your imagination! All cursor and display formations are fully programmable - there are very few hardware limitations inherrent in the design.

The VDM-1 can be used as a terminal when running BASIC or our Resident Assembler using the FREE software drivers included with every kit.

The VDM-1 contains 1024 bytes of low power high speed RAM memory which can be directly accessed by the computer as any 1K segment within its normal 65K address range. The VDM-1 is a single pc card and is plug-in compatible with the Altair 8800 bus. Multiple cursors are possible, each fully programmable. The display can be black on white, white on black, or both simultaneously. Output is standard EIA video with a signal bandwidth of 7 Mhz, compatible with any video TV monitor. The VDM-1 is so fast, efficient, and powerful we think it will soon become the standard against which other displays must be compared.

SPECIAL FREE OFFER!

Scientific Notation Software Package with Formatted Output

The floating point math package features 12 decimal digits with exponents from +127 to -127; handles assigned and unassigned numbers. With it is a 5 function calculator package: + - X & sq. root. It includes 3 storage and 3 operating memories and will handle chain and column calculations.

With the purchase of With the purchase of (1) VDM-1 and (1) 4KRA-4 Memory: \$299 00 (Offer Expires April 1, 1976)

Please write for details on these and other Altair bus compatible modules



2465 Fourth Street Berkeley CA 94710 (415) 549 0857

With Help Of Course From

With Help, Of Course, From Line of Compatible Plug-in

All our products are compatible with the 8800 — they just plug in to become an integral part of your system.

Each card can be used in the widest range of applications, giving maximum versatility to your Altair.

Our "no compromise" philosophy assures you the highest possible quality. We use a conservative thermal design to provide for long life and reliable operation. We've also put hysteresis bus receivers on noise prone high-speed inputs, giving you maximum noise immunity. And, finally, we cover it with a full six- month warranty.

Video Display Module

Your Altair already has the intelligence, so let us provide the display module. This is **not** a limited "TV Typewriter", but an ultra-high speed computer terminal built into your computer. The **VDM-1** generates sixteen 64-character lines from data stored in the 1K Byte on-card memory. Alphanumeric data is shown in a 7 x 9 dot matrix with a full 128 **upper and lower case** ASCII character set. The VDM-1 features EIA Video output for any standard video monitor. (Your TV set can be easily modified at your local television repair shop.) Multiple programmable cursors, automatic text scrolling and powerful text editing software are included **free**. Kit Price, \$160.

A Versatile I/O Card

Just one **3P+S** card will fulfill the Input/ Output needs of most 8800 users. There are two 8-bit parallel input and output ports with full handshaking logic. There is also a serial I/O using a UART with both teletype current loop and EIA RS-232 standard interfaces provided. The serial data rate can be set under software control between 35 and 9600 Baud. You can use your models 15, 28 or 33 TTY! This module gives you all the electronics you need to interface most peripheral devices with the 8800. And, should you decide to buy a 3P+S, we'll be happy to advise you on the best way to implement your system with our module. Kit Price, \$125.

FOCAL!

Get a full 8080 implementation of 8K FOCAL* (including the game of Lunar Lander). It's now at your local Processor Technology dealer. Object tape is available for the copying charge only: complementary source listing available with minimum purchase.

(*® Digital Equipment Corp.)

An EPROM Module

Read Only Memories do not lose their stored data when power is removed. Thus, they have an advantage when used in stored program applications. Some ROM's, called EPROM's, are both erasable and reprogrammable. Our **2KRO** module will accept up to eight EPROM's, providing the user with up to 2048 eight bit words of nonvolatile storage for monitor, executive, loader, and other programs. (We recommend the use of 1702A and MM5203 EPROM types. They are not included, but are readily available for reasonable prices on the industrial and surplus markets.) Kit Price, \$50.

Altair Grow!

Processor Technology's Growing Hardware and Software.

Low Power, Plus!

The **4KRA** is a 4096 word read/write static memory module. It provides faster, less expensive, lower power, and more reliable operation than any comparable memory module sold today. The static memories don't need refreshing, so the result is faster speed in actual operation. Lower power does not mean decreased reliability. All RAM's used in the 4KRA are 91L02A's by Advanced Micro Devices. These RAM's typically require one-third the power of standard 2102 or 8101 types, and, even under worst case conditions, draw only 30% more than any currently available dynamic memory. Each RAM is manufactured to military specification. Since our module draws so little standby current, memory can be maintained using a battery back-up, in case of power failure, allowing long term retention of data. Kit Price, \$139.

Software

Our Assembly Language Listing (Package #1) is \$3, and includes the source listing with hexidecimal object code. Each command is described and six pages of sample use are included. Paper tapes of this system are available from many Computer Clubs throughout the country.

Turn-On-The-Switch Power

With our ALS-8, the full power of your computer is available at the instant you turn the switch. It provides 6K of PROM's, preprogrammed with an **expanded** version of our Software Package #1, including advanced file management capabilities. Files can be appended together, re-numbered, moved, or taken apart...all the features you'd expect from a company willing to practically give away Software #1. We include a manual which explains the use of the program (with examples), each routine of the system, and how to call these routines from other programs you've written. You won't be locked into a ROM version -- you'll be able to customize your ALS-8 to your individual needs. The ALS-8 Firmware includes a module with all components capable of holding 8K of "turn-on-the-switch" program, so it will be upward compatible with future software developments. And, two of these are up and running now. Kit Price, \$250.

An Interpretive Simulator...

Our SIM-1 Expansion Firmware runs 8080 programs, in an interpretive mode, on the same 8080 that contains the Simulator. This isn't just a de-bug program, because the program actually "thinks" it's an 8080! A complete brochure explaining all its capabilities is available from Processor Technology. Price, \$95.

And, A Text Editor!

Every ALS-8 includes the edit command. This command combined with our **Expansion Firmware #2** (Text Editor) and the VDM, adds the world of text editing to your system. Single characters, entire lines, portions of lines can be inserted, deleted, moved and, ultimately, printed out. The addition of Firmware =2 to your ALS-8 will give you text editing capability equivalent to systems selling for \$30,000 just a few short years ago. It's been running at Processor Technology since January, and it's ready for shipment **now.** Price, \$95.

Write us for complete specifications on these and other compatible plug-in products: Our single-piece Mother Boards will give you 16-card capacity in one installation. A Wire Wrap Board, to help you do your own wire wrap prototyping, creating custom interfaces. An Extender Board, which allows accessibility in servicing any 8800 compatible module.


All items postpaid if full payment accompanies order. COD orders must include 25% deposit. Master Charge (minimum \$25) accepted, but please send an order with your signature on it. Discounts on orders over \$375.



6200-B Hollis Street Emeryville, CA 94608 BYTE June 1976 pp. 56,57

The 8080 Expa

Let Processor Technology expand your Altain of and reliable plug-in modules.



Your Altair already has the intelligence, so let our VDM-1 Display Module make the best of its capacity to communicate. This is not a limited "TV Typewriter." The VDM-1 is an ultra-high speed output device, built right into your 8800 system.

1

li

S

The VDM-1 generates sixteen 64-character lines in a large easy-to-read font with both upper and lower case letters. It contains 1K (1024) bytes of random access memory, to which the processor can read or write, just as though the memory were an integral part of the system. As the information is written in, contents of the on-card memory are displayed instantly without interrupting the operation of the processor.

Once the processor provides the display status parameters, the VDM-1 can be made to "scroll" its display upwards or downwards. A built-in timer allows scrolling at about 4 lines per second, eliminating complicated timing program routines. At top speed, the display scrolls through a

dump of 65K of memory in two minutes; that's about 1000 lines per minute!

Multiple programmable cursor circuitry is built in. All 1024 cursors can be displayed at one time or begin anywhere in the display. Thus, the VDM-1 can display white-on-black or black-on-white—perfect for many video games! The VDM-1 also features EIA Video output for any standard video monitor, or a television repair shop can easily modify your own TV set.


The VDM-1 comes with free terminal mode software, designed for teletype replacement when used with BASIC or our own Resident Assembly system. (Powerful text editing software and various game packages are also available from Processor Technology Corp.)

Our detailed VDM-1 Owner's Manual is available for \$4.00, refundable with purchase of the VDM-1.

Kit Prices, \$179 (premium grade, low profile IC sockets included).

rnsion Principle.

OI IMSAI system—with innovative, excellent quality es. [At most agreeable prices, too!]



Sharpen your Memory!

Processor Technology's new 8KRA Static Memory Module will add double-capacity, lower power, and greater efficiency to your Altair or IMSAI system. We've actually improved on our already popular 4KRA board, by doubling the capacity (8192 eight-bit bytes!) and lowering the power-per-bit.

The 8KRA uses full speed, low power static RAM's—our prime supplier is AMD (91L02A's). These RAM's are manufactured to stringent military specification, MIL STD-883A, to insure reliability. The 8KRA uses less power-per-bit than any other true static memory module—requirements so low, that two "D" flashlight cells will retain data for 4-5 hours. (Recharging circuitry for Ni-Cad cells

Processor Technology manufactures a full line of plug-in modules compatible with the Altair and IMSAI minicomputers.

Write us now—we have a lot to tell you!

and battery connectors are on the card.) Also, unlike dynamic memories, static memories do not require periodic refreshing, allowing them to run at the processor's maximum speed.

The 8KRA occupies any 8K segment at 1K intervals within the 8080 addressing range (for example, from 3K to 11K, not just 0-8K). Card address is selected by a DIP switch, located conveniently at the top of the card. Each of the 76 Integrated Circuits has its own premium grade, low-profile IC socket. We've included this special feature to increase reliability, and to make assembly, testing and repairs many times easier.

8KRA 8192-word Static Memory Module \$295 (all sockets 4KRA 4096-word Static Memory Module \$154 included)



6200-L Hollis Street Emeryville, CA 94608 1 EPI 1 - 11.1

EASI-IU-BUILD BURGLAK ALAKM FUR APARTMENT USE

Popular Electronics

WORLD'S LARGEST-SELLING ELECTRONICS MAGAZINE

JULY 1976/\$1

MOBILE COMMUNICATIONS: CB vs. 2-METER FM

Microwave Ovens for the Home


CMOS Probe Extends Multimeter Use

Guide to Choosing TV & FM Antennas

Learning Electronic Theory With Hand Calculators

TEST REPORTS:

Nikko 7075 AM/FM Stereo Receiver MXR Stereo Equalizer SBE "Opti/Scan" Scanner Hickok 370 Analog Multimeter





1 EPT 1 - 11.2

HERE are essentially two types of video computer terminals in common use. The "dumb" terminallittle more than a "glass Teletype" is a simple data transmitter receiver whose only stand-alone function is its use as a TV typewriter. The "intelligent" (also known as "smart") terminal, on the other hand, offers powerful stand-alone features. Built around a sophisticated microprocessor, intelligent terminals allow you to write, store, and edit programs for transmission to a computer or a hard-copy device. It also provides very powerful word processing at relatively low cost.

The SOL video terminal project presented here is one of the most ad-

BUILD SOL

AND LEE FELSENSTEIN

An Intelligent Computer Terminal

Based on an 8080 MPU, this hobbyist's computer terminal can compete with most commercial units

vanced of intelligent terminals. It can interface with any mini- or microcomputer via its built-in RS-232 or 20-mA current-loop interfaces, in either serial or parallel format. It can also tie into a time-sharing computer via a telephone line and a modem (such as the Pennywhistle described in the March 1976 issue of POPULAR ELECTRONICS). In fact, it is even possible for two SOL terminals to communicate with each other without human supervision.

The key to SOL's versatility is its integral 8080 microprocessor (μ P) chip. The μ P operates on instructions stored in PROM's (programmable




Fig. 1. Terminal accepts data from keyboard, parallel port, and RS-232 or 20-mA serial port. Output is 1 volt p-p for conventional TV requirements. Memory can be externally expanded to 65 k.

PARTS LIST

C1-10-pF disc capacitor C2, C11, C21, C22-0.001-µF disc capacitor

C3, C7, C15, C16, C17, C18, C20, C27 through C63—0 1-µF disc capacitor C4. C5—680-pF mica capacitor monolithic C6—1.5-µF, 25-volt ceramic capacitor C8, C13-1-µF, 35-volt dipped tantalum

capacitor C9, C10-15-µF, 20-volt dipped tantalum

capacitor

C12-0.01-µF disc capacitor C14, C23-680-pF disc capacitor

C19-100-µF, 16-volt upright aluminum electrolytic capacitor

C24—0.1-µF Mylar tubular capacitor C25—0.001-µF Mylar tubular capacitor C26—0.01-µF Mylar tubular capacitor D1, D2, D4 through D9—1N4148 diode D3-5.1-volt, l-watt zener diode

(IN5231B or similar) IC1, IC8, IC11, IC12, IC23, IC39, IC73, IC74—74LS175N quad latch IC

IC2, IC79-74LS20N dual 4-input NAND gate IC

IC3-74LS86N quad exclusive-OR gate IC IC4, IC42, IC45, IC47, IC71, IC72, IC94 -74LS02N quad 2-input NOR gate IC IC5, IC51-7406N open-collector hex in-

verter IC IC6—DC4049AE CMOS hex inverter IC IC7, IC14, IC25, IC26, IC53, IC57— 74LS161 or 74LS163 4-bit synchronous

counter IC IC9-6575 MOS character generator IC

-74166N 8-bit parallel-in shift regis-IC10ter IC

IC13. IC24-CD4029AE 4-bit up/down counter IC

IC15-74L161, 74L163, or 93L16 4-bit synchronous counter IC (do not substitute)

IC93-74LS10N triple 3-input IC16, NAND gate IC

IC17—CD4001AE CMOS quad 2-input NOR gate IC

IC18 through IC21, IC29 through IC32— 21L01-1 or 91L02APC MOS 1024-bit

IC22, IC33, IC40, IC46, IC66, IC67, IC68, IC75, IC80. IC81, IC82-8T97 hex tristate buffer IC

IC27, IC48, IC78, IC95-74LS109N dual JK flip-flop IC

IC28, IC50, IC89, IC96-74LS04N hex inverter IC

IC34, IC35, IC36-74LS157N quad 2-input data selector IC

37—74HOON high-speed quad 2-input NAND gate IC (do not substitute)

IC38-74SO4N Schottky hex inverter IC (do not substitute)

IC41-MH0026P MOS clock driver IC IC43, IC87, IC90-74LS74N dual D flip-

flop IC IC44, IC83, IC86—74LS00N quad 2-input NAND gate IC

IC49, IC88-74LS08N quad 2-input AND

gate IC IC52-CD4046AE CMOS phase-locked

loop IC 554—TR1602B, AY-5-1013, or \$1883 UART IC

IC55, IC56-74173N quad tristate latch IC IC58 through IC61-21L01 or 91L01PC

256 × 4 MOS RAM IC 62, IC63, IC64, IC65—S5204A or MM5204Q 512 × 8 MOS erasable PROM IC (optional; write to address

below for details) IC69-8080, 8080A, or 9080A micro-

processor IC IC70, IC77, IC84, IC91—74LS253N dual 4-input tristate data selector IC

IC76-DM8836N quad 2-input NOR gate IC85, IC92-74LS155 dual 2-to-4 line de-

coder IC J1-Right-angle PC mount (AMP206584-1

or DB25S) Q1, Q2, Q3-2N2907 transistor

The following resistors are 4-watt, 10% tolerance:

R1, R2-330 ohms R3, R9, R10, R21, R23 through R30, R80-10,000 ohms

R4. R5, R6, R14 through R20, R22. R31 through R35, R37, R39, R41, R43, R45, R46, R48, R52, R56, R57, R58, R65, R72, R73, R74, R76, R77, R78, R79, R82, R83, R84, R89 through R98, R100, R101-1500 ohms

R7, R8—47 ohms R36, R67, R68, R99—4700 ohms R38, R40, R42, R47, R49, R53, R55—2200 oms

R44, R60, R81—3300 ohms R50, R54, R64, R87—100 ohms

R51-200 ohms

R59. R63—33.000 ohms R61. R62, R66—1000 ohms

R69-15,000 ohms

R70. R71. R113-100.000 ohms

R75, R88-3.3 megohms R85-75 ohms

R103, R105, R107, R109, R110, R111,

R112-8200 ohms

45 X-- --

R106, R108-39,000 ohms

R11, R12, R13-100-ohm 1-watt, 10% tolerance resistor

R86-330-ohm, 1/2-watt, 10% tolerance resistor

R102, R104-50,000-ohm trimmer potentiometer (Bourns No. 3352-1-503 or similar)

\$1 through \$4-Four-position dual in-line switch

-Momentary-action spst switch S6-Single-pole, seven-position rotary switch

S7, S8, S9-Spst switch S10-Spdt switch

XTAL-14.318-MHz, 0.01% or better tolerance, series-resonant crystal in HC18U case

Misc.—Two 40-pin, five 24-pin, 54 16-pin, and 31 14-pin IC sockets (optional); 75-ohm coaxial cable; TV monitor; ASCII keyboard; power supply; suitable chassis: mounting hardware; hookup wire; solder; etc.

では、100mmのできない。 100mmのでは、100mmのできない。 100mmのできない。 100mmのできないできない。 100mmのできない。 100mmのできない。

Note: The following items are available from Processor Technology Corp., 6200 Hollis St., Emeryville, CA 94608: Complete SOL-PC kit of parts (does not infor \$297.00. Available separately are SOL-PCB etched and drilled printed circuit board for \$40.00; SOL-SS set of IC sockets for \$40.00; and SOL-FAN fan for \$20.00. A complete kit that includes \$10.00. A complete kit that includes \$10.00. A complete kit that includes \$10.00. cludes all parts, pc board, power sup-ply, ASCII keyboard, all cables and plugs, and a case is available for \$497.00; specify kit SOL-1. Free copies of the complete schematic, etching and drilling guide, and component placement guide are available from the same source on request when accompanied by a selfaddressed stamped (26c) envelope (9" ×

read-only memories). In its basic configuration, the SOL terminal consists of a printed circuit assembly that contains the μP , 512 eight-bit bytes of PROM, 2048 eight-bit words of RAM (random-access memory), 1024-character video display generator, keyboard interface, serial and parallel interfaces for connection to external devices, and an edge connector for memory expansion. All you add are a power supply, TV receiver or video monitor, ASCII keyboard, and a case.

Since the SOL terminal is 8080 based, its memory capability can be expanded to 65k bytes. Hence, one might ask, is the SOL an intelligent terminal or a powerful microcomputer? In essence, it is both.

How It Works. The complete schematic diagram for the SOL terminal is much too large to be reproduced in this article. Therefore, a complete schematic, an etching and drilling guide, and component layout diagram for the printed circuit board are available on request simply by sending a self-addressed stamped (26c) envelope (9" × 12") to the source given in the Parts List.

The block diagram shown in Fig. 1 will be used to explain circuit operation. Notice the similarity of this diagram to that of a conventional 8080 microcomputer. The 8080 (or 8080A or 9080A) microprocessor. *IC69*, is the "heart" of the terminal. It is supported by *IC66* through *IC97*, which include address and data line drivers and selectors: "wait state" timers; flag latches for data ports; and partial address decoding. Both address and data I O (input output) ports are available for expansion using currently available 8080-type memory cards.

As many as four PROMS (IC62 through IC65) allow up to 2048 bytes of program to be installed in the terminal. Up to 512 bytes of RAM can also be installed and are designated IC58 through IC61.

SOL TERMINAL SPECIFICATIONS

Display: 16 lines of 64 characters per line. Black characters on white background or reverse.

Character set: 96 printable ASCII upper-and lower-case characters. Plus 32 control characters (optional).

Display position: Continuously adjustable both horizontally and vertically.

Cursor: Solid video inversion (switch selectable blink), cursors are programmable.

Serial interface: RS-232 and 20-mA current loop, 75 to 9600 baud, synchronous.

Parallel interface: Eight data bits for input and output; output bus is tristate for bidirectional interfaces; levels are standard TTL.

Keyboard interface: Seven-level ASCII encoded, TTL levels; requires strobe pulse with data stable for approximately 100 μs following positive edge.

Microprocessor: 8080, 8080A, or 9080A.

On-card memory: 512 bytes PROM (expandable to 2048 bytes), 1280 bytes

RAM (expandable to 1560 bytes).

External Memory: Expandable to 56k bytes total ROM, PROM, and RAM.

Signal output: 1.0 to 2.5 volts peak-topeak with composite negative sync; nominal bandwith is 7 MHz.

Power required: +5 volts at 2.5 amperes, +12 volts at 150 mA, and -12 volts at 200 mA; all buses must be well regulated.

The heart of the video display section is character generator ROM IC9. The generator provides both upperand lower-case characters in a 7×9 dot matrix format. Descenders on lower-case characters g, j, p, q, and y go below the base line to provide true typewriter character formatting. The remainder of the IC's in the video section (IC1 through IC36) produce the horizontal and vertical sync, cursor options, video inversion (black characters on white background) and all video "handshake" requirements.

The video output has a maximum bandwidth of 7.15 MHz. It contains a composite sync to allow operation with any conventional video monitor or monochrome TV receiver converted for video input (Fig. 2). Color TV receiver CRT's may not be capable of providing the resolution required for a clean video display, although the authors have obtained acceptable results using a type-approved r-f modulator to feed color receivers through the antenna input. (CAUTION: Do not use a transformerless video monitor or TV receiver unless a line-isolating transformer is installed.)

The /C54 UART is used in the terminal for data transmission and reception. It is supported by /C48 and /C51. Clock pulses for the UART are provided by the baud-rate generator made up of /C52, /C53, and /C57. Phase-locked loop /C52 operates with dividers to produce the required clock signals. A switch is provided for setting the baud rate for 75, 110, 150, 300, 600, 1200, 2400, 4800, or 9600 baud (data bits per second). The serial port has both RS-232 and 20-mA current-loop provisions.

The parallel port consists of an eight-bit latch made up of *IC55* and *IC56*. These IC's have tristate outputs that enable their use with a bidirectional parallel data channel if desired. Signals are eight data bits wide at standard TTL levels at the input and output.

The ASCII keyboard connects to the main terminal board by a single connector that provides power to the keyboard and accepts signals from the keys. The interface requires seven-level ASCII at TTL levels and a strobe pulse with the data stable for approximately 100 µs following the positive edge.

Power for the main board must be 5 volts dc at 2.5 amperes. +12 volts at 150 mA, and -12 volts at 200 mA. The power bus lines must be well regulated.

Construction. Since the printed circuit board measures $13^{\circ} \times 11^{\circ}$ (33×28 cm) and has numerous traces and pads that require careful registration, home fabrication of the board is not recommended unless you are highly experienced in making complex double-sided boards. Once you have the board and are ready to start mounting components, save IC installation for the last.

Start wiring the board by mounting






Fig. 2 Video output is conventional with negative sync and 1-volt p-p signal level.





Large connector at left rear of assembled circuit board assembly is for external memory; coax cable is for composite video output. All input and output connectors are on rear edge.

IC sockets (recommended for all IC's to make removal and replacement easy) in place. Next, mount and solder into place the resistors, capacitors, diodes, and transistors. Then mount the baud rate switch and connectors lush to the surface of the board; make sure they do not sit askew after soldering them down.

Once the crystal is mounted and soldered into place, pass a length of bare hookup wire over its case and into the holes flanking the case. Solder the wire to the crystal's case and board pads. Install and solder into place the coaxial cable for the terminal's output.

Carefully check the board assembly for poor soldered connections, solder bridges between closely spaced pads and traces, and proper polarization of diodes and capacitors and basing of the transistors.

Checkout. Before installing any IC's, power up the circuit board assembly to verify that no short circuits exist. Measure the potential across zener diode D3; it should be -5 volts. Check the fine foil traces near R85 (at the video output) for short circuits on the +12-volt line. If everything checks out, turn off the power.

Insert IC37 through IC41 in their ockets, making sure you properly orient them. Install jumpers from pad A to pad B and pad D to pad E (next to IC37). Turn on the power and use an oscilloscope to check the 47-ohm resistors next to IC41 for the clock

pulses. When you obtain the pulses, turn off the power.

Install IC1 through IC36. Be particularly careful when handling IC9 to avoid static discharges. After removing this IC from its protective foam carrier, be sure to touch the pc board with your other hand before bringing the IC into contact with its socket. Seat the IC carefully in its socket and gently press it home. (Note: If you encounter excessive resistance when trying to install IC9, replace the IC in its foam carrier. Then loosen the socket pin receptacles by repeatedly inserting and removing a non-MOS IC or piece of bare 24 gauge wire.) Install IC9.

Set horizontal and vertical sync controls R104 and R102 to midposition and the four-position dual in-line switch so that S1 and S4 are off and S2 and S3 are on. Connect SOL's video output cable to the video monitor and turn on the power to both monitor and terminal board. Displayed on the screen should be at least one line of random characters and white cursor blocks. Adjust the v and H controls on the terminal board for proper sync and the contrast and brightness controls on the monitor for the best display.

Set S3 to off and S4 to on; the cursor should flash at a slow rate. Set S2 to off; the background should change from black to white. Set S1 to on; the control characters (symbols or abbreviations, depending on the type of character generator being used) should disappear. Turn off the board's power supply

Install IC42 through IC50 and IC66 through IC97. Practice the same precautions for IC69, the microprocessor chip, that you took for IC9 above. Connect the "wait state" jumper at IC71 from pad W to pad 1.

With the video monitor still connected to the terminal and operational, turn on the board's power. The CRT screen should display one or more lines of alternating 9 and "null" characters and should flicker every few seconds. This indicates that the μP is working. If there is any doubt, briefly operate the RESET switch. If you observe no activity on the screen, turn off and remove power from the board and check that all IC's are in their proper sockets and properly oriented.

Install IC52 through IC61 and program PROM IC62. Use the same precautions detailed above for IC9 and IC69 when handling and installing IC54, IC58 through IC61, and IC62. Make sure that the socket for UART IC54 is not too tight. If you encounter difficulties during insertion, use a non-MOS IC or 24 gauge wire to loosen the socket pin receptacles.

Once everything seems to check out, power up the board. If the program is running properly, the monitor screen should display a blanked screen with the proper "message" at the bottom.

This completes construction of the SOL video terminal. You can now add an ASCII keyboard and hook up to the outside world via the serial and/or parallel ports.

1 EPT 1 - 11.6

ALTAIR 8800 USERS!

Did you know...

- That all our modules are 100% compatible with the Altair 8800 computer, NO modifications necessary!
- That our 4KRA Static Read/Write Memory module doesn't have to lose it's data when you pull the plug!
- That our 3P+S Input/Output module will fully interface two TV Typewriters with keyboards and a modem or teletype at the same time!
- That we make the most powerful alphanumeric Video Display module anywhere!
- That our software is FREE, or close to it!
- That all our modules are truly high quality, computer grade, but that our prices are the lowest in the industry!
- That we have already shipped hundreds of modules on time, and we will continue to deliver what we promise, FAST!

CHECK THE SPECS:

4KRA Static Read/Write Memory

This 4096 word STATIC memory provides faster, more reliable and less expensive operation than any currently available dynamic memory system. The 4KRA permits Altair 8800 operation at absolute top speed continuously. All RAM's (Random Access Memories) used in the 4KRA are 91L02A's by Advanced Micro Devices, the best commercial memory IC on the market today. 91L02A's require typically 1/3 the power of standard 2102 or 8101 type RAM's and each one is manufactured to military specification MIL STD-883 for extremely high reliability. These memories can be operated from a battery backup supply in case of power failure with very low standby power consumption. (Ask for our technical bulletin TB-101 on power down operation.) in short we have done everything we could to make the best 4.0 memory module in the computer field, and because we buy in large quantity, we can make it for a very reasonable price. Available now

2KRO Erasable Reprogrammable Read Only Memory Module With this module the Altair 8800 can use 1702A or 5203 type Erasable Reprogrammable ROM's. The 2KRO accepts up to eight of these IC's for a capacity of 2048 eight bit words. Once programmed this module will hold its data indefinitely whether or not power is on. This feature is extremely useful when developing software. All necessary bus interficing logic and regulated supplies are provided but NOT the EYROM IC's. Both 1702A and 5203 PROM's are available from other advertises in this magazine for well under \$25. Available now.

3P+S Input/Output Module

Just one 3P+S card will fulfill the Input/Output needs of most 8800 users. There are two 8-bit parallel input and output ports with full handshaking logic. There is also a serial i/O using a UART with both teletype current loop and EIA RS-232 usindard interfaces provided. The serial data rate can be set under software control between 35 and 9600 Baud. You can use your old model 19 TTY! This module gives you all the electronics you need to interface most peripheral devices with the Altair 8800, it's really the most useful and versatile I/O we've seen for any computer. Available now.

MB-1 Mother Board

Don't worry any more about wiring hundreds of wires in your Altair to expand the mainframe. Our single piece 1/8-inch thick, rugged mother board can be installed as one single replacement for either three or four 88EC Expander cards, so you don't have to replace your already installed 88EC card if you don't want to. The MB-1 has very heavy power and ground busses and comes with a piece of flat ribbon cable for connection to the front panel board of the 8800. Available now.

VDM-1 Video Display Module

This module is the first real computer terminal display in kit form. Under software control the VDM-1 displays sixteen 64 character lines to any standard video monitor. Characters are produced in a 7x9 dot matrix, with a full 128 character set, upper and lower case plus control characters. Data is accessed by the VDM as a block from any 1K segment within the 65K address range of the 8800 computer. Multiple cursors are completely controlled by software and the display can begin anywhere on the screen (this is great for many video games). When the last line is filled the display scrolls up a line. Powerful editing capabilities are provided with the FREE software package included in every VDM-1 kit. Available in September 75.

SOFTWARE

Our Asignbler, Test Titlor and System Executive is being store provides software perhage gives you very powerful an interest of the guage capability in the Altair 8800. The Executive and Built allow you to call programs by name (including DASIGE) of then add, delete, change, or list programs by line number. The Assembler provides a form red symbolic mnemonic listing as well a local or binary object code from Assembly Language programs written using the Editor. The Assembler also gives valuable error messages to help in debuyging those inswitable errors. The Assembler, Editor, Executive Package No. 1 will be available in read only memory along with an expanded Executive and a powerful Interpretive Simulator by October or November of 1975.

We are working on two BASIC Language packages which should be ready by October. One will be a basic BASIC needing about 8K of memory as a minimum and the other will be an Extended version with additional string manipulation, matrix operations and double precision arithmetic capabilities requiring about 12K. Both these packages will be available in Mosd Only Memory for a reasonable price.

PRICE LIST					
Item	Kit	Ascamble	d Delivery		
2KRO EPROM module	\$ 50.	S 75.	2 weeks ARO		
3P+S I/O module	125.	165.	3 works ARO		
4KRA-2 RAM module w/2048 8-bit words	135.	185.	2 weeks ARO		
4KRA-4 w/4096 8-bit words of RAM	210.	28 0.	2 weeks ARO		
RAM only, AMD 91L02A 500n sec low power	8/\$40	_	2 week ARO		
MB-1 Mother Board	3 5.	-	2 weeks ARO		
VDM-1 Video Display module	160.	22 5.	Sep. 25, 175 than 3 weeks ARC		

Send for our FREE flyer for more complete shelf-lications and for pricing on additional items.

TERMS: All items posipaid if full payment alcompanies order. COD orders must include 25% dicerain. WasterCharge glicity accepted, but please send us all order with your signature on it. DISCOUNTS: Orders over COTO mail subtract 5%, orders over \$600 may subtract 10%.







T.L. Todd Box 319 Platteville, WI 53818 First literature
Processor Technology
ever sent out!

REQUESTED INFORMATION

Could you use a Resident Assembler, Editor and Monitor for the 8800?

We have them!

GET TO KNOW THE FULL POWER OF YOUR ALTAIR!

PROCESSOR TECHNOLOGY CORP. provides the hardware AND the software you really need to accomplish things with your Altair 8800.

Want specifics?

- The only CRT terminal display module ever offered that is actually part of the computer
- A reasonably priced, LOW POWER, 4K Memory
- A versatile input/output module designed to meet most common I/O requirements with one card
- A reprogrammable read only memory (EPROM) module
- · A rugged full length mother board with improved power distribution and integral bus terminator and card cage
- FREE SOFTWARE, or close to it!
- Firmware ROM modules containing our Software programs

FEATURES:

- Full 8800 hardware and software compatibility: JUST PLUG IN!!
- Maximum versatility: each card can be used in the widest range of applications.
- Conservative thermal design for long life and reliable operation.
- Maximum noise immunity: hysteresis bus receivers on noise prone high speed inputs.
- Highest possible quality: No compromise design!
- 100% Guaranteed: six month warranty.

READ ON ...

Each of our kits contains all necessary parts including double sided epoxy PC board with plated through holes and gold contacts, all IC's, voltage regulators, massive heatsink, and mounting hardware. Complete instructions are included for easy asser and checkout. Every kit and assembled unit also includes information on how to use the module most effectively, covering soft programming considerations as well as hardware connections.

THE DETAILS . . .

FAMILY SPECIFICATIONS:

Bus connection: Fully 8800 compatible, electrically and mechanically. Outputs to the 8800 bus are three state, standard TTL le Storage temperature range: -40 to +85° C

Operating environment: 0 to 50° C, humidity to 95%, non condensing.

ALS-8

Ever dream of just turning on your computer and having its full power available instantly? The ALS-8 Firmware Module gives you that kind of "turn on the switch" system with 4K of PROM's pre-programmed with a greatly expanded version of our Software Package No. 1.

This powerful file oriented package is the finest Resident Assembly Language Operating System available today. 8080 assembly language programs can be stored as named files (5 letter names) and called at will to be assembled, edited, or listed by line number. Six files can reside in memory at once, or, they can be stored in either source or object code on paper tape, cassette or any other form of storage medium for re-input at a later time. Assembly of the source file can take place from a memory file or from any input device you choose.

The assembler converts the mnemonic codes and labels of the sembly source language program to object code at any address choose. (The run address can be different from the location re the code is placed.) Symbolic addressing includes the ty to chain common symbols from one program to another though the other program was assembled long ago. Feaof the assembler include labels, comments, expressions, ants, relative symbolic addressing... in short a professystem just made for assembly language work.

Input/output for the program is so versatile that it defies imagination, the driver software can even change the configuration under program control. That's right . . . a program can output one batch of information to one port and a differ batch to another port, each seemingly at the same time with human intervention. The system can handle any I/O configuration you can hook up and will call to any driving software wish to implement for the I/O.

Also, if you are new to computers, the manual included weach module not only explains how to use the program (wexamples), but goes on to explain each routine of the Systand how to call these routines from other programs you hwritten. This combined with the I/O handling along with custom "command table" allows every ALS-8 to be customiwithin your system to your individual needs. You don't have worry about being locked into a ROM version, this one designed with your expansion and creativity in mind.

The ALS-8 Firmware comes complete with a module with components capable of holding 8K of TURN ON THE SWIT program. So why 8K? Because we wrote this system to upward compatible with future software developments and first of these, an interpretive simulator, is up and running no

LOW POWER... yes and don't be fooled by "undirected" statements about this subject. All RAM's used in the 4KRA are 91L02A's by Advanced Micro Devices (AMD). 91L02A's require typically 1/3 the power of standard 2102 or 8101 type RAM's and under worst case conditions draws only 30% more than any currently available dynamic memory. In addition each RAM is manufactured to military specification MIL STD-883. This all adds up to low power and reliability, notice... we're the ones who publish the maximum worst case power required by our memory.

Plus, our memory draws so little standby current that they can be operated from a battery back up in case of power failure. This allows long term retention of data under loss of power conditions. Our TB-101 illustrates how to add a few simple moments to implement this feature and is shipped with every sold. In short we've done everything we could to make

shis the best 4K memory module in the computer field.

SPECIFICATIONS: 4KRA

Maximum capacity: 4096 eight bit words

Operating mode: Static

Access time: 520 nsec. maximum

Cycle time: 520 nsec. maximum, read or write Bus pinout: Plug-in compatible with Altair 8800 bus

Edge contacts: Gold plated, 100 pins (dual 50) on .125" centers Power requirements: +8 to +10 VDC, 1.2 A Max, at 0°C, 0.9 A:

Typical.

Dimensions: 5.3" x 10.0" (13.46cm x 25.4cm)

2KRO EPROM MEMORY MODULE

Read only memories (ROM's) do not lose their stored data when power is removed and thus have an advantage (we specialize in understatements) when used in stored program applications. Some ROM's, called PROM's, are user programmable, and some PROM's, called EPROM's, are erasable and reprogrammable as well. The most common and least expensive types of EPROM's in use today are the 1702A and MM5203; both are organized as 256 x 8 bit arrays. Our 2KRO module will accept up to eight of these IC's, providing the user with up to 2048 eight bit words of non-volatile storage for monitor, executive, loader, and other programs.

Each 2KRO module is jumper selectable to fit any one of thirty-two 2K segments within the 65K addressing range of the 8800 computer. Additional jumpers are provided to select the appropriate number of "wait" states as determined by the access time of the EPROM's used. The EPROM's are not provided (everything else is) but are readily available for reasonable prices on the industrial and surplus markets. The module will accept either of two types of EPROM: the 1702, 1702A, MM5202 or 9702 made by AMD, Intel, MIL and National, or the MM5203 made by National. However, both 1702 and 5203 types cannot be used at the same time.

Erasing and programming services for the 1702, 1702A or 02 will be provided by Processor Technology Company. A ly printed or typewritten listing in octal (base 8) code of program or data must be submitted along with address orr. There will be a charge of \$5.00 per EPROM for additional information and pricing on our for our programming bulletin.

SPECIFICATIONS: 2KRO

Maximum capacity: 2048 eight bit words

Operating Mode: Static

Access & Cycle Time: Dependent of EPROM used, logic on card will work over an access time range of 30 to 2500 nsec. Number of "wait" states jumper selectable from zero to four. Voltage Requirements: +8 to +10VDC, -15 to -18VDC

Power Requirements: 10W max., 8W typical at 25°C with 8 1702A's. Replacement transformer available for full negative supply power (see price list).

Bus Pinout: Plug-in compatible with Altair 8800 bus

Edge contacts: 100 pins (dual 50) on .125" centers, gold plated

Dimensions: 5.3" x 10.0" (13.46cm x 25.4cm)

3P+S INPUT/OUTPUT MODULE

Getting data into and out of a computer can be one of the most difficult and expensive tasks in bringing up a working system. Our 3P+S module was designed to provide maximum versatility to allow this one card to meet all the I/O needs of most 8800 system users. For example, one teletype and two TV Typewriters with keyboards can operate simultaneously with the 8800 via one 3P+S module; or, one TV Typewriter, an EIA RS-232 modem, a teletype and another parallel data device can be fully interfaced at the same time.

In addition, one parallel output port is available to be used for setting up control conditions for both parallel and serial ports, as well as to set the serial I/O baud rate under program control. The Baud rate can be set between 35 and 9600 Baud and the module is the only one available that will allow 1.5 stop bits as required by the old model teletypes that are available at such low cost.

Also, one parallel input port is available for polling the Input Data Available flags and External Device Ready flags, as well as for checking the serial I/O error flags. Full handshaking with both input and output peripherals can be implemented with these provisions.

Interfacing to the 8800 vectored interrupt bus is provided on the card as a jumper selectable option, allowing any of the UART (Universal Asynchronous Receiver Transmitter) error flags or handshaking signals to be used to generate interrupts. The Vectored Interrupt Module is required for this purpose.

Addressing of the module is jumper selectable to any one of 64 four address segments within the 8800 range of 256 I/O addresses. Additional flexibility allows either the UART and control port, or the two parallel ports to occupy the lower two relative addresses.

Complete information on each of the options available is included with each 3P+S sold. In addition, a letter to us describing your system configuration will be returned illustrating the best way to implement the system with our module.

SIM-1 EXPANSION FIRMWARE

INTERPRETIVE SIMULATOR????? Yes, an interpretive simulator that runs 8080 programs, in an interpretive mode, on a same 8080 that contains the Simulator. This isn't just a bug program, because the program thinks it's an 8080! That's right, all registers, flags, program counter, and stack are SIMULATED! Breakpoints are in the simulator program, not a jump to a restart location. (How else would you debug a program that needed the restart location?) Also, when a call or jump instruction is encountered, full control remains with the simulator. This is the only system that will not lose control if a program error is made on this type of instruction.

All registers, flags, program counter, stack and memory contents can be changed at all times and there is even a single ep mode that allows full printout of all the registers, flags,

after each instruction is executed.

SA

input instructions within the simulated program can be handled three ways: Real Time, Simulated, and Pre-Set. In the simulated mode the simulator stops and asks "what input for input port X." You input from your regular input port for any of the 255 other input ports! Output instructions are also simulated directly to you from the simulator. The output to your regular output port identifies the data output as well as the port it would have been output to. Again, don't mistake this for a simple program that handles breakpoints, this simulator actually gets each instruction and runs it under simulator control.

The SIM-1 comes pre-programmed and ready to plug into the ALS-8 module. The ALS-8 is an integral part of the simulator and must be available for its operation. (It would have been a 6K program if the customizing power of the ALS-8 hadn't been there.)

As you can see, this without a doubt is the most powerful program development tool that has ever been resident on an 180 to this day. It's running now at Processor Technology and sample print-out illustrating its operation is available on request.

Will paper tapes of the ALS-8 software be available? We imagine they will appear but... using 8K of RAM to receive a paper tape that takes the better part of a half hour to load each time a power glitch occurs just doesn't make a real system. Using this module, loaded with the ALS-8 "PERMANENT PROGRAM" will save that expensive RAM for data and development programs as well as giving the true convenience of a "turn-on-the-switch" system.

SOFTWARE NO. 1 FIRMWARE

We have had a number of inquiries about providing Software No. 1 as a PROM Module, so we decided to provide one. The Software No. 1 Firmware Module is the ALS-8's little brother. Software No. 1, as we call it, contains the basic resident assembler, system monitor, and line oriented text editor. It has these features: 1) Teletype oriented I/O (i.e. only one I/O device permitted). 2) RAM resident files, perfect for small rograms, but difficult for files larger than about 1K Byte. 3) tware No. 1 Firmware cannot assemble from files not in 1. 4) It is not upward compatible with Disc or Cassette ratios Systems or the Simulator.

SPECIFICATIONS: ALS-8, SIM-1, & SW1F

MEMORY TYPE: 4096 word Erasable PROM's CYCLE TIME: 1.0 micro-second worst-case

ACCESS TIME: same as cycle time

POWER REQUIREMENT: +8 to 10 VDC at 300 Ma maximum,

-14 to -17 VDC at 300 Ma maximum.

BUS PINOUT: Plug-in compatible with Altair 8800 bus. EDGE CONTACTS: 100 pins (dual 50) on .125" centers

DIMENSIONS: 5.3" x 10.0" (13.46 x 25.4 cm)

VDM-1 VIDEO DISPLAY MODULE

Build a smart terminal into your Altair! Your Altair already has the intelligence, we provide the display module. This is not a limited "TV TYPEWRITER" but an ultra-high speed computer terminal built into your computer. The VDM-1 generates sixteen 64 character lines from data stored in the 1K Byte on-card memory. Alphanumeric data is shown in a 7x9 dot matrix with a full 128 upper and lower case ASCII character set. The VDM-1 features EIA Video output for any standard video monitor. (A TV set can be easily modified at your local TV repair shop.) Multiple programmable cursors, automatic text scrolling and powerful text editing software are included FREE!

SPECIFICATIONS: VDM-1

CHARACTER SET: 96 character ASCII, plus control characters 7 x 9 matrix with descending lower case.

DISPLAY FORMAT: 16 lines, 64 characters per line.

DISPLAY MEMORY: 1024 8-bit Bytes LOW POWER Static Read/Write memory

DISPLAY POSITION: Continuously adjustable, horizontally and vertically

I/O, DATA: Addressable as a 1K page of memory, Read or

CURSOR: Solid video inversion (blinking optional) appears at

all character positions when bit 7 is high.

I/O, CONTROL: Output from CPU is one 8-bit Byte. The lower four bits control Beginning Line Address; the upper four bits control Beginning Display Offset. Input to CPU is a one bit (DI), Parameter Change Ready flag.

BLANKING CHARACTERS: CR (octal 015) blanks test, except cursor, to end of line. VT (octal 013) blanks text, except cursor, to end of screen.

SIGNAL OUTPUT: 1.0 to 2.5 VP-P video composite, negative sync

MONITOR BANDWIDTH: 6.0 MHz (at -3dB) required video BW.

4KRA LOW POWER STATIC MEMORY MODULE

This 4096 word read/write memory module provides faster, less expensive, more reliable and lower power operation than any comparable memory module sold today.

Faster speed in actual operation results because static memories don't need periodic refreshing. Dynamic memories require a refresh period at least 500 times per second. During this period no data can be written or read from the memory and the computer must sit idle in a "wait" condition.

SPECIFICATIONS: 3P+S

Outputs: Two 8-bit parallel ports, standard TTL levels, relative addresses at 0 & 1, or 2 & 3.

One Teletype 20mA current loop output.

Four EIA RS-232C outputs for serial transmit data and/or control signals.

One Peripheral Interface Control driver (PIC) 50mA current source for paper tape reader control or cassette recorder control. Jumper selectable to control port output.

Inputs: Two 8-bit parallel ports, standard TTL voltage levels, input current is 0.36mA max.

One Teletype 20mA current loop receiver for UART data input.

Four EIA RS-232C receivers for received serial data and/or control signals.

Control: One 8-bit output port, relative card address selectable as 0 or 2. Lower four bits for baud rate control and/or EIA control outputs and/or PIC driver.

Upper four bits for UART control, i.e. word length, parity, and number of stop bits. Control conditions can be strapped on, off or to software controlled, latched output bits.

One 8-bit input port, relative card address selectable as 0 or 2. Bits selectable with jumpers to read UART error flags, i.e. parity, overrun, and framing errors, and/or EIA control inputs, and/or Data Available flags for parallel input ports, and/or External Device Ready flags for parallel output ports.

Interrupt Control: Any control input, status flag, or UART output may be jumpered to the Interrupt Bus Driver. Interrupt operation requires use of a Vectored Interrupt Module to gate the Restart instruction to the processor.

Bus Pinout: Plug-in compatible with Altair 8800 bus

Edge Contacts: Gold plated, 100 pins (dual 50) on .125" centers.

Voltage Requirements: +8 to +10VDC, +15 to +18VDC, -15 to -18VDC

Power Requirements: 7.0W maximum, 5.5W typical at 25°C I/O connection: Two standard 44 pin (dual 22) edge connectors, .156" centers

Dimensions: 5.0" x 10.0" (12.7cm x 25.4cm)

MB-1 MOTHER BOARD

Don't worry any more about wiring hundreds of wires in your Altair to expand the mainframe. Our single piece 1/8-inch thick, rugged mother board can be installed as one single replacement for either three or four 88EC Expander cards, so you don't have to replace your already installed 88EC card if you don't want to. The MB-1 has very heavy power and ground busses and comes with a piece of flat ribbon cable for connection to the front panel board of the 8800, a built-in bus terminator, and card guide cage for sixteen plug-in slots.

Specify MB-12 for replacement of three 88-EC's, or MB-1 for placement of four 88-EC's. Both are the same price. Available

rensions: .125" x 11" x 14.5" (0.32cm x 27.94cm x 3ε

WWB - WIRE WRAP BOARD

This is the card for all of you who do wire wrap prototyping. Now you can easily create your own custom interfaces or strange "Kluges" of any kind. The WWB has a "universal" pattern of seven rows of pads on .3" centers, so that standard 14, 16, 24, and 40 pin DIP IC sockets can be plugged in. Power and ground are dedicated to pins 16 and 8 respectively (i.e. for 16 pin DIP's) but the layout is designed for fast conversion of each position to other IC sizes. Up to 62 sixteen pin DIP IC's can be used. An extra six wire wraps socket positions have been set aside for connections to the 8800 bus.

Each WWB Kit comes with one 5 volt regulator, a heat sink, and decoupling capacitors. Space is reserved on the card for two more regulators for positive or negative supplies.

Dimensions: 5.3" x 10.0" (13.46 x 25.4 cm)

Contacts: Gold plated, 100 pins (dual 50) on .125" centers Board Materials: 1/16" G-10 glass-epoxy, plated through holes,

2 oz. copper: solder plated.

EXB - EXTENDER BOARD

This Extender Board makes troubleshooting and servicing of any 8800 compatible module much easier. With the EXB you can plug in a troublesome module five inches above the Mother Board so that both sides of the Board can be reached easily with an oscilloscope, VTVM, or logic probe.

Dimensions: 5.3" x 10.0" (13.46 x 25.4 cm)

Contacts: Gold plated, 100 pins (dual 50) on .125" centers. Edge Connector: Viking 3VH50/1CV (one included).

Software

Package No. 1: This is the self contained Assembly Language Operating System developed and distributed by Processor Technology for an "almost free" \$3.00. The \$3.00 package includes the source listing with hexidecimal object code and ample comments throughout. Each command is described and six pages of sample use are included. Paper tapes of this System were sent to Computer Clubs across the nation and are available from them on request. Get the listing and the tape and you will be running one of the finest Assembly Language Systems developed to date.

Package No. 2: We are working on two BASIC Language packages which should be ready by December. One will be a basic BASIC needing about 8K of memory as a minimum and the other will be an Extended version with additional string manipulation, matrix operations and double precision arithmetic capabilities requiring about 12K. Both these packages will be available in Read Only Memory for a reasonable price.

wile for free tisky

Up & Coming

THE NEWS IN A NUTSHELL!

The last edition of Nutshell produced an overwhelming stream of input to our product development department. This input did not go to thin air as you see.

MASS STORAGE

We have always wanted a low cost, reliable, fast access storage device using standard Phillips cassettes (we bet you have too), so we got to work and designed one - here it is! With the CDS-VIII Cassette Data System you have computer controlled access to 128K bytes of data within 20 seconds when using C-30 cassettes. We provide read/write electronics and transport controller, Altair interface, a case and power supply, and one or two multiple motor cassette transports plus FREE driving software! Yes, up to two cassette drives! Two drives provide much more powerful file handling and copying capabilities as well as, of course, twice the storage capacity. Data can be written and/or read asynchronously at any transfer rate up to 150 bytes/sec: at this rate 8K BASIC can be loaded in about 50 seconds! We have also included provision for use of any read/write electronic plug-in section so that tapes using HIT, Computer Hobbyist or Digital Group formats may be read at lower data rates. Full details will be available in November, 1975.

PTCOS

What is PTCOS you may ask? It stands for Processor Technology Cassette Operating System and it means a real Operating System program based around our CDS-VIII dual Cassette Data transport System. When operating under this program you have true file handling power to create, delete, edit, relocate, and copy all kinds of files (e.g. BASIC and programs written in BASIC). PTCOS can handle multiple I/O devices using a special type of file and suitable small driving routines. At last an integrated system concept for the 8800 is a reality! PTCOS is devilishly similar in its basic operation to an FDOS and is upward compatible with future software developments from Processor Technology.

TTK

The True Time Keeper is alive and well but had to take lower priority than the VDM & CDS. It will be ready about December or January and will include standby power. Complete facilities for vectored interrupt and the very necessary functions of a real time clock will be included along with the month, day, hour, minutes, seconds. . . . We're sorry it takes so long but this one is well worth waiting for. I WANT ONE, anyone?

MMM-1

Everyone was so firm about the CDS and VDM that the MMM's received hardly a mention. Our business guy insists on seeing the "I WANT ONE'S!" before he cuts us loose. Remember these modules really will play honest music under program control. Two tones on the first module with full program control of amplitude and frequency. Any other ideas?

PPM PROM PROGRAMMING MODULE

Did we really ask if you wanted both or "just" one or the other. We will make one of these as soon as we know the way pricing is going to go on the 5203 and 1702A's.

Warranty

PROCESSOR TECHNOLOGY COMPANY, in recognition of its responsibility to provide quality components and adequate instruction for their proper assembly, warrants its products as follows:

All components sold by Processor Technology Company are purchased through normal factory distribution and any part which fails because of defects in workmanship or material will be replaced at no charge for a period of 6 months following the date of purchase. The defective part must be returned postpaid to Processor Technology Company within the warranty period.

Any malfunctioning module, purchased as a kit and returned to Processor Technology within the warranty period, which in the judgement of P.T.Co. has been assembled with care and not subjected to electrical or mechanical abuse, will be restored to proper operating condition and returned, regardless of cause of malfunction, with a minimal charge to cover postage and handling. (This is really a good deal, we think,)

Any modules purchased as a kit and returned to P.T. Co. which in the judgement of P.T. Co. are not covered by the above conditions will be repaired and returned at a cost commensurate with the work required. In no case will this charge exceed \$20.00 without prior notification and approval of the owner.

Any modules, purchased as assembled units are guaranteed to meet specifications in effect at the time of manufacture for a period of at least 6 months following purchase. These modules are additionally guaranteed against defects in materials or workmanship for the same 6 month period. All warranted factory assembled units returned to P.T.Co. postpaid will be repaired and returned without charge.

This warranty is made in lieu of all other warranties expressed or implied and is limited in any case to the repair or replacement of the module involved.



1 EPT 1 - 11.13

PRICE SCHEDULE effective December 1, 1975

ITEM	DESCRIPTION	KIT PRICE	ASSEMBLED, TESTED	AVAILABILITY
2KRO	Erasable PROM Module	\$ 50.00	\$ 75.00	NOW
BP+S	Three Port Input/Output Module	125.00	175.00	NOW
IKRA-4	4096 Word Low Power, Static RAM Memory RAM only, 1024 x 8	139.00 25.00	195.00 —	NÓW
W1F	Software No. 1 Firmware	189.00	245.00	NOW
LS-8	Assembly Language Operating System Firmware Module	250.00	350.00	DEC. 15
SIM-1	Simulator Expansion Module	95.00	100.00	DEC. 15
/DM	Video Display Module	160.00	225.00	DEC. 15
XB	Extender Board Module	35.00	45.00	NOW
-vvB	Wire-Wrap Prototyping Module	40.00		NOW
MB-1/CC	16-slot Mother Board with Bus Terminator and Card Cage (includes BT-1 & CC 16)	70.00		NOW
CC-16	16-slot Card Cage for MB-1	20.00	-	NOW
4PC	Dual 22 pin edge connector (.156"), two required for use with 3P+S	3.00		NOW
100PC	Dual 50/50 pin edge connector (.125" centers) ONE REQUIRED FOR EACH MODULE TO PLUG INTO 88EC or MB-1	8.50		NOW
DB25S	Socket, 25 pins for I/O connections on 8800 rear panel	4.50		NOW
DB25P	Plug and hood, 25 pins for cables plugging into DB25S	4.50	_	NOW
TRF-1	High current transformer for PROM module replaces T3 in 8800	5.00	_	NOW

DELIVERY: From stock to 3 weeks after receipt of order.

TERMS: All items postpaid to U.S. and Canada if full payment accompanies order. COD orders must include 25% deposit. DISCOUNTS: Prepaid and COD orders over \$375 subtract 5%; orders over \$600 subtract 10%.

Prices, specifications, and delivery subject to change without notice.

PROCESSOR TECHNOLOGY CO., 2465 Fourth Street, Berkeley, Ca. 94710 Phone: (415) 549-0857

·+EM	DESCRIPTION	\$ EACH	\$ TOTAL
1			
	Subtotal Less % discount	discount	
	Taxable total	total	
	California residents add 6% tax	% tax	
RDERS POSTF PANIES ORD DE 25% DEPO	ALL ORDERS POSTPAID IF FULL PAYMENT ACCOMPANIES ORDER. C.O.D. ORDERS MUST INCLUDE 25% DEPOSIT.	TOTAL U.S.	Funds Only
R CHARGE A	MASTER CHARGE ACCEPTED. (MINIMUM \$25.00) NUMBER AND EXPIRATION DATE:		
SIGNATURE			
ADDRESS			
	STATE		
	_	The state of the s	how
PLEASE COMMENT ON PRESENT AND FUTURE		£3	1 to 2
DUCIS ON n	EVERSE SIDE.		

HowFar Can You Go

Find out-by adding 8080 compatibl

3P+S Input/Output Module

Our 3P+S is a simple inexpensive answer to handling a variety of peripheral devices. It has two 8-bit parallel I/O ports, with full handshaking logic. Plus, it has a serial I/O port, with a data rate range from 35 to 9600 Baud. Simultaneously handle a paper tape reader, a keyboard, a TV terminal, a tape punch, and a telephone coupler! Available with premium grade low-profile IC sockets, \$149. Owner's Manual, \$4.95.*

ALS-8 Assembly Language Operating System

Just turn on the switch, and instantly you have the power to write, edit, assemble, de-bug, and run your own programs. The ALS-8 is the most useful software development tool available today. Optional firmware indudes SIM-1, an interpretive simulator, that simulates programs without running them in real time. Thus, errors encountered during testing do not endanger your entire system. The TXT-2 firmware adds the dimension of text editing. Insert, delete, move entire lines or single characters, and much more! ALS-8 (assembled only), \$425. SIM-1, \$95. TXT-2, \$95.

VDM-1 Video Display Module

If you're setting up just the system you really want, don't fall short by limiting its communicating ability. The VDM-1 is an ultrahigh speed video output device. Its 16 display lines have 64 characters each, upper and lower case. 1024 bytes of random access memory are on the card. It scrolls up or down, even to 2000 lines per minute! Any combination of the 1024 cursors can be displayed as black-on-white or vice versa. Free terminal mode software is included, along with premium grade, low-profile IC sockets. \$199. Owner's Manual, \$4.95.*

8KRA Static Memory Module

We now offer a low-power static memory module, with a **full 8192 bytes of memory**.

It has an exclusive KSET^M address selection DIP switch, so you can conveniently set address boundaries in increments of 1K.

Our low-power RAM's typically require one-third less power than those commonly used by our competitors. They'll even retain memory for 4-5 hours when powered by two "D" flashlight cells. On-board recharging circuitry and battery connectors make it possible to protect your data against sudden power loss. Each RAM has its own IC socket. too, for easier assembly and repair. \$295.

Owner's Manual, \$4.95.*

2KRO EPROM Module

The **2KRO Read Only Memory** will accept up to eight 1702A or 5203 EPROM's (not included), providing 2048 eight-bit words of non-volatile storage for monitor, executive, loader and other programs. Programming services available from your dealer or write us for details. **\$65.** Owner's Manual, **\$4.95.***

4KRA Static Memory Module

The 4KRA (4096 bytes) was our first static memory module. It's still very popular, and uses the same low-power static RAM's as the 8KRA. Plus, we've added a DIP switch, and every RAM now has its own premium grade, low profile IC socket. On-board recharging circuitry (with battery backup) makes it possible to retain memory for 8-10 hours during power failure. \$159. Owner's Manual, \$4.95.*

MB-1 MotherBoard

Our single piece **Mother Board** for the Altair 8800 gives you 16-card capacity in one single installation. Available with 12 (**MB-12**) or 16 (**MB-1**) slots. \$70. (Discontinued; limited to stock on hand.)

Wire Wrap Board

Do your own wire wrap prototyping with the WWB Wire Wrap Board. Up to 62 16-pin sockets or various combinations of 14, 16, 24 and 40-pin sockets. \$40.

EXB Extender Board


The **EXB Extender Board** allows accessibility in servicing any 8080-compatible module. **\$35.**

*Fully descriptive Owner's Manual available separately. Price refundable with purchase of kit.

THIS PAGE LEFT BLANK INTENTIONALLY.

The and successful to the second of the seco

On The 8080 Bus? products from Processor Technology.



Write Us for further details on all our 8080-compatible products, and for the dealer nearest you.

ing


en

9



6200-V Hollis Street Emeryville, CA 94608 1 EPT 1 - 14

BYTE November 1976 pp. 72,73



The first complete small computer.

As you thumb through this magazine, you'll see a lot of ads for small computers. For \$600 you can find a pretty good box with a power supply, four slot mother board, CPU module, and all the expected lights and switches.

But you know what? It won't work. That's because in order to make the computer go you have to buy memory—normally both read-write (RAM) and read-only (PROM), interfaces to the outside world (parallel, serial, and cassette), keyboard, video display module, and software.

Add this all up and it's going to cost you at least \$1,400 for a complete system.

Got the picture?

Now listen to this. The remarkable new Sol-20 Terminal Computer will give you all of the above...plus more!...as standard equipment for just \$995, in kit form. This is because the Sol-20—like no other small computer—was designed from the ground up to be complete.

Here's what the Sol-20 includes as standard equipment:

- 8080 microprocessor.
- · Video display circuitry.
- 1024 words of static, low-power RAM.
- 512 words of preprogrammed PROM.
- Custom 85-key solid-state keyboard.
- Audio cassette tape interface.
- Both parallel and serial interfaces and connectors.
- · Power supply.
- A beautiful case with solid walnut sides.
- Software that includes a preprogrammed PROM personality module and a cassette with BASIC-5 language plus two sophisticated computer video games.
- Full expansion capability with all S-100 bus (Altair/IMSAI/PTC bus) products.

It's a handsome terminal or computer that will even look good in your living room or office. Small systems start at just \$475.

Full expansion capability

The Sol-20 system can be tailored to your applications using the complete line of peripheral products from Processor Technology. These include the video monitor, audio cassette and digital tape systems, dual floppy disc system, memories, and interfaces...plus all other peripherals compatible with the S-100 bus.

The Sol-20 greatly simplifies the computer-buying process. It's a splendid package that will excite both present and prospective computer owners.

Our brochure tells all. Write for

it today.

Processor Technology, 6200 Hollis Street, Emeryville, CA 94608. (415) 652-8080.





Introducing Sol Systems

BYTE December 1976 pp. 71-76

A complete computer/terminal concept with all the standard features, software and peripheral gear you want in your personal computer.







Sol Systems put it all together. One source for hardware and software. One source for engineered compatibility of computer and peripherals. That's the Sol plan.

Though the microprocessor made the powerful small computer possible, a lot of folks found out early efforts in the market-place were selling the sizzle a lot more than the steak. After an initial investment of several hundred dollars, you ended up with some nice parts, but no memory of any kind, no I/O devices or interfaces, no display, printout or software.

The Sol plan ends all that. Processor Technology takes the position that it's far better to be right than first. So let's get down to the Sol no tricks plan.

For \$995 in kit form, the first complete small computer

Standard is a basic word at Processor Technology. The Sol-20 has more standard features than any other small computer we know of. Here's what you get.

8080 microprocessor* 1024 character video display circuitry* 1024 words of static low-power RAM* 1024 words of preprogrammed PROM* a custom, almost sensual 85-key solid-state keyboard* audio cassette interface capable of controlling two recorders at 1200 baud* both parallel and serial standardized interface connectors* a complete power supply* a beautiful case with solid walnut sides* software which includes a preprogrammed Prom personality module and a cassette with Basic-5 language plus two sophisticated computer video games* the ability to work with all S-100 bus (Altair 8800/IMSAI/PTC) products.

There are no surprises. Everything you need to make it work is here. In kit form, nominal assembly time from our fully documented instructions is four to seven evenings.

Or start with the Sol-PC for just \$475

You can begin your Sol system with the all on one board Sol-PC kit. It has all the

memory and interface electronics including video display, keyboard interface, audio cassette interface, all necessary software and the ability to accept the full Processor Technology line of memory and interface modules. Use the Sol-PC as the basis of a microcomputer, low cost CRT terminal or editing terminal

And these specs are standard

Display: 16 lines of 64 characters per line. Character set: 96 printable ASCII upper and lower case characters plus 32 selectable control characters.

Display position: Continuously adjustable horizontally and vertically.

Cursor: Selectable blinking. Solid video inversion. Programmable positioning standard. Serial interface: RS-232 and 20-mA current loop, 75 to 9600 baud, asynchronous. Parallel interface: Eight data bits for input and output; output bus is tristate for bidirectional interfaces; levels are standard TL. Keyboard interface: Seven-level ASCII encoded, TTL levels.

Microprocessor: 8080, 8080A, or 9080A. On-card memory: 1024 bytes PROM (expandable to 2048 bytes), 2048 bytes RAM. External Memory: Expandable to 65,536 bytes total ROM, PROM, and RAM. Video signal output: 1.0 to 2.5 volts peak-to-peak. Nominal bandwidth is 7 MHz. Power required (±5%): +5 volts at 2.5 amperes, +12 volts at 150 mA, and -12 volts at 200 mA.

The Sol plan, completely expandable.

By filling the basic main frame with tailor made Processor Technology plug-in PC boards, you can really expand the computing power and flexibility of your Sol-20 Personal Computer.

New items are being announced frequently, but right now, here are some of the

things you can add to your Sol-20. The ALS-8 Firmware module is an assembly language operating system to give you the power to develop and run programs. Use it to quickly write, edit, assemble, de-bug and run your own programs. Some say it's the most useful software development on the market today, but modesty prohibits.

And when it comes to add-on memory boards, you've come to the right place. We've probably got more than anyone else. Choose from 2K ROM or 4, 8 or 16K RAM (read all about the 16KRA board on the last page of this ad). The PT 2KRO will accept up to eight 1702A or 5203Q erasable, reprogrammable memories (EPROM's) with the ability to store in a non-volatile fashion up to 2048 eight-bit words.

Our read/write memories are the industry standards for high reliability. We know, because we have literally scores of customer letters saying "Your memory modules work and keep on working."

To help you solve additional interfacing problems, add the 3P+S I/O module. Here's a board with two 8-bit parallel I/O ports with full handshaking logic and a serial data rate that can be set anywhere between 35 and 9600 baud. Set up control conditions for both parallel and serial ports. Data and error flags can be polled.

A full line of Sol-20 tailored peripherals

No computer can do the full job without the right set of peripheral gear. PT has sought out the best manufacturers of peripheral equipment and worked with them to give you a choice of quality so you can get the most out of your Sol-20. Choose from line and serial printers, perforated tape readers and punches, floppy disk memories, black and white or color graphics displays, A/D, D/A converters and more.

Software, the Computer Power Essential

A big part of making the first complete small computer is providing you with a wide range of easy to use, easy to obtain, low cost software. For the Sol-20, we've developed a whole group of offerings. And more are on their way.

TREK 80

Based on the NBC television series STARTREK, this 8K assembly language program uses the VDM graphics capability for real time war with the Klingons. No holds

barred, they're out to get you from each of the 100 quadrants. TREK 80 resides and runs in 8K of memory and requires the PTC Sol or VDM-1.

New PT 8K Basic

Processor Technology has the fast new BASIC you've needed for so long. Using our superior BCD math, the speed of the new language is double that of our own fast BASIC-5. To multiple program capability, we've added strings, multidimensional arrays and multi-line, multi-variable, user functions. This is the BASIC for full capability systems. Look at the BUSINESS ANALYSIS program example in the manual to find out how PT 8K BASIC gives you more while using less memory for the working program.

tc

fc

th

g

p

а

C

T

b

5

Five reasons why it's so good

- Strings are not limited to a length of 256 characters and can extend to the bounds of memory.
- Renumbering of lines with full gosub, etc. updating. Also EXAM and FILL allow for direct memory operations while IN and OUT provide direct I/O capability.
- Every statement is fully implemented. RESTORE, for instance, restores the data pointer as usual. BUT, with PT 8K BASIC, RESTORE 100 will set the pointer to the data located at line 100.
- 4. Fully implemented string and math functions include all of the standards VAL, STR, ASC....EXP and LOGI and LOG. Also, the more advanced statements such as ON-GOTO and IF THEN ELSE along with a loop EXIT are provided.
- PT 8K BASIC has a 'perfect' implementation of PRINT USING which saves program memory space while still providing more capability than the usual PRINT USING.

The new PT 8K BASIC is similar to the version we're developing for ROM. You use it here before buying the more expensive ROM.

You'll find your PT 8K BASIC also includes both a built-in VDM driver and special editor. The cassette version also includes named program SAVE and LOAD for the CUTS Cassette interface or Sol.

New 8080 FOCALTM DEC

8080 FOCAL has been updated to include operator precedence and all other standard FOCAL conventions. It also has a driver for VDM-1 display and PT Cassette program SAVE and LOAD This version is available only on CUTS Cassette and resides in 8K of memory.

GAMEPAC 1 to entertain family and friends

Show off your VDM-1 and computer with this lineup of video games. Each is included on the cassette or paper tape.

TARGET keeps track of your hits and misses while you blast away at the moving target. You and your family can get together for whole evenings at a time with this one.

ZING. Learn hexidecimal arithmetic fast with this VDM game as two players keep the five balls in the air. If both of you get too good . . . ZING, of course, will make it harder.

LIFE. The Sol or VDM makes a good display for the game of life and this version allows two modes of operation. The universe can be flat or wrapped around on itself. The real meaning of life we'll leave to you but it's fun to watch.

PATTERN. We haven't figured this one out ourselves but it's sure nice to have your computer doing it. You choose the geometric design and how rapidly it changes.

Sol Systems Price List

(prices are net, effective Dec. 1, 1976)

SOFTWARE

ITEM with manual	Source	CUTS cassette	Paper tape
BASIC 5 software #2	yes	**	\$19.50
8K BASIC	no	\$29.00	\$37.00
New 8080 Focal	no	\$14.50	N/A
TREK 80 video game GAMEPAC 1	no	\$ 9.50	\$14.50
video games	no	\$ 9.50	\$14.50
MATHPACK video calculator ASSEMBLER	yes	\$14.50	\$19.50
software #1	yes	\$14.50	\$19.50

^{**}CUTS cassette of BASIC 5 is included FREE with all orders for Sol units or CUTS cassette interfaces. Additional cassettes available for \$14.50.

Sol system owners be sure to note Sol system on your order. These special versions use less code and provide easier loading along with more convenient operation. SOLOS, SOLED and CONSOL all have provision for the special versions.

All Processor Technology software is distributed on an individual sale basis for personal use. No license to copy, duplicate or sell is granted with this sale. Each software package has been copyrighted by Processor Technology and all rights therein are reserved.

Sol Terminal Computers	Kit Price
SOL-PC SINGLE BOARD TERMINAL	
COMPUTER™	\$475.*

SOL-10 TERMINAL COMPUTER™	
Sol-PC with case, power supply	
and 70 key solid state keyboard.	\$795.*

SOL-20 TERMINAL COMPUTER™
all features of Sol-10 with larger
power supply, 85 key solid state
keyboard, fan, and five slot
expansion backplane.
\$995.*

*Sol prices include CONSOL Personality Module. If SOLED Intelligent Editing Terminal Module or SOLOS Standalone Operating System Module is desired instead, add \$100. If ordered separately, personality modules are \$150 each.

AA ---- AA - d. .l. -

Memory Modules	Kit	Asmbld.
ALS-8 PROM Resident Assembly Language Operating System	_	\$425
SIM-1 Interpretive Simulator add-on option for ALS-8		\$ 95
TXT-2 Text Editing add-on option for ALS-8	_	\$ 95
2KRO Erasable PROM module	\$ 65	\$ 89
4KRA 4096-word Low Power Static RAM	\$159	\$195
8KRA 8192-word Low Power Static RAM	\$295	\$375
16KRA 16384-word Dynamic RAM		\$529
Interface modules		
3P+S Parallel, Serial I/O module	\$149	\$199
CUTS Computer Users Tape System cassette interface	\$ 87	\$119
VDM-1 Video Display Module	\$199	\$295

Mass Storage Systems Helios II Disk System™ includes dual PerSci 270

floppy disk drive, cabinet, fan,S-100 bus compatible controller, power supply, system diskette with complete

PTDOS software \$1895 \$2295

Misc.

EXB Extender Board \$ 35 \$ 45 WWB Wire Wrap Board \$ 40 —

Prices, specifications and delivery subject to change without notice. Please allow up to two weeks for clearance of personal checks. Mastercharge accepted. All orders amounting to less than \$30 must include \$3 for handling.



16K RAM, fully assembled, \$529

More bits per buck than ever before on a fully burned in and tested board unconditionally guaranteed for one year.

Processor Technology made the first 4K static RAM modules for the home computer market. Now in a price performance breakthrough we offer you a 16,384 byte dynamic memory module assembled, tested and burned in. Not a kit—and at \$529 who'd want to build it from scratch?

Processor Technology gives you the features to make 4K dynamic RAMS work for you.

- · Invisible refresh, no waiting while CPU is running.
- High speed 400 μsec access time worst case Z-80 and 8080 compatible.

- 1 EPT 1 21 Versatile addressing, each 4096 byte segment is individually addressed to any of the sixteen available 4K segments.
 - Low power typically 5 watts when running — the same as most 4K memory modules.
 - BATTERY BACKUP capability built-in for standby operation.
 - IMPORTANT NOTICE—No 16K memory module available is fully, truly static. 4200/4402 type "static" RAM's have high level, high current clocks with high transient power levels. Any RAM with 12 volt 30 mA clock pulses should not be called "STATIC" just because each memory cell is a flip-flop.

Specifications

Access Time 400 nsec max Cycle Time 500 nsec max

Rams Used Intel 2104 or Mostek 4096

types

Capacity 16384 8-bit bytes

Memory **Protect** Addressing

standard on card each 4096 byte page

addressable

Operating Power

+7.5 to 10 VDC at 0.4 A typical +15 to +18 V at 10 mA typical

-15 to -18 VDC at 20 mA max

The new Processor Technology 16K board is available for immediate delivery. See your nearest dealer listed below or contact us directly. Address Processor Technology, 6200 Hollis Street, Emeryville CA 94608, Phone 415/652-8080.

Processor Technology Dealers

CALIFORNIA

The Byte Shop 1514 University Ave Berkeley CA 94703

The Byte Shop 2559 South Bascom Ave Campbell CA 95008

The Computer Mart 624 West Katella #10 Orange CA 92667

The Byte Shop 2227 El Camino Real Palo Alto CA 94306

The Computer Center 8205 Ronson Road San Diego CA 92111

The Computer Store of San Francisco 1093 Mission Street San Francisco CA 94103 509 Francisco Blvd. San Rafael CA 94901

The Byte Shop 3400 El Camino Real Santa Clara CA 95051

The Byte Shop 2989 North Main St. Walnut Creek CA 94596

FLORIDA

Microcomputer Systems Inc. 144 So. Dale Mabry Hy. Tampa FL 33609

GEORGIA

Atlanta Computer Mart 5091-B Buford Hwy Atlanta GA 30340

The Numbers Rocket 518 East Green Street Champaign IL 61820

itty bitty machine co , inc. 1316 Chicago Ave Evanston IL 60201

The Chicago Computer Store 517 Talcott Road Park Ridge IL 60068

INDIANA

The Data Domain 111 South College Ave. Bloomington IN 47401

MICHIGAN

The Computer Store of Ann Arbor 310 East Washington Ann Arbor MI 48104 **NEW JERSEY**

The Computer Mart of New Jersey 151 Kline Boulevard Colonia NJ 07067

Hoboken Computer Works 56 Second Street Hoboken NJ 07030

NEW YORK

Audio Design Electronics 487 Broadway, Ste. 512 New York NY 10013

The Computer Corner 200 Hamilton Ave. White Plains NY 10601 The Computer Mart

of Long Island 2072 Front Street East Meadow, L.I. NY 11554 TEXAS

The Computer Mart of New York 314 Fifth Ave New York NY 10001

Synchro Sound Enterprises 193-25 Jamaica Ave Hollis NY 11423

OREGON

The Real Oregon Computer Co. 205 West 10th Ave Eugene OR 97401

RHODE ISLAND

Computer Power, Inc. M24 Airport Mall 1800 Post Road Warwick RI 02886

The Micro Store 634 South Central Expressway Richardson TX 75080 WASHINGTON

The Retail Computer Store 410 N.E. 72nd Seattle WA 98115

t

F

1

WISCONSIN

The Milwaukee Computer Store 6919 W. North Ave Milwaukee WI 53213

CANADA

The Computer Place 186 Queen St. West Toronto, Ontario M5V 1Z1

Trintronics 160 Elgin St. Ottawa, Ontario



DESIGNING CONSUMER-SYSTEM PERIPHERALS

INTELLIGENT-TERMINAL DESIGNERS OPT FOR 8080-COMPATIBLE CIRCUITRY

by Lee Felsenstein and Robert Mersh

Because the "home computer" serves a consumer market, both it and the peripherals designed for use with it must exhibit high-volume production and adequate customer support. With these fundamental requirements in mind, we designed the Sol product line to simultaneously meet the needs of two applications. Both Sol-10 and Sol-20 function as intelligent terminals—each unit lacks only a CRT monitor. Additionally, Sol-20 incorporates a power supply and expansion chassis, which with adequate memory allow it to operate as a stand-alone computer. And the system's basic electronics, housed on one board and designated Sol-PC, serves OEM applications that require a single-board computer.

To provide Sol with the required customer support, we developed Basic and Focal language packages as well as application and game programs. We also developed two ROM-resident programs—Solos, which optimizes Sol-20 functions for stand-alone computer applications, and Soled, which implements the functions of an intelligent terminal on either Sol-10 or Sol-20.

Lee Felsenstein is the founder of LGC Engineering, Berkeley, CA, and a consultant to Processor Technology, Emeryville, CA. Robert Marsh is vice president of Processor Technology.

All of these actions hinged on one major development in the hobby-computer market. Within the past year, several peripheral-interface and memory kits have appeared, each of which utilizes the "hobbyist," or S-100, bus structure used in several 8080-based computers. To take advantage of such kits, we decided to design the Sol family around this same S-100 bus structure. In essence, Sol is the combination of a microprocessor circuit with several S-100 peripheral modules.

implementing the design

As initially conceived by one of us (Marsh), Sol consists of a typewriter-sized cabinet on whose flat top a video monitor



can rest (Fig 1). One 10" x 16" PC card contains all electronics except the unit's keyboard and power supply, and the video signal generated by the device serves any EIA-standard monitor. A PC edge connector on the board accepts a backplane daughter board that holds as many as five S-100 cards. All I/O connectors, also available on the rear edge of the PC card, are accessible from the cabinet's rear.

To implement this basic structure (Fig 2), we buffered the system's 8080 address and data lines to the circuit and bus connector through tri-state drivers, much as do other S-100-type processors. Next, we paralleled two unidirectional data buses to form a bidirectional bus and thereby eliminated the need to run eight additional lines around what promised and proved to be a very crowded card. We also connected a 4-input multiplexer to select data input to the processor from the keyboard port, the parallel port and an internal data bus, as well as from the external data bus.

We created the internal bus as a unidirectional circuit for low-drive, on-card memory and I/O devices that cannot meet the heavy drive requirement of the full external data bus; it allows maximum utilization of the tri-state capabilities of the universal asynchronous receiver/transmitters (UARTs) used in the serial and tape channels. The flag and status outputs of these devices arrive in parallel at the 8080 chip; port addresses from the board's address decoder section enable the outputs. The decoder also controls the multiplexer's switching: default direction comes from the system's external bus. We defined the 4K bytes of memory in Page C (high-order hex digit of the address) as on-card memory, divided between 2K of ROM, 1K of RAM and 1K of "visible RAM" in the video display circuit.

The display section treats its RAM as 2-port memory; the processor has the highest priority. We placed the second port under control of the screen refresh circuitry, which calls up data as required for conversion by the character-generator ROM into video signals for display. We didn't connect the video display section to the internal bus because we felt we had to allow for its being loaded directly from an external DMA device, which can gain control of the data bus but not the internal bus. We made the data bus the source of all data fed to memory and I/O, both on-card and off; the only other data input to the processor from on-card circuitry through the data bus comes from the sense switches, an 8-wide DIP array that lets the CPU sense an alterable parameter byte under program control through input port FF.

We derived board timing from a 14.31818-MHz crystal oscillator, the frequency, four times that of the NTSC color burst, provides compatibility with color video graphics devices. This "dot clock" goes to an external connector and feeds the output shift register and character divider of the video display section as well as the 8080 clock divider. We configured the clock circuit using MSI and SSI TTL chips rather than the Intel 8224 LSI chip to allow for several selectable microprocessor clock rates; that way, we can retrofit higher-speed processor chips into the same board. When designing the clock, we took care to ensure non-overlapping

Fig 1 Moused in a typewriter-sized cabinet on which a CRT monitor can sit, Sol-20 contains all circuitry necessary to function either as an intelligent terminal or a stand-alone computer. The system's designers chose to configure it around the "hobbyist," or S-100, bus structure used in several 8080-based computers; Sol is basically the combination of several S-100 peripheral modules with a microprocessor circuit.

THE PERSONAL COMPUTER RETAILER

/OL.1 NO.1 PUBLISHED BY PROCESSOR TECHNOLOGY CORP., 6200 HOLLIS ST, EMERYVILLE, CA 94608 MARCH, 1977

This is the first issue of our new newsletter distributed solely to retail computer stores. PCR will be mailed monthly and is free to bona fide retail computer stores. In the newsletter we will try to give you advance notice of all Processor Technology ads in national magazines as well as the latest dope on new products. We will use PCR as a medium for discussion of detailed specifications, selling points, competitive comparisons, price changes, and special promotions as well as for quasi philosophical diatribes on business policy and general P.R.

sophical diatribes on business policy and general P.R.

We believe you will find the PCR an invaluable source of information whether or not you are a Processor Technology dealer. Your responses are welcomed and encouraged since we hope to make PCR an interactive medium of communication. In this vein take note of our Q & A column on page 7 where we will gladly respond in print to your questions about PTC products

and policies. Yes, we'll even answer the nasty ones!

SOLOS?-CUTER?-GPM?

What Is Going On?

Many of the PT dealers have long ago seen most of the software packages we recently advertised. Each package, in one form or another, has been fully implemented and essentially ready for delivery for a number of months. Why then have we created the two month void by not delivering? Quite simply the answer is: Real System Thinking.

The advent of the Sol-20 and CUTS cassette board opened an opportunity to at long last provide a oftware configuration that allows a major step forward in standardation. Think about it.

Someone using a parallel output keyboard with the 3P+S had a hard

time getting status at port 0 and data at port 1.

Bootstrap loaders for paper tape had to assume the user had memory at some location outside of the area required by the program. (For the paper tape version of TREK 80 we put the loader on the VDM screen!!)

The Sol System, however, has clearly defined I/O.

Ø for Keyboard and Display

1 for Serial IN and out

2 for Parallel

3 for user defined

These numbers are used with the SOLOS "SET" commands to dynamically determine I/O. And, the Sol System always has available memory (1K worth) at C800. In addition, the Sol System has a cassette tape interface ready and willing to load or save programs.

As SOLOS became a reality, we discovered a method of using the CUTS board and CUTER software to make the "other" brands' mainframes almost as easy to use as the Sol.

CUTER defines the 3P+S Ports in a manner similar to the Sol I/O. CUTER allows the user to have key-board, serial and parallel I/O on the 3P+S just as with the Sol-20.

(cont. on page 2)

cont.

What Is Going On?

But, more important, CUTER allows our software to run on any machine even though we designed it for the Sol System running SOLOS!!

Was it worth the delay?? Yes, indeed!

Now for the Important Details

In case you haven't received it yet, SOLOS (CUTER, too) features 18 commands to provide super-convenient operation of the computer. Standard-ized Input/Output, Variable Display Speed and complete tape load and store provisions are some of the highlights. And, buried deep within the code are routines that provide BYTE BY BYTE access to the cassette tape data. SOLOS handles two buffers to read blocks of tape while the user calls for data one byte at a time!

Using this feature, Sol BASIC-5 allows the user to:

10 READ #1; A,B,C 20 PRINT #2; A*2, B/C

But the "other brand" user must have CUTER to use these features.

CUTER is provided on a cassette tape for \$11.00 with each CUTS purchase. It loads to ANY selected memory address using a short bootstrap loader. Then, when the user loads a P.T. program he places his selected address into the loaded program. (We assume address CODD and the programs are provided with this address.)

CUTER assumes I/O is provided by a 3P+S but can be modified for less conventional boards. A very new good VDM-l driver is also resident in CUTER.

Wouldn't it be nice if everyone had a 3P+S, VDM-I and CUTER IN ROM at C000? Well...the March issues of the magazines will announce the

Processor Technology GPM (General Purpose Memory) in a very special way. Here's how it goes.

The GPM has space for ROM, PRO and RAM. The GPM is given FREE wit. CUTER in ROM right at C000 and 1K of RAM starting at C800.

Have we lost our bananas?
Actually, we lost them a long
time ago but the GPM is FREE only
with the purchase of a SUBSYSTEM "B"
and the SUBSYSTEM "B" is the keynote
of our forthcoming ads.

The user buys a 3P+S, VDM-1, CUTS and any one of the PTC Memory Boards as a SUBSYSTEM "B". The total price is exactly the sum of the individual prices. The GPM, CUTER ROM and 1K of RAM is then absolutely FREE.

The March ads for the Subsystem will create a little confusion because they refer to a "bootstrap" loader instead of CUTER. CUTER is provided!! This error is corrected in the April '77 issue.

If the entire Subsystem "B" is not needed, the price of the GPM with CUTER AND RAM is \$129.00 Kit or \$169.00 assembled.

The GPM can be ordered without CUTER and RAM for \$89.00 Kit, \$100.00 assembled for use in Sol Systems.

About Deliveries

Delivery of the GPM is solely dependent on our receipt of the CUTER ROM. For this reason each SUBSYSTEM "B" will be shipped with a mailing card for the buyer to receive his ROM. We have been promised 5-week delivery on the ROM's so please expect at least seven weeks per the usual.

The GPM is general purpose for another very special reason. The ALS-8 ROMS are now available and they reside on the GPM right along with CUTER.

The ROM's are sold separate of the GPM and are priced as follows:
ALS-8 \$159.00 6144 bytes of ROM
SIM-1 &
TXT-2 60.00 2048 bytes of ROM

(cont. on page 3)

What Is Going On?

Thus the price for the ALS-8, SIM-1, TXT-2, CUTER and 1K of RAM is \$348.00 when not purchased with Subsystem "B", but for use in NON-Sol main frames.

Note: Subsystem "B" purchasers need only buy the ROM's. The GPM is free with their Subsystem purchase.

The GPM module will fit in the Sol-10 cabinet without a backplane, as well as into all other S-100 computers. Don't forget the Sol version customers for these catalogs is left GPM is \$40 less than the Subsystem up to each individual store owner, but we recommend that they be given

The First Issue Of Processor Technology ACCESS Is In The Mail

This is the "technical newsletter" we referred to in our Fall '76 new product flyer. We think you will find the ACCESS an extremely valuable information source. Yearly subscriptions are \$4.00 for 8 issues. The order of distribution will be as follows:

- 1) paid subscribers
- 2) complimentary copies to retailers and trade press, simultaneous with No. 1
- 3) newsstand copies to retailers, about one week after Nos. 1 and 2

Newsstand copies are distributed free Processor Technology dealers to sold for 75¢ per copy. Other retail computer stores or suitable outlets may purchase the ACCESS from us for 30¢ each--minimum order \$30.00, i.e., 100 copies.

New Small Computer Catalog Available – 22 Pages!

PTC's new color catalog is currently being distributed to all of our retail outlets. You should find these beautiful catalogs more than helpful in explaining the features of PTC equipment and software. not charge stores for these catalogs. The decision whether or not to charge up to each individual store owner, but we recommend that they be given out free to "qualified" customers. Initially we will be quite liberal with the number sent to each store. Expect us to get "uptight", however, when you have distributed 1000 catalogs, sold only three Sol-20's, and want more catalogs.

The March-April issue of PERSON-AL COMPUTING MAGAZINE will contain the entire PTC catalog. Since most present personal computer owners get a copy of PERSONAL COMPUTING one way or another, the demand for actual catalogs from retail stores will be somewhat reduced.

TV/Monitor

The new catalog announces for the first time our PT-872 Video Monitor/TV Set. This is a Panasonic TV modified for selectable Monitor or Television operation. We added the unit to our line as a customer service to provide an excellent quality monitor at \$199.00. Because of the Customer Service aspects and because \$199.00 is very close to the retail price, the net discount for P.T. Dealers has been set at 25% regardless of quantity. Also, to limit our processing costs further, please place your PT-872 TV/Monitor orders along with regular orders.

Diatribe Department

You too can have your name in print when you become the famed author of a PCR Diatribe. This month we will monopolize the column, but we would really enjoy printing guest Diatribe editorials written by you. Send your double-spaced type-written manuscript to PCR's Robin Content, Diatribe Dept.

Real System Thinking-This Month's Diatribe

A wise old sage named Anon once said "A mess of parts doth not a computer make." Anon was once also heard to utter the timely phrase neither do working hard, firm, or soft-ware a Real System make."

Real Systems are more than a stack of different modules plugged into a main frame. Real Systems are more than a consistently interfaced and reliably connected group of peripherals. Real Systems are more than a series of different debugged programs that run on a given set of hardware.

So far the personal computer industry and the "movement" as a whole have shown a decided lack of system thinking. Home computers typically grow erratically and contain an eclectic blend of modules and programs from many sources that rarely work together without substantial modification. Usually the modification process is ongoing and continuous so that never is one guy's rig completely compatible with another's.

Much of the incompatibility problem has been created by manufacurers, PTC among them, who have not been able to get together with their competitors to agree on standardization of I/O or software. The problem derives though, not from this

seemingly inevitable inability to standardize, but from non-system thinking.

What is system thinking? System thinking's number one principle is "All system elements must always be compatible with all other elements." To the system owner and user this principle implies that his system should be:

- 1) consistent and reliable
- 2) easy to operate
- 3) easy to expand (or reduce)
- 4) easy to repair and maintain
- 5) easy to link to other systems

To the system designer and manufacturer this principle implies that his system should be:

- 1) conservatively rated,
 software too!
- 2) designed with strong user input and feedback
- 3) modular
- 4) pluggable, unpluggable, as simply as possible
- 5) conventionally interfaced whenever possible

What makes a Real System? Real Systems, i.e., real Computer system always have these five elements:

- 1) Human Being(s) for and
 with whom the computer
 is working--the most
 important element
- 2) Hardware, everything you can touch, even if you shouldn't
- 3) Software, everything you can't actually touch that must be there for the system to function
- 4) Manufacturer(s) and Designer(s), they've got to support Nos. 1 and 5 as well as crank out Nos. 2 and 3 in volume
- 5) Sales and Service people, hopefully they will be organized and take prime responsibility for solving No. 1's problems.

Notice that most of these system elements are people not products. Real Systems must have organized people backing them up. The people hat made the machine had better be apable of fixing it or you will certainly never be able to fix it. The people who wrote the systems software had better be able to listen to you and maintain and improve their programs or you won't be able to adapt, not even if you have a rare source listing. In general, they had better be able to help you solve

your problems.

As for the hardware, all elements including CPU, memory, input/ output, expansion interfaces, keyboard, and power supply must be designed together in as simple a manner as possible without sacrificing versatility and the virtually certain necessity of future expansion. All of these elements must be both simple to operate and simple to build, test and repair. External peripheral de-vices should always be "plug-in-able" using commonly available connectors and cables. Keyboards are critical elements! Real Systems never scrimp n keyboard costs since this is the first place the user will discover the results of a cheap design.

As for software: rule No. 1-Real System software designers must
talk to the hardware designers. Both
designers should even ask each other
for advice fairly often. This would
be an unusual situation in the computer business, to say the least, but
it is a very important principle. As
an example of hard/software interaction, commonly used housekeeping programs should be accessible to all
programs that run on the system. Accessibility should imply also that
the whole works should run as soon as
it is turned on.

Rule No. 2--System software must be modular and expandable, very much as the hardware must be. For example, a 4K BASIC program has got to run in a 12K BASIC system without odification. The author recommends the preceding ideas as guidelines to be followed by both computer owners and makers when considering buying, modifying or expanding a computer system. Whatever the application problems, if we can all direct our thoughts and energies toward integrating the multitudinous available pieces and parts into one systems package we will have taken a giant step toward eliminating the threat of the creeping Kludge.

CONSOL Update

All standard PTC software is designed around CUTER and SOLOS ROM's. Normally these ROM's reside at C000 to C7FF (hex) on either a Sol personality module or GPM board. CONSOL, since it is a temporary introductory package, has its I/O routines in nonstandard locations. Therefore such programs as BASIC-5 will not work properly with CONSOL. PTC will be glad to reprogram without charge CON-SOL modules to standard I/O locations if customers or retailers return them to us. However, we strongly recommend replacing the CONSOL module with SOLOS. ONLY SOLOS has the subroutines which permit cassette write operations, dynamic port switching and BASIC file manipulation.

Module Department

16KRA

PTC's new 16KRA module is just about the lowest price per bit, high quality S-100 RAM module available. At \$529 the 16KRA is a memory that is fully assembled, burned-in (for 12 hours at maximum rated temperature) and thoroughly tested. Only highest quality premium grade parts are used.

The Intel 2104-6 or Mostek MK4096-11 RAM's used are spec'd at 350 nanosec. access time and 500 nanosec. cycle time worst case. [NOTE: we can get faster RAM's--down to 150 nsec. If you need them, let us know right away.] The S-100 bus interface circuiting is fully asynhronous and uses the latest low power Schottky and integrated Schottky delay time technology. There are no "one shots" in critical timing paths and refresh is automatic and invisible to the CPU. Each 4096 byte page is individually addressable, using four of the 16 DIP switches on the card, conveniently placed at the top edge. A connector is provided for optional battery backup during power failures.

The 16KRA is guaranteed compatible with Sol, IMSAI 8080 and Altair 8800 mainframes as well as the Helios II DMA disk controller. The 16KRA is the perfect high density memory since the Sol has a limited number of ex-

pansion slots.

Important: Phantom, pin 67 in the S-100 bus is recognized by the 16KRA and is required for proper operation of Sol's and ALS-8.

Deliveries: First deliveries of 16KRA modules to retailers are now cheduled for late March with our large current order backlog eliminated in April. As is usual at PTC once this product is in production, we will be stocking it in depth!

CUTS

We will start delivering CUTS modules to all those with current back orders on March 9, 1977. demand for this product has far exceeded our expectations so we expect it will take another month to elimin-

ate our backlog.

CUTS, the Computer Users Tape System, is hardware, the key element required to make full use of our many systems software packages. The CUTS module is compatible with the builtin tape interface in Sol Systems and can read and write at either 300 bits per second, pure "Byte/Kansas City standard," or 1200 bits per second. All PTC CUTS cassettes are recorded at 1200 baud and cannot be read at 300 baud. Cassettes recorded with SWTPC, Poly 88, or Morrow boards can be read at 300 baud by CUTS or Sol hardware but the software in CUTER, CONSOL or SOLOS requires a specific data header format not used by these suppliers. So far as we know, Tarbell cassettes are not CUTS compatible.

Once PTC software is in your stores in volume, every S-100 bus computer owner will find the CUTS module indispensable -- That is a promise!

Memories -- 4KRA, 8KRA, 16KRA

All three PTC RAM modules incorporate circuity which disables any RAM at location zero during power-on start up. This feature, called PHANTOM, is mandatory with Sol systems and only PTC memory modules have it! ALS-8's and GPM modules can generate PHANTOM for auto-start up operation in Altair and IMSAI mainframes.

Sol Department

We hardly need say that the Sol Terminal Computer is the highest quality and most cost effective Real System available in the small computer field. Inventories of Sol-20 in particular are being built up by PTC to-meet the quick turn around needs of your store. Once the SOLOS personality modules and Sol software are in the field in quantity we expect to see another surge in demand. We urge all PTC retail dealers to place realistic orders for Sol Systems soon (for up to three month's needs) to eliminate the possibility of demand exceeding our ability to supply retailers quickly. If you order Sol Systems for a two or three month period, we will allow you to schedule shipments with reasonable minimum quantities per shipment. advised: be accurate -- we will ship the numbers you request.

SOL POSTERS!

PTC still has a good number of beautiful Sol-20 color posters. If you would like more of these posters to decorate your retail store or computer repair shop or to give to Sol buyers as a "freebie," let us know. They're off the shelf.



- Q: Can a customer trade in his CONSOL module when upgrading to SOLOS?
- A: Yes--PTC will credit the customer \$30 for a returned CONSOL module in working condition.
- Q: What is the expansion power supply capacity of the Sol-20?
- A: The Sol-20 can supply +8VDC unregulated at 8A and ± 17VDC at
 .9A unregulated. These are conservative ratings for the five
 slot backplane only. The Sol-PC
 and keyboard supplies are separate
 from the backplane.
- Q: How do I add more slots to my Sol?
- A: One way is to add a Helios II disk system. The Helios cabinet has space for an additional optimal 10 slots. We have not yet announced price or availability of this option to the Helios system.
- Q: Why do we advertise before products are ready?
- A: In the past we were forced to give in to that unfortunate temptation because of intense competitive pressure in an expanding marketplace.
 - We want you to know that we are committed to avoiding this practice in the future. Our goal is to have products on the dealers' shelves when the new announcements appear.

Subsystem "B" makes the computer you already have work almost as well as a new Sol-20.

Add it now, and for a limited time we'll throw in a new module with 2048 bytes of preprogrammed PROM or ROM and 1024 bytes of RAM memory free!

Processor Technology's Subsystem "B" puts together the major system elements you need to get your Altair or IMSAI up and running.

You get both RAM and PROM memory, parallel, serial, cassette and video display interfaces, and software. Software includes a bootstrap loader program so you can load any Processor Technology CUTS ("Byte/Kansas City") 1200 BAUD cassette tapes. Standardized subroutines in ROM, similar to those in a Sol personality module, are used by many Processor Technology software packages to improve program efficiency. You'll find you rarely need to touch your front panel switches. With our Subsystem "B" you are up and running as soon as you turn on the power.

Three subsystems are available, depending on your memory requirements. Each Subsystem "B" includes five S-100 bus compatible modules as listed below. Each is dependent upon our new GPM module (GPM = General Purpose Memory) which provides 1024 bytes of low power static RAM and 2048 bytes of preprogrammed ROM or EPROM as well as space for up to 8192 bytes more of ROM or 2708 type EPROM. The GPM module accepts the new ROM version of our well known ALS-8 Editor/Assembler software package.

With Subsystem "B" you have guaranteed compatibility with all Processor Technology software and hardware products.

Subsystem Model	B70	B 110	B 190
Total memory provided (bytes)	7168	11264	19456
Display I/O	VDM-1	VDM-1	VDM-1
Parallel, Serial I/O	3P+S	3P+S	3P+S
Tape Cassette I/O	CUTS	CUTS	CUTS
Memory	4KRA	8KRA	16KRA
Price	\$594	\$73 0	5964

NOTE: The GPM module with both RAM and PROM is included FREE in all the above subsystems. The GPM kit is \$129 if purchased separately.


The ALS-8/ROM chip set is \$159. SIM-1 & TXT-2/ROM add-on set is \$60 and requires both GPM and ALS-8/ROM.

☐ Enclosed is a check for 5 California residents add 6% sales tax. No shipping charge. ☐ Mastercharge =	I want: ☐ B70 at \$594 ☐ B110 at \$730 ☐ B190 at \$964
☐ Send more information Name	
Address State	Zip
Processor Technology	

The Small Computer Catalog.




And Sol Solution chart showing applications in business, science, home entertainment and management, art, law, medicine and education.



One source for quality hardware, software, and peripherals.



That's the Sol plan.



The new Sol-20 is unique. It's the first small computer de-

signed as a complete system.

Most small computers simply "grew like Topsy" — a memory here, an expansion module there. They weren't conceived or integrated to provide maximum efficiency at lowest possible cost.

Sol-20, a true breakthrough in small computer systems, includes all the essential elements as *standard* equipment — central processor, memory, keyboard and display, software, a power supply, and appropriate packaging.

There are no "surprises." You don't have to buy expensive peripheral equipment to make it run. Its own keyboard and "smart" terminal are built-in.

Use it without being a programming expert.

In fact, you can operate it efficiently without any prior computer experience.

Unlike other small computers, Sol is already programmed to receive our commands the moment it's turned on, thanks to Sol plug-in Personality Modules.

And Sol systems are supported in depth by extensive software and additional peripherals — such as flexible disk memories — so it's appropriate for more sophisticated applications.

Sol computer systems never grow old. Add new modules to update and expand your computer's power.

Sol is easy to use

Sol operates like a typewriter so many applications require no special programming. Packaged in handsome cases with solid walnut sides, Sol computers look good in the living room, office or lab. Sol computers come in kit or fully assembled form.

Sol-20 is a scaled-down big computer system

Use Sol in a variety of applications.

In the home. Home uses are limited only by your imagination. Regulate heat and light to save fuel. Run a complex model railroad. Compute taxes. Play a variety of TV games, not only computer hockey and tennis, but more interesting, more complex games such as TREK-80, where your starship takes on a whole fleet of Klingons. Several sophisticated TV games come with the Sol-20. And you can even design your own.

At the office. Use it as a full-fledged business computer. Use it to compose and edit letters electronically, store and retrieve mailing lists, process orders, maintain journals and general ledgers, and produce statements and reports.

In the lab. Use Sol to reduce and analyze data statistically, control lab equipment, prepare graphics, and fit curves. Sol-20 frees your time and expands your overall capability.

In schools and universities. Use Sol-20 to teach computer programming. Use it for computer-aided instruction. Use it for notes, records and sorting.

So much is standard


Here's the computer with a microprocessor, display and input/output circuitry, memory, full alpha-numeric keyboard, big power supply, handsome cabinet, and software.

Add extras for more power

Extras include a module to help write, edit, assemble, de-bug and run your own programs. There's no better collection of add-on memories anywhere...up to 16,384 words per module. Solve additional interfacing problems with our I/O module. Get big system performance with our Helios II "floppy" disk system. Display results on our video monitor. Output on line or serial printer. Other peripherals include joysticks, paper tape readers, A/D and D/A converters, and PROM programmers.

1 EPT 1 - 36

Sol Computers



Sol computers are currently offered in three forms: the Sol-20, Sol-10, and Sol PC.

The Sol-20 Stand Alone Computer

Sol computer systems are currently offered in three forms: the Sol-20, Sol-10, and Sol PC.

Sol 20 is the most complete and sophisticated of the three packages, a fully contained "personal" computer able to take on an infinite variety of tasks. Sol-20 comes with:

- 8080 microprocessor, still the most sophisticated computer-on-a-chip available and the "brains" of the Sol-20.
- 1024-character video display circuitry. View your output on any standard video monitor or specially adapted TV.
- 1024 words of static low-power read/write memory (RAM) for program storage.
- 1024 words of static low-power, preprogrammed permanent memory (ROM) takes care of important system "housekeeping" chores. ROM memory automatically readies the computer for your commands as soon as the Sol is turned on.
- a custom designed, beautifully laid-out 85-key solid-state upper and lower case keyboard with cursor keys and arithmetic keypad.
- an audio cassette interface capable of controlling two recorders at 1200 bits per second.
 Store and retrieve programs and large amounts of data at very low cost.
- both parallel and serial standardized interfaces with connectors on card.
- a complete rugged power supply and quiet cooling fan.
- a handsome case of walnut and metal.
- software including a preprogrammed PROM personality module and a cassette with BASIC-5 language, plus two sophisticated computer video games.

- a design compatible with all S-100 bus products.
- a back plane capable of accepting five expansion modules.

The Sol-10 Terminal Computer

Sol-10 comes in the same handsome package as the Sol-20, but because of limited memory, it is designed more specifically for "smart" terminal applications. Price of the Sol-10 includes case, power supply, and 70-key solid state keyboard. A fifteen key arithmetic pad is optional.

Later you can upgrade to a Sol-20 by adding an expansion backplane, extra power supply, fan and keypad.

Sol-PC Single Board Terminal Computer


Here's the heart of the Sol system. The Sol-PC is a single printed circuit board with microprocessor, memory, display and interface electronics, and plug-in personality module that is fully compatible with our complete line of memory and interface modules.

The board comes in kit or fully assembled form with all of the following:

- Display: 16 lines of 64 characters per line.
- Character set: 96 printable ASCII upper and lower case characters plus 32 selectable control characters.
- Cursor: Selectable blinking. Solid video inversion. Programmable positioning standard.
- Serial interface: RS-232 and 20mA current loop, 75 to 9600 baud, asynchronous. 25 pin female "D-type" connector on card.
- Parallel interface: Eight data bits for input and output; output bus is tristate for bidirectional interfaces; levels are standard TTL. 25 pin male "D-type" connector on card.
- Keyboard interface: Seven-level ASCII encoded, TTL levels.
- Microprocessor: 8080, 8080A, or 9080A.
- On-card memory: 1024 bytes PROM (expandable to 2048 bytes); 2048 bytes low power static RAM.
- External Memory: Expandable to 65,536 bytes total ROM, PROM and RAM.
- Video signal output: 1.0 to 2.5 volts peakto-peak. Nominal bandwidth is 7 MHz. Power required (±5%): +5 volts at 2.5 amperes. +12 volts at 150 mA, and -12 volts at 200 mA.

1 EPT 1 - 37

A. Personality Modules



Sol Personality Modules allow you to choose three different levels of operation. Software in each module optimizes Sol for a particular application and at the same time provides a measure of general purpose capability. For custom applications and for volume OEM users personality modules are available without memory for three different types of EPROM and two types of factory-mask ROM.

SOLOS, the most popular module, optimizes the Sol for stand-alone computer applications. Choose SOLOS if you intend to use your Sol system to store and retrieve business or personal records, control electronic instruments, perform independent calculations for business, science or education, or any other application where the Sol system will be "on its own" operating independently of other computers.

SOLOS is oriented around use of the Sol's built-in CUTS audio cassette data interface. Programs such as Sol-BASIC and ALS-8 can make extensive use of the cassette handling and screen-cursor manipulation routines contained in SOLOS. Commands included are: Dump. Enter, Execute Terminal (i.e. enter Terminal mode), Tape Load (reads CUTS format cassette tapes into memory), Tape Save (stores memory contents on CUTS tape) and Set I/O (permits dynamic switching of input and output devices under manual or program control). With SOLOS the Sol can also be used as a "smart" terminal in conjunction with other computer systems, but ordinarily the SOLED module is the better choice when the Sol system is often used as a terminal.

With the SOLED personality module installed the Sol becomes an advanced editing terminal system. Like SOLOS, SOLED uses the full 2048 byte capacity of its module. It contains programs and routines which allow remote direct cursor addressing and file and cassette tape editing. Data and text can be edited on or off-line and transmitted in blocks under local or remote control. Large cassette data files or text messages can also be transmitted and received automatically from remote locations.


SOLED has the ability to dynamically change input and output device assignments. Stored information can be transmitted via modem. printed on one of several printers or stored on additional cassettes or flexible disks.


CONSOL is a 1024 word low cost personality module which gives minimal capability to the system. Commands include Enter, Dump, Execute, Tape Load, and Terminal. CONSOL permits operation as a low level CRT terminal and is useful for simple stand-alone applications. Full keyboard cursor control, up, down, right, left, home, clear is provided. CONSOL is not needed with SOLOS or SOLED modules because its functions are duplicated.

1 EPT 1 - 38

B. Software







Software is the sine qua non of any computer system. It's the computer power essential. No computer can be more powerful than the software that goes with it.

That's exactly why Processor Technology has devoted more effort to the development of software than other small computer makers. Maybe that's why some of our worthy competitors have taken our source listings, added a few twists and taken title. But the truth will out.

All Sol systems software is designed to make full use of the routines and programs permanently stored in all Sol personality modules. User programs such as BASIC require less memory space, because personality module routines are called up whenever needed for functions such as keyboard input, screen formating, and cassette tape storage operations. Interface with the user is straightforward and consistent because keyboard commands and control sequences are standardized for all Sol software.

Sol BASIC

Processor Technology offers three versions of BASIC language, each suited to a different application. BASIC-5 is a small version of this versatile language designed for applications requiring just mathematical manipulation without extensive processing of text. BASIC-5 is the perfect language for an introduction to computer programming because it's easy to learn and requires a small amount of memory storage. Many hundreds of programs already written in BASIC work with Sol BASIC-5 and our 8K BASIC as well.

Processor Technology 8K BASIC is a very high speed full function language with all the virtues of BASIC-5's multiple program capability and BCD floating point math. Speed is at least double that of the already fast BASIC-5. For even greater power, we've added strings, multidimensional arrays and multi-line, multi-variable, user functions. Here's the language for full capability systems. For instance, in our instruction manual, take a look at the *Business* analysis program. See how you get more power while using less memory for the working program.

Advantages of Sol BASIC

Processor Technology 8K BASIC offers several unique and unusual features. Versatile print statements provide fully formatted output to multiple devices, from CRT screen to teletype to line printer. Multi-dimensional arrays permit powerful fast processing of any data that can be organized graphically or in tabular form. Several statements are provided to give complete and direct high level language control over system memory and input/output channels. Full capability string functions simplify manipulation

and processing of text and alphabetic materials to they are more straightforward and easy to use than ever before. In short, with this BASIC, no effort has been spared to bring you high level problem solving power.

Extended Disk BASIC has all the powerful

features of the 8K memory-resident version and includes disk commands and big system file handling capability. Disk BASIC is perfect for such complex applications as inventory control and payables-receivables accounting.

BASIC CHART				
Commands:		BASIC-5	8K BASIC	Extended Disk BASIC
ASAVE	ASCII DISK SAVE			+
CONT	Continue		+	+
CLEAR		+	+	+
GET	tape or disk	+	+	+
KILL	delete file			+
LIST		+	+	+
MEM	multiple programs	+	+	+
NULL	for printers	+	+	+
RESAVE				+
RNUM	Renumber		+	+
RUN		+	+	+
SAVE	tape or disk	+	+	+
SCR	Scratch	+	+	+
XEQ	Get + Run	+	+	+
Statements:				
CALL	call machine subroutine	+	+	+
CLEAR			+	+
CLOSE	disk file			+
DATA		+	+	+
DEF	define function	al O i a	+	+
DIM(X)		+	+	+
DIM(X,Y,Z,)			+	+
ELSE	if,then,else		+	+
END	Para iei Padan	+	+	+
EXAM	memory "dump"		+	+
EXIT		.fr+m:	+	+
FILL	"deposit" memory		+	+
FOR		+	+	+
FREE	free space		+	+
GOSUB	Lance de la company	+	+	+
GOTO	dards en el	+	+	+
IFTHEN		+	+	+

INP(X),Y	from inport x		+	+
INPUT		+	+	+
INPUT," "	suppress CRLF	+	+	+
LET		+	+	+
ON	ON GOSUB		+	+
OPEN	disk file	M AUS		+
OUT(N),	to out port N	Marier.	+	+
PAUSE	remik-eng n		+	+
PRINT		+	+	+
PRINT USING			+	+
READ		+	+	+
READ#N	read file	+	+	+
REM		+	+	+
RESTORE		+	+	+
RESTORE	with line #		+	+
RETURN		+	+	+
REWIND	rewind file pointer			+
SET I/O	for peripherals	+	+	+
STOP		+	+	+
WAIT	for input port bit(s)	land had	+	+
WRITE	disk			+
BASIC Functions		BASIC-5	8K BASIC	DISK
ABS	absolute value	+	+	+
ARG	16 bit conversion	+	+	+
ASC	ASCII value		+	+
ATN	Arctangent		+ +	+ +
ATN CHR COS	Arctangent Decimal value	+	+	+
ATN CHR	Arctangent Decimal value of character	+	+	+ +
ATN CHR COS	Arctangent Decimal value of character Cosine	+	+ + + +	+ + + + + +
ATN CHR COS EOF EXP INT	Arctangent Decimal value of character Cosine End of file ex Integer	+	+ + + + + + + + + + + + + + + + + + + +	+ + + + + + +
ATN CHR COS EOF EXP INT LEN	Arctangent Decimal value of character Cosine End of file ex Integer String length		+ + + +	+ + + + + +
COS EOF EXP INT LEN LOG	Arctangent Decimal value of character Cosine End of file ex Integer String length Natural logarythm		+ + + + + + + +	+ + + + + + +
ATN CHR COS EOF EXP INT LEN	Arctangent Decimal value of character Cosine End of file ex Integer String length Natural logarythm LOG base 10		+ + + + + + + +	+ + + + + + + + + +
COS EOF EXP INT LEN LOG	Arctangent Decimal value of character Cosine End of file ex Integer String length Natural logarythm LOG base 10 Random number		+ + + + + + + +	+ + + + + + + + +
COS EOF EXP INT LEN LOG LOG10	Arctangent Decimal value of character Cosine End of file ex Integer String length Natural logarythm LOG base 10	+	+ + + + + + + +	+ + + + + + + + + +
ATN CHR COS EOF EXP INT LEN LOG LOG10 RND SEARCH	Arctangent Decimal value of character Cosine End of file ex Integer String length Natural logarythm LOG base 10 Random number Search string for string Sign of number	+ + +	+ + + + + + + + + + +	+ + + + + + + + + +
ATN CHR COS EOF EXP INT LEN LOG LOG10 RND SEARCH	Arctangent Decimal value of character Cosine End of file ex Integer String length Natural logarythm LOG base 10 Random number Search string for string	+	+ + + + + + + + +	+ + + + + + + + + + + +
ATN CHR COS EOF EXP INT LEN LOG LOG10 RND SEARCH	Arctangent Decimal value of character Cosine End of file ex Integer String length Natural logarythm LOG base 10 Random number Search string for string Sign of number	+ + +	+ + + + + + + + + + +	+ + + + + + + + + + + + + + + + + + + +
ATN CHR COS EOF EXP INT LEN LOG LOG10 RND SEARCH SGN SIN	Arctangent Decimal value of character Cosine End of file ex Integer String length Natural logarythm LOG base 10 Random number Search string for string Sign of number Sine	+ + + + + +	+ + + + + + + + + + + + + + + + + + + +	+ + + + + + + + + + + + + + + + + + + +
ATN CHR COS EOF EXP INT LEN LOG LOG10 RND SEARCH SGN SIN SQR	Arctangent Decimal value of character Cosine End of file ex Integer String length Natural logarythm LOG base 10 Random number Search string for string Sign of number Sine Square root Convert no. to	+ + + + + +	+ + + + + + + + + + + + + + + + + + + +	+ + + + + + + + + + + +
ATN CHR COS EOF EXP INT LEN LOG LOG10 RND SEARCH SGN SIN SQR STR	Arctangent Decimal value of character Cosine End of file ex Integer String length Natural logarythm LOG base 10 Random number Search string for string Sign of number Sine Square root Convert no. to string	+ + + + + +	+ + + + + + + + + + + +	+ + + + + + + + + + + + +

The ALS-8 Program Development System

Applications with very high speed data manipulations or critical timing elements demand "custom fit" programs and subroutines. High level languages written for microprocessors such as FOCAL, BASIC or FORTRAN cannot always handle these assignments. In these cases the best solution is programs written in assembly language, a language much more closely related to actual real-time computer operations. Assembly language is easy to learn and, with either of our two assemblers, quite easy to use.

To simplify the development process as diagrammed on the right both Processor Technology assembler programs organize user


programs as files.

Processor Technology's much imitated Software #1 package is a small assembler-monitor system designed for development of small to medium length programs which must be stored in system RAM memory for assembly. The ALS-8 is a more versatile and expanded development package with many additional powerful features.

With the ALS-8 up to six source programs can be stored in memory as named files and called at will to be listed, edited, assembled or simulated. Files may also be stored on tape or disk and can be assembled from any selected input device. Files can be appended, moved, re-numbered, taken apart or linked together. Using the FCHK command, crashed files can be restored.

Assembly language source programs are entered using line numbers from paper or mag tape, keyboard or disk. All editing is done by line number but with the TXT-2 Text Editing software, it becomes possible to automatically add line numbers to un-numbered text.

The Assembler includes labels, comments, expressions and constants, along with relative symbolic addressing, which gives you the ability to chain common symbols from one program to another (even if the other program was assembled at some other time). Also, various assembly error messages are provided to help you eliminate program bugs.



ALS-8, a powerful, new development procedure

adjust the system's I/O handling configuration. The system includes an I/O driver table accessible through use of three resident commands or the drivers themselves. I/O device driver routines may switch themselves on and off or transfer I/O control to a different device driver under program control.

Your development system might have a CRT terminal, a high speed line printer, paper tape reader/punch and a teletype. The System can print a listing to the line printer, then input from the paper tape reader and return console control to the CRT terminal or teletype, all under program control.

Up to 20 custom commands can be entered by the user and called in exactly the same way as the standard resident commands. With the

custom commands, I/O driver table, dynamic I/O switching capability and common symbol tables, you can change your system's configuration and operating modes at any time.

Resident commands are:

ASSM CUST ENTR FIND MOVE SYME ASSME CUSTD EXEC **FMOV NFOR** SYML ASSMI CUSTE FCHK FORM **SYSIO** SIMU ASSMX DUMP FILE **IODR STAB SWCH FILES** AUTO EDIT LIST SYMD **TEXT**

Custom commands: Up to 20 specified by

by user.

The ALS-8 requires 2048 bytes of random access memory (4096 is recommended) for symbol tables and system global area, addressed at D000 (hexidecimal).

The SIM-1: The SIM-1 Interpretive Simulator is a program that actually thinks it's an 8080! With the SIM-1/ALS-8 combination, simulate 8080 programs on your Sol, IMSAI, or Altair computer without actually running them in real time. All registers, flags, program counter, and stack are simulated. Try out programs with no fear of crashing your system if something goes wrong. The system doesn't lose control if a program error is encountered (e.g., an incorrect jump or call).

With SIM-1, you can set breakpoints, enable or disable register/memory content printout. I/O instructions can be run in real time, simulated from the system console, or set to predetermined values for any I/O port address.

SIM-1 is a powerful de-bugging tool for 8080 programming.

TXT-2, Text Editor

Adds the world of text editing to your system. Using TXT-2, insert, delete and move single characters, entire lines or portions of lines. Complete text files can be scanned at several user controlled rates, up to almost 2000 lines per minute when used with our VDM-1 Video Display Module.

Both ALS-8 and Software #1 packages are available on "CUTS" 1200 bps cassette or paper tape. The ALS-8 is also available preprogrammed into permanent ROM memory to provide "Instant-on" efficiency and speed.

TREK 80

Based on the NBC television series STARTREK, this machine language program uses

8K of memory and the VDM graphics capability for real time war with the Klingons. No holds barred, they're out to get you from each of the 100 quadrants. You can warp through hyperspace, fire phasers, photon torpedos or experimental rays, or if you just can't go on, self-destruct. TREK 80 resides and runs in 8K of memory and, if not used with a Sol, requires a Processor Technology VDM-1 Video Display Module.

New 8080 FOCAL (™ DEC)

FOCAL is a high level math language originally written for the PDP-8 minicomputer. Many thousands of FOCAL programs are in existence and now they can run in the Sol. Our original 8080 FOCAL has been updated to include operator precedence and all other standard FOCAL conventions. It also has a driver for VDM-1 or Sol displays and CUTS cassette program save and load. FOCAL is available only on CUTS 1200 bps Cassette and resides in 8K of memory.

Gamepac 1

Show off your Sol system with this line up of video games. Each is included on the CUTS cassette or paper tape.

TARGET — Keeps track of your hits and misses while you blast away at the numerous flying objects. Includes sound effects. You and your family will spend whole evenings at a time with this one.

ZING — Learn hexidecimal arithmetic fast with this video game as two players keep the five balls in the air. If both of you get too good...
ZING of course, makes it harder.

LIFE — The Sol or VDM-1 make a good display for the game of LIFE and this version allows two modes of operation. The universe can be flat or wrapped around on itself. The real meaning of life we'll leave to you, but it's fun to watch.

PATTERN — We haven't figured this one out ourselves, but it's sure fun to have your computer doing it. You choose the geometric design and how rapidly it changes. The computer dazzles you with its artistic genius.

All Processor Technology software is distributed on an individual sale basis for personal use. No license to copy, duplicate or sell is granted with this sale. Each software package has been copyrighted.

Sol Solution Chart


THE HOME COMPUTER

THE LEARNING MACHINE

	teractive learning programs
Tax form preparation Financial records keeping	Research data storage and retrieval
Electronic diary	Thesis preparation
Sol-20	Sol-20 with SOLOS personality module
Solos Personality Module 8000 words memory	16000 words memory
B/W TV-Monitor	B/W TV-Monitor
Cassette recorder	Cassette recorder
BASIC-5 language	PT 8K BASIC language
various games	FOCAL language

THE LEGAL LIBRARY egal precedent libraries Pattern recognition Time keeping Automatic billing Sol-PC Sol-20 with SOLOS module SOLOS personality module 32,000 words memory 8000 words memory Helios II disk system B/W TV-Monitor Cassette recorder Color graphics interface A/D-DAC converter(s) Printer ALS-8 ROM system **BASIC-5 language** PTDOS 1.4 System Disk **FOCAL language** Disk BASIC ALS-8 assembler

C. Memories 1 EPT 1 - 44



As your computing needs grow you will inevitably need more memory for storage of larger programs. Processor Technology offers one of the most complete lines of memory modules for small computers available. Choose either the 4096 word or the 8192 word static read/write memories in kit or assembled form. Or add the completely assembled 16,384 word dynamic module. A 2K erasable PROM module for permanent storage is available in kit or assembled form. A powerful software development tool, the ALS-8 firmware module, with its optional firmware SIM-1 and TXT-2, gives you the power to write, edit, assemble, debug and run your own programs the moment power is turned on.

All Processor Technology memory modules include our exclusive "Phantom Disable" feature which is necessary for proper power-on operation of the Sol mainframe. The ALS-8 firmware module also generates this signal as an option when used in Altair or IMSAI computers.

Two low power, highly reliable RAMS — 4K and 8K

Now you can have fast static random access memories with 4K and 8K capacity with all the bells, whistles you need plus Processor Technology quality.

The 4KRA Static Memory Module

Here's a 4096 word read/write static memory which gives you better operation for lower cost than any other 4K memory on the market today. Run it at max MPU speed all the time.

Processor Technology uses only low power static RAM Integrated circuits. So you know you're getting outstanding reliability.

In fact our module draws so little power, you can use standard "D" cells to give you long term back up data retention. We've even built in a battery connector, and recharge circuitry.

The 8KRA Static Memory

PT's 8K memory gives you all the advantages of our 4K with twice the capacity and more flexible addressing circuitry. The 8KRA uses less power than two 4KRA memories.

All address and data lines are fully buffered. Noise immunity circuitry is built-in. The 8KRA has PT's exclusive built-in KSET switch giving you card address offset in 1K increments. Address is set by a dual inline switch easily accessible at the top of the PC board.

Each IC — all 76 of them — has its own top quality IC socket so that assembly, test and repairs are far easier.

16KRA Memory

Fully burned in, tested and assembled, PT's new 16,384 byte memory offers a better price performance ratio than anything remotely comparable. It's the quality, reliable low-cost way to add high density memory to your system. Every board is "burned in" at high temperature for twelve hours before test to insure reliability in the field.

This PT memory offers invisible refresh. There's no waiting while the CPU is running. Worst case access time is 400 nsec. Each 4096 word block is independently addressable for maximum system flexibility. Power is typically 5 watts, the same as most single 4K memory modules. It's got back-up battery capability built in.

2KRO Erasable Programmable Memory

Accepts up to 2048 bytes erasable programmable read-only memory. Stores data even when power is off. Great for your custom loader or monitor programs.

The 2KRO is jumper selectable to fit any one of thirty-two 2K segments within the 65K addressing range of the 8080. Additional jumpers select the appropriate number of "wait" states, determined by the access time of the EPROMs in use.

The 2KRO was designed for either the 1702A or MM5203 EPROMs. EPROMs are not included, but both are readily obtainable for reasonable prices on the industrial and surplus markets.


The ALS Firmware Module for fast software development

The ALS-8 is a low power "turn-on-the-switch" program developer. Quickly write, edit, assemble, de-bug and run your own programs. Here's an easy to use, easy to understand software development tool you can begin to use with only 15 minutes instruction.

Two firmware options are available, the SIM-1 Interpretive Simulator, a program that thinks its an 8080, and TXT-2 text editing firmware which adds the world of text editing to your system. For more details on this equipment please turn to the section in this brochure on software. The ALS-8 is only available factory assembled and tested.

		PTC MEMO	RY MODULES		
	4 KRA	8 KRA	16 KRA	2 KRO	GPM/ALS-8
Maximum Capacity (8-bit words)	4096	8192	16,384	2048	5120 to 8192 bytes ROM
RAMS used	91L02A or 2102LPC	91L02A or 2102LPC	Intel 2104 or Mostek 4096 types	1702A EPROM	9216B ROM
Operating Mode	Static	Static	Dynamic	Static	Static
Access and Cycle Time	520 nanoseconds worst case maximum. Typical 400 nanoseconds.	Same	400 nsec access 500 nsec cycle	Dependent on EPROM used. Works over range of 30 to 2500 nsec	450 nsec
Bus Pinout	Plug in compatible with Sol, Altair 8800 and IMSAI 8080 bus	Same	Same	Same	Same
Power: Operating	+7.5 to 10 VDC @ 1.0A max (0°C), 0.8A typical at 25°C. 0.8A typical, 1A max.	+7.5 to +10 VDC at 1.4A typical (25°C); 1.9A max (0°C to 70°C)	+7.5 to 10 VDC @ O.4A typical, 0.8A max. +15 to +18 @100mA typical, 150mA max15 to -18 VDC @20mA max.	+8 to +10 VDC © 0.6 max15 to -19 VDC @350mA max with 8 1702As installed. (Replace- ment transformer available for full negative supply in Altair 8800)	+7.5 to +10 VDC @ 600 max. +14 to 19 VDC@ 200mA max (with SIM-1 and TXT-2 options installed)
Power: Standby	+1.6 to 2.5 VDC at 0.5A max worst case. 0.4A typical	+1.6v to 2.5 VDC typical; 0.9A max (power connector provided for battery connection)			
Address Selection	Dual in line switches	Dual inline switch at top of PC board allows manual selection of any 8K segment on 1K increments	Each 4096 byte page addressable with dual in line switches at top edge of PC board	Jumper selectable to any 2048 byte block of the 32 available.	Fixed at E000 to FFFF (hex)
Dimensions	5.3"x 10.0" (13.46 cm x 25.4 cm)	5.4"x 10.0"	5.4"x 10.0"	5.3"x 10.0"	5.3"x 10.0"
Phantom RAM (for Sol and ALS-8)	Yes	Yes	Yes	No	Yes

D. Disk Storage



Disk Storage

Every computer owner longs for all the advantages of fast random access memory. We're ready when you are to put big system disk memory power at your command. The new Helios II is more than just a floppy disk drive and controller. It's more than just scattered pieces of wire and patches of software. Helios II is a complete, integrated disk storage system which should meet every program and data storage requirement your system is likely to have. The Sol-Helios pair forms a cost effective, high performance system without equal.

Helios II gives you BIG SYSTEM PERFORMANCE

Big system performance is unique to the Helios II. Used in any application requiring manipulation of large data files, Helios II will outperform all other microprocessor based systems by a factor of at least 10 to 1.

Big system performance means all disk and memory buffer space allocation, all file management, all device interaction, comes from the system. Big system performance means extended DISK BASIC, DISK FOCAL, and Processor Technology software support. DISK FOCAL is provided free on the system diskette and extended DISK BASIC is offered on a separate diskette for \$50. Using these simple languages you can immediately write programs for any application you have in mind. The file operations include random byte or block access as well as update and rewrite in place of standard sequential files. Other application packages are under continuous development at Processor Technology. And in line with our basic software philosophy, each will reach the market at the lowest possible cost.

Helios II comes complete with dual drive, controller, system diskette with DOS, power supply, case, all necessary cables and full systems documentation. A 12K assembly language program to test and report on every aspect of your unit is included too.

Helios II loads an 8000 byte program with a look up in the system directory in 0.3 sec....a speed which becomes truly significant when you are working on two 100K source files to create a third, adding up to a total of 200,000 bytes.

"Firm sectored" Controller raises disk storage to 386,000 bytes per diskette

The Helios controller is a genuine performance breakthrough, increasing formatted data capacity per diskette surface to over 386,000 bytes and at the same time assuring higher reliability than the older IBM format. Standard Helios II storage capacity is over 750,000 bytes. With two dual drives, capacity can be doubled to 1.5M bytes.

Asynchronous data transfers are made directly to memory at an effective rate of one-half million bytes per second. A sixteen byte fifo memory accumulates the data to or from the drives, freeing the computer for useful work. A standard hardware CRCC error test is performed on each transfer of data and an optional read-after-write verification mode is easily selected. The controller requires at least one S-100 bus slot and is fully compatible with Sol, Altair or IMSAI systems.

No need to buy special, expensive diskettes—the controller will pre-format any standard 32 hole "floppy" diskette.

Software

PTDOS 1.4.0 is a proven disk operating system with total file and memory management. Features include:

Complete management of static, dynamic user buffers.

Device files for generality of input/output operations.

System calls for complete file operations from external programs.

Three level, triple option error handling/trapping.

Random/Indexed Files for direct positioning to any word of a file, anywhere on the disk(s).

Command Line Interpreter accepts and executes a string of commands from you or a file.

System utility call performs a random search to the utility operation of your choice.

Helios II can be configured and reconfigured for any size buffer area. Over 40 files can be open at one time. System calls provide standardized access for all file operations from external programs and routines.

The Command Interpreter accepts input from the current command input file to provide direct file operations from the keyboard or another file. Support program calls are identical to commands, but executed outside of the system area (e.g. in low memory).


Want more information

A full product description of Helios II is available for \$1. We are also making the PTDOS 1.4.0 portion of the Helios II System Manual available for \$20. (which we credit toward your purchase of the system). But, if you are already familiar with the consistent quality, features and support given to all Processor Technology products, order your Sol-Helios system today. You'll have Big System Performance working for you that much sooner.

New extended DISK BASIC

Further increasing the value of your Helios II is our extended DISK BASIC. This powerful language offers advanced string and math functions plus direct commands (SAVE, RESAVE, ASAVE, KILL and XEQ) and program statements. DISK BASIC is the only available small computer BASIC with powerful disk file handling commands, statements and functions. These features make complex application programs for inventory control, data reduction and general accounting run ten times more efficiently on the Helios system.

E. Interfaces



When we talk about making the complete small computer, we mean interfaces, too. Nothing is left out. There's a video display module designed to work with computing equipment you may already have or auxiliary equipment you may need. There's the Computer Users Tape System so you can add additional audio cassette tapes for expanded program and data storage/interchange. There's a wire wrap extender board for anyone who does prototyping. If you're troubleshooting, you can see what you're fixing with Processor Technology's Extender Board. You can handle any additional input/output needs of your system with our 3 P+S Input Output Module.

In sum, Processor Technology has built every basic element you need into Sol for integral operation. And we have generated the extra equipment for use with peripheral devices or other existing computer you may have. Processor Technology is dedicated to helping you get optimum computer performance.

VDM-1 Video Display Module

We call it the communicator. It provides almost Sol-like performance for Altair and IMSAI computers. It's a high speed module which has 1024 bytes of random access memory, scrolling and multiple programmable cursor circuitry. Sixteen 64-character lines are generated in a large easy to read upper and lower case font. Data handled by the read/write on-card memory is displayed instantaneously with no interference to the processor. Top display scroll speed is 2000 lines per minute!

VDM-1 lets you display white on black or black on white. VDM-1 offers EIA video output. Terminal mode software comes with the module at no extra cost so you can use it with your existing programs. Most Processor Technology software packages already include versions of these display driver routines, so no time comsuming software patching is necessary. The VDM-1 can be used in Sol systems to add a second display output for expanded special applications.

CUTS: The computer users tape system

Here's the low cost high speed audio cassette interface for computer program and data

storage interchange.

Operate at 300 bits per second or 1200 bits per second in the new Processor Technology CUTS format, upward compatible with the "Byte/Kansas City" standard. (see Popular Electronics, p. 86, March 1976)

Electronics, p. 86, March 1976)

Using CUTS you can load programs ten times faster than with a teletype paper tape reader. You can load Processor Technology BASIC in 58 seconds. There are no critical adjustments. Just about any ordinary cassette recorder will do. CUTS has AGC in both read and write modes. So you won't lose bits at 1200 or 300 baud.

Software on CUTS cassettes costs less than

equivalent paper tape.

The following software for the CUTS module is available for \$11, all on one cassette.

A. CUTER™— Computer Users Tape Entry and Retrieval monitor program.

B. BASIC-5 with CUTER compatible commands implemented.

C. Lunar Lander written in BASIC-5.

Many more programs are under development. You can reasonably expect a new one every few weeks.

Wire Wrap and Extender Boards

Wire wrap boards are designed for prototyping. Create custom interfaces or whatever your fancy dictates.

WWB has a "universal" seven-row pattern of pads on .3" centers, so standard 14, 16, 24 and 40 pin DIP IC sockets can be plugged right in. Power and ground are dedicated to pins 16 and 8 respectively (for 16 pin DIPs). Converts to other IC sizes easily. Use up to 62 sixteen-pin DIP ICs; six extra wirewrap socket positions have been set aside for wire wrap connections to any S-100 bus computer (Altair or IMSAI).

Use the Extender Board to help you troubleshoot any S-100 bus compatible module. Plug in a glitchy module 5" above the mother board for easy scope, VTVM or logic probe. Sol-20 systems already have a built-in extender connector on the back plane assembly.

3P+S Input Output Module

Processor Technology's 3P+S input/output module offers a low cost way to handle virtually all the I/O needs of any S-100 bus compatible computer system.

The 3P+S has two 8-bit parallel I/O ports, with full handshaking logic, plus a serial I/O port with a data rate that can be set anywhere

between 35 and 9600 baud.


One parallel output port can be used to set up control conditions for both parallel and serial ports, as well as for setting the serial I/O baud rate under program control. One parallel input port is available for polling Input Data flags and External Device flags, and for checking the serial I/O error flags. You can implement full handshaking with both input and output peripherals.

Interfacing to the Sol System, Altair 8800, or IMSAI 8080 vectored interrupt bus is provided by a jumper selectable option which allows any of the UART (Universal Asynchronous Receiver Transmitter) error flags or handshaking signals to generate interrupts. (A Vectored Interrupt Module is also required for this mode

of operation.)

Addressing of the module is selectable to any of 64 address segments within the range of 256 I/O addresses.

F. Peripherals



Peripherals

Processor Technology has selected a number of quality peripheral devices from other manufacturers to help you put complete systems together for many different applications. All these devices are only available factory assembled and tested.

TV-Monitor

Here's an 11" diagonal completely solid state black and white television specially modified for use with the Sol or VDM-1 units. A switch allows use as either a standard UHF/VHF television or as a video monitor. These units provide extremely crisp and stable displays and are fully grounded for safety. Manufactured by Panasonic.

High Speed Paper Tape Reader

All programs produced on paper tape for the 8080 may be loaded into Sol at up to 1000 characters/second with this handy low cost paper tape reader. The OP-80 is completely solid state and has no moving parts. The unit comes with a cable for plugging directly into the Sol Parallel Data Interface connector. Made by Oliver Audio Electronics.

PROM Programmer

The Bytesaver™ PROM programmer gives you two powerful features:

1) fast easy programming of 2708 Erasable Programmable Read-Only Memories (EPROMS).

2) Sol-bus compatible non-volatile storage of up to 8192 bytes of program.

The Bytesaver can be used to permanently store programs for use on custom application Sol personality modules or for expanded permanent storage.

Use the Bytesaver in any application where your special programs need to be permanently stored yet instantly accessed by the computer. Complete driving software included at no extra cost. Manufactured by Cromemco.

Multi-channel Analog Interface

The D+7AI/O™ module is the low cost efficient way to interface the Sol System's digital computer with the analog world. Use this module when joysticks, instruments and amplifiers, voltage and temperature sensors or any other analog device needs to be controlled or monitored by the Sol Computer.

Provided are:

- 7 multiplexed analog input channels for Analog to Digital conversion with 8 bit resolution and 5.5 microsecond conversion time.
- 7 Digital to Analog output channels with 8 bit resolution.
- 8 bit parallel interface post for digital control applications.
- +2.56 to -2.54 VDC input and output signal range (20mV monotonic increments).

The D+7AI/O is software compatible with the ALS-8 development system and PT8K BASIC language. Manufactured by Cromemco.

JS-1 Joystick

The Joystick is the fastest data entry method for interactive prompted programs and games. The JS-1 has both two axis analog outputs and four on-off switches. Requires D+7AI/O module. Manufactured by Cromemco.

See Sol now at your nearby dealer

ALABAMA

(P. Computerland 1550 Montgomery Hwy Birmingham, AL 35226 (205) 979-0707

ARIZONA

Byte Shop Tempe 813 N. Scottsdale Rd. Tempe. AZ 85281 (602) 894-1129

Byte Shop Phoenix 12654 N. 28th Dr. Phoenix, AZ 85029 (602) 942-7300

Byte Shop Tucson 2612 E. Broadway Tucson, AZ 85716 (602) 327-4579

CALIFORNIA

The Byte Shop 1514 University Ave. Berkeley, CA 94703 (415) 845-6366

Byte Shop Computer Store 6041 Greenback Lane Citrus Heights, CA 95610 (916) 961-2983

Computer Center 1913 Harbor Blvd. Costa Mesa. CA 92627 (714) 646-0221

Data Consultants, Inc. 2350 W. Shaw, Suite 114 Fresno. CA 93711 209) 431-6461

3its N Bytes 679 S. State College Blvd. Fullerton. CA 92631 (714) 879-8386

The Byte Shop 16508 Hawthorne Blvd. Lawndale. CA 90260 (213) 371-2421

The Byte Shop 1063 El Camino Real Mountain View. CA 94040 (415) 969-5464

Digital Deli 80 W. El Camino Real Mountain View, CA 94040 (415) 961-2828

The Computer Mart 624 West Katella #10 Orange, CA 92667 (714) 633-1222

The Byte Shop 2227 El Camino Real Palo Alto, CA 94306 (415) 327-8080

Byte Shop 496 South Lake Ave. Pasadena, CA 91101 (213) 684-3311

The Computer Store of San Francisco 1093 Mission Street San Francisco. CA 94103 (415) 431-0640 Byte Shop 321 Pacific Ave. San Francisco, CA 94111 (415) 421-8686

The Byte Shop 2626 Union Avenue San Jose, CA 95124 (408) 377-4685

The Computer Room 124H Blossom Hill Rd. San Jose, CA 95123 (408) 226-8383

The Byte Shop 509 Francisco Blvd. San Rafael, CA 94901 (415) 457-9311

The Byte Shop 3400 El Camino Real Santa Clara. CA 95051 (408) 249-4221

Recreational Computer Centers 1324 South Mary Ave. Sunnyvale, CA 94087 (408) 735-7480

Byte Shop of Tarzana 18424 Ventura Blvd. Tarzana, CA 91356 (213) 343-3919

The Byte Shop 2989 North Main St. Walnut Creek, CA 94596 (415) 933-6252

Byte Shop 14300 Beach Blvd. Westminster, CA 92683 (714) 894-9131

COLORADO

Byte Shop 2040 30th St. Boulder. CO 80301 (303) 449-6233

FLORIDA

Sunny Computer Stores University Shopping Center 1238A S. Dixie Hwy. Coral Gables. FL 33146 (305) 661-6042

Delta Electronics 2000 U.S. Hwy. 441 East Leesburg. FL 32748 (904) 357-4244

Byte Shop of Miami 7825 Bird Road Miami, FL 33155 (303) 264-2983

Microcomputer Systems Inc. 144 So. Dale Mabry Hwy. Tampa, FL 33609 (813) 879-4301

GEORGIA

Atlanta Computer Mart 5091-B Buford Hwy. Atlanta, GA 30340 (404) 455-0647

ILLINOIS

The Numbers Racket 623½ South Wright St. Champaign, IL 61820 (217) 352-5435

itty bitty machine co. 1316 Chicago Ave. Evanston, IL 60201 (312) 328-6800

Reeves Communications 1550 W. Court St. Kankakee, IL 60901 (815) 937-4516

itty bitty machine co. 42 West Roosevelt Lombard, IL 60148 (312) 620-5808

INDIANA

The Data Domain 406 So. College Ave. Bloomington, IN 47401 (812) 334-3607

The Byte Shop 5947 East 82nd St. Indianapolis. IN 46250 (317) 842-2983

The Data Domain 7027 N. Michigan Rd. Indianapolis. IN 46268 (317) 251-3139

The Data Domain 219 West Columbia West Lafayette. IN 47905 (317) 743-3951

KENTUCKY

The Data Domain 3028 Hunsinger Lane Louisville, KY 40220 (502) 456-5242

MICHIGAN

The Computer Store of Ann Arbor 310 East Washington Ann Arbor, MI 48104 (313) 995-7616

Computer Mart or Royal Oak 1800 W. 14 Mile Rd. Royal Oak, MI 48073 (313) 576-0900

Genral Computer Store 2011 Livernois Troy, MI 48084 (313) 362-0022

NEW JERSEY

Hoboken Computer Works No. 20 Hudson Place Hoboken, NJ 07030 (201) 420-1644

The Computer Mart of New Jersey 501 Route 27 Iselin, NJ 08830 (201) 283-0600

NEW YORK

The Computer Mart of Long Island 2072 Front Street East Meadow, L.I., NY 11554 (516) 794-0510

Synchro Sound Enterprises 193-25 Jamaica Ave. Hollis, NY 11423 (212) 359-1489

The Computer Shoppe 444 Middle Country Rd. Middle Island, NY 11953 (516) 732-3086

Audio Design Electronics 487 Broadway, Ste. 512 New York, NY 10013 (212) 226-2038

The Computer Mart of New York 118 Madison Ave. New York, NY 10001 (212) 686-7923

The Computer Corner 200 Hamilton Ave. White Plains, NY 10601 (914) 949-3282

OHIO

Cybershop 1451 S. Hamilton Rd. Columbus. OH 43227 (614) 239-8081

OKLAHOMA

High Technology 1020 West Wilshire Blvd. Oklahoma City, OK 73116 (405) 842-2021

OREGON

Byte Shop Computer Store 3482 S.W. Cedar Hills Blvd. Beaverton, OR 97005 (503) 644-2686

The Real Oregon Computer Co. 205 West 10th Ave. Eugene, OR 97401 (503) 484-1040

Byte Shop Computer Store 2033 S.W. 4th Ave. Portland. OR 97201 (503) 223-3496

RHODE ISLAND

Computer Power. Inc. M24 Airport Mall 1800 Post Rd. Warwick, RI 02886 (401) 738-4477

SOUTH CAROLINA

Byte Shop 2018 Green Street Columbia, SC 29205 (803) 771-7824

TENNESSEE

Microproducts & Systems 2307 E. Center St. Kingsport, TN 37664 (615) 245-8081

TEXAS

Byte Shop 3211 Fondren Houston, TX 77063 (713) 977-0664

Computertex 2300 Richmond Ave. Houston, TX 77098 (713) 526-3456

Interactive Computers 7646¹ ² Dashwood Rd. Houston, TX 77036 (713) 772-5257

The Micro Store 634 So. Central Expressway Richardson, TX 75080 (214) 231-1096

VIRGINIA

The Computer Systems Store 1984 Chain Bridge Rd. McLean, VA 22101 (301) 460-3634

Media Reactions Inc. 11303 South Shore Dr. Reston, VA 22090 (703) 471-9330

WASHINGTON

Byte Shop Computer Store 14701 N.E. 20th Ave. Bellevue, WA 98007 (206) 746-0651

The Retail Computer Store 410 N.E.72nd Seattle, WA 98115 (206) 524-4101

WISCONSIN

The Milwaukee Computer Store 6916 W. North Ave. Milwaukee, WI 53213 (414) 259-9140

CANADA

Trintronics 160 Elgin St. Place Bell Canada Ottawa, Ontario K2P 2C4 (613) 236-7767

First Canadian Computer Store, Ltd. 44 Eglinton Ave. West Toronto. Ontario M4R 1A1 (416) 482-8080

The Computer Place 186 Queen St. West Toronto, Ontario M5V 1Z1 (416) 598-0262

Pacific Computer Store 4509-11 Rupert St. Vancouver, B.C. V5R 2J4 (604) 438-3282 All components sold by PROCESSOR TECHNOLOGY CORPORATION are purchased through normal factory distribution and any part which fails because of defects in workmanship or material will be replaced at no charge for a period of 3 months for kits, and one year for assembled modules, following the date of purchase. The defective part must be returned postpaid to PROCESSOR TECHNOLOGY CORPORATION within the warranty period.

Any malfunctioning module, purchased as a kit and returned to PROCESSOR TECHNOLOGY within the warranty 3 month period, which in the judgement of PTCO has been assembled with care and not subjected to electrical or mechanical abuse, will be restored to proper operating condition and returned, regardless of cause of malfunction, with a minimal charge to cover postage and handling.

Any modules purchased as a kit and returned to PTCO which in the judgement of PTCO are not covered by the above conditions will be repaired and returned at a cost commensurate with the work required. In no case will this charge exceed \$20.00 without prior notification and approval of the owner.

Any modules, purchased as assembled units are guaranteed to meet specifications in effect at the time of manufacture for a period of at least one year following purchase. These modules are additionally guaranteed against defects in materials or workmanship for the same one year period. All warranted factory assembled units returned to PTCO postpaid will be repaired and returned without charge.

CONDITIONS and EXCLUSIONS

This warranty is made in lieu of all other warranties expressed or implied and is limited in any case to the repair or replacement of the module involved.

The warranty herein extends only to the original purchaser-user and is not assignable or transferrable.

Processor Technology Corporation is under no obligation to extend this warranty to any product for which a Warranty Registration Card has not been completed and mailed to Processor Technology Corporation within fifteen (15) days after date of delivery.



6200 Hollis Street Emeryville, CA 94608 415/652-8080



Lily Hou

"I designed the Sol!"

These words are made to be spoken from a pinnacle of technical authority, preferably by a gimlet-eyed Herr Doktor who pursues exact solutions to the nineteenth decimal place and who reigns over a limitless sea of subordinates slaving away over rows of drafting boards.

Or they could come from a furry little gopherlike creature with a piece of string for a belt who sleeps all day and occasionally surfaces to deposit a few dog-eared pages of scrawled diagrams with his custodians.

Since I fit neither of these descriptions, I hesitate to make that claim (except as part of a put-down), for it is only partly true. Besides, as I look over the reasons for making certain design decisions along the way, I am struck by the fact that most of those reasons had little to do with the ultimate advantages of the decisions.

The Sol, therefore, got designed—partly by me, partly by Bob Marsh, and partly by chance and circumstance. My description of that process is intended to instill confidence in those who feel that there are great secrets involved in the design of products and that mastery of most of the universe is a prerequisite to successful design. It is also intended as a warning to

those who think that the design process is deterministic and uncomplicated.

WHAT IS THIS THING CALLED SOL?

For the benefit of future historians, I shall state that the Sol is a singleboard computer built around the 8080 microprocessor and the S-100 bus structure. It incorporates an integral video alphanumeric display circuit, serial and parallel interfaces, and random-access and read-only memory on the board along with an audio cassette tape interface. A keyboard plugs into a connector on the board, and a video signal comes off through a coaxial cable. Regulated DC power is supplied to the board through another push-on connector, and that's all that is needed to make it compute.

Sol's main feature is a 100-pin edge connector that provides all the signals of the S-100 bus to any number of memory, I/O, or other peripheral cards available from different sources. An important secondary feature is the "personality module," a tiny (3-by-1½-inch) printed circuit card on which sits the ROM. The personality module plugs into a small edge connector on the Sol board. By this means the personality of the Sol can easily be

changed without technical skill. Also, all the serial, parallel, and audio connectors are mounted along one edge of the card, requiring no external harness or connector assembly.

The Sol-10 and the Sol-20 both put this card, along with a power supply, into a metal chassis with walnut sides and a typewriter-style keyboard. The Sol-20 has a five-slot "daughter board" that plugs into the 100-pin edge connector and itself provides five more similar connectors, so that cards of the S-100 type can be plugged in within the cabinet. It has additional power supply capacity to feed these extra cards.

BEFORE THE BEGINNING

In 1974 I was helping to run a public-access "computerized bulletin board" system (called Community Memory), which was essentially a labor of love for me and several other people. It had two terminals in public where people could come in off the street and enter information items as well as search for them. Since the terminals were unattended, hardware reliability was an obvious problem, especially when we postulated much larger systems.

My way out of this future problem

was to design an all-purpose "convivial vbernetic device" as a terminal/conntrator/processor—in such a way that amateurs would be encouraged to get their hands on it. In theory, each place where one of these "Tom Swift Terminals" was installed would develop a computer club. Then, when a terminal broke down, relief would be a local matter, and people would not have to place their trust in a remote maintenance structure.

It was by placing a notice about this conceptual design on the system and inviting respondents to form a discussion group that I met Bob Marsh for the second time. (The first had been during our college days when we lived in the same co-op residence hall at Berkeley. We did not share many interests then.)

Now, however, Bob had raised himself to the state of an unemployed electronics engineer (self-taught) who had nearly won an encounter with a glorified version of Don Lancaster's TV Typewriter that he had built, improved, and fixed from scratch. After a while Bob suggested that I go in with him on the rental of a workshop. I .greed, and we signed a three-year lease on a garage in industrial Berkeley, commencing from January of 1975. I moved my workshop out of my living room, and Bob took up residence in the upstairs office, trying to find a product to manufacture. A plan to produce a limited-edition digital clock with a fancy wood case never materialized, which was a disappointment both for Bob and for Steve, a friend of his who did woodworking (we shall hear more of this later). Bob spent much time investigating the possibilities for a logic analyzer similar to others then available, doing much design before he gave it up as impractical.

In March 1975 I took Bob to the second meeting of the Homebrew Computer Club, where about twenty-five people stood around the first Altair 8800 to reach the area and watched it blink its front panel lights. That was all it could do, since it had no I/O circuitry and only 256 bytes of memory. There was a lot of empty space inside that cabinet.

Processor Technology was founded as a partnership in April of that year (I was not one of the partners) and began designing ROM, RAM, and I/O cards for the Altair. Incorporation followed in July, and I began to get bits and pieces of work—redrawing schematics, writing preliminary manuals, and other minor chores.

In July Bob finally got to me. He had a proposition: he would pay me to design the video display section of the Tom Swift Terminal. In October the VDM-1 video display module first saw Revision A. The Tom Swift Terminal never did get designed exactly as I dreamed it. But, as the hordes of amateur computer enthusiasts swarmed out of the woodwork, its purpose was being fulfilled.

THE SOL SOLUTION

I like to say that, in the process leading to the birth of the Sol, Leslie Solomon, technical editor of *Popular Electronics* magazine, performed the act equivalent to that of the male. I still don't know who solicited whom, but Les agreed to carry a construction article on "an intelligent terminal" on the cover if a working model could be supplied in thirty days. This proposal was made in the middle of November 1975. I was summoned to Bob's office.

Bob tactfully asked me if I thought such a project was impossible. I reluctantly admitted that I did not but strongly suggested that an unintelligent terminal be designed, mainly because I wanted badly to exercise the features designed into the VDM-1 for such an eventuality. Besides, I had already turned down an offer from Bob to design an 8080 CPU board for Processor Technology.

Alternate designs were roughed out and prices compared. Both were for terminals using the basic circuitry of the VDM-1. His had an 8080 thrown in, mine had decoders and counters. Mine was cheaper, but only by about ten dollars. Gradually I came to realize that if the inevitable were to happen, it would be better to be on the inside than on the outside. After a day or two of discussions, I agreed to contract to do the design. I pulled out of a volunteer project on the grounds that "the roof was about to fall in again." And somewhere in the midst of all this I looked up at Bob and said: "Let's advertise it as having 'the wisdom of Solomon." From the comment came the name Sol, which is meant to be written in biblical-movie-poster letters chiseled out of stone. Les will never live it down.

ROMEUTORIAL ROMEUTORIAL

Single Board Computer: Electronic devices are built nowadays on "printed circuit cards" of fiberglass with patterns of copper foil instead of wires. In the old days, ten years ago, computers had hundreds of these boards, each containing a tiny portion of their electronics. Now things have shrunk so much that an entire computer can fit on one printed circuit board.

Microprocessor: the "thinking" section of a computer is called the central processing unit (CPU) or just the processor. If it's so small that you need a microscope to examine it, it's called a microprocessor.

S-100 bus structure: a bus is a wire connected to many places. Usually it's used to carry electricity for power, but, in a computer, very fast, low-power electrical impulses are sent between sections on buses. Since there are a lot of these signals happening at once, computer buses have a lot of wires in them. The S-100 is a 100-wire bus used by many personal computers. Because they all have the same pattern of four interconnections, the plug-in board from one will work (usually) when plugged into another S-100 machine. The S means standard.

Integral video alphanumeric display circuit: electronic circuitry which produces a signal that can be connected to a TV set and that causes the set to display letters and numbers on the screen. It is integral because it is built into the computer.

Romtutorial Romtutorial

Scrial and parallel interfaces:

An interface is the dividing line between two electronic devices. A wire or cable usually goes across an interface carrying electrically coded information. If the cable carries several different signals at once, it's a parallel interface. If the information moves in a sequence through a single wire the interface is serial.

Random access Memory: memory like a set of pigeon holes, into any of which the computer can put new information or from any of which it can read old information. The computer can choose any pigeon-hole (or address) at any time.

Read Only Memory: memory like a telephone directory which can only be read by the computer and not written in. It's used to hold instructions for the computer (the program).

Push-on Connector: a set of metal posts wired or soldered to electrical circuitry. A set of spring clips held in a plastic block can be pushed down onto these posts in order to make an electrical connection to a cable.

Edge Connector: a socket built as a long thin slot in a plastic block. A number of spring fingers are held in the block. If a printed circuit-board edge is pushed into the slot the spring fingers will "wipe" against both sides of the board and make contact with the copper foil patterns.

I/O: Input/Output. The electrical channels through which the computer moves information to and from the outside world.



"Who, me?" Leslie Solomon, Technical Editor of Popular Electronics, looks startled as the first Sol speaks its words of wisdom.

In the process leading to the birth of the Sol, Leslie Solomon performed the act of the male. I still don't know who solicited whom.

Bob had already developed an architecture for the device. It involved taking the on-card memory and I/O devices, disconnecting the S-100 "DI" data input bus, and creating a separate low-drive "internal bus" that would get data to the CPU through a four-way data selector or multiplexer. One input of this would be the regular S-100 DI bus, another the internal bus, and the other two would be used for keyboard and parallel data inputs. The reasoning behind this was to minimize the need for high-power tristate drivers on the card and to allow the low-power tristate output features of the RAMs, ROMs, and UARTs to serve their intended functions.

I should explain here that designing for Bob Marsh can be somewhat of a trial. At least at that time, when he had little else with which to concern himself, he was continually turning up with new features and economies that he suddenly wanted incorporated in the design. He would explain the problem or opportunity and then

preface his technical solution with an inevitable "All's ya got to do is...."
This would be forgivable if he were not so often right and possessed of a truly useful and valuable idea. Were the designer a prima donna, the relationship would terminate after the second such incident, with the designer fuming about "professionalism" and "interference." Of course, since my workshop was in the same room as his, I could not have gotten very far if I had wanted to stamp out in a rage. The situation did, however, call heavily on my sense of futility, absurdity, and ultimate irrelevance.

A few days after I started on Sol, Bob had another idea. He wanted all clocks on the card derived from a single crystal. The VDM-1 had been using a 13.4784-Mhz crystal, and Bob had been doing some division problems with his calculator. It seemed to him that not one but three relevant clock speeds could be extracted from this frequency, allowing operation with 2.5-Mhz and 3-Mhz 8080 chips if

desired. I protested, but without rounds, and very soon gave in and esigned a simple clock generator which allowed (through a variable-modulo flip-tail ring counter, if you must know) the kind of clocks Bob wanted.

bly MITS's) boards did not use the DBIN signal and were therefore useless with Sol, unless modified, is still a source of defensiveness in discussions of the design. I take the position that Bob made me do it, and he takes the position that history will absolve him.

Bob tactfully asked me if I thought the project was impossible.

After a decent interval Bob informed me that he would like to increase the crystal frequency to 14.31818, which would be necessary if color video peripherals were to operate with it. Please to redesign all relevant circuits accordingly. I fumed and grumbled but found a way out eventually. After all, the clock frequency to the 8080 would be of a 488-nanosecond period, a whole 1.8 percent shy of the spec sheet minimum! Why worry?

The biggest upset actually had the flimsiest reason. Bob wanted to be able pextend the S-100 bus of the Sol to an aternal cabinet through a flat ribbonstyle cable, which came in 50-conductor maximum widths. With my avid agreement, Bob wanted to ensure that there were plenty of ground return lines sprinkled through this cable—a practice that had been neglected on the Altair and that probably caused many of the noise problems associated with it. To do this would require more than 100 wires.

Bob and I did some figuring while driving down to a Homebrew Club meeting, and he reached the conclusion that it would be permissible to take the DI and DO buses and connect them in parallel, making one single DIO bus. We assumed that every manufacturer who was anybody was doing the same as Processor Technology, using the DBIN signal from the 8080 as an enabling signal for data to the DI bus. DBIN could therefore be used at the Sol as a "direction signal" for the DIO bus and data could be sent both ways on one set of wires. Think of 'I the cable you'd save!

As it turned out, those eight extra traces saved on the Sol board nearly made the difference between a buildable board and an impossible one. The fact that some manufacturers' (nota-

As the design progressed, we realized that we were building a general-purpose computer rather than just "an intelligent terminal," but the decision was made to soft-pedal the fact until the last possible moment. Once published, all the fuss possible was to be made about its general-purpose nature; but until it actually saw print, it was to be treated first as a terminal.

To jump ahead a bit, when I finally delivered the working prototype to Les Solomon's desk and pointed out its salient features, his eyebrows began twitching. Why couldn't he, he wanted to know, plug in a ROM board with BASIC burned in (as he could do with a Bytesaver) and run stand-alone? I smiled my blandest smile and muttered, "Beats me."

THE BIG PUSH

Originally I had been given to believe that I would be required by the terms of the contract only to provide a schematic diagram and to help interpret it for the benefit of the layout artist. When it came time to start lay-



Lee Felsenstein after the deed.

ROMTUTORIALROMTUTORIAL

Multiplexer: an electronic circuit which can choose one of several inputs and route the signals at that input to its output.

Internal Bus: Eight bus-type wires which are connected to most of the devices on the Sol which feed information to the processor. The information moves in eight-bit units (bytes), one wire for each bit.

Tri-State Drivers: electronic circuits used for feeding signals to a bus. They can either force the bus wire to a high voltage or a low voltage, or they can let the bus "float" at whatever voltage other drivers decree.

Variable-modulo flip-tail ring counter: an electronic worm continually chasing its tail. The worm's back is black and its belly is white. Each time around, it makes a half twist. A line of ants does close-order drill using the color of the worm as a cadence (clock signal). Since worms travel at a steady rate, the cadence can be changed by changing the length of the worm (variable-modulo).

DI Bus: Eight bus-type wires which carry electrical data signals from S-100 boards into the processor. Short for Data Input Bus.

DO Bus: Data Output Bus. Same as DI Bus, except that the electrical signals are carried out of the processor board to all of the S-100 boards.

DBIN Signal: Data Bus In. A timing signal which the microprocessor uses to tell anyone who cares that it can accept electrical data (one byte only) going in.

ing tape, I discovered that I was expected to pitch in with a will and help stick down the many miles of crepe tape that would be required to produce the printed circuit artwork. Time was of the essence, as I agreed, and the layout artist who had been engaged was somewhat out of his depth with a 110-package layout to be done at four-to-one enlargement. Besides, he apparently didn't believe in making

with needle-point X-acto knives, which we constantly had to hand, were the main hazards of working there.

In addition, there was the chill at night and the heat that accumulated during the day. People downstairs never had the same opinion about a comfortable temperature as we did. We soon settled into an insane schedule of fourteen- to seventeen-hour days, seven days a week. I kept going

tor lay in the other guy's area of concern. He had to cross over about seventy-five traces in order to flip the connector, and he did not succeed. Some traces were brought out to deadend pads with no hole through them, leaving some of the pins to be connected by tack-soldered jumper wires later during assembly.

I should point out that this printed circuit board was the prototype; no wire-wrap or other version had been made. Only two boards were ultimately produced (by a specialty shop run by a work addict), and one of them sits on my window ledge at home to remind me of how rough things can become. Besides, I like to point out my half of the layout and how obviously superior was my technique compared

with the other half.

The other board I loaded with parts, tack-soldered with almost a hundred jumper wires out of sight on

the rear side where traces were incomplete due to the hasty layout, checked out, and presented to the software people to see what they could do. I have no recollection whether that was

before or after Christmas of that year; I think it was before.

The crowning moment came when Bob changed his mind for the last time.

preliminary pencil sketches to test possible routings.

Steve the woodworker had built a large light table to Bob's specifications, and this was set up in the only available space in the now crowded garage – a loft above some offices that Processor had installed. I personally made sure that an electrical conduit running at forehead level was padded and tried to get someone to put up a fence to prevent one of us from stepping backwards off the edge of the loft. That, the knocking of heads against rafters, and the sticking or scratching of various parts of the head


on orange juice, the younger layout man used Coke. He succumbed at the very end and I had to finish up alone. The task took almost three weeks of standing up looking down into a fluorescent-lit white background on which crawled worm tracks of black tape.

The crowning moment came when Bob changed his mind for the last time about which side he wanted the 100-pin connector to emerge from (this was determined by whether the S-100 boards were to mount above or below the Sol board). Layout had already started, and fortunately that connec-

IN THE BAG

Bob had laid out the basic outlines of the cabinet and had patched together a power supply and a sample keyboard. One of his design criteria from the absolute beginning was that the cabinet have walnut sides of a certain height or less. Steve had told him of a great bargain to be had from center-cut pieces of walnut, which were ordinarily almost thrown away. There is some cause to believe that the primary reason for the existence of the Sol was to provide an outlet for this inexpensive wood. At any rate, Steve is now in the wilds of Wisconsin running a mill to make walnut Sol sides.

As the project proceeded, Bob was undecided as to whether a cassette interface or drive would be included in the production version. As photographic deadlines approached, he decided to put a dummy cassette drive in the cabinet. This was to symbolize the fact that cassette tape would ultimately be available in one way or another—how he did not know. The text of the article, when it appeared, mentioned nothing about it, and the mysterious tape deck has proved to be



Bob Marsh with the Sol up and running. All's well that ends well—though in this case it seems to be only the beginning for Processor Technology.

Carrying the Sol shrouded in two paper bags, we embarked for the big-time world of New York.

the biggest single source of questions from the readership of that article.

The printed circuit board was ready forty-five days after the start of the project. About sixty days from the goahead, the cabinetry, power supply, and software were coming down the home stretch. Bob scheduled a night flight to New York, to save money, and informed me that I was coming; everybody went into a final homestretch panic lasting the better part of twenty-four hours.

We made the helicopter only because my watch was fast. Bob forgot to bring his tickets to the heliport and broke numerous traffic laws going back to get them. Carrying the Sol shrouded in two paper bags, we embarked for the big-time world of New York.

Of course we got no sleep on the plane and arrived an hour too early for our purposes. We went directly to Les Solomon's home and shared breakfast with him, discovered that the Sol wouldn't work (you could see it trying behind a veil of "snow"), then took the train to Les's offices on Park Avenue. where we met the boss and everyone else. Leaving behind a trail of excuses, we emplaned for Boston, where the folks from Byte magazine took us to dinner and drove us up to Peterborough, New Hampshire to see the snow. I conked out on this last trip, after attempting to stay awake by gorging myself at every available opportunity. I fear that I made a poor impression by so doing.

Back at the workbench a day or so later, I traced the trouble to a tiny speck of wire obviously loosed from the shield braid of the coaxial cable as it was stripped. This crumb had been captured underneath a socket, where it had plainly stayed during all the checkout without causing mischief. In transit it had shifted to the worst possible position—shorting two obscure but critical traces together. Murphy's Law confirmed!

After that it was bundle up again, this time myself alone—but carrying my oscilloscope and tool kit as well as

the Sol. An hour or two of demonstration in the offices of *Popular Electronics* convinced them that Sol would indeed work. Then it was back home directly, where I passed "Go" and collected the balance of my lump payment.

DEBUT

A great deal of work remained to be done after the prototype Sol was finished. Bob wasn't through with suggesting new things and better ways—I suspect he never will be. One major change in the design bears pointing out, though.

The personality module, which owes its name to Don Lancaster, came about as a result of unpredictable EPROM supplies. Some way had to be found to plug in three different EPROMs without taking up extra area. The first suggestion was for a "piggyback" card with upright pins that plugged onto a row of socket connectors on the board. I take credit for extending this idea to one of a miniature printed-circuit plug-in card with a row of edge-connector "fingers" that would mate with a right-angle PC connector and be guided by rails so it could be changed from outside the cabinet. This leads to fantasies of employees swapping in game personality modules during lunch time and returning to the business modules when the whistle blows.

Almost everything except the circuit was redesigned between prototype and production, and even the circuit was the object of much straightening out of wrinkles. The printed-circuit board was totally re-laid out, and the layout was digitized for computerized photoplotting. More expediting, twenty-four-hour days, and dead runs from plane to plane.

In late August the Sol, in its production form, had its debut at the Atlantic City Personal Computing Show. I understand the cocktail party was splendid. Personally, I spent the time trying to trace down a bug that I was later told was in software.

ROMEUTOFIAL ROMEUTOFIAL

BASIC: A computer program which allows anyone to use the computer and get instantaneous feedback as to whether they are doing OK or making a mistake.

Bytesaver. An S-100 plug-in board which can write information supplied by the processor into special read-only memory chips. Once written, the information cannot be erased by the computer but it can be read. A trademark of Cromemco.

EPROM: Erasable Programmable Read-Only Memory. Used on things like the Bytesaver. A chip which will hold information indefinitely after being written, but which will forget the information if exposed to ultraviolet light (the cover of the chip is clear quartz).

Right-angle PC Connector: A printed circuit edge-connector with pins bent 90 degrees so that once it's soldered down to its own board the slot is parallel to the board. Now a printed circuit card pushed into the slot will be parallel to the "mother board" rather than perpendicular.

The Sol-20 Computer Terminal

By Rudolf Hirschmann

Rudy Hirschmann has written a review of the Sol computer. Rudy is a professor of German at the University of Southern California, where he is using microcomputer based systems for typesetting and for teaching.

The Sol-20 terminal computer from Processor Technology certainly makes a good first impression. It has the general appearance, shape and size of an electric typewriter with a full keyboard, attractive blue metal case and genuine walnut end plates. These would make it seem more at home in a modern office somewhere downtown rather than in my less elegant computer shack at home.

But beneath that sleek exterior lurks a genuine microcomputer that is capable of doing most everything that a state-of-the-art microcomputer ought to do. A fully operational Sol-20 consists of five circuit boards, namely the main circuit board, the plug-in personality board, the keyboard, the bus extender board and the power supply. I will discuss each of these in turn.

The main circuit board is by far the largest and most complex of the subassemblies for this computer. It combines the functions of several conventional S-100 plug-in boards, namely that of an 8080-based CPU board and a video display generator for sixteen lines of 64 characters each. In addition, it also provides a very useful combination of functions that are normally available only on several additional boards, namely one serial and one parallel I/O port, a reliable cassette I/O port that uses the "Kansas City/Byte" standard at

either 30 or 120 characters per second, a modest amount of RAM and address decoding as well as a connector for up to 2K bytes of ROM. This ROM is actually held on a small board that plugs into the main board. A power-on-jump is also provided to this ROM, and for that reason this board is known as the personality module. More on that below.

The layout of the main board seems to be straightforward, logical and well executed. All features of this board worked as they are supposed to, although three errors in trace routing had to be corrected. This problem should be solved in boards marked Rev. E and beyond. The physical quality of this and the other boards is first rate. All traces and plated-through holes conducted properly, and a solder mask and parts labeling are provided.

Four sets of DIP switches are included on this board to allow easy selection of certain options. One switch allows changing the characteristics of the video display (which is virtually identical to Processor Technology's VDM-1), another selects the baud rate, while the third changes the word format for the serial I/O port. The final DIP switch is a thoughtful concession to those of us who have grown accustomed to a front panel, namely a set of eight sense switches connected as input port 255. While the location of these switches is a bit awkward (the cover has to be removed to get at them). it is nevertheless possible to run programs that depend upon the use of the front panel sense switches of an Altair or IMSAI system. It should be noted that the single step and the memory protect/unprotect functions are not provided for. This means that your memory boards must always go to the unprotect mode when power is turned on and then stay there. An easy modification circuit for this purpose appeared in SCCS Interface vol. 1, no. 4 (March, 1976). page 43, that will take care of any problems in this regard.

In order for you to assess other potential hardware/software incompatabilities with your present system. let me give you the port and memory locations implemented on the main board. Port F8 functions as a control and status port for serial I/O, F9 is the serial data channel, FA is the control and status port for parallel, cassette and keyboard I/O, FB is the cassette data port, FC is keyboard data, FD is parallel data, FE is status and control for the video display and FF is sense switch input. So far as memory allocation is concerned, personality ROM is from C000 to CFFF, system RAM is C800 to CBFF, and video display RAM is CC00 to CFFF.

Turning now to the personality plug-in module, this is available in several different implementations. As a CONSOL module it consists of a small plug-in board with two 5204 PROMs and space remaining for two more. In other words, 1K of firmware is implemented and space for an equal amount is left empty. As a SOLOS module, this same board is supplied with four 5204s. Presumably the SOLED will be supplied in the same form when it becomes available. Plug-in modules using other PROMs, such as the 2708, are also supposed to be in the works. That way all of us Bytesaver owners can implement our own firmware.

I had a chance to work with one CONSOL and two different SOLOS modules. Each of them has drivers for all I/O ports and the video display system as well as some very useful file handling firmware for the cassette I/O channel. When you record a section of memory onto tape, you must specify a starting address, a length and a name: you also have the option of specifying an execution address. All of this information is automatically stored as a header on the tape before the specified block of memory is stored. The beauty of this system becomes apparent when retrieving stuff from tape, because, although you could specify everything manually, you can

also simply specify the name mentioned above, and the firmware will then ignore all data on the tape until it encounters the same name in a header. It then transfers the block to the address that is also specified in the header. This may not be as convenient as a floppy disk, but it is a big step upward from systems that have no firmware support.

The keyboard is custom designed for the Sol terminal and is made up of high quality parts throughout. The keys feel solid and durable, and a good selection of special-function keys is included. The keys of the numeric pad (not included in all models of the SOL) are not simply connected in parallel with the corresponding keys on the main section of the keyboard. Instead, they are encoded separately, and the output code of the numeric pad has the eighth bit turned on, even though this bit is not used in the ASCII standard. It is easy enough to ignore this bit for most applications, but in special situations, that extra bit can be used to implement special control functions via the numeric pad. An application I am presently working on will have these keys control a set of cursors in a fairly complicated text editor.

A little quirk of this keyboard is that the key used for the backspace function does not generate the standard ASCII backspace code. This may not become a problem until you try to interface existing software with this system, but even then the solution will be straightforward. The time I found this anomaly disturbing was when I used the Sol as a remote terminal connected to a large computer over the telephone lines. In this situation it is necessary to transmit a control-H in order to have the large computer understand. This, however, shows up as a displayed character on the screen instead of an actual backspace. Moreover, the character that is used as a backspace in the terminal is blocked in firmware from being transmitted. In short, there is no way of implementing a

satisfactory backspace in this situation. In addition, the firmware allows most (but not all) control characters coming from the large computer to be displayed on the screen. For those who will use the Sol as a remote terminal, these may be regarded as annoying factors; but they can surely be solved in firmware. Processor Technology, are you listening?

So far I have been talking about the basic components that make up many good terminal computers. What makes the Sol particularly noteworthy, however, is the inclusion of a bus extender board that adopts the essential conventions of the S-100 bus. That means that virtually all plug-in modules available for the IMSAI and Altair 8800 computers can be used in the Sol, and this shows the great advantage to the hobbyist (and manufacturer) for adopting some sensible standards. Are the other manufacturers listening?

The bus extender board plugs vertically into the main circuit board, it has plug-in positions with card guides for five horizontally oriented boards and an additional test position on top. This board has good large traces for power distribution and is double sided with plated through holes. Why all that trouble on a simple board like this? It allows for shielding, because little fingers of grounded conductors are placed between all the other bus conductors. I couldn't test them for their actual effect, and one might question their necessity on such a small backplane. But this type of design is also being adopted by others, and it is certainly indicative of fine engineering practice and is a step in the right direction.

I have saved the power supply for the end, because this is where a tendency that was evident throughout the entire machine was evident most clearly, namely the tendency to overdesign. This power supply is gutsy and will never have to be upgraded unless you somehow double or triple the size of that bus extender card.

There are two separate +8 V

supplies, one supplying power only to the main mother board, and the other only to the bus extender board The first of these is filtered by 18,000 ufd., regulated with discrete parts and protected by a crowbar circuit! It is normally called upon to supply about 1.5 A, but I loaded it down to twice this value, and everything looked fine even after an hour. The other +8 V supply is filtered by a capacitor of 54,000 ufd., and according to my measurements it can safely supply more than 10 A and still not run very hot. That translates to over 2 A per bus-extender slot, and that is certainly adequate. The + and - 16 V lines are hefty enough to handle any reasonable load.

All of these components are put together in an attractive case. The metal is fairly heavy gauge steel throughout, and everything has a very solid feel to it. The only thing I can quibble with is that in order to get at certain components, many others must first be removed. Some additional thought on this score, such as splitting the subassembly that holds the card guides in two, would make disassembly easier.

My overall impression is that the Sol-20 is a well designed machine and that many potential problems have been solved before releasing the product, a practice that should be more widely observed. As it stands, this machine still has a few problems as mentioned above, but they seem to be small ones that can either be solved in firmware or in slight adjustments in packaging.

There are a few other machines that have characteristics similar to those of the Sol-20, but none of the other single-package terminal computers presently on the market uses the 8080 and the S-100 bus. These factors alone should make the Sol-20 an attractive machine for many. The fact that the cost is relatively modest (\$475 for the main circuit board only in kit form, \$995 for the whole machine as a kit and \$1395 assembled with the CONSOL module) should serve to add to its popularity.

SOL SYSTEM SUGGESTED RETAIL PRICE LIST (September 1, 1977)

1.	Sol Systems		Order No.	Price
	Complete systems are available from Processor Technology to fulfill the application requirements outlined on the Sol Solution Chart in our catalog These systems include all necessary connecting cables and manuals.	9.		
A.	Sol System I includes Sol-20/8 with 8192-byte memory and SOLOS module, PT-872 monitor, RQ-413A cassette recorder, and BASIC 5 tape	Assembled/Tested Kit	400100-01 400100-02	\$2129 \$1649
В.	Sol System II includes Sol-20/16 with 16,384-byte memory and SOLOS module, PT-872 monitor, RQ-413A cassette recorder, and BASIC 5 tape	Assembled/Tested Kit	400200-01 400200-02	\$2283 \$1883
C.	Sol System III includes Sol 20/16 with 32,768-byte memory and SOLOS module, Helios II Disk System with DISK BASIC, and PT-872 monitor	Assembled/Tested Kit	400300-01 400300-02	\$5450 \$4750
D.	Sol-20/8 Terminal Computer with 8KRA 8192-byte Memory Module and SOLOS Personality Module	Assembled/Tested Kit	400400-01 400400-02	\$1850 \$1350
E.	Sol-20/16 Terminal Computer with 16 KRA 16,384-byte Memory Module and SOLOS Personality module	Assembled/Tested Kit	40 0500-01 40 0500-02	\$1975 \$1550
II.	Sol Components			
A.	Sol-PC Single Board Terminal Computer with SOLOS Personality Module	Assembled/Tested Kit	101036-01 101036-02	\$745 \$575
В.	UGKPC-20 Sol cabinet, 85 key keyboard, fan, power supply and backplane expansion. Upgrades Sol-PC to Sol-20	Kit	101035	\$675
C.	Sol-KBD 85-key solid state Keyboard as used in Sol-20 series units	Assembled/Tested	104000	\$230
D.	PM 2708 Personality Module for use with 2708 EPROMs (does not include EPROMs)	Assembled/Tested Kit	107000-01 107000-03	\$40 \$30
E.	SOLOS Personality Module	Assembled/Tested Kit	107000-02 107000-04	\$90 \$75
F.	220-Volt Transformer for all Sol-20 series units. Note: All Sol-20 series units and Sol Systems are available for 220 Volt, 50 Hz operation. Contact factory for pricing and delivery information.	Kit	105034	\$50
III.	Mass Storage Systems			
	Helios II, Model 2 Disk System. Includes dual PerSci 270 floppy disk drive, cabinet, fan, S-100 bus compatible controller, power supply, system diskette with complete PTDOS software	Assembled/Tested Kit	300 000-01 300 000-02	\$2695 \$2395
IV.	Subsystem B for all S-100 Bus Mainframes other than Sol			
A.	Subsystem B70. Includes 4KRA memory, VDM-1 Video Display Module, 3P + S Parallel, Series I/O Module, CUTS Computer Users Tape System cassette interface and GPM General Purpose Memory Module	Assembled/Tested Kit	40 6000-01 40 6000-02	\$829 \$594
В.	Subsystem B110. Includes 8KRA memory, VDM-1 Video Display Module, 3P + S Parallel, Series I/O Module, CUTS Computer Users Tape System cassette interface and GPM General Purpose Memory Module	Assembled/Tested Kit	406 100-01 406 100-02	\$998 \$730
C.	Subsystem B190. Includes 16KRA memory, VDM-1 Video Display Module, 3-P + S Parallel, Series I/O Module, CUTS Computer Users Tape System cassette interface and GPM General Purpose Memory Module	Assembled/Tested Kit	4062 00-01 4062 00-02	\$1095 \$895

V.	S-100 Bus Compatible Modules		Order No.	Price
	Memory			
A.	GPM General Purpose Memory Module with 1024-byte Read/Write memory and 2048-byte CUTER program on ROM	Assembled/Tested Kit		\$169 \$129
В.	GPM-Sol. Same as GPM without Read/Write or ROM memory. These memories are included with the Sol.	Assembled/Tested Kit	210000-03 210000-04	\$119 \$89
C.	ALS-8 ROM Resident Assembly Language Operating System with Interpretive Simulator (SIM-1) and Text Editor (TXT-2). For use with GPM or GPM-Sol. If purchased together, price includes assembly and testing. (ALS-8, SIM-1 and TXT-2 programs are copyrighted.)	Assembled/Tested or Kit	900014	\$190
D.	2 KRO Erasable Programmable Read Only Memory Module	Assembled/Tested Kit	204000-01 204000-02	\$89 \$65
E.	4KRA 4096-byte Static Read/Write Memory Module	Assembled/Tested Kit	201000-01 201000-02	\$150 \$125
F.	8KRA 8192-word Static Read/Write Memory Module	Assembled/Tested Kit	202000-01 202000-02	\$250 \$225
G.	16KRA 16,384-word Dynamic Read/Write Memory Module Semikit—assembled & insp	Assembled/Tested ected but not tested		\$399 \$369
	Interface Modules			
Н.	3P + S Parallel Serial I/O Module	Assembled/Tested Kit	209000-01 209000-02	\$199 \$149
1.	CUTS Computer Users Tape System cassette interface (includes CUTER tape)	Assembled/Tested Kit	207000-01 207000-02	\$140 \$110
J.	VDM-1 Video Display Module	Assembled/Tested Kit		\$295 \$199
K.	WWB Wirewrap Prototyping Module	Kit	211000-02	\$40
L.	EXB Extender Board	Kit	212000-02	\$35
VI.	Peripherals			
A.	PT-872 TV-Video Monitor by Panasonic		722016	\$199
В.	RQ-413A Cassette Recorder by Panasonic		722019	\$85
VII.	. Software (including manual)	Minimum Memory Required		CUTS cassette
A.	BASIC/5	10K	727000	\$14.50
B.	8K BASIC	12K	727017	\$29.00°
C.	New 8080 FOCAL	8K	727024	\$14.50*
D.	TREK 80 Video Game	8K	727009	\$14.50
E.	GAMEPAC-1 Video Games	4K	727006	\$14.50
F.	MATHPACK Video calculator	4K	727020	\$14.50
G.	ASSEMBLERS: Software #1 Resident Assembler Package	8K	727022	\$14.50
Η.	ALS-8 Resident Assembler, Simulator and Text Editor	12K	727012	\$35.00
1.	Software Technology Music System cassette	8K	727015	\$24.50

Attentior

All listed software products require CUTER or SOLOS programs.

All Processor Technology and Software Technology software is distributed on an individual sale basis for personal use. No license to copy, duplicate or sell is granted with this sale. Each software package has been copyrighted by Processor Technology or Software Technology and all rights therein are reserved.

Prices and specifications are subject to change without notice.

^{*}Available soon at your dealer.



Why Sol Should be your Small Computer Choice.

Sol-20 Terminal Computers are complete. You don't spend an extra penny for necessary interfaces. Sol computer systems start at \$1350 in kit form.

We've done the software job. Only Processor Technology offers a fully implemented disk operating system for small computers: PTDOS. Our high level languages include Extended BASIC, FORTRAN* FOCAL, PILOT* and Assembler.

You can expand the Sol to handle business, engineering and research problems. Today's Sol can handle 65,536 bytes of memory and operate with a three megabyte on-line disk memory. S-100 bus compatibility means you can use a big group of standard peripherals.

Sol systems are conservatively rated. They won't quit on you. With over 5,000 in the field, we know the track record for reliable performance is outstanding.

We back Sol with the best documentation in the industry plus a factory support team to give you caring counsel by phone or letter. What's more, on site maintenance and service folks are located in over 50 cities throughout the U.S. and Canada.

So when you are shopping for a small computer, see your Sol dealer last.

Then you can take your Sol with you!

For more information, please address Processor Technology Corporation. Box G, 7100 Johnson Industrial Drive, Pleasanton, CA 94566. (415) 829-2600.

*available soon

Processor Technology

HELIOS II Disk Memory System

1 EPT 1 - 64





When you want big system performance from your small computer, turn to Processor Technology's Helios II Disk Memory System. Helios II brings your small computer up to a level fully comparable and frequently superior to many mini-computer systems. Perhaps best of all, you can reach this point for thousands of dollars less than the typical mini-computer installation.

Today. Sol Systems using Helios II and PTDOS Processor Technology Disk Operating System) are on line doing a variety of business, industrial, engineering.

educational and scientific jobs.

A school system has replaced their time share terminals with our stand alone computer. A pharmacy system, specially configured for the Sol/Helios II combination, handles the complex and previously error prone task of prescription processing. Business firms use this powerful system for inventory control, invoicing and payroll. A small college stores the student-faculty directory, course requests, accounts receivable and student schedules on their system.

In the West, an advertising agency is using the system for media analysis while an astronomer plans to use the system to program astronomical observations.

A university reports the Sol System with Helios II provides superior performance for computer assisted and computer managed instruction.

Other applications are continuously under development by Sol/Helios II users everywhere.

Powerful software.

PTDOS 1.4 is a proven disk operating system with total file, device and memory management. Since the prototype was developed in 1975, PTDOS has undergone continuous expansion and refinement.

PTDOS-increases the all-important throughput of your computer.

With the command interpreter as a convenient interface to the system, the user can type short commands which perform complex tasks. The powerful DO

command provides a facility for editing and executing command procedure files.

Over 40 commands span from simple file management primitives to complex editors, assembler and other data management utilities.

PTDOS 1.4 System Commands

MAJOR SUBSYSTEMS

EDIT Video Display Text Editor EDT3 Standard Text Editor ASSM 8080 Assembler

DEBUG 8080 Program Debugging Aid Command Interpreter Macro Facility

DISK MAINTENANCE

DISKCOPY Disk to Disk Copy

RECOVER Reclaim lost space on disk

INFORMATIVE

FILES List Information About Files
FREE? List Remaining Free Space
SYST List Configuration Information
OPEN? List Names of Currently Open Files

FILE MANIPULATION COMMANDS
COPY Move Data Between Files
IMAGE Save Memory Contents

BLDUTIL Build Utility File

EXTRACT Modify or List Image File Structure

KILL Kill a file

RENAME Change the name of a file Change the type of a file

REATR Change File Protection Attributes

DATA MANAGEMENT

XREF Assembly Language File Sort and

Cross Reference

DUMP Dump a file in Hex or ASCII
PRINT Print ASCII contents of text file
RNUM Renumber an Assembly Language File

SAVE Create Archive Copy of Files

GET Load SAVEd files or COPY from a Disk

FILE PRIMITIVES - LOW LEVEL

FILE MANIPULATION

CREATE Create a new file OPEN Open a file

READ Read a file into memory WRITE Write data into a file

CLOSE Close a file SPACE Move File Cursor

RANDOM Make a file randomly accessible
SEEK Position the cursor of an indexed file
ENDF End file at current cursor position

CONFIGURATION AND CONTROL COMMANDS

SETIN Set CI input file SETOUT Set CI output file

SET Set various miscellaneous parameters
EXEC Begin execution at some address

ZIP Set Memory

CONFIGR Change System Configuration Change Console Output Drive

LANGUAGES. PROCESSORS AND GAMES

BASC5 Small BASIC Interpreter FOCAL The FOCAL language TREK80 A video Star Trek game

Languages.

Several high level languages are available. BASIC/5 and FOCAL come with the system. Low cost options include Extended Disk BASIC. Disk PILOT and a FORTRAN compiler extended to support all PTDOS operations.

PTDOS supports device-independent files.

Device files turn any peripheral, such as a printer or tape drive, into a "file." The device file then performs necessary manipulation of the device, for instance, reading a block of data or rewinding a tape mechanism. In this way the device can be accessed as a PTDOS file.

Easy interface at the assembly language level.

System calls provide an easy interface to PTDOS services from any assembly language program.

FORTRAN available March 1978. PILOT available mid-1978.

Memory management provides complete system management of static or dynamic buffers. Fully protected system memory area helps prevent inadvertent destruction of the system or managed data. For added flexibility, the user can manage his own file buffers as well as instruct the system to protect a specified block of memory.

The system utility call provides a powerful path to virtual memory with simple, fast program and data overlays.

Hardware interrupt speeds system operation and allows fast response to device requests for service.

Check these unique features.

Random indexed files offer direct, rapid positioning to any byte or block in a file, anywhere on the disk(s).

BOOTLOAD, a small bootstrap program, loads PTDOS in one simple command. BOOTLOAD, included with the system on a CUTS cassette, is also available as an optional Sol personality module.

A start-up file lets you run any sequence of commands automatically on a bootstrapped system.

Each individual diskette may be named and dated for easy identification.

A disk password with system lock secures your data.
As requirements change, the user can reconfigure the system.

Two drives...a must for any disk system.

The Helios II dual drive disk system uses inexpensive, widely available floppy disks for high speed data storage and retrieval. Two drives means you can have two floppy disks on line at all times. The Disk Operating System (PTDOS) resides on part of one diskette — the System Disk. A second diskette provides additional user space and also allows fast and easy production of backup copies to protect critical data.

Helios II uses a unique recording technique known as "firm" sectoring. Under optimum conditions each diskette can store 384,000 bytes of information. That's over 3/4 million bytes on line with each Helios dual

For a new dimension of small computer power, the Helios II Floppy Disk Drive and Processor Technology Disk Operating System. Software includes Extended BASIC, Assembler, PILOT, **Extended FORTRAN** and FOCAL.

drive. Firm sectoring also allows faster data access and variable block sizes.

Up to four dual drives (8 diskettes) can be accessed by the system so that over 3.000,000 bytes of data are on line.

Fast access.

Helios II is fast, with a typical access time of 33 thousandths of a second. Large block size allows programs and data to be transferred very quickly. A 4K block can be read from the disk to RAM computer memory in the proverbial blink of an eye.

Reliable performance.

Helios II was designed for system reliability using proven technology. No compromises are made nor chances taken with your data. Standard single sided diskettes store data using 77 tracks on each 8-inch diskette. Such data formatting has been used over the years for consistent, reliable storage. Helios II uses direct memory access (DMA) to asynchronously transfer data to and from memory. Data transfers are made at an effective rate of over 660,000 bytes per second. Data integrity is assured with a standard hardware CRC error test performed on each transfer to or from the diskette. In addition. an optional read-after-write verify mode can be selected to handle crucial data requirements. Three level. triple option error handling and trapping allows up to nine different ways to handle errors on every system call.

Helios II comes complete with dual drive, cabinet. controller, PTDOS System Disk, power supply, case. all necessary cables, and full systems documentation. A 12K program that tests and reports on every aspect on your disk system is included.

PTDOS Users Group.

HELIUM is an independent organization of HELIOS users. It publishes a newsletter with useful hints. systems support and updated PTDOS information. To join, write to HELIUM, c/o Ian Kettleborough, P.O. Box 9269, College Station, TX 77840.

HELIOS II SPECIFICATIONS

Electrical Power Requirements

117 Volts. 60 Hz AC Controller 7.25 VDC min.

8 VDC at 1600 ma typical

Formatter 7.25 VDC min.

8 VDC at 600 ma typical

PerSci Model 270 Drive.

+ 5 VDC 1.7 amps nominal - 5 VDC 0.15 amps nominal

+24 VDC 1.0 amp nominal - seeking 0 2 amp nominal - not seeking

Operator Controls and Indicators

Locking power switch with key Motorized disk eject switches - one for each drive LED indicators Unit Ready. Write Seek Power

Physical Dimensions

Height.	9.5 in	24 13 cm
Width	14 in	35 56 cm
Depth	21 in	53 34 cm
Weight	53 lbs	23 85 kg
Shipping weight	70 lbs	315 kg

Temperature Requirements

Operational	50 to 100°F	10 to 38°C
Non-operational	-20 to 120°F	-29 to 49°C

Head Positioning

Servo-controlled voice coil – 77 tracks

Head Positioning Times

Track to track, including settling time - 10 msec [maximur Track 0 to track 76, including settling - 100 msec (max

Miscellaneous

Cooling - forced air with filter

Direct-Coupled DC Spindle Motor - 360 RPM

Head Engage Time - less than 40 milliseconds

Read/Write Data Transfer Rate - 250 kilobits per second


Recording Capacity - Unformatted 3.1 megabits per diskette

Actual data storage capacity 384,000 bytes per diskette (maximum)

Processor Technology

Processor Technology Corporation 7100 Johnson Industrial Drive Pleasanton, CA 94566 (415) 829-2600

See it at your Processor Technology dealer



Sol Small Computer Systems

ProcessorTechnology

Your key to 1 EPT 1 - 71 effective, economical computer power.

If you ever wished to gain the force of a powerful general purpose computer operating with the simplicity and ease of ordinary office equipment, you can.

Now a scant year after the early 1977 introduction of the Sol* computer system. over 7.000 Sol's are on the job.

Their tasks are varied. Users all over the world are analyzing the stock market, tracking prescriptions, keeping the books, doing chemical, mathematical and physical research, controlling industrial processes, handling the payroll and profit and loss statements, correlating market research, analyzing product design and countless other tasks.

In a word, they are a working tool never before available to the average person or small business. They are saving time and earning money for lots of people like yourself. And they are doing all these things for a remarkably low investment!

Sol systems don't go out of date either. They were designed from the ground up to build on as newer memories, more powerful languages and more advanced peripheral equipment come along. As your needs for more computer force grow, no matter what Sol system you start with, you'll own a set-up beyond the dictates of the calendar. You'll know why you bought the best.

Processor Technology customers often tell us their original intent was to use a Sol small computer system at home or as a hobby. Sooner than you might believe, they were using the Sol system in their business, profession or education.

Processor Technology Corporation

So by simply adding a disk memory system, the Helios II, a printer or other peripheral, perhaps putting one of several easy to learn languages to work, our users were solving routine, sometimes very complex, problems with amazing ease and speed. And solving them profitably.

Compare Sol to any other small computer

As the first totally integrated system in the small computer field. Sol has had imitators. None has matched Sol's high quality engineering and all around flexibility. No wonder it's the number one choice.

Notice the keyboard. Letters are positioned for standard touch typing. The key tops are contoured for comfort. When depressed, they respond with a resilient, springy touch. You can use the computer for hours without tiring. For extensive text editing, word processing, order entry, and similar continuous keyboard tasks, the Sol keyboard quality is unmatched.

Inside, the keyboard circuitry is non-contacting (capacitive). There are no contacts to wear out.

A sturdy metal cabinet protects Sol. A 200 pound person can stand on the top of it without damage. The wood sides are solid. hand-finished walnut.

Inside Sol. Processor Technology has taken some special pains. Engineers call the main motherboard "beautiful"—conservatively designed and rugged. No corners were cut.

Processor Technology paid particular attention to the video circuitry. Notice that the cursor block on the video screen (the spot that shows you where you are when entering text) surrounds the character completely leaving it still legible. All the characters on the screen are crisp and legible. They don't wobble or swim as you look at them. As you scroll the text up and down on the screen, the image moves smoothly without strobing or flashing. There's little eye fatigue from long time viewing.

Few wires are strung around on the main board. Connectors are mounted at the rear to plug in other electronic components, just like a hi-fi amplifier. No modifications are needed to plug in Teletype * machines. cassette recorders. tv monitors, telephone couplers (modems), and ASCII standard terminals (EIA & current loop). You can hook up a Sol computer system as easily as a home stereo system.

* Teletype Corp.

S-100 bus compatibility

Significantly. Sol systems are compatible with other 5-100 bus products. The S-100 bus is a standard connecting configuration used by more than 100 manufacturers of small computer equipment. Many of these products can be easily plugged inside a Sol system when you need special hardware for voice input, control of electrical appliances elsewhere in the building, analog to digital conversion, or video graphic capability.

Another important feature unique among microprocessor systems is Sol's flexibility. It can switch in a moment from a stand alone computer to an intelligent terminal. Many people have access to large computers via telephone hookup. You can use the Sol as a computer to develop your program and reduce the data. Then switch to terminal mode to use it as a timesharing terminal with a large computer.

Easy to use, the Sol is ideal for learning. Adults find hours of intellectual challenge and stimulating involvement. Kids enjoy the Sol. They start with games but quickly pick up the elements of programming. Sol's rugged construction is kidproof so you don't have to worry.

All Sol systems come with excellent, understandable documentation. Schematics and instructions are geared to learning. You don't have to be an electronic engineer to understand them. Even if you purchase a Sol fully assembled and factory tested. Processor Technology's instruction manuals will help keep your Sol up and running. Sol is easier to service. You'll have less down time and lower maintenance costs.

Factory Guarantee

Sol systems are backed by a factory warranty. Processor Technology guarantees assembled and tested products for one year (parts and labor). Kit products have a three month guarantee on parts. Any authorized Processor Technology dealer can service Sol systems. and many offer maintenance contracts.


Sol's flexible

Change operating software quickly and easily. The operating system is preprogrammed on ROM (Read Only Memory) chips located on a small personality module inside. You can change the Sol's "personality" in one minute. The transformation requires no technical skill at all.

There are now two personality modules. SOLOS gears the computer for stand alone operation. It automatically readies the computer for your commands as soon as the Sol is turned on and controls the cassette, keyboard and video operations. SOLOS has terminal mode functions to switch the computer between stand alone and terminal operation.

BOOTLOAD personality module works with our Helios II Disk Memory System. We've replaced the terminal mode functions with a special loading program for the Disk Operating System. In other respects it is identical to SOLOS.

Additional personality modules are in development.



Sol small computer systems with the add on power of \$40,000 mini's.

The Sol-20/16 Terminal Computer

The Sol-20/16, our basic computer, features the SOLOS personality module, 16.384 bytes of memory and BASIC/5 cassette plus a complete 300 page manual. It's available either fully assembled and factory tested or as a kit. A single, low power module carries the 16K dynamic memory.

BASIC/5 is a small version of the very versatile BASIC language. It is designed for applications requiring primarily mathematical manipulation without extensive processing of text. BASIC/5 is the perfect language for an introduction to computer programming because it's easy to learn and requires only a small amount of memory storage. Hundreds of published programs already written in BASIC work with Processor Technology's BASIC/5.

The 300 page Sol manual carries the most complete set of instructions, theory of operation, software information, drawings and operating information offered by any small computer manufacturer. And after you get it, we send you periodic updates. Many of our users also file their copies of ACCESS, the Sol users journal, in this handsome sturdy 3 ring binder.

You will need to add some device for storage and retrieval of data and programs. A standard cassette recorder will do this. Plug it directly into the back of the Sol. You will also need some means of visually displaying data — a tv monitor, teletype or similar device. These also plug into the back without special adaptors or modifications.

The Sol-20/16 offers the option of using equipment you have or selecting peripherals of your choice. It's an excellent low cost starting system.

Here are a few of the features of the Sol-20/16.

 8080A microprocessor, a sophisticated computer-ona-chip and the "brains" of the Sol.

 1024 character video circuitry which displays 16 lines of 64 characters on a video monitor or suitably adapted tv.

• a custom designed, comfortable to use 85-key capacitive (non-contacting) keyboard with cursor keys and arithmetic keypad.

 an audio cassette interface capable of controlling two recorders (one read, one write) at 1200 bits per second. Store and retrieve large amounts of data on low cost, standard cassettes.

 parallel and serial standard interfaces with connectors permit a teletype and many other devices to plug directly into the back of a Sol.

• a complete rugged power supply and quiet cooling fan.

a handsome case of walnut and metal.

16.384 byte dynamic RAM module.

• software on cassette with BASIC/5 language and two sophisticated computer games.

 a back plane capable of accepting five expansion modules.

Sol-20/32 Terminal Computer

Sol-20/32 offers all the features of the Sol-20/16 with twice as much memory. A single low power module carries 32.768 bytes of dynamic random access memory. Four slots remain open in the back plane for hardware additions.

Fully configured Sol Systems.

Presently four fully integrated Sol Systems with all the hardware, peripheral equipment, documentation and software are available. Depending on the complexity of your tasks, one will give you the kind of computer power you need now and still let you add more later.

All offer the best price/performance value on the market today. All integrated systems come with Processor Technology's new Extended BASIC. This new language is one of the fastest and certainly the most complete for the personal small computer on the market today.


Extended BASIC

Extended Cassette BASIC features string and advanced file functions, special screen commands, timed input, complete matrix, logarithmic and trigonometric functions, exponential numbers, 8 digit precision, and advanced mathematical functions including log, natural log, sine, cosine, tangent, are tangent and square root. Using this BASIC, you can do all of the mathematics needed to solve 5 equations with 5 unknowns in a matter of 4 seconds using just 2 lines of code.

Extended Cassette BASIC handles serial access files. It has provisions for tape rewind. Cursor control gives you some graphic abilities.

Extended Disk BASIC has all the number crunching talents of Extended Cassette BASIC plus almost instant access to data and programs on floppy disks. It has random as well as sequential files and a unique ability to update sequential data in place. It takes advantage of the powerful Processor Technology Disk Operating System and Helios II.

In sum, when you purchase a Sol system, you get real computer versatility. You can do the general ledger, the payroll, or engineering and scientific problems. You can display and print out the results. You can edit text. You can use it for computer aided instruction. You have computer power, not computer-like power.



Sol System I-A

Sol System I-A. offered in assembled form only. includes the Sol-20/16 Terminal Computer with 16.384-byte memory and SOLOS module plus PT-872 video monitor. RQ-413A cassette recorder. Extended Cassette BASIC. cables and the Sol system manual.

The PT-872 is a specially modified 11" Panasonic black and white TV set. It is switchable from the video display mode to the standard UHF VHF television mode. Fully isolated for safety, this unit provides extremely crisp and stable displays. The cassette recorder is a standard Panasonic unit.

Sol System II-A

Sol System II-A is exactly the same as Sol System I-A except for a larger memory. 32,768 bytes (eight bit words). The memory is contained on a single dynamic RAM module, using only one slot of the back plane. Sold fully assembled and tested, it includes the Sol-20/32 Terminal Computer with 32K of memory and SOLOS personality module plus PT-872 video monitor. RQ-413A cassette recorder. Extended Cassette BASIC cables and Sol System manual.

For serious business, you need a disk.

Cassettes are a convenient low cost way to store programs and data, but it takes time to wind and rewind the tape. For most business uses, the fast retrieval time of a disk is the way to go. With a Helios II Disk Memory System you can bring your Sol System up to a level fully comparable and frequently superior to many mini-computer systems. Helios II is fully supported by the most advanced disk operating system in the small computer field. It is a system under development since 1975 designed to make full use of the up to 1.5 million bytes of memory that are available to the user.

PTDOS offers total file. device and memory management. Add to, delete or edit files. List. copy or combine the files on any disk. Over 40 commands span from simple file management primitives to complex editors, assembler and other data management utilities.

Sol System III

Here's the system that stands up to the mini's. It includes the Sol-20 with 49,152 bytes of memory and BOOTLOAD personality module. Helios II Model 2 Disk System with Extended Disk BASIC. PT-872 video monitor, cables and documentation.



Sol System III comes assembled, burned-in and tested. Inclusion of Helios II brings this system up to a level fully comparable and frequently superior to many mini-computer systems. And, you reach this operational level for thousands of dollars less than typical mini-computer installations. A separate brochure on the Helios II and PTDOS is available on request.

Newest member of the Sol family, Sol System IV

Sol System IV consists of the Sol-20 with 49,152 bytes of memory and BOOTLOAD personality module. Helios II Model 4 Disk System with two dual drives. Extended Disk BASIC, PT-872 video monitor, cables and Sol System manual.

It comes completely assembled, tested and burned-in. Except for the larger data storage capacity.

1.5 million bytes, it is like Sol System III. Obviously with so much memory available the scope of problems and the amount of data that can be manipulated become much greater. Suitable for larger business applications.

Software.

1 EPT 1 - 75 FORTRAN

Languages on both cassette and disk include BASIC/5. Extended BASIC. FOCAL.* FORTRAN* and PILOT.* ALS-8 is an "assembler" for program development which includes text editing and 8080 simulation. It is available either on cassette or on preprogrammed ROM (Read Only Memory) chips which mount on the Sol General Purpose Memory module. A variety of games and other special programs are also available.

Using one of these languages, you can program your Sol to perform a wide variety of tasks. Thousands of special programs have already been written in these languages. You will find many of them in readily available books and periodicals.

Processor Technology has devoted more effort to the development of software than any other small computer manufacturer. We are the first small computer company to offer a fully implemented disk operating system: PTDOS with over 40 major commands, several languages and numerous utilities. New programs are in development.

FOCAL

FOCAL is a math language originally written for the PDP-8 mini-computer. Many thousands of FOCAL programs exist and now can run in Sol. 8080 FOCAL includes "operator precedence" and all other standard FOCAL conventions. FOCAL is available on CUTS SOLOS compatible cassette. It is also included on the PTDOS system disk that comes with Sol Systems III and IV.

FORTRAN is a high level language which includes the following functions:

- Explicit run time error comments during compilation and at run time
- Eight significant digits of precision
- String manipulation
- Cursor plot function
- Hexadecimal constants
- Direct in-line 8080 assembly language mnemonics accepted by the compiler.

Processor Technology FORTRAN is identical to FORTRAN IV except for the extensions and lack of COMMON and Double Precision statements. It is available on CUTS cassette or disk. The disk version interfaces well with PTDOS.

PILOT

Processor Technology PILOT, available in mid 1978, is offered on both disk and cassette.

PILOT is a string-oriented interactive language well suited to the applications of educators, educational institutions and psychologists. It is excellent for testing and computer aided instruction.

Custom tailored for Processor Technology by the creator Dr. John Starkweather of the University of California, PILOT runs on the Sol using the SOLOS I O with direct screen cursor positioning, program and data files.

And for fun

8080 CHESS* Here's a wonderful way to improve your chess skills. Operating at a healthy level 5, the 8080 chess program is the finest available for microprocessor computers. Under development for less than a year, the program has already proved its mettle in competition against the truly big computers.

Offered in cassette form, and accompanied by a complete instruction manual, it gives education and delight to both the novice and the expert player.

TREK 80. Based on the NBC television series STARTREK, this machine language program uses 8K of memory for real time war with the Klingons. No holds barred, they're out to get you from each of 100 quadrants. You can warp through hyperspace, fire phasers, photon torpedos, or experimental rays. If you just can't go on, self-destruct.

GAMEPAC 1. Show off your Sol system with this line up of video games.

MATH PACK. Processor Technology floating Math Pack is a self contained five function calculator designed to run on any system using the 8080 code. The following functions are offered: addition, subtraction, multiplication, division and square root.

All Processor Technology software is distributed on an individual sale basis for personal use. No license to copy, duplicate or sell is granted with this sale. Each software package has been copyrighted.

^{*}available soon.

See your Sol dealer for a demonstration.

Sol stores are located conveniently throughout the U.S. and Canada. Your Sol dealer has been carefully selected on the basis of his computer knowledge and ability to meet your needs. Not every store carries the Sol line. The dealers who do are the best in the world.

Sol Specifications

- Keyboard: 85 key upper/lower case with separate numeric keypad. Upper-case shift, shift-lock, cursor control and repeat keys provided. System reset performed by simultaneous depression of control keys. Indicator lights (LED) for local, upper case and shift.
- Character set: 96 printable ASCII upper and lower case characters plus 32 optionally displayable control characters.
- Cursor: Switch-selectable blinking. Block video inversion. Program controlled positioning standard. Cursors may exist at any or all character locations.
- CPU: 8080A. Uses same machine language as other 8080 systems. 2 MHz clock cycle time. 78 instructions.
- Cassette interface: 120 character per second CUTS format or 30 character per second Kansas City format. selected by software. Uses audio cassette function of microphone start-stop switches. AGC for level insensitivity. Phase-locked data recovery tracks with speed variations. Software performs CRC data integrity check each 256 characters.
- Serial interface: RS-232 and 20 mA current loop. 75 to 9600 baud, asynchronous. 25 pin female "D-type" connector on card.
- Parallel interface: Eight data bits for input and output: output bus is tristate for bidirectional interfaces: levels are standard TT1.25 pin male "D-type" connector on card.
- External memory: Expandable to 65.536 bytes total ROM. PROM. and RAM. Uses S-100 standard modules.
- Video signal output: 1.0 to 2.5 volts peak-to-peak. Nominal bandwidth is 7 MHz.
- Power requirements: 117 volts AC 60 Hertz. 250 Watts. 220 Volt 50 Hertz option available.

Sol SMALL COMPUTER SYSTEMS						
	Sol-20/16	Sol-20/32	Sol System I-A	Sol System II-A	Sol System III	Sol System IV
Mainframe	Sol-20	· Sol-20	Sol-20	Sol-20	Sol-20	Sol-20
Personality Module (Operating System)	SOLOS	SOLOS	SOLOS	SOLOS	BOOTLOAD & PTDOS	BOOTLOAD & PTDOS
Random Access Memory (RAM) (8-bit words)	16K bytes	32K bytes	16K bytes	32K bytes	48K bytes	48K bytes
Language Included	BASIC/5	BASIC/5	Extended Cassette BASIC	Extended Cassette BASIC	Extended Disk BASIC FOCAL BASIC 5	Extended Disk BASIC FOCAL BASIC 5
Video Monitor	_	_	PT-872	PT-872	PT-872	PT-872
Cassette Recorder			RQ-413A	RQ-413A	_	-
Disk Memory System	_	_		-	Helios II Model 2	Helios II Model 4
Available Disk Memory (8-bit words)	_	_	_	_	750K bytes	1500K bytes
Number of Disks On-line	_	-	_		2	4

Proces Technology Processor Technology Corporation

Processor Technology Corporation 7100 Johnson Industrial Drive Pleasanton, CA 94566 Dulk Rate
U.S. Postage
PAID
Permit #54
Pleasanton,
CA 94566

Sol Systems: Why they are first choice

THE ERSOHAL COMPUTER RETAILER

Vol.2 No.3 Published by Processor Technology Corporation May 3, 1978
7100 Johnson Industrial Drive, Pleasanton, CA 94566

Teachers meet Sol in San Diego

Elementary and high school teachers are generally familiar with small computers but do not yet realize their potential as teaching aids.

Our marketing staff had the opportunity to learn more about this virtually untapped market at the National Council of Teachers of Mathematics annual convention in San Diego on April 13, 14 and 15. Processor Technology was the only small computer manufacturer represented.

More than 7000 teachers and administrators were on hand to look over what was new. The teachers were especially enthused by our demonstration of a computer-aided instruction program written in PILOT.

PILOT USEFUL
AND EASY TO PROGRAM

Brett Bullington, dealer sales rep, commented, "PILOT is very useful for teachers because it is text- and string-oriented, yet versatile and easy to program. You don't have to be a programmer to use this language effectively."

Based on teachers' questions and responses, Ralph Palsson, also of our marketing staff,



Sit back, relax...let your phone visit the typesetter for you.....story page 4

You want it when?!....page 2

TV ads work for Maryland dealer....page 3

Tips for troubleshooting the 16KRA.....page 5

found that most instructors were interested in using small computers as aids in teaching mathematics and science. There was also interest in teaching programming to junior and senior high school students.

Both Ralph and Brett distributed dealer lists and referred many teachers to local Processor Technology dealers.

"It's usually inexpensive (around \$60) for a dealer to rent a demonstration booth at a regional educators' conference. The local market exposure is great," says Ralph. "Once you get your name on the mailing lists of local school districts and community colleges, you will receive information about upcoming conventions and trade shows. You can then make your reservations early.

You want it when?!

NEW PRODUCT UPDATES

Item	Begin Shipping	Change	
HARDWARE			(6)
ParaSol Debugger	week of April 24	shipment has begun	Jus
НуТуре І	week of May 26	on schedule	(((
HyType II	week of May 8	moved back one week	
SOFTWARE		The same	
8080 FOCAL	within the next 30 days		
SPARE	PARTS		

Spare Parts Kit (#900050). These kits are in stock and available for immediate shipment.

The kit contains a sampling of the various components, particularly integrated circuits, used in our product line. Dealer price is \$400.

April FORTUNE, BYTE picture Sol

Both Fortune and Byte magazines picture the Sol's versatile personality in their April issues.

"Putting the Microcomputer to Work"

Whodunnit

Editor......Dottie Wanat
Graphics.....Lois Esser
Ray Oleson

General Input....Rick Meyer
Chuck Rosas
Elizabeth Fairchild
Brett Bullington
Loren Willey
Ralph Palsson

(Fortune, April 24, 1978, page 54) features the Sol in use by "Big Brother Biasi-otto" at the Franciscan Friars Provincial Headquarters in New York City.

On page 126 of the April '78 issue of <u>Byte</u>, the Sol is pictured enjoying life in a Victorian parlor. The accompanying article, "User's Report: The Sol-20", records the author's favorable impressions of the Sol.

TVadvertising pays off for Maryland dealer

by Elizabeth Fairchild

"Dollar for dollar, television advertising has paid off for our store more than any other media," says Dave Gardner, partner and manager of COMPUTERS, ETC...in Towson, Maryland.

Undaunted by the high cost of video production and TV time, Dave experimented with producing his own ads. He kept costs down by writing the copy himself and selecting an inexpensive though effective format. Total production cost for two 30-second spots was only \$230.

In each ad, a written message "crawls" across the screen one letter at a time at an average reader's pace. A voice in the background describes current sale items and special services offered by COMPUTERS, ETC... The description frequently ties in with the store's current newspaper ads. Sometimes business applications are emphasized, some-

times hobby uses. This format appeals to potential computer buyers without appearing obviously

"low-budget."

The spots have been running on a Washington D.C. independent station in bursts Thursday through Sunday, one week per month. Dave spends approximately \$1400 per weekend. He selects programs which appeal to his target audience: men ages 18-45 with medium incomes. To determine which shows are appropriate, he studies the rating guide provided by the So far he has used sports specials, a program about the movie GREASE, the Odd Couple, Perry Mason, and late movies.

The response has been so good, Dave is planning to expand to a UHF station which broadcasts to both Washington and Baltimore. (COMPUTERS, ETC... has a second store in the Baltimore area.)

Summing up his experience with media so far, Dave says, "I would rank TV #1, newspapers #2, and radio a poor third. Radio has only worked for us at Christmas time to advertise video games."

Low-hassle warranty cards coming soon

Beginning soon new warranty registration cards will accompany all hardware manuals. These cards are stamped and selfaddressed -- no envelopes, postage, glue, staples or tape is required. The customer can simply fill it, fold it, seal it, and send it to Processor Technology.

We require a separate card for each product purchased. For example, if a customer purchases a Sol System III, he should send us warranty registration cards for the Sol, the Helios, and each 16KRA board.

Please pass this information along to your customers.

> SEE YOU AT NCC IN JUNE.

How we typeset the new 16KRA and FOCAL manuals with a little help from Sol

by Rick Meyer

A Sol System III, assisted by special electronic word processing and typesetting equipment produced the new 16KRA and FOCAL manuals which you will receive soon.

This small computer application allows a small staff in our publications department to produce more and better quality work. The new manuals are easier to read, more compact, and more professional in appearance. I'm quite excited by the results and believe you will find the procedure of interest.

It begins when one of our technical writers enters his or her original draft into a Sol System III using a special word processing editor. The new Sol-HyType Interface prints the intermediate drafts on a HyType Printer and the manuals are stored on Helios floppy disks which allow

for rapid revisions and additional drafts.

When the text for a manual is complete, we can transmit it out the serial port of the Sol through a 300 baud acoustic-coupled modem via telephone to a computerized photo-typesetting firm in San Francisco forty miles away. By inserting additional commands in the file, we give detailed instructions for type face and point size, pagination and construction of tables.

The typesetter sends the edited file through special software which drives the photo-typesetting machine and produces the cameraready pages. In just a few days the copy is mailed to us ready for printing.


If you have any questions about

details, please feel free to

the system, or would like further

and the manuals are stored on Helios floppy disks which allow Publications Department.

Page 4, Vol.2 No.3



tips for 16KRA

Excedrin headache number 16

When a 16KRA has a serious headache and you want a systematic treatment to give it fast, fast relief (before you get a headache), try this approach:

Check voltages

 We recommend using a dual trace oscilloscope capable of triggering at .2 microseconds. Instructions are given below for a single trace scope also.

2. Set the scope at an amplitude of 5 volts per division and check the 7 pin J2 connector. located on the bottom lefthand corner of the board.) Starting from P2-1, you should read approximately +16v, -16v (unregulated) and +8v on P2 pins 1, 2, and 3 respectively.

O. If no voltage is present, there is probably an open connection on J2. You can test this by checking the incoming voltages on P2-5, 6 and 7, which should read +8v, -16v and +16v respectively. If you get no voltage here, see page 7.3 of the 16KRA manual for further instructions.

4. Next, check the on-board voltages. Select any RAM chip and measure the voltages at pins 1, 8, 9 and 16. You should read -5v, +12v, +5v and ground respectively. An extra hot heatsink indicates a short.

J. If, when powering up, the monitor is grossly distorted with large dark areas across the screen, +12v is shorted to ground. Frequently such a short is caused by (continued on page 6)

Troubleshooting tips...

(continued from page 5)
the socket pins of U29, 30 and 31
slicing into the insulation of the
Rev J jumper and shorting either
+12v or +5v to ground. Simply
bend this insulation away from the

pin. Please DO NOT use a soldering iron because this voids the warranty. If you still cannot locate the short, send the board back to the factory for repair.

Check delay lines

I. The delay line in socket U71 is vital to the board's operation. A failure (whether hard or intermitent) is often due to the socket itself. Often a simple dump command will clue you into the problem. Type in the command "DU Ø EF <cr>
" If a dump does not occur, the delay line is a likely source of trouble."

To troubleshoot U71, temporarily remove the D to DN jumper in area D. The board is now in an undefined state; this condition is sufficient for testing the delay line. Another approach is to put the board into a wait state by grounding U68-11. In the wait state, pin 72 of the S-100 bus should be at ground potential.

3. The delay line determines the pulse widths of MC and RC. If you are using a single trace

scope, check the signal at U61-8. Whenever it goes high or low, the delay line should follow it. A floating signal (+2 volts) at U57-5, 2, 4 or 1 indicates a bad delay line. The pulse out of the delay line should be a crisp 350 nsec long. Any variation indicates a defective delay line.

With a dual trace scope, set the sweep to 100 nsec per division. U61-8 should have a stable pulse of 300 to 350 nsec. Due to the output of NAND gate U57-6, there will be a 100 nsec delay relationship between U61-8 and U57-5.

Trigger on U61-8 to observe the timing relationships. The result should be:

- a. a 50 nsec delay between U57-5 and U57-2.
- b. a 100 nsec delay between U57-2 and U57-4.
- c. a 100 nsec delay between U57-4 and U57-1 with a pulse width of 300 to 350 nsec.

More tips later


Another set of problems can occur on the address lines. I'll discuss these in a future article. 'Til then, take two aspirin and get plenty of rest.


--Chuck Rosas

Build an all-in-one


home computer

Arithmetic keypad (far right) on Sol 20 microcomputer simplifies entry of long data lists. For clear readouts, TV atop computer is modified to accept video signals.





Plug-in module carries the system monitor, a microcircuit with thousands of permanently stored instructions that regulate basic operations of the microcomputer.



Memory board slipped into Sol 20's five-slot backplane stores 16,384 bytes (16K of computer words). A quiet fan cools the power supply (left) and other circuit boards.

By JOHN FREE

Home-computer kits can be a hassle if you discover that several "optional" plug-in boards and accessories are needed to make your computer perform adequately. I built Processor Technology Corp.'s (PTC) Sol 20 Terminal Computer because video, memory, computing, input, and output circuits are all included. PTC (Pleasanton, Calif.) markets its computer separately or in complete systems: computer, 11inch TV modified to accept non-RF video signals, plus a cassette recorder for loading and storing programs.

The Sol 20 is called a terminal computer because it has a built-in keyboard and functions that could enable you to communicate with other computers. PTC's computer uses the popular 8080 microprocessor, which means there are many programs around that you can use. It also accepts S-100 boards [PS, Nov. '77] that can play music, talk, listen, and do other amazing


things. The computer has a trim, low silhouette, however, and room for only five boards.

I spent about 58 hours putting a Sol 20 together, and made only one blunder: A bridge rectifier installed backwards in the power supply shorted several components. Lesson learned: Since the manual has few step-by-step drawings, extra-careful reading is a must.

The computer displays 16 lines of 64 black characters, or white readouts on a black background. Compared to displays I've seen from some microcomputers, the system's Panasonic TV gives an exceptionally clear readout. Data for upper- and lower-case characters are stored in permanent memory.

The Basic 5 computer-language cassette included in the kit can run many programs listed in magazines and other sources. Basic 5 works with the 16K memory board included with the \$1850 Sol 20-16 kit. A "brainer" \$45 extended-Basic cassette requires either 15K or 12K of

memory, depending on whether you load matrix capability or not. With extended Basic and more memory you can tackle virtually all Basic programs. PTC's \$2495 System I-A (Sol 20, cassette recorder, TV extended Basic, 16K memory) is now sold only in assembled form.



Master circuit board for Sol 20 kit covers over half the chassis. Keyboard section and 100-pin memory boards are assembled and tested at the factory.

60 POPULAR SCIENCE

ProcessorTechnology

Sol® SYSTEM SUGGESTED U.S. RETAIL PRICE LIST (July 1, 1978)

Sol SYSTEMS		Order No.	Price (\$US
 Sol-20/16 Terminal Computer with SOLOS personality module and 17,408 bytes of memory, includes BASIC/5 cassette and Sol System manual 	Factory Assembled/Tested Sol Kit/16KRA A & T	400 500 400 502	\$2095 \$1850
2. Sol20/32 Terminal Computer with SOLOS personality module and 33,792 bytes of memory, includes BASIC/5 cassette and Sol System manual	Factory Assembled/Tested Sol Kit/32KRA A & T	400 600 400 601	\$2395 \$2150
 Sol System I-A includes Sol-20/16 with 17,408 byte memory and SOLOS module, PT-872 video monitor, RQ-413A cassette recorder, Extended Cassette BASIC, cables and Sol System manual 	Factory Assembled/Tested	40 0700	\$2495
4. Sol System II-A includes Sol-20/32 with 33,792 byte memory and SOLOS module, PT-872 video monitor, RQ-413A cassette recorder, Extended Cassette BASIC, cables and Sol System manual	Factory Assembled/Tested	400800	\$2795
5. Sol System III includes Sol-20 with 50,176 bytes of memory and BOOTLOAD module, Helios II Model 2 Disk System (stores 769,000 bytes) with Extended Disk BASIC, PT-872 video monitor, cables and Sol System manual	Factory Assembled/Tested	400300	\$599 5
6. Sol System IV includes Sol-20 with 50,176 bytes of memory and BOOTLOAD personality module, Helios II Model 4 Disk System (two dual drives store 1.5 million bytes) with Extended Disk BASIC, PT-872 video monitor, cables and Sol System manual Note: All Sol-20 series units and Sol Systems are available for 220 Volt, 50 Hz oper Contact factory for pricing and delivery information.	Factory Assembled/Tested ation.	400340	\$799 5
SOI COMPONENTS			
1. Sol-PC Single Board Computer with SOLOS personality module	Factory Assembled/Tested Kit	101036-01 101036-02	\$745 \$575
2. BOOTLOAD Personality Module with 2048 byte PROM stored program loads PTDOS directly into Sol main memory. (BOOTLOAD is included with Sol System III or IV.)	Factory Assembled/Tested	107015	\$100
3. Sol-Hytype 1* Printer Interface includes assembled and tested interface board, all cables and mounting hardware. Plugs directly from any Diablo* Series 1200 printer into Sol Parallel Data Interface connector. No modifications to Sol are required. Driving software included.	Installation Package	900023	\$150
4. Sol-HyType II* Printer Interface like Sol-HyType I above for any Diablo Series 1300 printer. Driving software included.	Installation Package	900024	\$150
MASS STORAGE SYSTEMS			43 - 3 18
1. Helios II, Model 2 Disk System includes dual PerSci 270 floppy disk drive, cabinet, fan, S-100 bus compatible controller, power supply, and system diskette with complete PTDOS software and documentation. (Stores 769,000 bytes.)	Factory Assembled/Tested	300000	\$299 5
2. Helios II, Model 4 Disk System includes two dual PerSci 270 floppy disk drives, cabinet, fan, S-100 bus compatible controller, power supply, and system diskette w complete PTDOS software and documentation. (Stores over 1.5 million bytes.)	ith Factory Assembled/Tested	304000	\$4 995
S-100 BUS SUBSYSTEMS			
Subsystem B110 includes 8KRA memory, VDM-1 Video Display Module, 3P + S Parallel/Serial I/O Module, CUTS Computer Users Tape System cassette interface and GPM General Purpose Memory and Extended Cassette BASIC	Factory Assembled/Tested Kit	40 6100 40 6101	\$1095 \$799
2. Subsystem B190 includes 16KRA memory, VDM-1 Video Display Module, 3P + S Parallel/Serial I/O Module, CUTS Computer Users Tape System cassette interface and GPM General Purpose Memory and Extended Cassette BASIC	Factory Assembled/Tested Kit (16KRA A & T)	40 6200 40 6201	\$1195 \$995
3. Subsystem B350 includes 32KRA memory, VDM-1 Video Display Module, 3P + S Parallel/Serial I/O Module, CUTS Computer Users Tape System cassette interface and GPM General Purpose Memory and Extended Cassette BASIC	Factory Assembled/Tested Kit (32KRA A & T)	40 6300 40 6301	\$1495 \$1295

^{*}Hytype I, Hytype II and Diablo are registered trademarks of the Xerox Corporation.

ProcessorTechnology 1 EPT 1 - 86

Sol ® SYSTEM SUGGESTED U.S. RETAIL PRICE LIST (July 1, 1978)

S-100 BUS COMPATIBLE MODULES (MEMORY)		Order No.	Price (\$US
 GPM General Purpose Memory Module with 2048 byte CUTER masked ROM, space for 8192 bytes of 2708 type EPROM or ROM, and 1024 bytes RAM. 	Factory Assembled/Tested Kit	210000-01 210000-02	\$189 \$149
2. GPM-Sol same as GPM without RAM or CUTER ROM. Includes space for 10,240 bytes of 2708 type EPROM.	Factory Assembled/Tested Kit	210000-03 210000-04	\$129 \$99
3. ALS-8 ROM Resident Assembly Language Operating System with Interpretive Simulator (SIM-1) and Text Editor (TXT-2). For use with GPM or GPM-Sol. If purchased together, price includes assembly and testing. (ALS-8, SIM-1 and TXT-2 programs are copyrighted.)	Factory Assembled/Tested or Kit	900014	\$190
4. 2KRO Erasable PROM S-100 bus Module with capacity for up to 2048 bytes of EPROM-stored programs. (Does not include EPROM's.)	Factory Assembled/Tested Kit	204 000-01 204 000-02	\$89 \$65
5. 4KRA Memory Module with 4096 words of Low Power Static RAM	Factory Assembled/Tested Kit	201000-01 201000-02	\$150 \$125
6. 8KRA Memory Module with 8192 bytes of Low Power Static RAM	Factory Assembled/Tested Kit	202000-01 202000-02	\$250 \$225
7. 16KRA Memory Module with 16,384 bytes of Dynamic RAM	Factory Assembled/Tested	203000-01	\$429
8. 32KRA Memory Module with 32,768 bytes of Dynamic RAM	Factory Assembled/Tested	203100	\$750
S-100 BUS COMPATIBLE MODULES (INTERFACE)			
1. 3P + S Parallel/Serial I/O Module features two 8-bit parallel I/O ports plus a serial port with RS-232C and 20 mA current loop I/O, 75 to 9500 baud.	Factory Assembled/Tested Kit	209000-01 209000-02	\$199 \$149
2. CUTS Computer Users Tape System audio cassette interface (includes CUTER tape) operates at 300 or 1200 baud. Panasonic RQ-413A cassette recorder recommended.	Factory Assembled/Tested Kit	207000-01 207000-02	\$189 \$149
3. VDM-1 Video Display Module offers EIA video output with either 625 or 525 vertical line resolution. 16 lines X 64 characters generated in upper and lower case font. High speed module has 1024 bytes of RAM, multiple programmable cursor control, selectable blinking and scrolling up to 2000 lines per minute.	Factory Assembled/Tested Kit	208 000-01 208 000-02	\$295 \$199
4. WWB Wirewrap Prototyping Module	Kit	211000-02	\$40
5. EXB Extender Board	Kit	212000-02	, \$35
SOFTWARE (INCLUDING MANUAL)	Minimum Memory Required		
1. Extended Cassette BASIC	16K	727017	\$45.00
2. BASIC/5 cassette	10K	727000	\$19.50
3. New 8080 FOCAL* cassette	10K	727024	\$19.50
4. TREK 80 Video Game cassette	8K	727009	\$19.50
5. GAMEPAC 1 Video Games cassette	4K	727006	\$19.50
6. MATHPACK Video calculator cassette	4K	727020	\$19.50
7. Software #1 Resident Assembler Package cassette	6K	727022	\$19.50
8. ALS-8 Resident Assembler, Simulator and Text Editor cassette	12K	727012	\$45.00
9. Extended Disk BASIC	32K	727036	\$50.00
O. PTDOS 1.4 System Disk (replacement)	32K	727030	\$50.00
1. Extended Disk FORTRAN	32K	727100	\$50.00
12. Cassette PILOT	16K	727110	\$24.50
13. EDIT, 8080 Cassette Editor	8K	727140	\$19.50

^{*} Registered trademark of Digital Equipment Corporation.

Attention

A SOLOS or CUTER monitor program is necessary to load and run cassette software products.

All Processor Technology software is distributed through authorized dealers or on an individual sale basis for personal use. Each software package has been copyrighted by Processor Technology and all rights therein are reserved. No license to copy or duplicate is granted with distribution or subsequent resale.

Prices and specifications are subject to change without notice. Prices are in U.S. dollars, apply in U.S.A. only and may be slightly higher elsewhere.

THE PERSONAL COMPUTER RETAILER

Vol.2 No.6 Published by Processor Technology Corporation July 18, 1978
7100 Johnson Industrial Drive, Pleasanton, CA 94566

New extended BASIC option

A recent letter to all Processor Technology dealers announced the new family of BASIC's. Included is an option which converts any Extended BASIC disk (currently 8-digit precision) to 6, 10, 12, 14 or 16 digits of precision. This option is available to all authorized Processor Technology dealers for an initial flat fee of \$350.

Dealers can customize the level of precision at the time of sale or retroactively for Sol users who would now like the advantages of greater precision, particularly for accounting applications.

Programs written in the original

New software to expand and protect YOUR programs.....story page 1

In this issue...

You want it when?!page	2
EditorialAvoid unnecessary chargespage	2
Upcoming tech training seminars emphsize day-to-day maintenance & standardized repair procedurespage	4
Your free copy of revised SOLOS/CUTER Manualpage	3
Memory board task force develops field quality assurance programpage	3

version of Extended BASIC will be fully compatible after the conversion.

Business BASIC protects YOUR valuable software

Also announced was the new Processor Technology Level I Business BASIC for software developers. For a flat fee of \$2,000 you get a unique version which includes both development and runtime programs. Your BASIC programs will run but cannot be listed, thereby insuring you of privacy and added security.


Your version of BASIC is unique and another developer cannot unscramble your programs with his version of Business BASIC. With this approach you get the major advantage of both interpreters and compilers, i.e. easy development and debugging plus runtime security.

Optional precision is included with Level I Business BASIC.

By paying this low, one-time-only fee you will never again have to pay royalities when using the programs.

Both Optional Precision and Level I Business BASIC will be available for delivery soon.

Memory board Task Force at work



We've had a group of our technical staff from engineering, production, and quality control working since May on the top-priority project of identifying all areas of difficulty in the 16KRA memory board and to insure that all such difficulties are eliminated.

According to the latest reports they are more than 90% there now. When the work is completed all hard failures and all timing discrepancies will be eliminated as well as most intermittent failures.

The Task Force has also developed a new complete test and verification procedure for use in the factory and field. The new Field

Quality Assurance Program will guarantee 100% performance if followed carefully by your technicians. Included will be specs for test fixtures and equipment, comprehensive test and diagnostic software, and a fixed test procedure. We will also be covering these procedures in depth at our Technical Training seminars in August.

New SOLOS/CUTER Manual benefits all Solusers

A greatly expanded second edition of the SOLOS/CUTER Manual is now being shipped with all Sols. Included with this newsletter, free of charge, is your reference copy.

After looking it over I'm sure you'll agree with us that all Sol users, old and new, will benefit from the useful additional information contained in this new edition. Therefore, we encourage you to notify your customers of the availability of the new manual.

These manuals are available for immediate shipment at the normal dealer discount of 40%. The suggested retail price is \$5.00.

The new issue of Access will also

carry an article on the new edition. Manuals will be available for enduser purchase directly from the factory for \$5.00. We will, however, make it clear that these manuals are also available through the local dealers.

KEY CHANGES IN THE MANUAL

- 1. All command descriptions are expanded and clarified.
- Procedures for the use of the cassette recorder controls are now integrated with the command procedures.

(Continued on page 4)

Tech training seminars to introduce standardized repair procedures

"By popular demand the upcoming seminars have been designed to cater to practical applications with an emphasis on day-to-day maintenance and troubleshooting," says the coordinator, Aram Attarian II, formerly lead technician in Warranty Repair and Editor of Access.

Our main goal is to introduce to you a list of factory authorized repair procedures. These procedures will be identical to those used in-house. We are planning to share a coveted list of procedures and short-cuts which have been accumulated by our techs over the years. For the first time we will have a common set of terms and definitions from which to communicate.

You will also have hands-on experience by actually doing debugging, as well as a chance to work with the Helios and become more familiar with PTDOS.

You'll have a chance to meet and chat with your counterparts around the country. There is an hour set aside at the end of each day's session for an interchange of ideas and general discussion. Plus a reception is planned for the evening prior to the start of the seminar.

We are limited to around 30 participants at each seminar and registration must be made in advance. So be sure to set aside these days:

PLEASANTON, CA. AUGUST 7, 8 & 9th
PHILADELPHIA, AUGUST 28, 29 &
PENN. 30th

Just fill out the registration form and return it to us as soon

as possible in order to reserve your place. Then bring your manuals, questions and ideas and join us for this worthwhile experience.

Remember, whether you live on the East Coast, West Coast, or some-where in between, there is a Tech Training Seminar just waiting for you. Don't miss it!

New SOLOS CUTER Manual

(Continued from page 3)

3. The use of typesetting allows for easier reading. Quicker reference also is possible because of a special "monospace" typeface which is used to denote all dialogue with SOLOS.

KEY ADDITIONS TO THE MANUAL

Several important new sections have been added:

- Section 1.6. Deals with entering commands. Describes various functions in SOLOS and how they may be edited and used.
- Section 5, System Interfacing. Instructs the user on how to call SOLOS sub-routines from other programs.
- Appendix I. Gives general tips on using cassette recorders for data storage.
- Appendix II. Contains a complete chart of ASCII Codes.

You want it when?!

NEW PRODUCT UPDATES

Item

SOFTWARE

Software #1, Resident 8080 Assembler

Extended Disk FORTRAN

Cassette PILOT

EDIT,

Advanced 8080 Editor

ASSM,

Advanced 8080 Assembler

Math Pack Video Calculator

8080 Chess Cassette

Game Pac II

Debug,

Advanced 8080 Debugger

Begin Shipping

Change

shipment has begun shipment has begun shipment has begun on schedule on schedule

shipment has begun

on schedule

week of July 31
week of July 31
week of July 31
week of August 14
week of September 4





Avoid unnecessary charges!

by Dottie Wanat I'm sure you've all received the recent letter regarding the implementation of a 15% restocking

Whodunnit

Editor......Dottie Wanat
Graphics.....Lois Esser
Ray Oleson

General Input....Loren Willey
Rick Meyer
Brett Bullington
Aram Attarian II
Elizabeth Fairchild

Copyright © 1978, by Processor Technology Corporation. All rights reserved. charge for refused merchandise. I'm also pretty sure you're not jumping up and down! So, just a brief word in our defense. (Please don't stop reading).

First of all, remember that this charge is only made when a shipment is refused. Also, it only covers the additional costs that we incur by such a practice. As long as you give us reasonable notice that you wish to either reschedule or cancel part of your order, no charge will be made. This policy places the cost burdens on those who create them.

I'm sure that by working together in a cooperative manner we will all realize the benefits from these cost— and time—saving procedures.

Gentlemen, start your oscilloscopes!

Our new Technical Training Seminar will be presented for the first time on August 7, 8 and 9 at the factory in Pleasanton. Be sure to bring your manuals, questions and a PTDOS system diskette. During the seminar we will copy new diagnostic procedures for Sol and Helios onto your diskette.

Software Sentre

by Connie Hawkinson This is the first in a series of columns about Helios software developed by Processor Technology dealers. My purpose is to serve as an information clearinghouse. I will briefly describe the Helios software package you offer and list your name, store, and phone number so that interested dealers may contact you directly for further information. Processor Technology will NOT be involved in any of these transactions. do intend to encourage software exchange among dealers to benefit your Helios system sales as well as to prevent any duplication of efforts.

Below is the current listing. Due to time constraints I cannot contact all of our dealers. fore, if you are interested in participating in the "exchange", please contact me at the factory.

CURRENT LISTINGS:

COMPUTER EMPORIUM, Cherry Hill, New Jersey. Contact Joel Schusterman at (609) 667-7555. They have developed a standard system (stored Both Sol and Helios manuals may be on four diskettes) designed to provide a basic computerized package to meet the small to medium-sized company's information needs in the areas of sales order entry, invoicing, inventory control, accounts payable, accounts receivable, and sales analysis.

At the completion of the session your tech will receive certificates which verify that he has completed a factory-sponsored technical seminar for either hardware, software or both.

Also, don't forget the getacquainted reception planned for Sunday evening at 7 p.m. at the Howard Johnson's Motor Inn, 6680 Regional Street, Dublin, CA.

For those of you in the Midwest and on the East Coast, this same Seminar will be conducted again in Philadelphia on August 28, 29 and 30.

We hope you will send a representative to one of these valuable sessions.

Sales tip

Here's an idea from Loren Willey, our Retail Marketing Manager: many dealers sell the Sol and Helios manuals separately. A potential customer who is technically inclined will often appreciate the opportunity to become familiar with the details of the system before he makes a purchase.

How about "loaning" the manual on a short term basis? Even if your customer is still undecided, he will have to come back to your store to return the manual, and you'll have another chance to present the product.

purchased separately. A scheduled order is not necessary. Just send a purchase order to your dealer coordinator. The Sol System manual has part number 730000 and retails for \$25. The Helios manual, part number 730023, retails for \$50.

by Ron Carpenter "If anything can go wrong, it will. If there is a possibility of one of several things going wrong, the one that will happen is the one that will do the most damage."

Murphy's Law is particularly relevant when dealing with electronic systems, and, of course, microcomputers are certainly no exception. So, given this theoretical base, what's the best way to approach the inevitable?

A systematic approach to troubleshooting

We've designed some broad-based guidelines to give you a good overview of a systems approach to troubleshooting.


One of the most important things to remember when troubleshooting is NEVER JUMP TO CONCLUSIONS.

With any computer system, a combination of elements rather than just one may be at the root of a problem. Possible sources of difficulty are: 1) The Operator; 2) The Recording Media; 3) Mother Nature; and finally, 4) The Hardware. Start your analysis by first duplicating the symptoms. Then eliminate each possible cause one-by-one in the following order.

- Check for Operator Error. possible, let the customer operate the system. You may discover the problem lies right there. If not, go on to Step 2.
- or cassette). Be sure that you are using the same diskette or cassette used when the failure occurred. It's possible that a crashed diskette

caused the problem. If not, continue on to Step 3.


- Mother Nature. Was there some type of storm or electrical disturbance going on at the time of failure? Weather has been the cause in a surprising number of cases.
- Hardware Error. If, after eliminating the first three possibilities the system is still not performing properly,



check the hardware. Run an individual comprehensive test on each of the four subassemblies in this order: 1) Memory; 2) Helios cabinet: 3) Controller/Formatter: and 4) the Sol. Each test will isolate problems within the subassembly itself. As you discover and repair each problem, rerun the comprehensive test. Continue repeating the test for each subassembly until all problems are found and repaired.

Also, remember that the more information (detailed symptoms, test results, etc.) you have, the easier it is to locate and solve a problem. So be sure to keep records of your findings at each stage of the analysis.

Again, these are very general guidelines. A detailed set of Standardized Repair Procedures will Recording Media Error (diskette be given to each attendee at our upcoming Tech Seminars. In combination with the detailed procedures, these general tips can improve the efficiency and effectiveness of your troubleshooting.



FACTORY TRAINED

This certifies that

has completed a program in Systems Diagnostics and Maintenance

Wice-President of Marketing

Instructor Roct Lupps

__August 1978

Date

See it at your Sol dealer...

ALABAMA

ICP, Computerland 1550-D Montgomery Hwy. Birmingham, AL 35226 (205) 979-0707

CALIFORNIA

The Byte Shop 1514 University Ave. Berkeley, CA 94703 (415) 845-6366

Byte Shop Computer Store 6041 Greenback Lane Citrus Heights, CA 95610 (916) 961-2983

Orange County Computer Center 1913 Harbor Blvd. Costa Mesa, CA 92627 (714) 646-0221

Computerland of Hayward 22634 Foothill Blvd. Hayward, CA 94541 (415) 538-8080

The Byte Shop 16508 Hawthorne Blvd. Lawndale, CA 90260 (213) 371-2421

Computer Magic 700 McHenry, Suite E Modesto, CA 95350 (209) 527-5156

Digital Deli 80 W. El Camino Real Mountain View, CA 94040 (415) 961-2670

Computer Center, Inc. 4014 Geary Blvd. San Francisco, CA 94118 (415) 387-2513

The Byte Shop 509-B Francisco Blvd. San Rafael, CA 94901 (415) 457-9311

The Byte Shop 2989 North Main Street Walnut Creek, CA 94596 (415) 933-6252

COLORADO

Byte Shop 3101 Walnut Street Boulder, CO 80301 (303) 444-6550

Byte Shop E. 1st Ave. & University Denver, CO 80206 (303) 399-8995

CONNECTICUT

Technology Systems 20 Chestnut Street Bethel, CT 06801 (203) 748-6856

FLORIDA Byte Shop of Ft. Lauderdale 1044 E. Oakland Blvd. Ft. Lauderdale, FL 33334 (305) 561-2983

Byte Shop of Miami 7825 Bird Road Miami, FL 33155 (305) 264-2983

Microcomputer Systems, Inc. 144 S. Dale Mabry Hwy. Tampa, FL 33609 (813) 879-4301

GEORGIA

Atlanta Computer Mart 5091-B Buford Hwy. Atlanta, GA 30340 (404) 455-0647

ILLINOIS

Midwest Microcomputer 708 S. Main Street Lombard, IL 60148 (312) 495-9889

OWA

The Computer Store of Davenport 4128 Brady Street Davenport, IA 52806 (319) 386-3330

KENTUCKY

Martronix Associates 1235 E. Oak Street Louisville, KY 40204 (502) 459-0500

MARYLAND

Computers Etc. 13A Allegheny Towson, MD 21204 (301) 296-0520

MINNESOTA

Computer Depot 3515 W. 70th Street Minneapolis, MN 55435 (612) 927-5601

MISSOURI

Computer Country 235 Dunn Road Fiorissant, MO 63031 (314) 921-4434

NEW HAMPSHIRE

Computerland of Nashua 419 Amherst Street Nashua, NH 03060 (603) 887-5238

NEW JERSEY

Computer Emporium 2438 Route 38 Cherry Hill, NJ 08002 (609) 667-7555

Computer Mart of New Jersey 501 Route 27 Iselin, NJ 08830 (201) 283-0600

NEW YORK

The Computer Tree 409 Hooper Road Endwell, NY 13760 (607) 748-1223

The Computer Mart of New York 118 Madison Ave. New York, NY 10001 (212) 686-7923

The Computer Corner 200 Hamilton Ave. White Plains, NY 10601 (914) 949-3282

NORTH CAROLINA ROMs 'N' RAMs Crabtree Valley Mall Raleigh, NC 27604 (919) 781-0003

OHIC

The Basic Computer Shop Fairlawn Plaza 2671 W. Market Street Akron, OH 44313 (216) 867-0808

Byte Shop 2432 Chester Lane Columbus, OH 43321 (614) 486-7761

Computer Mart of Dayton 2665 S. Dixie Ave. Dayton, OH 45409 (513) 296-1248

OREGON

Byte Shop Computer Store 3482 S.W. Cedar Hills Blvd. Beaverton, OR 97005 (503) 644-2686

Byte Shop Computer Store 2033 S.W. 4th Ave. Portland, OR 97201 (503) 223-3496

Computer Pathways 145 Alice Street So. Salem, OR 97302 (503) 399-0534

PENNSYLVANIA

Computer Mart of Pennsylvania 550 DeKalb Pike King of Prussia, PA 19406 (215) 265-2580

RHODE ISLAND

Computer Power, Inc. M24 Airport Mall 1800 Post Road Warwick, RI 02886 (401) 738-4477

SOUTH CAROLINA

Byte Shop 1920 Blossom Street Columbia, SC 29205 (803) 771-7824

TENNESSEE

Microproducts & Systems 2307 E. Center Street Kingsport, TN 37664 (615) 245-8081

TEXAS

Computer Port 926 N. Collins Arlington, TX 76011 (817) 469-1502

Micro Store 312 Randol Mill Road Arlington, TX 75080 (817) 461-6081

Interactive Computers 7620 Dashwood Houston, TX 77036 (713) 772-5257

Interactive Computers 16440 El Camino Real Houston, TX 77058 (713) 486-0291

Neighborhood Computer Store 4902-34th Street Lubbock, TX 79410 (806) 797-1468 Micro Store 634 S. Central Richardson, TX 75080 (214) 231-1096

UTAH

Home Computer Store 2343 East 3300 South Salt Lake City, UT 84109 (801) 484-6502

VIRGINIA

The Computer Systems Store 1984 Chain Bridge Road McLean, VA 22101 (703) 821-8333

WASHINGTON

Byte Shop Computer Store 14701 N.E. 20th Ave. Bellevue, WA 98007 (206) 746-0651

Byte Shop of Seattle 2605 2nd Ave. Seattle, WA 98121 (206) 622-7196

WISCONSIN

The Madision Computer Store 1863 Monroe Street Madision, WI 53711 (608) 255-5552

The Milwaukee Computer Store 4710 W. North Ave. Milwaukee, WI 53208 (414) 445-4280

WASHINGTON, D.C.

Georgetown Computer Emporium 3286 M Street NW Washington, D.C. 20007 (202) 337-6545

CANADA

The Computer Circuit Ltd. 737 Richmond Street London, Ontario N6A 3H2 (519) 672-9370

Computer Mart Ltd. 1543 Bayview Ave. Toronto, Ontario M4G 3B5 (416) 484-9708

Basic Computer Group Ltd. 1548 West 8th Ave. Vancouver, B.C. V6J 4R8 (604) 736-7474

ARGENTINA

Basis Sistemas Digitales Colombres 849-1-A 1218 Buenos Aires 93-1988 or 57-7177

AUSTRALIA

Automation Statham Pty. Ltd. 47 Birch Street Bankstown 2200 Sydney (02) 709.4144

BELGIUM

S.P.R.L. Finncontact Square Larousse, 5 1060 Bruxelles 2/345-98-95

COLOMBIA

Video National Diagonal 34 N. 5-62 Apartado Aeree 27499 Bogota 326650

GREECE

Attikos, Inc. 41 Char. Tricoupi T.T. 145 Athens 3604091

JAPAN

Japan Personal Computers, Ltd. Yamamoto Bldg. 11-18 2-Chome Yoyogi, Shibuyaku Tokyo 151 (03) 375-5078

MEXICO

Industrias Digitales S.A. de C.V. Plateros 19, D.F. Mexico (905) 524-5132

PHILIPPINES

Integrated Computer Systems, Inc. Suite 118 LIM KET KAI Bldg. Ortigas Avenue San Juan, Metro Manila 3113

SWEDEN

Wernor Elektronix Torsvagen 61 Box 72 S-133 01 Saltsjobaden Stockholm (0) 8 717-62-88

UNITED KINGDOM

Comart, Ltd. 24A Market Square St. Neots, Cambridgeshire Huntingdon, PE19 2AF England (0480) 74356

VENEZUELA

Componentes Y Circuitos Electronicos Ttlca Ave. Fco.de Miranda Res. Concordia-Local 4 Los Ruices, Caracas 101 355591

ProcessorTechnolog,

THE PERSONAL COMPUTER RETAILER

Vol.2 No.9

Published by Processor Technology Corporation September 7, 1978 7100 Johnson Industrial Drive, Pleasanton, CA 94566

Word processing debuts in Philadelphia

Processor Technology's new Word Processing software was greeted with enthusiasm by dealers at the Philadelphia Personal Computer show August 24-27.

Our first business application package uses PTDOS in a Sol System III with a Diablo printer. Basic Computer Group Ltd. of Vancouver, B.C., developed and has already installed the Word Processing system in a number of legal offices in the Vancouver area.

According to Brian Bristow, owner of Basic Computer Group, complete installation and training of operators can be accomplished in two weeks. His customers have found that the system actually improves morale in an office. Secretaries compete for time at the machine. The Sol is particularly popular because it makes less noise than an electric typewriter.

Installation, operator training and maintenance service are an integral part of Basic Computer Group's sales package. In most cases they repair or replace down equipment within four hours. (Continued on page 3)



Rita & Larry Johnson (Microproducts and Systems, Kingsport, TN) discuss the new Word Processing system with Dottie Wanat (seated) at the Philadelphia Personal Computing show................see story page 1

Inventory flooring announced

Fifty dealers packed into our breakfast seminar held Friday morning August 25 in conjunction with the Philadelphia Personal Computing show. The star presentation came from Paul Cottone of FinanceAmerica who explained the details of our new retail inventory flooring program.

Offering up to 90-day financing on all purchases from Processor Technology Corporation, this program will free qualified dealers to schedule deliveries based on current need rather than cash flow considerations. (Continued on page 5)



You want it when?!

<u>Item</u>

Shipment Begins

Change

8080 CHESS cassette

week of September 18

moved back 3 weeks

GAMEPAC 2

week of September 11

moved back 2 weeks

DEBUG

week of September 18

moved back 2 weeks



Meanwhile, back in Pleasanton...

I'm filling in for Dottie on this issue while she has all the fun in Philadelphia. It's sure been quiet in the Advertising Department since she left.

In addition to listening for the phone to ring with news about the show, we've been trying to get some work done here. Bob Marsh and Connie Hawkinson have hammered out the details for next quarter's order packet which includes a number of product changes.

Linda Allen has been organizing all the administrative details for the "Christmas in Hawaii" sales contest. She tells me that only 18 people have signed up so far. I'd say that gives them good odds for getting one of the twelve prizes. So if you want to be a winner, SIGN UP.

Linda Bilbrey tells me that Warranty Repair has borrowed techs from the production department to speed up the process of reducing the backlog. She would also like to remind you that after August 31 we will no longer accept any equipment returned for repair or for credit without an R.A. (return authorization).

Here in the advertising department, I'm working on a new ad,
the latest in our series featuring
successful Sol dealers for COMPUTER DEALER and COMPUTER RETAILING. In this one, Larry Stein
(Computer Mart of New Jersey)
talks about his approach to the
business customer.

So, that's the latest.

--Elizabeth Fairchild

Whodunnit

Editor.....Dottie Wanat

Stand-in Editor.....Elizabeth
Fairchild

Graphics.....Lois Esser
Ray Oleson

Photography...Brett Bullington

General Input.Connie Hawkinson
Edith Reisner
Terry Walters
Drew Rogge
Rick Meyer
Ellwood Douglas

Copyright © 1978,
Processor Technology Corporation.
All rights reserved.

Word processing debuts...

(Continued from page 1)
The most impressive feature of the Word Processing software, according to dealers who saw it in Philadelphia, is the ability to edit one document on the screen while the printer is putting out another document at 45 characters per second.

Text can be typed in at high speed since carriage returns are

Co-op ads hard at work

Two dealers have submitted co-op ads that are running successfully.

Bob Vipond (Computer Magic) has written and produced a first-rate radio commercial about Sol Systems to run on a local Modesto, California station. He says that store traffic has doubled as a result of the ad.

Hal and Harriet Shair (Computer Corner) ran the "Play a little Sol Music" ad in the business section of nine papers in West-chester County on Sunday, August 27. By Tuesday, Harriet reported that the ad was pulling more responses than any they had run previously in newspapers.

Due to the newspaper strike in New York City, the Westchester papers have tripled their circulation giving the ad extra exposure. Many people were calling and coming in who had not been aware of the Computer Corner before.

She added that the piano image has not created any confusion for her readers who were mostly business people looking for a business system.

added by the software. Automatic justification creates an even right margin, or the text can be left ragged right. Since all formatting is done on the screen, lines of text will be printed exactly as they appear. Several modes of cursor control and scrolling allow rapid access to any position of the document.


Commands which affect format (headings, footings, character and line spacing, top and bottom margins, and widow elimination) can be imbedded in the document for dynamic control of the printed output. Non-printing comments can also be added.

With only a small portion of the document in memory at one time, a given document can be up to 110 pages in length. Disk access is handled automatically as the document is scrolled or edited. In the event of a power failure or crash, the file structure remains intact, and only a small segment of text is lost. Up to 20 different documents totalling 110 pages can be on one diskette.

Another useful feature is that the software permits line length up to 128 characters wide. The 64-character width on the video monitor is expanded by sideways scrolling commands which allow the operator to see what is on the right side of the copy.

Two letter quality printers and one dot matrix printer will be available from Processor Technology beginning November 15.

Details on price and availability of the Word Processing software will be announced soon.



New software introduced by Processor Technology this quarter includes two new video games called GAMEPAC 2. There's also three development programs on cassette which are modifications of portions of our PTDOS disk operating system. These three programs may be used in combination to create or modify large programs in a minimum amount of memory.

GAMEPAC 2

HANGMAN is an entertaining game that keeps children of all ages amused for hours. The program comes with a word list which you can add to or alter.

In addition to entertainment, HANGMAN is useful for teachers to make learning spelling, foreign language or any specialized terminology fun for students.

QUBIC is very much like a three-dimensional tic-tac-toe with a playing grid of 4 by 4 locations on 4 levels with 76 ways to win. You can play either with another player or against the computer. Rumor has it that the program sometimes cheats when the computer is about to lose.

EDIT

EDIT is a cassette based editor similar to EDT 3.0 on the PTDOS system disk. It allows you to create or alter source programs in a form usable by Cassette FORTRAN, ASSM, or Extended Cassette BASIC.

Editing may be done on character, string, line and page levels. At any of these levels additions, insertions, substitutions and deletions of text may be made. Additionally, EDIT offers the

option to retain a command string as a macro and execute it repeatedly.

The EDIT program itself resides in low memory and requires approximately 4K.

When you use EDIT, you will most likely be using two cassette recorders, reading from one and writing to the other. EDIT saves and loads text as a multiple-block file on cassette.

DEBUG

DEBUG is an aid for debugging a (Continued on page 5)

technical stuff

For those of you who missed the technical seminars where our new family of dynamic RAM memory modules were introduced, here's some details:

The 16KRA-1, 32KRA-1, 48KRA-1 and 64KRA-1 utilize either 8K or 16K dynamic RAM's. These new boards are designed to maximize reliability and to optimize manufacturing flexibility. Entirely new rigorous QC tests and procedures are being used to guarantee high reliability.

The boards are totally synchronous with the S-100 bus "Phase 2" signal and have access times of 400 nsec worst case. Address is switch-selectable in four blocks.

A variety of options for Extended Memory Address make the board very flexible through use of memory "Bank Select" techniques.

The 32KRA-1 version of the new design has already been shipped in Sol System III's and IV's. The 16, 48 and 64K versions will be on their way in September and October.



(Continued from page 4)
machine language program developed and assembled on a Sol or
other 8080 computer system with
CUTER. With this program, you
can set as many as fifteen "breakpoints" in a program you want to
debug or examine. It is capable
of dumping memory in hexidecimal,
ASCII or instruction modes.

When a program is executed under the control of DEBUG, it will stop at each of these addresses so that CPU registers, flags, and specified memory locations may be examined and modified. You can resume execution at a breakpoint or other specified memory location after making modifications. At the conclusion of debugging, you can save the modified version of your program.

There are five versions of the DEBUG program on the cassette tape. Each resides at a different memory location. Each occupies 4½K.

ASSM

The ASSM program on cassette tape translates symbolic 8080 assembly language source code into object code. It is designed for use with the Sol or other 8080 machine using CUTER. The assembler itself occupies almost 8K of memory. Additional memory is required for the symbol table and user program. Two cassette recorders are used.

Two other programs are recorded on the tape, PACK and UNPAC. These programs convert a cassette file from single-block format to multiple-block format and vice versa.

DELIVERY

ASSM and EDIT have already been shipped to dealers. GAMEPAC 2 is scheduled for shipment during the week of September 11; DEBUG during the week of September 18.


Flooring announced...

(Continued from page 1)
FinanceAmerica is a subsidiary
of the Bank of America, the
world's largest bank.

The flooring program will go into effect on October 1 with Fall Quarter scheduled orders and will be administered from the factory.

At the same time, Processor Technology is now able to extend its regular Net 15 terms to Net 30 for dealers who qualify.

Also on the program for this byinvitation-only seminar was a
presentation by Loren Willey,
our Retail Marketing Manager,
with ideas for successful instore merchandising. Dottie
Wanat from our Advertising Department offered guidelines for
developing your own ad campaign
and utilizing the co-op advertising funds effectively.



Don't miss out. The "Christmas in Hawaii" sales contest is on. Register today. Full details available from Linda Allen in the Dealer Sales department at the factory.

Quality control tightens up

New and more rigorous test procedures will be reflected in the quality of Sol, Helios and memory board products we are now shipping. These higher standards are geared to the requirements of the small business system market.

We are testing all Sol Systems III and IV as complete systems after the individual units pass final tests. This system test procedure, in effect for the past two months, has already resulted in improved reliability in the field.

All incoming parts are now screened before they are put into stock. Critical components such as the 8080A are individually tested.

In addition to regular test procedures during construction, all Sol's must now pass a final 15-hour monitored test with no errors before shipment.


Our new family of dynamic RAM memory boards (16KRA-1, 32KRA-1, 48KRA-1, and 64KRA-1) must pass a 48-hour burn-in and rigorous test procedure before shipment. The test software isolates specific RAM chips that malfunction as well as the total number of errors during the entire test period. "Good" boards must have no errors. In-house experience indicates that these new boards are equal in reliabilty to our well known static boards, the 8KRA and 4KRA.

The same rigorous tests used for the new memory boards will also apply to the original 16KRA. This board has been the focus of a recent quality assurance task force which proposed some specific modifications to improve operation in the field.

As a further measure, Warranty Repair is running all 16KRA boards

through the production tests before returning them to the dealers. According to Technical Support Manager Mike Mills, 200 16KRA's have passed through his department for repair in the past two months. Only three have come back a second time. And those three had mechanical problems rather than component or electronic failures.

Our highest priority is now focused on reducing any backlog of dealer equipment in our Warranty Repair Department and restoring a 5-day turnaround time.



LOOK, MA, NO KNOBS! Beginning October 1, our video monitors will have an attractive front panel eliminating the channel select and volume control knobs.

New 64KRA-1 goes to New Jersey

Alice Golembo of the Computer Mart of New Jersey won the door-prize at our open house held Thursday night, August 24, at the Philadelphia Hilton Hotel. Her prize-the new 64KRA-1 memory module. Her husband, Eri Golembo, the store's Administrative Director, says they will probably use the board in a Sol-20 they may buy through the salesperson's purchase plan.

WordWizard Electronic Typing System from Processor Technology

ng the speed and efficiency of the newest technology our office without breaking your budget



Handle your typing load faster and more accurately.

Electronic typing used to be expensive... \$20,000 and up for a typical word processing machine. Only large corporations and government agencies could afford these advanced systems with all the professional features.

Now. Processor Technology drastically cuts the cost of electronic typing to give big company typing power to even the smallest office. Here's how our WordWizard system works to cut your paperwork costs:

Your typist can type from dictation at top speed without stopping to check for errors. There's no need even to gauge the end of a line for the carriage return because WordWizard automatically moves to the next line.

Proofreading and corrections are done on the screen before anything goes down on paper. Change spelling, add or delete words, and move sentences or whole paragraphs with a few keystrokes. Once you have a good draft, the printer produces a single, double or triple spaced copy in minutes. WordWizard memorizes the original draft and stores it on a WordWizard diskette.

After you've reviewed the document and marked your additions or corrections, your typist can display the draft on the screen and enter your changes electronically. No retyping is necessary. Only the changes. WordWizard automatically makes room to add sentences or paragraphs and closes up space where you've made deletions.

If a word or phrase needs changing anywhere in the document, a simple operation called Global Search & Replace will locate every occurrence of the word or phrase and correct it in seconds.

When the document is complete, the SolPrinter will produce a copy at 480 wpm with single or double spacing, with even right-hand margins, or with bold headings. In minutes, you'll have a perfect, professional-looking report or letter without a single visible correction. Your secretary will be delighted to see an end to constant retyping.

One more thing. While the printer is running, your typist can work on the next project at the screen. No waiting for the printer to finish.

Your WordWizard electronic typing system pays for itself fast. You'll wonder how you ever did without it.

Attorneys and accountants say WordWizard is particularly cost effective.

Legal offices have been among the first to use WordWizard. Legal documents must be absolutely error-free and frequently contain standard paragraphs used over and over again. Such paragraph are stored on diskettes and later called up by number or name. Your current numbering system for standard paragraphs will, in most cases, adapt to WordWizard without modification. Clerical time to produce wills and contracts can be cut drastically.

Accountants appreciate WordWizard's ability to type copy up to 128 characters wide. You can view half of a wide page at once on the screen. By using the horizontal scroll, you can move the image left or right to view the entire page.

A WordWizard feature especially useful in sales and customer service offices is its ability to type many original versions of a letter for different individuals quickly. Your mailing list is stored on a diskette which can be easily updated. To type a group of letters, call up the list on the screen, or any part of it. For example, you may want to write to customers in a particular zipcode area who own just one of your products. Then, the list or any part of it can be merged with the letter you want to send. A secretary who used to type 25 sales letters in a day now can do 200.

Accountants, medical offices and many other businesses take advantage of WordWizard's speedy form completion. As your secretary fills in a form, the system remembers the next space and jumps there directly with two keystrokes.

So easy to learn you can begin to use it with just a few minutes of instruction.

You don't have to be a technical genius to use WordWizard. Unlike many systems that require memorizing special "codes," WordWizard includes a set of keyboard labels to mark all the editing keys. Use two keystrokes to set a tab. jump to the beginning of the document, delete a line, close up a space, and so forth. WordWizard frequently prompts the operator with easy to understand, ordinary language instructions.

The manual is straightforward with special hands-on exercises to speed learning. It's comprehensive with complete descriptions of all the special functions.

Your typist can start typing electronically right away without worrying about setting margins or making other formatting decisions. WordWizard has useful standard values for an 8½ x 11 page which take over automatically if you don't ask for a special format.

Design your own text format on the screen just as it will be printed.

When you do want a special page arrangement, WordWizard will show your instructions right on the screen. You can change the margins in the middle of a document, switch from double to single spacing, or ask for a header or footer of one or more lines to appear at the top or bottom of each page. You can create an even (justified) right-hand margin, develop a new form or reorganize a group of pages. Such changes appear on the screen as they will look on paper. No guesswork. WordWizard makes it all so easy.

Enter or retrieve up to 110 pages on each diskette.

Each diskette has an alphabetized index that appears on the screen when the disk is inserted. From this index you can locate documents, destroy documents and create new ones. As you make changes, the index is updated automatically. An erasure doublecheck prevents accidental deletion.

You can copy a document from one diskette to another quickly and easily. It's easy to make a duplicate or backup of all your most important documents to keep in an accident-proof location.

In addition to the WordWizard System Diskette, you get one Document Diskette which stores up to 20 different documents totalling as much as 110 pages. The diskette can be reused almost indefinitely. Because the system uses inexpensive, standard diskettes, additional supplies are readily available.

Three optional SolPrinters to choose from.

You can choose a letter-quality SolPrinter 2 with metal print wheel, an economy model SolPrinter 2E with plastic print wheel, or a draft-quality SolPrinter 3 with very fast dot matrix printing.

The SolPrinter 2 prints up to 480 wpm. It's rugged, long-lasting metal print element is the "Daisy Wheel" type. Several interchangeable typefaces are available to work with either carbon or cloth ribbons. The quality of the printed copy is equal to the output of the finest electric typewriter. An economy version, the SolPrinter 2E, uses plastic print wheels.

The much faster SolPrinter 3 prints up to 2400 wpm. Each character pattern of dots is called a dot matrix. This output copy is ideally suited to rough drafts, memos, and in-house documents.

The most efficient installation includes two printers — one Daisy Wheel machine for highest quality letters, reports or reproduction copy, and a dot matrix unit for rapid turnaround of drafts. Alternate between the two printers with a few strokes from the keyboard.



Programmability keeps your system up to date.

WordWizard electronic typing programs work with Processor Technology's multi-purpose small computer systems. The Sol Systems III and IV give you all the power of high-priced word processing machines plus the capability of programming for a wide range of business tasks.

As improvements and new features become available for WordWizard you take advantage of them simply by purchasing new System Diskettes. Many different business and accounting applications packages are available from your Sol Systems dealer. More are on the way. Because WordWizard and the Sol System are totally programmable, your system will stay up to date.

At the outset, you get two machines for the price of one — a full capability word processor and a general purpose business computer — for less than you would expect to pay for either one. Your office can take advantage of new, time- and money-saving programs to keep books, send invoices, manage inventory, or provide you with valuable management reports. All without the need for major additional capital investment. As time goes on, you'll be glad you planned for the future.

See your nearby Processor Technology dealer today and ask for a demonstration.

Compare the features. Then compare the price!

Enter up to 110 text pages per diskette.

- Store up to 20 different documents on each diskette
- Identify each document with any name or number
- Unlimited document storage on inexpensive diskettes
- · Duplicate or format diskettes rapidly
- Select from menus on screen no need to learn complex command codes
- Handle common operator mistakes with easy to understand instructions from the screen
- Alphabetized document index is continuously updated and displayed
- 64 character by 16 line video display
- Horizontal scrolling lets you compose and view lines up to 128 characters long
- · Adjustable left and right margins
- Automatic margin readjustment by paragraph
- · Unlimited adjustable tab stops
- Automatic carriage return, word wraparound, and justification with manual hyphenation
- Easy merging of frequently used phrases, paragraphs and mailing lists
- All documents may include comments which appear on the screen but not on the printout

Changes and corrections are easy with these editing features.

- · Easy insertion. deletion or alteration of text
- Removable keyboard labels define edit keys no need to memorize "edit codes"
- Instant positioning of cursor to start or end of document
- Automatic scrolling horizontal or vertical, forward or reverse
- Single step or continuous cursor movement in four directions. home cursor, and jump to screen edges
- Automatic search and selective replacement of words, phrases, format statements or comments (Global Search & Replace)
- · Copy. move or delete in blocks of up to 16 lines

- Merge standard paragraphs into any document
- · Easy merging of mailing lists with letters
- Merge and assembly text can be organized in special library documents

Design your text format right on the screen.

- Margins, indents and justification appear on the screen as they will be printed
- Embedded format control statements are displayed on the screen
- Store many standard text formats to maintain document consistency
- Optional headers and footers on each page versatile location and multiple lines
- Automatic pagination divides long documents into separate pages with forced page breaks and widow elimination
- Automatic page numbering from 0 to 99 beginning with any number anywhere in the document

Print one document at up to 2400 wpm while editing another on the screen.

- Three optional SolPrinters with speeds of 480 wpm (letter quality) to 2400 wpm (draft quality)
- Bidirectional printing
- · Adjustable character and line spacing
- Boldface through multiple overstrike
- Underscore capability
- Copy up to 128 characters wide
- Quick printer selection for multiple-printer installations
- Printing options for skipping pages, page stops, and printing embedded statements or comments

Protect your confidential reports and documents.

- Lock and key power switch prevents unauthorized system use
- Erasure doublecheck protects documents from accidental deletion
- Continual transfer of the document to the diskette prevents loss of all but a small portion in case of power failure
- ASCII communications capability with special programming

Specifications subject to change without notice

DOCUMENT ACTIVITIES

Create (start new document) Remove (erase a document)

Select Merge (select a merge document)

Print

Stop Printing

Eject Page (paper feed)

Archive (copy document to System Disk) Retrieve (copy archive document to

Document Disk

EDIT KEY FUNCTIONS

Cursor Control (up. down. right, left, or home) Cursor to Edge of Screen (four directions)

Repeat (character or cursor)
Return (forced end of paragraph)

Left Right Margin Set Release
Tab Set Clear
Jump to Start End (of document)
Justify On Off
Search
Continue Search
Replace
Continue Replace
Copy Block
Move Block
Insert Block
Delete Line

Insert Split

Close Paragraph

Call Merge Reserve Blanks (through justification process) Escape (go from editing to Document Activity menu)

FORMAT STATEMENTS

Pitch (horizontal space per character)
Vertical (spacing per line)
Spacing (double, triple, other multiples)
Define Form Length
Lines Per Page
Title (running header)
Footer (running footer)
Header Lines (header = margin)
Bottom Lines (footer = margin)
Number (set or reset page number)
Eject (force new page to start)
Widow (keep lines together on page)


Under (underline, boldface, overstrike)

ProcessorTechnology

7100 Johnson Drive, Pleasanton, CA 94566 (415) 829-2600


Sol® SYSTEM SUGGESTED U.S. RETAIL PRICE LIST


Sol	TERMINAL COMPUTER and Sol SYSTEMS		Order No.	Price (\$US)
1.	Sol-20/16 Terminal Computer with SOLOS personality			
	module and 16,384 bytes of memory, includes			
	Extended Cassette BASIC and Sol System manual	Factory Assembled/Tested	400500	\$2095
2.	Sol-20/32 Terminal Computer with SOLOS personality			
	module and 32,768 bytes of memory, includes			
	Extended Cassette BASIC and Sol System manual	Factory Assembled/Tested	400600	\$2395
3.	Sol System I-A includes Sol-20/16 with 16,384			
	byte memory and SOLOS module, PT-872 video			
	monitor, RQ-413A cassette recorder, Extended			
	Cassette BASIC, cables and Sol System manual	Factory Assembled/Tested	400700	\$2495
4.	Sol System II-A includes Sol-20/32 with 32,768			
	byte memory and SOLOS module, PT-872 video			
	monitor, RQ-413A cassette recorder, Extended			
	Cassette BASIC, cables and Sol System manual	Factory Assembled/Tested	400800	\$2795
5.	Sol System III-A includes Sol-20 with 65,536			
	bytes of memory and BOOTLOAD module, Helios II			
	Model 2 Dual Disk System with Extended Disk			
	BASIC, PT-872 video monitor, cables and Sol			
	System manual	Factory Assembled/Tested	400310	\$6495
6.	Sol System IV-A includes Sol-20 with 65,536			
	bytes of memory and BOOTLOAD personality			
	module, Helios II Model 4 Quad Disk System (two			
	dual drives) with Extended Disk BASIC, PT-872			
	video monitor, cables and Sol System manual	Factory Assembled/Tested	400350	\$8750




Sol System III-A

H	ELIOS DISK MEMORY SYSTEMS		Order No.	Price (\$US)
1.	Helios II, Model 2 Dual Disk System includes dual PerSci 270 floppy disk drive, cabinet, fan, S-100 bus compatible controller, power supply, and system diskette with complete PTDOS software and Extended Disk BASIC	Factory Assembled/Tested	300000	\$3195
2.	Helios II, Model 4 Quad Disk System includes two dual PerSci 270 floppy disk drives, cabinet, fan, S-100 bus compatible controller, power supply, and system diskette with complete PTDOS software and Extended Disk BASIC	Factory Assembled/Tested	304000	\$5395







SolPrinter


1.	SolPrinter ® 2, Word Processing Printer includes			
	Xerox/Diablo Model 1355WP printer mechanism,			
	high-quality metal print wheel in Titan 10 font, carbon			
	film ribbon, RO cover, power supply, friction platen,			
	paper out, cover open and ribbon out detect options,			
	and Sol-HyType interface installed with connecting cable for Sol-20 parallel port	Assembled/Tested	910010	\$3695
)	SolPrinter ® 2-E, Economy Printer includes Xerox/	Maaciiibicu/ i catcu	310010	00000
•	Diablo Model 1345A print mechanism, economical			
	plastic print wheel in Courier 10 font, carbon film			
	ribbon, power supply, friction platen, RO cover, paper			
	out, cover open and ribbon out detect options,			
	Sol-HyType interface installed with connecting cable			
	for Sol-20 parallel port	Assembled/Tested	910020	\$3395
3.	SolPrinter [®] 3, High speed 200 cps dot matrix printer			
	with RS-232 serial interface (up to 9600 Baud), power			
	supply, RO cover, friction platen, paper out, ribbon			
	out and cover open detect options with connecting cable for Sol-20 serial port. Includes forms tractor	Assembled/Tested	910030	S3695
1	Forms Tractor for SolPrinter 2 and 2-E (SolPrinter 3	Assembled/Tested	310000	
٧.	includes forms tractor)		910100	\$250

S	STEM ACCESSORIES		Order No.	Price (\$US)
1.	16KRA-1 Memory Module with 16,384 bytes of Dynamic RAM	Factory Assembled/Tested	214010	\$ 429
2.	32KRA-1 Memory Module with 32,768 bytes of Dynamic RAM	Factory Assembled/Tested	214020	\$750
3.	48KRA-1 Memory Module with 49,152 bytes of Dynamic RAM (available November 1, 1978)	Factory Assembled/Tested	214030	\$1095
4.	64KRA-1 Memory Module with 65,536 bytes of Dynamic RAM (available November 1, 1978)	Factory Assembled/Tested	214040	\$1350
5.	GPM-Sol, General Purpose Memory Module	Factory Assembled/Tested Kit	210000-03 210000-04	\$129 \$99
6.	ALS-8 ROM Resident Assembly Language Operating System with Interpretative Simulator (SIM-1) and Text Editor (TXT-2). For use with GPM-Sol. If purchased together, price includes			
	assembly and testing. (ALS-8, SIM-1, and TXT-2 programs are copyrighted.)	Factory Assembled/Tested or Kit	900014	\$90



Sol System I-A

MI	SCELLANEOUS			1117
1.	Sol-PC Single Board Computer with SOLOS personality module	Factory Assembled/Tested Kit	101036-01 101036-02	\$745 \$575
2.	PM 2708 Personality Module without EPROMs	Factory Assembled/Tested Kit	107000-01 107000-03	\$40 \$30
3.	SOLOS Personality Module	Factory Assembled/Tested Kit	107000-02 107000-04	\$90 \$75
4.	BOOTLOAD Personality Module	Factory Assembled/Tested	107015	\$100
5.	220/240 Volt Transformer for all Sol-20 series units	Kit	105034	\$50
	Note: All Sol-20 series units and Sol Systems are available for Contact factory for pricing and delivery information.	220 Volt, 50Hz operation.		
6.	WWB Wirewrap Prototyping Module	Kit	211000-02	\$40
7.	Helios II Upgrade Option provides all necessary hardware to upgrade Model 2 Helios Disk Systems to Model 4 including additional dual drive, front bezel, fan, cables and power supply. (Must be installed by factory.)	Installation	304100	\$2295
8.	Sol Systems Technical Manual		730000	\$25
9.	Helios II and PTDOS Technical Manual		730009	\$50



This video game is included with GAMEPAC 1









Extended BASIC is available in both disk and cassette versions.

		Minimum Memory		
SO	FTWARE (including manual)	Required**	Order No.	Price (SUS)
1.	Extended Cassette BASIC	16K	727017	\$45.00
2.	BASIC/5 cassette	10K	727000	\$19.50
3.	New 8080 FOCAL* cassette	10K	727024	\$19.50
4.	TREK 80 Video Game cassette	8K	727009	\$19.50
5.	GAMEPAC 1 Video Games cassette	4K	72700 6	\$19.50
6.	GAMEPAC 2 Video Games cassette	4K	727160	\$19.50
7.	Software#1 Resident 8080 Assembler cassette	6K	727022	\$19.50
8.	ALS-8 Resident Assembler, Simulator and Text Editor cassette	12K	727012	\$45.00
9.	Extended Disk BASIC	32 K	727036	\$95.00
10.	PTDOS 1.4 System Disk (replacement)	32 K	727030	\$95.00
11.	Extended Disk FORTRAN	32 K	727100	\$95.00
12.	Cassette PILOT	16K	727110	\$24.50
13.	8080 CHESS cassette (available soon)	16K	727150	\$19.50
14.	ASSM, Advanced 8080 Assembler cassette	10K	727120	\$19.50
15.	DEBUG, 8080 Cassette Debugger	8K	727130	\$19.50
16.	EDIT, Advanced 8080 Editor cassette	8 K	727140	\$19.50

^{*} Registered trademark of Digital Equipment Corporation.

Note:

A SOLOS or CUTER monitor program is necessary to load and run cassette software products.

All Processor Technology software is distributed through authorized dealers or on an individual basis for personal use. Each software package has been copyrighted by Processor Technology and all rights therein are reserved. No license to copy or duplicate is granted with distribution or subsequent resale.

Prices and specifications are subject to change without notice. Prices are in U.S. dollars, apply in U.S.A. only and may be slightly higher elsewhere.

^{**}If cassette CUTER is used, an additional 3K of memory is necessary.

ProcessorTechnology

1 EPT 1 - 109

Processor Technology Corporation 7100 Johnson Industrial Drive Pleasanton, CA 94566 (415) 829-2600 Cable Address PROCTEC

October 12, 1978

Dear Retailer:

Due to temporary circumstances, I have suspended publication of the Personal Computer Retailer for a short period of time. A regular publication schedule will begin again soon.

In the meantime, here is some information you should know about right away!

I. Changes In The Marketing Department . .

Our Marketing Department has been reorganized to improve its responsiveness to your needs. The following changes are effective as of October 10.

SALES DEPARTMENT

Loren Willey has been appointed Sales Manager, National and International Accounts. He will continue to manage all existing dealer accounts as well as established O.E.M. and international accounts.

Ralph Palsson becomes the Sales Manager for all new national and international accounts and will be working to develop new accounts in the retail, O.E.M., and international markets.

Brett Bullington and Debby Oester are our new Sales Representatives and as such will be handling all of your needs at the factory. Contact either one of them regarding the status of your account, orders, shipping information, etc.

SALES ADMINISTRATION DEPARTMENT

Comile Hawkinson becomes Manager of our newly formed Sales Administration Department. Connie will be in charge of co-ordinating a gamut of internal sales support functions,

ADVERTISING DEPARTMENT

Dottie Wanat is the new Advertising Manager and Sally Turner replaces Dottie as Advertising Assistant.

Elizabeth Fairchild moves from Advertising into a staff position in Marketing.

CUSTOMER SERVICE DEPARTMENT remains unchanged. Continue to contact: Diane Ascher for Return Authorization requests and Linda Bilbrey for Warranty Repair and parts requests.

TECHNICAL SUPPORT also remains unchanged as do technicians' hours.

Processor Technology Corporation

Page Two . . .

II. The CORONA...Color Graphics Board Announced . . .

You'll be getting inquiries shortly from your customers about the Processor Technology CORONA, IK color graphics board which is described in the cover story of the November issue of Popular Electronics magazine. I've attached a short article by Sally Turner which summarizes the Popular Electronics story in case you cannot get a copy.

The <u>Popular Electronics</u> story says that the product is still in development and will be available through computer stores in kit form for \$395. The CORONA is indeed still in the design/development stage. It is currently scheduled to begin production in February and begin shipment in April. That projection assumes no obstacles arise to slow up the schedule. We'll keep you informed as the shipping date becomes more firm.

Meanwhile, you can assure your customers that the product will not be available until next year and that no other store has it either. We are not accepting prepayment or preliminary orders.

We'll be sending you sales literature and additional marketing information when we are closer to delivery.

III. Toll Free Dealer Locator Hotline . . .

Beginning in October, prospective customers can find the dealers nearest them by calling our toll-free hotline. The line will be answered between 8 and 5 Pacific Standard Time on weekdays. A friendly voice will take the callers name and address and give the names and phone numbers of nearby dealers. The names and addresses of callers will then be referred to dealers for followup.

The hotline phone is not connected to our regular switchboard. Calls cannot be transferred to other factory telephones.

The hotline numbers, one for California and one for the rest of continental USA, will appear in Processor Technology's smaller ads such as the one in November Popular Electronics. These ads do not include enough space for a dealer list. We will continue listing dealers in BYTE and Creative Computing,

I've included reprints of two new black and white ads with this letter.

IV. YOU WANT IT WHEN!?

Item	Shipment Begins	Change
8080 Chess cassette	week of 10/23	moved back 4 weeks
GAMEPAC 2	shipment begun	
DEBUG	week of 10/9	moved back 4 weeks
Faceplate for video monitors	week of 10/16	
16KRA-1,32KRA-1 48KRA-1, 64KRA-1	shipment begun shipment begun	

Processor Technology Corporation

Page Three . . .

V. WordWizard SHOWN IN NEW YORK AND DALLAS . .

Our new word processing software package has been christened the Word-Wizard. It will retail for \$295 with a 50% Dealer discount. We should begin shipment in the next 30 days.

Diane Ascher from our Customer Service Department demonstrated the program at the New York Personal Computing show (Sept. 15-17) where she divided her time between three dealers' booths--Computer Mart of New Jersey, Computer Mart of New York, and the Computer Corner. Sales Rep. Debby Oester went to the Dallas show (Sept. 30-Oct. 1) where she presented the same demonstration at two dealer booths--Computer Port and Interactive Computers. (Debby, by the way, won a bottle of champagne for thinking up the name "WordWizard.")

Overall, supporting dealers at shows in this way seems to be very successful both for us and for you. We plan to do more of this in the future.

VI. NKRA . . .

Within the next week you will be receiving update information on the new NKRAs (16KRA-1, 32KRA-1, 48KRA-1 and 64KRA-1) which will enable you to make them compatible with all S-100 bus computer.

CHRISTMAS IN HAWAII . . .

Don't forget to keep sending in your sales verification forms for the "Christmas in Hawaii" contest. Thirty-nine salespeople have signed up so far.

Best regards.

Dottie Wanat

ADVERTISING DEPARTMENT

CORONA: Color Graphics is Coming

by Sally Turner

The November <u>Popular Electronics</u> will feature a cover story about Processor Technology's innovative high resolution <u>full color graphics</u> accessory for microcomputers. The CORONA System is a graphic display memory capable of providing 256 different colors in a 256-by-256 display with both graphics and alphanumerics. These are mixed and overlaid to interleave graphic and. text information anywhere desired on the screen.

CORONA is fully bus compatible with the So1-20 microcomputer and VDM-1 video display module but can be modified to fit other S-100 bus formats. It operates both for color-picture storage or conventional black and white computer memory (256 shades of grey).

The CORONA's circuitry mounts on three printed circuit boards. Two boards plug directly into the S-100 bus of the computer. In Sol, only one slot, the "top slot", is needed. The third board is packaged externally with the analog circuitry and video connectors.

Memory access by the computer is handled in one of two modes: "bit mode", which simplifies interfacing with BASIC and FORTRAN, and allows direct access to individual points on the screen; and "byte mode" used for high speed data transfers from the CPU to the CORONA. Its color-video encoder transforms the red, green, blue and luminance data from the color map into NTSC or RGB color signals.

In addition to opening new visual frontiers for video games, CORONA is a powerful tool for business, artistic, scientific and educational applications. Full animation, vivid graphics, and poster-like displays can transform any presentation into a colorful multi-media event.

Many of your customers will undoubtedly be interested in this dynamic new product.

THE PERSONAL COMPUTER RETAILER

Vol.2 No.10

Published by Processor Technology Corporation 7100 Johnson Drive, Pleasanton, CA 94566 November 20, 1978

Portland attorneys view WordWizard

Byte Shop of Portland introduced three new systems to an invited group of 130 attorneys and accountants at a special show on November 7. Debby Oester from our Sales Department represented Processor Technology with a demonstration of the WordWizard Electronic Typing System.

WordWizard--Star of the Show

WordWizard turned out to be the star of the show. According to Debby, some of the guests already owned word processing systems from companies like Vydec, Word-Stream and Lexitron. They were very impressed with the capabilities of WordWizard compared to these more expensive systems. They also liked the flexibility of the Sol System for many other business applications.

The show was held in a banquet room of the Travel Lodge Inn from 10 in the morning to 7 at night. A hostess/receptionist greeted all prospective customers at the door. She made name tags and invited the guests to sign the register. Three systems were in operation with Debby and two Byte Shop salespeople always on hand to make presentations.



Marketing Staff looks on as Debby Oester demonstrates WordWizard.

Who's Who in the Marketing Dept.
Back Row, L to R: Bob Marsh,
Bob Groppo, John Chong,
Loren Willey, Don Regaller,
Brett Bullington, Liz Fairchild, Dee Wunderlich, Mike
Mills, Ralph Palsson
Front Row, L to R: Sally Turner,
Freddie Jacobowitz, Denise
Faria, Dottie Wanat, Linda
Bilbrey, Connie Hawkinson,
Diane Ascher and Debby Oester

Pat Terrell, co-owner of the store, was more than pleased with the successful event. He expects four to six word processing system sales to result directly from the show. His Seattle store will host a similar show very soon. He also plans variations on the show for insurance people and doctors.

Asked what he will do differently at the Seattle show, Pat said he wants to handle the people more efficiently. "Frequently there (Continued on page 5)



You want it when?!

Item 8080 CHESS Cassette DEBUG Faceplate for video

monitors

SolPrinters 2 and 3

WordWizard

Shipment Begins

Shipment begun

Week of November 27

Shipment begun

Week of November 27

Week of December 4

Change

Moved back 7 weeks



FinanceAmerica user happy with service

by Sally Turner To get more information about the FinanceAmerica flooring program, I contacted a local appliance store owner who uses it.

Frank Lozano of Frank's TV & Appliances in Pleasanton told me, "No other finance company has ever

Whodunnit

Editor.....Dottie Wanat Stand-in Editor...Sally Turner Assistant Stand-in Editor....Elizabeth Fairchild Graphics.....Lois Esser Ray Oleson

General Input....Diane Ascher Connie Hawkinson Rick Meyer Terry Walters

Copyright © 1978, Processor Technology Corporation. All rights reserved.

served us so well. FinanceAmerica works WITH you. They eagerly pitch-in to help us with displays and special promotions."

Frank especially likes the flexibility of Finance America compared to other flooring companies. "They don't hold you to the bottom line," says Frank. "When we've needed extra merchandise for special occasions like Christmas, they stretch the budget to accomodate us."

When asked if he minded the monthly inventory check, Frank said, "Not at all. In fact, it's helped me keep my own books better. Besides, the benefits are so good, they far outweigh any disadvantages. All in all, the service offers more than I expected."

Frank generously consented to answer any questions you might have if you'd like to phone him at (415) 846-5505.

Selling Sol Systems to educators


by Ralph Palsson
As you are aware, microcomputers
are becoming increasingly popular
as an educational tool in schools
and universities at all levels.
Some estimates predict that 25%
of the dollars that will be spent
on small computers in the next
few years will come from the education segment.

How can you insure having a fair edge on this lucrative market? Virtually all public institutions purchase equipment on the basis of competitive bids. I'd like to discuss some aspects of bidding and a few points that will be helpful in winning contracts.

REGISTER YOUR PRODUCTS AND SERVICES

Many dealers shy away from proposing bids and contracts because of the red tape involved. I argue that this effort is worthwhile. Many times one winning bid will lead to the subsequent sale of scores of systems.

For bidding and contract proposals, the purchasing agencies in your locality must be aware of your products and services; so, you need to register with your state's (and neighboring state's) "Division of Purchasing" or the "Department of Education" in the state capitol. You will be sent an Application Form and Commodity Listing to indicate what products and services you're qualified to bid on. Needless to say, you also become eligible to bid on appropriate computer systems for other state agencies.



One form of bid you may receive is a Request for Quotation. Typically, RFQ will ask specific quote, delivery information, terms, etc. on an approved system. You are held to your submitted quote and may be issued a purchase order on the same document.

Another form you may encounter is a Request for Proposal; this is a contract proposal, used mainly for Multiple Systems Purchases and high-dollar volume potential, also for open number of systems over a given time period, e.g. one year.

SECRETS OF SUCCESSFUL BIDS

It is important to comply with the administrative requirements contained in bid specifications. For complicated proposals you might want to hire a professional contract writer. If you have specific questions on a proposal, phone me, I'll be glad to help you.

You can find out who your competition is and what they're offering from the bid-generating agency upon request. This will increase your chance of winning the contract.

I suggest you register with individual school districts and colleges. (Continued on page 4)

Selling Sol to educators

(Continued from page 3)
They frequently have the funds to make direct purchases.

It may take a while to close sales for schools because of limited budgets and fiscal years. But remember, once funds are allocated, they're almost never diverted to other uses, and educational institutions are virtually always "good" for the money.

Sol Systems are useful in educational applications in a variety of rolls from classroom to administrative. They're useful in computer aided instruction from mathematics to bilingual learning.

Because of Processor Technology's comprehensive and high quality product line, we expect to hold a large share of this market.

We're fully committed to supporting the education market and your place in it. So, let's work together for a profitable future.



Ralph Palsson, educational marketing specialist for Processor Technology, has been writing sucessful bids for two years.

COMING IN JANUARY

Customized sales lit kits

We believe pictures generate excitement which in turn sparks enthusiasm...an effect that snowballs when sales literature is used right. We want you to have the tools that enable you to make well planned sales presentations. So, we designed a colorful 4 page folder and an array of data sheets describing our products, which you'll receive in January. By adding your own store's literature, you can customize to meet individual needs.

In the past sales literature consisted of brochures aimed at technical users. The new data sheets address a broader audience, particularly the business user.

The first 3 data sheets will be sent to you in early December.

They consist of 2 pages on the nKRA memory boards, 4 pages on WordWizard electronic typing, 4 pages on Extended BASIC.

Our colorful 4 page folder will be a brochure explaining Processor Technology as a company; who we are, our history and our marketing intentions.

We'll continue to use the Sol and Helios brochures temporarily. The Helios brochure is being revised to include explanations and pictures of the Helios II model 4.

We developed this colorful set of materials to enable you to compliment and tie together sales promotion efforts. T TEI I - TI1

Attorneys view WordWizard

(Continued from page 1)
were almost twenty people in the
room at once, all trying to get
their questions answered. One
solution is to schedule demonstrations at definite times. Another
approach is to give a fairly short
formal demonstration, then qualify
the prospects for a followup
appointment with a complete demonstration later."

Store manager Tom Rich was responsible for most of the organization and planning of the show. He reported that total costs for the entire production were under \$600 including the room rental and all advertising costs.

Primary advertising for the show was 500 formal, printed invitations to attorneys in the Portland area. In addition, he ran a small ad in the local paper for three days before the show.

As Tom pointed out, "A turnout of 130 people was excellent. We could easily have had more systems with more salespeople demonstrating them. I think Pat's idea of scheduled presentations would be helpful. It's also important to have hands-on time so people can



Participants in the August Technical Seminars received this attractive certificate! see how easy the systems are to
use."

"Another thing, I'd have the hostess do some qualification of the visitors. If she knew what their specific interests were, she could cue them to a particular system."

"And one last thing, I liked Debby's suggestion that we should have a quiet room, a closing room, where we could take people to discuss terms and sign papers. If we had had a room like that, we might have sold ten systems right at the show."

Tom Rich will be happy to talk with any dealer planning a similar event.

All new ACCESS coming January 1

Diane Ascher from our Customer Service Department, recently volunteered (Army Style) to take over as editor of ACCESS magazine.

Her first official decision was to establish a regular bi-monthly schedule for the magazine. Her plans also call for some major format changes.

"My goal is to make ACCESS a magazine that appeals to both the technical and non-technical customer," says Diane. "Customer contributed articles will be featured, as well as regular articles about hardware and software updates. We are particularly interested in applications software. And, I encourage lettersto-the-editor," says Diane.

All previous subscribers will get the next three issues as part of their original subscription.

So here's your chance! See your name in print or encourage your customer to submit articles, Diane awaits your contributions.

Helios II user's manual well received by dealers

"The new manual has a good Table of Contents so you can find what you're looking for right away," commented Paul Matzke of the Madison Computer Store. "The style makes it easy to understand, and I like the way it looks, too."

Our new Helios II User's Manual uses simple language to explain how to operate the Helios. All theoretical and service-related information is left out. We developed this manual to meet the



We know you're all anxious to find out who won the Christmas in Hawaii contest. We're going to tell you. But, all the verification forms aren't in yet. So, ... you'll just have to wait for the next issue. Keep Smilin'.

needs of the business user who typically has no technical know-ledge and depends entirely on the dealer to test and repair his equipment.

Dealers should be receiving the new PTDOS User's Manual soon, to be used in conjunction with the Helios User's Manual. It describes the operating system for the Helios.

Plans for the future call for both a User's Manual and a Technical Service Manual for each of our hardware products. The Sol is currently undergoing this change.

New price list "Best one yet"

This was the frequent reply from dealers and sales staff when asked how they liked our new Price List.

"It sure helps to have such a professional Price List," reported Gerald Wright of the Digital Deli (Mountain View, CA). "Before, I had to circle appropriate items for our customers. Now they can understand it and make selections themselves. The pictures really helped to tie it all together."

He liked the folder idea, too.

Several dealers commented that the new layout and pictures make this price list especially useful as a sales tool, unlike other price lists.

THE PERSONAL COMPUTER RETAILER

Vol.2 No.11

Published by Processor Technology Corporation 7100 Johnson Drive, Pleasanton, CA 94566 December 18, 1978

New Jersey dealer ready for Hawaii

The news you've all been waiting for! Processor Technology proudly announces the 1978 Winner of the Christmas in Hawaii Contest:
JOEL SHUSTERMAN, COMPUTER EMPORIUM, Cherry Hill, New Jersey. Congratulations, Joel! (Mind if we send along your friendly roving reporter for an on-the-spot interview?)

Second prize, a Sony Trinitron Color TV goes to HARRIET SHAIR, COMPUTER CORNER, White Plains, NY.

Third prize winners of the Polaroid Pronto Camera Outfits are: BILL BLOCK, INTERACTIVE COMPUTERS, Houston, TX; GRAHAM MEAKINS, BASIC COMPUTER GROUP, Vancouver, B.C.; LARRY STEIN, COMPUTER MART OF NEW JERSEY, Iselin, NJ; and ROBERT VIPOND, COMPUTER MAGIC, Modesto, CA.

Congratulations to all these winners, and a special Thank You to everyone who participated in this event.

airchilo nameo new sales manager

"My objective is to enhance the working relationship between dealers and our Sales Department. I intend to clarify certain policies," says Elizabeth Fairchild, our new Sales Manager. "For example, putting our OEM sales program in writing so dealers will be able to work with us in pursuing OEM accounts."

As Processor Technology becomes more involved in the business market, Elizabeth plans to give dealers more sales support similar to the Word-Wizard Marketing Overview and product training seminars.

Elizabeth has a background in elctronics, and before joining Processor Technology in April 1976, she worked in retail sales.



Prior to promotion to Sales Manager, Elizabeth headed up our Advertising Department and was largely responsible for helping to develop our public image.

We know you'll enjoy working with Elizabeth and her staff. They're a hard working team committed to getting results!

Special Coliday Sssue

ou want it when?!

Item

Shipment Begins

DEBUG

Shipment begun

SolPrinter 2, 2E,

and 3

WordWizard

Shipment begun

Shipment begun





round the country

Twenty thousand miles and fifteen days later we had managed to visit many of you and give your staff a personal introduction to Word-Wizard and the advertising program developed to promote it. Your response was more than enthusiastic. It was obvious you shared our excitement for WordWizard and its market potential. As Ben Bennett from Roms 'N Rams in Raleigh, North Carolina put it, "The market is ready for a lowcost system which is as easy to learn and as simple to use as

Whodunnit

Editor.....Dottie Wanat Asst. Editor.....Sally Turner Graphics.....Lois Esser Ray Oleson

General Input....Diane Ascher Elizabeth Fairchild Connie Hawkinson

Copyright © 1978, Processor Technology Corporation. All rights reserved.

WordWizard. We already have customers ready to buy."

Again, Gary Ingram, Mike Mills, Ralph Palsson and I would like to thank all of you for making us feel so welcome. Although we succeeded in totally exhausting ourselves, we all agree that we were glad for the opportunity to visit your stores and get better acquainted with each of you.

We appreciate the time you took from your hectic schedules to share with us your comments and suggestions on WordWizard as well as your thoughts and ideas about Processor Technology and the industry in general. Your input is extremely valuable. The information exchanged will help us in formulating future policies and programs--policies and programs which will, hopefully, enable all of us to work together in the most effective and profitable manner.

From myself and the staff of the Personal Computer Retailer, HAPPY HOLIDAYS to all of you and your families!

What you've wanted to know about Sol Printers

...but didn't know whom to ask

- Q. Why can't I put a plastic wheel into a metal wheel machine and vice-versa?
- A. The mechanism is completely different in these two machines. Using the wrong print wheel will damage the wheel and void the warranty.
- Q. What's the difference between the metal and plastic wheels?
- A. Metal print wheels are actually a very hard plastic that has been metal-plated. Metal wheels last 4 times as long as plastic and are available in different fonts.

Software Sentre

We're back again with Software Sentre. Here's some new software available for Helios:

CP/M will soon be available for Helios from: Lifeboat Associates, 164 W. 83rd St., New York, NY 10024. (212) 580-0082.

General ledger, Accounts Receivable, Accounts Payable, Payroll with Job Accounting, Inventory Control and Order Entry...a complete package for Sol Systems III and IV available now with extensive dealer training. Contact Dick Babb, MicroSun, 2989 North Main St., Walnut Creek, CA 94649. (415) 933-6252.

- Q. How can I tell when the wheel is beginning to wear out?
- A. Serifs, periods, commas, hyphens and underscores wear out first. You can spot-check these symbols periodically.
- Q. When will I receive delivery?
- A. Delivery will be limited this quarter. We will get the major part of your scheduled order to you. In some cases, the SolPrinters are beige rather than black. We expect the delivery situation to improve next quarter.
- Q. Where do I get supplies such as ribbons and additional print wheels?
- A. These are available from Processor Technology as well as many other sources. We encourage dealers to find a local source.
- Q. What about maintenance contracts from Diablo?
- A. Diablo Warranty Extension contracts are \$135 (SolPrinter 2 & 2E) and \$110 (SolPrinter 3) and available to the end-user at time of purchase. Five maintenance depots exist around the U.S. We highly recommend this contract to you since without one, Diablo will charge you \$80/hr. for the first hour and \$40/hr. thereafter for service.

(Continued on page 4)

...about Sol Printers

(Continued from page 3)

(0002404 1	zom page 37		
Model	SolPrinter 2	SolPrinter 2E	SolPrinter 3
Type	Word processing (letter & repro- duction quality) Metal daisywheel	Word processing (letter quality) Plastic daisywheel	<pre>High-speed dot matrix (drafts & reports)</pre>
Nominal speed	33 cps (480 wpm)	37 cps (540 wpm)	200 cps (2400 wpm)
Interface included	Parallel	Parallel	Serial (RS-232) (110-9600 baud)
Model # of Diablo Print Mechanism	1355 WP	1345 A	2300
Forms Tractor	Optional (\$250)	Optional (\$250)	Included
Print Wheel included	Titan 10 - 96 characters (others will be available in future as option)	Courier 10 (others available as option)	<pre>7 x 9 dot matrix (both upper & lower case with descenders) - equivalent to 10-pitch type</pre>
Ribbon	Carbon film or cloth	Carbon film or cloth	<pre>self-re-inking ribbon</pre>
Carbon Copies	Up to 12 plus original	Up to 12 plus original	Up to 5 plus original
Print Wheel life expectancy	Approximately 16 million characters (30-50 million characters possible	Approximately 4 million characters)	N/A
Forms Width	15 inches max.	15 inches max.	15 inches max.
Carriage Return time	300 ms max.	300 ms max.	350 ms max.
Character Set	96 characters	88-96 characters	96 characters
Bidirec- tional Printing	Yes	Yes	Yes
High Speed Vertical and Horizontal Tabbing	Yes	Yes	Yes
Automatic Tabbing for Multiple Spaces	Yes	Yes	Yes

Return Authorization Policy now in full effect

The Return Authorization lets us know in advance that you are returning a unit. It enables us to schedule technicians, order parts, issue credit, etc., more efficiently. So, to avoid unnecessary delays, remember these procedures:

- Notify Customer Service by phone or mail what equipment you're sending in for repair. Give the serial number and the symptoms of the problem.
- 2. Use the Return Authorization number as a packing label on the outside of the box.
- 3. If more than one item is

- covered by a single Return
 Authorization slip, but the
 items are being shipped separately, please do the following:
- A. Indicate on the Return Authorization slip which of the items is being shipped under separate cover;
- B. Attach the Return Authorization slip to the <u>outside</u> of either of the boxes;
- C. On the outside of the other box, clearly indicate the Return Authorization number covering the return. OR, better yet, attach a copy of the original Return Authorization slip.

memory Board upgrade program

If you have customers who would like to upgrade their system but don't have the additional memory or the cost is too high, here's their chance to purchase one of our new state-of-the-art memory modules.

For a limited time only (offer good through January 30, 1979) we are offering a special program which allows a customer to trade-in their present memory board(s) for credit toward the purchase of one of our new, more powerful memory modules, 32KRA-1, 48KRA-1, and 64KRA-1.

The benefits of this program are two-fold:

THE DEALER

This provides you with a good opportunity to contact old customers and fill them in on new products which are currently available:

New energy and space conserving memory modules * New software application programs such as WordWizard

THE CUSTOMER

Since the trade-in values are high, the customer gets an upgraded system at minimal cost. New applications programs (such as WordWizard) can be easily run on his upgraded system. And the nKRA family of memory modules offers:

- * Up to 64K on a single board-more usuable backplane slots
- * Lower power consumption and less heat
- * Extended memory through Bank Select
- * Synchronous operation--no wait states required

Specific details of the program may have already reached you. If not, you will be receiving them very shortly. So, get ready to sell those boards!

The staff at Processor Technology wish all of you



happy holioays

filled with good old-fashioned cheer



THE PERSONAL COMPUTER RETAILER

Vol.3 No.1

Published by Processor Technology Corporation 7100 Johnson Drive, Pleasanton, CA 94566

January 26, 1979

The next in our series of technical seminars is scheduled for February 12-16. It is especially designed for the technician who has not yet attended a Processor Technology tech seminar. Since both hardware and PTDOS software will be discussed, you may want to send two technicians. Enrollment is limited to ten people, so get those reservations in now. Phone your dealer representative, Debby Oester or Brett Bullington.

Technical seminar scheduled

The seminar will be conducted as follows:

HARDWARE

Monday: System III troubleshooting and interfacing Tuesday: Morning-Helios service and maintenance Afternoon-SolPrinters Wednesday: SolPrinters (continued)--differences and board swapping.

SOFTWARE

Thursday: Introduction to PTDOS 1.5

Friday: PTDOS System interfacing and device drivers

Be sure to bring a PTDOS manual and two blank diskettes.

Prerequisites for attendance:

Hardware technicians must be familiar with the Sol and Helios manuals and the nKRA theory of

In this issue...

The next in our series of technical seminars..see page 1
An updated PTDOS 1.5 has been released.....page 2
Businessmen will get a chance to see WordWizard through ads placed just for them.....page 2
Enthusiasm for WordWizard continues.....page 3
More sales literature is coming your way.....page 3
DAP has some new business software; see Software
Sentre.....page 4

operation (theory will not be covered during the seminar). Technicians should have an AA or the equivalent in digital electronics or computer maintenance plus at least six months experience with microcomputers.

Software attendees should be familiar with the 8080 assembly language and should be able to read and understand the code. Each should have primary responsibility for writing and/or maintaining applications software and/or drivers.

Technicians attending the seminar will be responsible for their own transportation and motel accomodations. We recommend the California 6 Motel in Pleasanton at (415) 462-2626, or Howard Johnson's in Dublin at (415) 828-7750. Both are close to the plant.

WordWizard enthusiasm running high

by Sally Turner
Here we are embarking on another
year and perhaps the most exciting
quarter we've yet experienced.
We're well into the most comprehensive sales campaign we've
ever undertaken.

It began with the whirlwind crosscountry visits by Gary Ingram, Dottie Wanat, Mike Mills and Ralph Palsson. Various dealers had the chance to preview WordWizard and hear all about the marketing plan to introduce it.

When asked what he thought of the visit, Eri Golembo (Computer Mart of New Jersey) said, "In this day and age it's important to have a close relationship with the vendor in order to do the best job. I was very pleased with the visit. In fact, we sold a WordWizard the day after Dottie and Gary were here. An attorney walked in looking for a word processing system. We were 'hot' from the visit. It was a natural."

Following the cross-country visit, the first of our advertising campaigns began in the WALL STREET JOURNAL. Responses have been good. When a phone call is received, the customer is referred to his local dealer. The caller's name and address is also recorded, and then this information is sent to you along with all the inquiries received from the mail-in coupons. If a customer requests a demonstration, we phone the local dealer immediately. In all cases, we immediately send the prospective customer a WordWizard data sheet.

The Monday Machine co-op ad mats were designed to help you create an awareness of both you and

WordWizard in your local community. When used in conjunction with the WALL STREET JOURNAL ad dates, the impact has been good. Be sure to take full advantage of your co-op advertising allowance and run these ads. Remember, we pay 60% of those costs.

The marketing overview which you received with your first WordWizard shipment provides you with a general overview of the system, its position in the market place, and tips (based on our experiences) on how to do an effective (Continued on page 4)

More sales literature coming

The WordWizard, nKRA, and Extended BASIC data sheets which you recently received are the first in a series of new product literature planned for publication during this year.

These data sheets are designed to be used in conjunction with, or independently from, the colorful new six-page brochure which is currently in production. You should receive these brochures within the next month (weather conditions permitting the photography work to be completed).

The brochure is directed at a very general audience. This allows you to custom-tailor your sales literature package to the needs of a specific customer. All you have to do is insert the appropriate data sheet or sheets into the flap on the last page. Or, if a single data sheet will suffice, you can simply give that to the customer since each sheet is self-explanatory.

Software Sentre

DAP Systems is releasing the Osborne and Associates accounting package on Helios II diskettes. Representing five man-years of development by Osborne personnel, the Helios version is marketed exclusively through qualified dealers and consultants.

The package consists of three modules: payroll with cost accounting, accounts payable/receivable, and general ledger. Each can operate independently or in conjunction with the others, sharing data files where appropriate.

The dealer price for the diskettes is \$100 per module. After making the initial purchase, dealers may copy the diskettes for resale for no additional royalty.

The documentation was prepared by Osborne and is available from them under their normal bookseller's terms. It includes file layouts, file maintenance programs, data entry instructions, screen display formats, and report printout formats. In addition, the individual programs are documented with a

WordWizard

(Continued from page 3)
demonstration. Your early responses indicate that this too has proven to be a very useful sales tool.

In fact, from all indications, it appears that all of these marketing efforts are very effective. Your enthusiasm is high. I believe Ed Hammontree (Computer Port, Arlington, TX) put it best when he said, "Y'all started right and followed through; finest promotion we've ever seen in the computer business." And, I might add, we intend to keep it that way.

user's manual, flowcharts, and a narrative description. The package runs under CP/M and CBASIC, available for the Helios II from Lifeboat Associates (164 West 83rd St., New York, NY 10024).

The first module, payroll with cost accounting, is now being delivered. Accounts payable/receivable and general ledger are scheduled for release in February and March respectively. Prepayment is required with orders.

DAP Systems is located at 3901 Victoria Lane, Midlothian, VA 23113. (NOTE: This product has not yet been tested by Processor Technology.)

Sol saga

As told to Phil Dorcas (Computer Port, Arlington, TX): Last June, John Cade (a Computer Port customer), his two sons, and a Sol System III took a 3,000 mile, cross-country trip in a Winnebago. Weather conditions varied from 110 degrees in the desert to below freezing in the Colorado Mountains.

Hooked to a 110 volt auxillary power unit, Sol ran all day, everyday... the kids played games, and John did his work long into the night.

While crossing the hot desert during a sandstorm, the air-conditioner went out. The boys opened the windows in the van...sand went flying everywhere, and John...well, he ran off the road and the Helios disk drive fell to the floor.

John and his sons picked up the unit, shook out the sand, and plugged it in. It worked! "And to this day it still works perfectly." THE MORAL OF THIS STORY: Sol Systems are even better than they're cracked up to be!



Monday Machine ad's aiming at business

Again this quarter we have planned an aggressive advertising campaign for the WordWizard aimed at the business end-user. The "Introduing the Monday Machine" ad will appear in the following publications:

THE WALL STREET JOURNAL (East and West Coast editions)
THE OFFICE (a special issue on word processing systems)
THE AMERICAN WAY
SMALL BUSINESS COMPUTERS (a special issue on word processing systems)
BYTE.

As before, you will receive all sales leads generated from these ads either through our Dealer Locator Hotline or from the mailin coupon request.

When a customer calls or sends in a coupon, he receives a WordWizard data sheet from us and, of course,

Updated PTDOS 1.5 now being shipped

The new release of our disk operating system, PTDOS 1.5, is being shipped with all Helios orders. All reported bugs in PTDOS 1.4 have been fixed and a number of useful features added. The changes are summarized in the preface of the second edition of the PTDOS User's Manual.

Customers using PTDOS 1.4 will undoubtedly want to switch to 1.5. We encourage you to offer the new release at no charge to customers. Anyone switching, however, should have the second edition of the User's Manual, which we suggest you sell for \$30.

the name and address of his local dealer. BUT, don't wait for them to contact you! Remember, these leads are HOT so be sure to follow-up on them as fast as you can.

Hawaiian holiday begins for winners

With great eagerness, Joel and Sheryl Shusterman embarked on their seven day trip to the beautiful island of Maui in Hawaii. (And ready they were since both their children spent the preceeding weeks with chickenpox.)

They're staying at the Kaanapali Beach Hotel on the strip. Since neither one had ever been to Hawaii, their excitement and anticipation were high. But we'll let them tell you all about it in our next issue. (In case you hadn't guessed, your friendly, roving reporter didn't get to go along despite all her protests!)

Whodunnit

Editor......Dottie Wanat
Asst. Editor....Sally Turner
Graphics.....Lois Esser
Ray Oleson
General Input....Mike Mills

Diane Ascher Connie Hawkinson

Copyright © 1979,
Processor Technology Corporation.
All rights reserved.

YOUR PROCESSOR TECHNOLOGY 90 DAY LIMITED WARRANTY

- 1. If you are not satisfied with the service, warranty or otherwise, provided by Processor Technology or its factory authorized warranty centers, write directly to our Customer Service Manager, 7100 Johnson Dr., Pleasanton, California 94566. We will make sure your problem receives our immediate and personal attention.
- 2. Processor Technology warrants each of its Products to be free from defects in materials and/or workmanship for a period of ninety (90) days from the date the product was originally purchased. This warranty applies to the original purchaser only and is limited in all cases to repair or replacement of the defective product.
- 4. Please carefully note that this is a two-way agreement. We promise to make repairs or replacements as stated above, but you agree that except for our obligation to make good on this promise we shall not be responsible for any expense or inconvenience which you might incur or experience with respect to the product, and which may relate to any incidential or consequential damages, nor shall we be liable for defects, damage or failures caused by unreasonable use, accident or abuse, including failure to provide reasonable and necessary maintenance after the products have been delivered to you. Any product which has been mechanically, electrically or electronically altered without specific written authorization by Processor Technology is excluded from this warranty.
- 5. You are responsible for the transportation cost to and from the Processor Technology authorized Warranty Repair Center, If you need to ship the product to the Warranty Repair Center you must use the original carton or a suitable replacement to prevent shipping damage. We recommend you store the original cartons for this possibility. To expedite Warranty service you must return the Warranty Registration Card to the Processor Technology Customer Service Manager, at 7100 Johnson Drive, Pleasanton, CA 94566.
- 6. No other person or entity is authorized to give any other warranties or to assume any other liabilities on Processor Technology's behalf unless made or agreed to in writing by Processor Technology, and no other person or entity is authorized to give any warranties or to assume any liabilities on the seller's behalf unless made or agreed to in writing by the seller.
- 7. INCIDENTAL OR CONSEQUENTIAL DAMAGES SUCH AS TELEPHONE CALLS. LOSS OF TIME, INCONVENIENCE, OR COMMERCIAL LOSS, ARE NOT COVERED UNDER THIS WARRANTY.
- 8. Any Processor Technology product purchased outside of the United States is not covered by this warranty.
- 9. The foregoing paragraphs constitute Processor Technology's entire warranty with respect to any product purchased or operated for personal use, as opposed to commercial use.
- 10. ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCANTABILITY OF FITNESS, ARE LIMITED TO THE NINETY (90) DAY DURATION OF THIS WRITTEN WARRANTY.
- 11. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS. SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED. INCLUDING WITHOUT LIMITATION WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICLUAR PURPOSE, ALL OTHER REPRESENTATIONS TO THE FIRST USER PURCHASER, AND ALL OTHER OBLIGATIONS OR LIABILITIES, INCLUDING LIABILITY FOR INCIDENTAL AND CONSEQUENTIAL DAMAGES, ON THE PART OF PROCESSOR TECHNOLOGY OR THE SELLER.

Processor Technology Corporation
7100 Johnson Drive, Pleasanton, California 94566 (415) 829-2600

THE PERSONAL COMPUTER RETAILER

Vol.3 No.3

Published by Processor Technology Corporation 7100 Johnson Drive, Pleasanton, CA 94546

April 18, 1979

New hardware and software debut at NCC

An entire line of new Processor Technology hardware and software products will be shown to the public for the first time at the National Computer Conference in New York, June 4-7.

Dealers who attended our April seminar had the opportunity to preview many of these new products.

HARDWARE

In the hardware department we'll be showing the all new SolDisk 1, a double-density, dual mini-floppy packaged in a compact enclosure. It has a storage capacity of 350K bytes. SolDisk 3 is a hard disk packaged in a rack-mountable enclosure. It stores up to 28 Megabytes of data.

The controller hardware for each of these systems is divided into two modules. One module resides in the processor on the S-100 bus backplane and can communicate with up to seven device controllers. The device controller resides in the first disk drive enclosure and allows for the connection of up to

In this issue...



Our new Quality
Assurance Policy is
now in effect...see page 2

An update disk for WordWizard and FORTRAN is now available....page 5

NCC....Starting on page 1

three additional drives before requiring another controller device.

SOFTWARE

PTDOS 2 is a modified and enhanced version of PTDOS that will support the new hardware.

In the area of Business Applications software, there are programs to manage mailing lists, do general ledger, accounts payable and accounts receivable. All packages are completely integrated and compatible with each other as well as with WordWizard. They may be purchased individually or as an entire package.

NewsWorthy Notes.

Joel Shusterman, Computer Emporium, bought the Computer Systems Store Cherry Hill, New Jersey, sold 30 Sol Systems to one company as the result of his participation "The sale rein trade shows. sulted from the Mini-Micro Show in Philadelphia in May of '78 and the Office Products & Environment/ Sales Expo '79 at the Philadelphia Civic Center in December, " reported Joel's proud wife, Cheryl.

()

0

0

Terry Batt, Midwest Microcomputers, Lombard, Illinois, recently exhibited at the Biz Services and Equipment Show in Chicago. got follow-up requests from 83 companies. To handle all the requests, he's holding Open House in his store on weekends.

Roms 'N' Rams, Raleigh, North Carolina, has a new name--Bennett-Stiles Computers. They also have a new full-time outside salesman, Jerry Thomas, who coordinated their Business Applications Seminar.

Due to popular demand, the Memory Upgrade Program will continue until June 30.

Bristol of Georgetown Computers in Washington, D.C. recently

Whodunnit

Editor.....Dottie Wanat Asst. Editor.....Sally Turner Graphics.....Lois Esser

Ray Oleson

General Input.....Mike Mills Elizabeth Fairchild Connie Hawkinson Edith Reisner

Copyright © 1979, Processor Technology Corporation. All rights reserved.

in McLean, Virginia.

Wernor Electronik in Sweden has developed Swedish and Danish character generators for the Sol and Processor Technology software. They will be distributing throughout Sweden and Denmark. Interested dealers should contact their Sales Representative for further information.

New D.O.A. policy now in effect

Beginning March 26, a new policy went into effect for equipment received "Dead on Arrival."

If you test an out-of-box product and find it faulty within 15 days of our shipment date, call Customer Service to receive a Return Authorization number. Be prepared to provide the following information:

A. Product name

B. Date received

C. Invoice number

D. Serial number

E. Problem with the product.

Repack the product in our shipping container and return it to us freight collect. When packing be sure to:

- A. Enclose a brief description of the problem;
- B. Mark the outside of the container with the R.A. number in two places.

We will repair or replace the unit within 48 hours of our receipt of the product and ship it back to you (postpaid).

If you have any questions, please contact Linda Bilbrey in Customer Service.

New products debut at NCC

(Continued from page 1)
the ability to expand their data
management capabilities while
cutting some routine paperwork.
Some of its more powerful features
include:

1. Operator can use two to four disks, allowing for 1500 to 5000 names.

2. Entries can be located within

three seconds, can be up-dated, added on, or de-leted.

- 3. Groups of entries sharing specific characteristics may be deleted or printed.
- 4. Prints out list of all changes after update.
- 5. Prints out
 a selected
 group of entries or a
 statistical
 sample, either alphabetically or
 by zipcodes.
- 6. Prints mailing labels
 for each entry, a se-

lected group, or a sample.

- 7. When used in conjunction with WordWizard Electronic Typing System:
 - A. The mailing list data can be merged into form letters or tables;
 - B. Prints out personalized form letters to all entries or a selected group without reinitiating the processing for each letter.
- 8. Print speed can be up to 540 words per minute for letter

quality, 2400 for draft type quality.

General Ledger is a comprehensive bookkeeping system for financial reporting, offering flexibility for specifying own criteria (numbering of accounts and defining departmentalization). Some features include:

35 Dealers attending Software Seminar

By the time most of you receive this newsletter our Software Seminar will be underway. Scheduled to begin on Sunday, April 22, the seminar is designed to introduce you to Processor Technology's new line of business software.

For those of you who were unable to attend, we plan to hold a condensed version of this seminar in conjunction with the National Computer Convention (NCC) show in New York in June. Also, for those unable to attend, the May issue of Personal Computer Retailer will include a summary of the seminar.

- Maintaining data on a monthly basis for 24 months, stores budget figures for 12 months.
- 2. Data need only be input once for automatic transfer from receivables, payables and payroll into general ledger program.
- 3. Closes income and expense accounts to retained earnings at year end.
- 4. Fully automatic audit trail shows printed reports of all transactions facilitating the tracing

of an item back to a source document.

- 5. Reports produced automatically include:
 - A. Chart of accounts
 - B. Work sheet trial balance
 - C. Source journals
 - D. Audit trail control reports.

Accounts Payable records all incoming invoices and due dates by vendor. Other features include:

1. Outgoing checks are printed

(Continued on 4)

New products debut at NCC

(Continued from page 3)
automatically, making appropriate deductions to payables.

- Multiple invoices can be paid on one check.
- Credit memos and adjustments maintained with accurate payables totals.
- 4. Prepares financial reports valuable for planning cash flow requirements.
- 5. Outstanding invoices listed according to last possible due date each week.
- Schedule of payments picture, focusing on discount opportunities with discount date, amount and final payment date.
- 7. Aged trial balance sheet reviews monies owing.
- Aged cash requirements report treaks out monies owed according to due date.

Accounts Receivable provides customer master maintenance file cording all information regarding balances and sales history.

Other features include:

- All invoices entered into computer and posted to receivables automatically.
- Payments and/or adjustments are posted against the invoices as received.
- 3. Computerized month-end processing initiates balance forward process wherein all invoices with nil balance are removed, leaving only outstanding invoices.
- 4. Produces upon request:
 - A. Customer statements
 - B. Aged trial balance reports
 - C. Exception reports listing by due date.
 - D. Offers advice on customer credit limit.

SolSign Astrology System is a complete natal astrology program which includes the calculation

and explanation of the birth chart. Accurate calculations of the planets, sun, moon and house cusps. Other features include:

- Complete transit (daily) astrology system gives daily interpretations as back-ground, and specific interpretation of the daily sun and moon positions.
- Easy data input, stores the longitude and latitude of major U.S. cities and remembers any new cities that are input.
- Gives printed output, or can be restricted to the TV screen.
- Allows chart storage on the disk for research or for personal daily transit information.

Miss our usual?

Frankly, so do we, but in this case, don't feel as though you need to consult your local physician because you're not seeing green. Due to the prolonged strike at the paper mills, we couldn't get our regular green paper for this issue. We hope to be back "on the green" for the next edition of PCR.

New, updated disk versions of WordWizard and FORTRAN available

A new, improved version of WordWizard has recently been released. It includes:

- + Print control statements to center and offset printed text;
- + A center command to center text typed in a document;
- + A screen print activity that lets you preview the printed format of a document without actually printing it;
- + A type-ahead feature that lets you keep typing during a disk access;
- + Various general improvements.

The package is available in two forms:

 A regular software distribution kit consisting of a

- System Disk (Rev. F), a Document Disk (Rev. D), the key-board and diskette labels, and a User's Manual;
- An update disk--free to dealers who have already bought WordWizard. It will put the new version on existing WordWizard disks.

The update disk will update not only WordWizard, but also FORTRAN. An existing WordWizard disk is updated to Release 4.0 (mod 1); an existing FORTRAN disk is updated to Release 1.1 (mod 0). Any dealer who has purchased WordWizard and/or FORTRAN at any time in the past will automatically receive this update disk free of charge.

Seminar teaches customers AND dealer

We asked Eri Golembo, Vice President of retail sales at the Computer Mart of New Jersey, if he thought their recent Business Applications Seminar was sucessful. Here's his reply:

"We sure learned a lot from that seminar. We learned just how important a structured sales approach is. If you just sit and chat with someone about, let's say, WordWizard, you may forget to mention some important features. Then the customer does some competitive shopping, and someone mentions some special feature you forgot to point out. The customer thinks, 'Wow, that other machine didn't have all this,' and you've lost a sale.

"Another thing we've learned," says Eri, "was the average awareness level of our customers.

We've always assumed that the people who came to us inquirying about computers really knew a lot. Our seminar showed us that we were wrong.

"Most of our potential customers actually know very little about computers—only that they think they need one. Often, they don't even know the questions to ask. Or, amybe they're just too embarrassed to ask. They feel that they're the only ones who don't understand the terminology. So, it's important to use use simple, easy—to—understand, non-technical language when explaining the features. Avoid 'computerese'."

Processor Technology's Elizabeth Fairchild and Debby Oester participated in this seminar.



We're hoping to see all of you at the National Computer Conference (NCC) in New York in June. Our exhibit is located on the 4th floor, booth numbers 4048, 4050, 4052 and 4054.

In the next few weeks you will be receiving from us five guest passes for the show. If you will need more, please let your sales representative know.

We'll have an entirely new booth with two elevated sections devoted to business applications software plus a special area to demonstrate the new disk systems.

Besides showing the new product line, we're also planning a reception for all of you, as well as a condensed version of the dealer business software seminar.

We'll be publishing a full schedule of events in the May issue.

Processor Technology Goes Under

by Tom Williams

Processor Technology Corporation, of Pleasanton, California, has closed its doors and had its telephone disconnected. On June 8th, police cars were observed at the doors of the building. A source close to *IMJ* asked one of the officers what was going on, and was told that they were attempting to serve a summons, but had as yet been unable to do so.

IMJ has been able to verify that at least two computer dealers in the San Francisco area have been contacted by the Bank of America, and told to make payment on invoices due to Processor Technology directly to the Bank of America and not to the company. Checking with the Federal Bankruptcy Court has revealed that the company has not filed for bankruptcy or for Chapter 11. It is also known that Processor Technology has laid off approxi-

mately 75 employees.

A telephone number, (415) 846-9951, has been located which appears to reach the company's offices. Repeated attempts by *IMJ* to reach Bob Marsh, president of the company, for comment, or to get comments from other officers of the company, have proven fruitless.

There has also been talk, albeit unconfirmed, that the company was planning to liquidate assets, such as office furniture and, perhaps, some equipment, by means of a public auction to be held sometime in the near future.

The question that arises for owners and users of Processor Technology equipment is: what sort of future support can they look forward to, and from what source would it come? *IMJ* has learned that Proteus, the Processor Technology User Society, is attempting to keep things together for users. Plans are to try to preserve as much information as possible by collecting and distributing manuals and technical data.

Processor Technology is not committed to providing manuals or notices of engineering changes. Manufacturers marketing Processor Technology accessories will also try to keep up enough orders for another production run. In addition, Proteus will try to set up a service center, employing factory-trained technicians. More information on Proteus' efforts can be obtained from: Proteus, 1690 Woodside Road, Suite 219, Redwood City, CA 94061.



About the Author

Bob Bumpous is a machine controls design engineer with Adolph Coors Company and has been doing discrete and computerized machine control design for the past four years. He previously worked for Bendix Navigation & Control Division on documentation of SKYLAB experiments. He is a 1969 graduate of Texas Technological College with a BS in engineering physics, and has an avocational interest in personal computing.


A User's Reaction to the SOL-10 Computer

Robert Bumpous 212 N Ford Golden CO 80401

When I first saw the Processor Technology SOL it was love at first sight. After acquiring the SOL system, I found that it has everything (almost) a hobbyist needs in one package.

The SOL-10 system which I purchased

MEMORY MAP



ccoo

consists of a single 10 inch by 16 inch board computer, a keyboard, a power supply and cabinet. Figure 1 shows a memory map of the system which gives an idea of its overall structure. Processor Technology also makes the SOL-20 which has a heavier duty power supply and backplane for five extra S-100 cards.

The SOL single board computer is a complete beginning system. The board contains an 8080A processor with fully buffered data and address buses which are brought to a connector at the center of the board where an S-100 compatible backplane daughter board can be plugged in. It also has a complement of IO ports. The board and operating system are oriented around the parallel keyboard input port and video display output port. 1 K of the 2 K of programmable memory on the board is used to store the 64 character by 16 line video display contents. The output of the display driver is an EIA composite video signal (1.0 to 2.5 V peak to peak) which will drive any standard monitor or even a modified TV set. The full 128 upper and lower case ASCII character set is available for display. With the addition of a video monitor the system becomes a smart video terminal with either full or half duplex communications modes selectable from the keyboard.

The SOL design has an asychronous serial interface port with switch selectable data rates from 70 to 9600 bps. This serial 10 port has both an RS-232 and 20 mA current loop output. Also included is an 8 bit

Figure 1: Memory allocations of the SOL design. Within the 10 area at D000 to FFFF, the SOL-10 has a UART dedicated to the tape interface, a UART dedicated to the serial communications interface, a parallel keyboard interface, one 8 bit input port and one 8 bit output port.




Figure 2: One minor printed circuit bug found by the author in testing out the SOL computer was the run from point L to point M from U86 to the data rate selection switch. If 4800 bps operation is desired as an option, the run in question has to be broken and a jumper wire from point K to point M on the board has to be substituted.

parallel 10 port which allows a user to drive any external peripheral.

An option which I think is important to any system is the cassette interface. This option, used with the SOL, allows the user to read or write programs or data to a cassette tape at a software selectable rate of 300 bps or 1200 bps using standard asychronous Manchester coded signal at 1200/2400 Hz or 600/1200 Hz.

The SOL-PC board itself is a high quality double sided G-10 type material with plated thru holes. There is an excellent solder mask on the board with all component locations clearly labeled. The unit I received, which was Revision D of the board, had two defects which Processor Technology asked the assembler to change: two lines crossed on the same side of the board and two lines to the S-100 bus were reversed. Both were easy to correct and I'm sure these defects will have been corrected on the next revision of the board.

I also discovered what I think is another error on the board. In the circuit that

selects the serial data rate there is a jumper that enables either 2400 or 4800 bps to be switch selectable. The board had the switch permanently connected to the 2400 brosition. This caused the serial IO to wo improperly when 4800 bps was selected. Because there are lines feeding from this circuit to the cassette interface circuit, the cassette interface would not work properly. The problem is easily corrected by breaking the lines between the L and M jumper contacts (see figure 2).

There is a moderate amount of large scale integration on the board. The 8080A processor, the ASCII 7 by 9 dot matrix encoder, the two UARTs used for the serial and cassette tape interfaces and the 5204 (512 by 8) EROMs in the personality module are the LSI chips used. The programmable memory for the computer and display is made up of 2102 parts. All of the IO select switches and the IO connectors are located at the rear of the board for easy access. The personality module is located along the back edge to allow an easy change of the operating system.

The system timing is derived from a 14.31818 MHz crystal controlled oscillator that feeds the video character generator, UARTs, and 8080 clock divider circuits, MSI and SSI TTL along with an AH 0026 dual MOS clock driver supply the 808° clock signals. There is an RC charge-ucircuit that provides an automatic reset signal when power is turned on and a controlled "wait" period immediately after the reset signal.

The keyboard supplied as part of the SOL-10 system is a custom unit from Key Tronics which connects to the SOL-PC board through a ribbon cable connector which plugs into a header on the board. The keyboard uses no LSI encoder and no mechanical contacts and can easily be disassembled for cleaning.

The keyboard is easy to assemble and check out. All of the data bits are latched so that they can be examined at leisure. The strobe bit is only on for a very short time, two to ten μ s. There is only one tricky part of the keyboard assembly procedure. This is the installation of the four SIP resistor networks. Extra care must be used in installing these since they are not as clearly marked as most of the other items, and the two different sets of values will not allow the keyboard to work properly if interchanged.

The power supply for the SOL-10 consists of a power transformer, an external filter capacitor for the 5 V supply and a regulator card to supply the required vol-

153.6 KHz




Photo 1: Processor Technology SOL, with cabinet cover removed to reveal its inner secrets.

tages (12 VDC at 150 mA, 5 VDC at 2.5 A, -12 VDC at 200 mA) to the SOL-PC and keyboard. The SOL-20 system power supply, in addition to these voltages, provides 16 VDC at 1 A unregulated, -16 VDC at 1 A unregulated, and 8 VDC at 6 A unregulated for the backplane Altair (S-100) bus daughter board. The regulated 5 V to the SOL-PC board has an over voltage crowbar on its output which, on my original version, had an overly sensitive turn on characteristic. Processor Technology has since sent a revision which corrected this problem.

The SOL system cabinet is sheet metal with solid walnut sides. It is designed to house the SOL-PC, the keyboard, power supply, backplane and five additional S-100 cards in a fan cooled card cage. The cabinet is constructed so that the power supply is isolated from any radio frequency interference (RFI) switching transients in the memory or processor cards. The whole system looks well shielded, which is an important consideration in this age of CBers. The walnut sides come sanded but unfinished; they look nice but take a lot of time to finish properly.

The assembly manual that came with the system describes the assembly procedure very well. It features the kind of complete, step by step format that kit builders have come to expect. It seems very complete, including pictures and drawings of how to assemble the components and subassemblies

into a useful computer and terminal. However, there were no flowcharts, block diagrams or explanations of how the different sections of the computer are supposed to work, or how they interact with each other. As of this writing (spring 1977) I have still not received two sections of my manual, operating procedures, and theory of operation. Most of the information that I have on the operation of the machine has come from an article in the February Digital Design by Lee Felsenstein of LGC Engineering and Robert Marsh (vice president of Processor Technology), who are the codevelopers of the SOL terminal system. This article gives a fairly complete though not detailed description of the operation and interactions of the SOL system components.

The CONSOL operating system, which is the minimal operating system, is stored in 1024 K bytes of EROM starting at C000. This operating system has seven commands that can be executed from the keyboard, sufficient to allow the operator to enter his or her own programs or prerecorded programs and execute them. The following are the commands available through CONSOL:

- DUmp ADDR1 ADDR2 dumps the contents of memory between address 1 and address 2 onto the CRT terminal in a hexadecimal format.
- 2. ENter ADDR1 enters hexadecimal format data into memory starting at address 1.




Photo 2: The SOL's display generator produced this video character graphics pattern on the author's television monitor.

- EXecute ADDR1 executes a program in memory starting at address
- 4. TErminal is a program designed to allow the SOL system to be used like a standard CRT terminal with serial 20 mA or RS232 interface. This ability could make the SOL system very attractive to a small business user who needs an inexpensive terminal.
- 5. TL (tape load) loads a prerecorded cassette tape into memory at an address specified by the tape. The information supplied with the software doesn't give a very good definition of how the TL command looks at the tape header data. Because of this, it is very difficult for the user to configure a tapeheader for any data he or she would like to store on a cassette.
- 6. BAsic executes a program located at address 0000, typically BASIC.
- The final command is the MODE command which calls a program that allows all the other commands to be entered on the keyboard and recognized by the computer system.

The early version of CONSOL which I received does not have a command to dump data from memory into a cassette tape. This is a great disadvantage when trying to develop a program. Whether the program being developed bombs out or is successful it is nice to have a copy so it doesn't all have to be typed in again.

The purchaser of a SOL system is also supposed to receive a 5 K BASIC operating system with the purchase of the on board audio cassette interface. This 5 K BASIC includes two computer video games. I had not yet received this when this article was written in the spring of 1977.

I ordered my SOL system on September 4 1976 and anxiously awaited its arrival. Only a portion, the SOL-PC, arrived on November 18 1976 along with part of the manual. When I opened the box I was confronted with what appeared to be a rather large, random accumulation of parts. However, all of the parts called out in the parts list were there. The assembly would have gone faster if the components had been sorted, placed in small bags, and marked as to the section of the assembly procedure they were for.

The procedure given in the manual calls for construction and checkout to proceed together. To follow the manual you must have a power supply and keyboard to properly assemble the complete SOL system. Because I didn't have either of these items. I was only able to proceed with the assembly until I came to the first step, which required the power supply; there I stalled. I spent all of Christmas 1976 lurking around the mail box, awaiting the delivery of the rest of my system. Finally, on January 4, it arrived and off to my basement "laboratory" I scurried, not to emerge "til the beaste was up and running."

After much soldering, bending and clipping, I reached the point of the first operations test. I plugged in my TV monitor, turned on the SOL system power, hit the MODE key, and typed in the DUMP command. Nothing! All I could get was the CURSOR in the upper left hand corner of the screen. This is when the lack of block diagrams and explanations of the system really hit me. After what seemed an extremely long time, I managed to solve the problem. The display uses the first several words of user memory to store the line and character positions for the video display, and somehow, in my haste to complete the assembly, I had bent a pin under on one of the memory chips. Dumb, but almost impossible to locate. Once this problem was solved? the rest of the system went together very smoothly.

The total assembly time, excluding the

time I spent looking for my own error, was about 36 hours. The sanding and coating of the walnut cabinet sides took about five more hours. I used clear atin polyurethane finish of the type found in most hardware stores. This is a very hard, clear, fast drying resin that puts a tough, mar resistant sealer on the side panels.

Overall, I feel that the Processor Technology entry in the microprocessor race is a good buy. I have had what seems to me excessive delays but I believe that now that the production of these units is in full swing, there should be a minimal amount of lead time on the system hardware. Processor Technology says that they have sold almost 1,000 of these systems. The software development, however, seems to be lagging well behind the hardware as might be expected from the history of computer science in general.

If you are planning to develop your own software or plan on buying it somewhere other than Processor Technology, the SOL system will serve you nicely. The CONSOL routine provides a step up from the front panel toggle switch design philosophy of most of the other microcomputer manufacturers and I feel it warrants the purchase of this system.

Editors' Note:

At the time this article was edited (August 15 1977) a SOL-20 with 16 K memory and CONSOL was resident in our office at BYTE. 5 K BASIC is now being delivered, according to Terry Holmes of Processor Technology.

The Following Comments Were Received from Bob Bumpous with His Author's Proofs on October 7 1977.

Since completing my SOL-10 I have written a couple of short programs to test the various hardware options of my system.

I have also purchased the SOL upgrade kit which adds the larger power supply fan and backplane and an IMS 8 K memory.

I have received the two missing sections of my manual and my BASIC tape. I have not yet been able to run BASIC due to a problem I'm having getting my cassette tape interface to operate properly.

1 have also received my SOLOS operating system; all of the functions except the tape interface seem to work well.



This page intentionally left blank.



The SOL-20 in a New England parlor context, obviously enjoying life. The entire system fits on one table with a video monitor on top of the computer and an audio tape recorder for mass storage to the right.

User's Report: The SOL-20

Dennis E Barbour 2 Coliseum Av Nashua NH 03060

John Kemmeny in his book, Man and the Computer, reveals his thoughts concerning the future of computers. Kemmeny believes that people will have access to large regional computers in the future. This will allow people to do many jobs in the home and provide entertainment and knowledge. A computer terminal in the home will be tied to a large regional supercomputer giving people the ability to do many things at home not now possible, such as reading the latest news stories, studying subjects for degree credit, storing recipes to allow the input of a week's menu and production of a grocery list of needed items, and the recording and computation of family financial matters. The possible uses of this type of computer are unlimited.

Processor Technology has taken this concept of the home computer terminal attached to a supercomputer one step toward reality by providing the home user with a terminal and microprocessor combination, the SOL, capable of functioning

with, or independent from, another computer. The operating systems provided by Processor Technology allow the SOL system to operate as a microprocessor independent of any outside processor with its own peripherals until the terminal command is issued, which causes SOL to operate as a computer terminal. This combination will allow the greater use of your home microcomputer today and in the future. What follows is a brief description of a SOL system based on my personal experiences.

Hardware

My microprocessor, a SOL-20, uses an 8080 processor chip. (The 8080A and the 9080A are also available.) This system has both parallel and serial communication interfaces, a keyboard interface, audio cassette interface, a video display generator, 1024 8 bit words of volatile system memory, and 1024 8 bit words of volatile display refresh memory. My system also has 8 K

bytes of volatile main user memory for programming and an operating system in a "personality module" with preprogrammed read only memories.

A feature of the hardware is a parallel interface consisting of eight bits for each input and output plus control handshaking signals. The output bus uses three state TTL levels for bidirectional interfaces. The serial interface circuit includes both asynchronous RS-232 and 20 mA current loop provisions and operates at from 75 to 9600 bits per second, switch selectable. (When I say that something is switch selectable, I mean that there is a series of small switches on the printed circuit board and an explanation in the hardware manual of what the switch does and what your options are.) The keyboard interface handles a 7 level ASCII encoded TTL keyboard which requires a strobe pulse after the data is stable.

The audio cassette interface is program controllable and self-clocking with a phase lock loop. It operates at the dual rate of 300 or 1200 bits per second. Included is an automatic level control in both the record and playback modes. Recording is the CUTS/BYTE standard compatible, an asynchronous Manchester code at 1200/2400 Hz or 600/1200 Hz.

The video display circuitry generates 16 lines from data stored in its 1 K refresh memory. Alphanumeric and control characters (the character set includes all upper and lower ASCII plus control characters) are displayed in either black on white or white on black (this feature is switch selectable). The solid video cursor with a switch selectable blink is programmable. This circuitry can drive any video monitor or monochrome television converted to handle video input.

The assembly of the SOL appears to be relatively easy. I bought my SOL fully assembled, but I read the assembly instructions, looked at the diagrams, and thoroughly examined the hardware. I believe that I could quite easily put a SOL together. The instructions are simple and straightforward. The assembly notes include parts lists, assembly tips and precautions, pictures and drawings, and step-by-step instructions on assembly and testing. Also included are instructions on handling integrated circuits, soldering techniques, and a list of the tools that will be needed. Processor Technology provides schematic and detailed assembly drawings in a separate section of their manual.

Another important feature of the SOL is the system's completeness and modularity. All of the hardware is in one package and looks like a large electric typewriter. The

DUMP ENTER	ADDR, ADDR	Dump memory locations to screen Enter data to memory
TLOAD		Load to memory
EXECUTE	ADDR	Execute a program at a given address
BASIC		Execute a program located at address zero
TERMINAL		Return to terminal mode

Table 1: CONSOL operating system command summary.

DUMP ENTER TLOAD	ADDR, ADDR ADDR	Dump memory locations to screen Enter data to memory Load data from tape to memory
EXECUTE BASIC	ADDR	Execute a program at a given address Execute a program located at address zero
TERMINAL TSAVE (NAME) TXEQ (NAME) TCAT SET SET DI SET IN SET OUT SET TAPE	ADDR, ADDR ADDR	Return to terminal mode Save certain memory locations on tape Load a certain program from tape and execute in List tape header information Allows the setting of the following things Set display speed Set input driver Set output driver Set tape speed
SET CI SET CO SET TY SET XE		Set custom input driver address Set custom output driver address Set types into tape save header Set execute address into tape save header

Table 2: SOLOS operating system command summary.

video monitor and cassette recorders are attached at the back panel with cables. The system does not have exposed boards or parts to collect dust or be damaged. The system can be easily transported.

Operating Systems

SOL, at present, has three operating systems. They are CONSOL, SOLED and SOLOS. CONSOL allows simple terminal operations and computer functions. SOLED allows more advanced terminal operations than CONSOL with additional screen, file and cassette tape operations. SOLOS allows use of the full range of the microprocessor plus the full functions of an intelligent terminal. I cannot describe SOLED any further, not having the information available to me. However, CONSOL and SOLOS will be described in detail.

CONSOL, the simplest of these operating systems, allows the SOL to function both as a standard CRT terminal and as a microcomputer. This software system is not as sophisticated as SOLOS which has many more commands and greater abilities.

All the operating systems work in the following fashion. The same switch to power up the hardware serves to initialize the operating system. The operating system initializes system memory, clears the screen and enters the terminal mode. Depressing the mode key causes SOL to operate as a microcomputer. The operating system issues a prompt character and awaits further commands.

```
10 REM THIS PROGRAM IS FOR TEACHING YOUNGSTERS MULTIPLICATION.
20 PRINT "DO YOU WANT TO TRY THE MULTIPLICATION PROGRAM?"
30 PRINT "ANSWER I FOR YES, AND 2 FOR NO."
    INPUT X
50 IF X=2 THEN 340
 60 PRINT
 70 PRINT "INPUT THE FIRST NUMBER."
80 INPUT A
90 PRINT AI" TIMES"
110 PRINT "INPUT THE SECOND NUMBER."
120 PRINT B
 130 PRINT A;" TIMES"; ;B:" EQUALS"
140 PRINT
150 PRINT "INPUT WHAT YOU THINK THE ANSWER SHOULD BE."
160 J=A+B
170 INPUT C
160 PRINT A;" TIMES";B;" EQUALS";C
190 IF C=J THEN 260
200 PRINT
210 PRINT "YOUR ANSWER WAS INCORRECT."
220 PRINT
230 PRINT AJ" TIMES";BJ" EQUALS";J
240 PRINT
250 GOTO 290
260 PRINT
270 PRINT
           "CONGRATULATIONS, YOUR ANSWER WAS CORRECT."
280 PRINT
290 PRINT "DO YOU WANT TO CONTINUE?"
300 PRINT "ANSWER I FOR YES, AND 2 FOR NO."
310 INPUT X
320 IF X=2 THEN 340
330 GOTO 60
340 PRINT
350 PRINT "HAVE A NICE DAY!"
360 END
PRUN
DO YOU WANT TO TRY THE MULTIPLICATION PROGRAM?
ANSWER I FOR YES, AND 2 FOR NO.
INPUT THE FIRST NUMBER.
    2 TIMES
INPUT THE SECOND NUMBER.
      TIMES
                 2 EQUALS
INPUT WHAT YOU THINK THE ANSWER SHOULD BE-
      TIMES
                    EQUALS
YOUR ANSWER WAS INCORRECT.
    2 TIMES
                 2 EQUALS
DO YOU WANT TO CONTINUE?
ANSWER 1 FOR YES, AND 2 FOR NO.
INPUT THE FIRST NUMBER.
    2
      TIMES
INPUT THE SECOND NUMBER.
      TIMES
                   EQUALS
IMPUT WHAT YOU THINK THE ANSWER SHOULD BE.
      TIMES
                 2 EQUALS
CONGRATULATIONS, YOUR ANSWER WAS CORRECT.
DO YOU WANT TO CONTINUE?
ANSWER 1 FOR YES, AND 8 FOR NO.
```

Listing 1: A tutorial BASIC program of the simplest variety, created one evening to instruct a 6 year old in some of the complexities of arithmetic.

There are five commands for operating SOL as a microcomputer under CONSOL. two for entering data, two for executing programs, and one for displaying the contents of memory on the monitor. (See table 1 for the complete list of CONSOL commands.) A person can enter data either through the keyboard by means of the ENTER command or through a cassette tape recorder by means of the TLOAD command. The ENTER command permits the altering of any byte or series of bytes of storage with either data or a machine language program. Program execution begins with the issuance of either of two commands. EXECUTE allows the execution of a program beginning at any point that you name in memory, whereas the issuance of the BASIC command starts program execution from memory location zero. The fifth command, DUMP, allows the displaying of any byte or series of bytes on the video monitor.

The SOLOS operating system allows for more advanced operation of the SOL. (See table 2 for a complete list of SOLOS commands.) Besides the six basic commands allowed under CONSOL, there are four additional commands, with one of these additional commands, SET, having eight different options. To begin with, the TLOAD command is different under SOLOS than under CONSOL. Under SOLOS, the TLOAD command allows the searching of a tape with multiple files for a certain named file, skipping over all files before it. Under CONSOL, you have to manually move the tape to the beginning of the tape file.

TSAVE allows the saving on tape of the contents of the memory locations indicated. TXEC allows the loading of a named program from tape to memory and the immediate execution of that program. TCAT allows the listing of the tape file header information on the monitor. This information includes the file name, execution address, and the beginning and ending addresses of the program when loaded to memory.

The SET command has eight different options. One can set the display speed, allowing the speeding up and slowing down of characters on the monitor to suit your programming. Using this option of the BASIC language interpreter, I was able to generate a very impressive lightning bolt image for my young son and his friends. The input and output driver speeds can be controlled through the use of the SET command along with the tape speed, and

HAVE A MICE DAY!

MEAN OF FERTILITY FIGURES:

the input and output driver addresses. The tape save headers can also be altered using SET. The more useful of the two operating systems is obviously SOLOS since it allows greater flexibility.

Software

My system has a BASIC interpreter, the BASIC-5 package. This interpreter has many of the usual BASIC commands and statements. It also allows use of system commands within programs. BASIC-5 allows the usage of single dimension arrays, many BASIC functions, and the ability to read and write tapes. It also has 8 digit precision and the ability to link to machine language subprograms.

I would advise the purchase of the 8 K BASIC for one important reason: the ability to have several commands and features not available in the BASIC-5 interpreter. These would be the RNUM command which allows the renumbering of statements, and also the ability to utilize alphanumerics and matrices (instead of only single dimension arrays) which would be particularly useful.

Uses

I have utilized my SOL for several things. First and foremost, I have introduced my 6 year old son to computers through games and learning programs, such as the multiplication program reproduced and described in listing 1. I have also used it for entertainment especially through the use of the target game provided by Processor Technology, and a few games I have written. Lastly, I have used it to fool around with my first love, history. I have written several statistical analysis programs for the SOL using the BASIC-5 software to continue with my research on colonial New England. Also reproduced here, as listing 2, is a sample of a simple program to do elementary fertility figures.

I have reproduced and wholly written a few programs to assist in the mathematical education of my son. MULT and two other programs have been written as interactive quizzing programs to test and teach mathematics through praise when he is correct and by showing him the correct way when he is wrong. Thus the computer acts as a teacher and could be utilized in this fashion in every home and classroom for elementary school aged children. More sophisticated programs could be implemented on the SOL for older children. These programs, in the form of games, could serve two purposes, entertainment and education.

Listing 2: A sample of a statistical BASIC application typical of programs used by the author in his avocation of historical studies.

```
10 PRINT"THIS PROGRAM WILL PRODUCE FERTILITY FIGURES"
11 PRINT"FOR THE DATA INPUT. THE OUTPUT CONSISTS OF"
 12 PRINT"THE PROPORTION OF BIRTHS TO MARKIAGES OVER"
13 PRINT"A DECADE WITH FIVE YEAR INCREMENTS BETWEEN DATA."
14 PRINT"THESE FERTILITY FIGURES (THE BIRTH RATE) CONSIST OF
 15 PRINT"THE NUMBER OF BIRTHS FOR A DECADE DIVIDED BY THE"
 16 PRINT"NUMBER OF MARRIAGES FOR A DECADE WHICH BEGAN FIVE"
17 PRINT"YEARS EARLIER."
65 D1=0
100 PRINT"INPUT THE STARTING YEAR (BETWEEN 1650/1795) DESIRED
 105 INPUT Y
 106 PRINT"INPUT THE NUMBER OF SETS OF YEARS OF DATA
107 INPUT D
110 PRINT"INPUT THE NUMBER OF FIVE YEAR INCREMENTS DESIRED
 120 INPUT N
125 DIM Y1(40),M1(40),B1(40),F1(40),Y2(40)
129 DIN F2(40), Y3(40)
130 FOR J=1 TO D
140 READ Y1(J), M1(J), B1(J)
160 NEXT J
195 PRINT"
                          MARRIAGE YEARS
                                                       FERTILITY"
200 FOR J=1 TO D
205 IF I=N THEN 340
210 IF Y1(J)<Y THEN 290
220 Y2(J)=Y1(J+2)-1
230 F1(J)=(B1(J+1)+B1(J+2))/(M1(J)+M1(J+1))
250 PRINT Y1(J), Y2(J), F1(J)
260 S=S+F1(J)
270 D1=D1+1
280 I=I+1
285 F2(1)=F1(J)
266 Y3(1)=Y1(J)
290 NEXT J
340 N=S/D1
350 PRINTENEAN OF FERTILITY FIGURES
395 PRINT
396 PRINT
398 PRINT " YEAR
                                         FERTILITY"
399 PRINT"++++
400 FOR K=1 TO I
ARD L. INT ((FR(K)=10)/2)
430 PRINT Y3(K);"++";TAB(L);"+"
490 NEXT K
900 DATA 1650,5,28,1655,8,32,1660,14,43,1665,9,44
910 DATA 1670,20,78,1675,18,90,1680,26,125,1685,29,168
920 DATA
          1690,24,163,1695,20,156,1700,24,179,1705,34,196
930 DATA 1710,54,839,1715,40,247,1720,64,267,1725,66,269
940 DATA 1730,64,333,1735,66,328,1740,88,371,1745,92,354
950 DATA
          1750,87,372,1755,105,365,1760,88,388,1765,80,377
960 DATA
          1770,65,342,1775,80,311,1780,108,298.1785,105,344
970 DATA 1790,118,228,1795,99,350
THIS PROGRAM WILL PRODUCE FERTILITY FIGURES
FOR THE DATA INPUT. THE OUTPUT CONSISTS OF
THE PROPORTION OF BIRTHS TO MARKIAGES OVER
A DECADE WITH FIVE YEAR INCREMENTS BETWEEN DATA. THESE FERTILITY FIGURES (THE BIRTH RATE) CONSIST OF
THE NUMBER OF BIRTHS FOR A DECADE DIVIDED BY THE
NUMBER OF MARRIAGES FOR A DECADE WHICH BEGAN FIVE
YEARS EARLIER.
INPUT THE STARTING YEAR (BETWEEN 1650/1795) DESIRED:
71650
INPUT THE NUMBER OF SETS OF YEARS OF DATA:
230
INPUT THE NUMBER OF FIVE YEAR INCREMENTS DESIRED:
120
            MARRIAGE YEARS
                                              PERTILITY
                          1659
                                            5.769231
         1650
                                            3.954545
         1655
         1660
                          1669
                                            5.304348
         1665
                          1674
                                            5.793100
         1670
                          1679
         1675
                          1684
                                            6 . 659091
         1680
                          1689
                                           6.018182
                          1694
                                           6.018668
         1685
         1690
                          1699
                                            7.613636
         1695
                          1704
                                           8.522727
         1700
                          1709
                                                 7.5
                                           5-522727
         1705
                          1714
                          1719
         1710
         1715
                          1724
                                           5.538462
                                           4.784615
         1780
                          1729
                                           4-406667
                          1734
         1725
                          1739
                                           4.063953
         1730
         1735
                          1744
                                           4-119318
                          1749
                                           4.033333
         1740
                          1754
         1745
```

5.553943

SEMINARS

Micro Diversions Continuing Microcomputer Education announces

MICROCOMPUTING HARDWARE AND SOFTWARE

An introduction to the design. construction, and programming of microprocessor-based computers.

These are companion "how-to-do-it" courses on the hardware and software technologies of personal computing taught by Micro Diversions product designers.

SOFTWARE OUTLINE HARDWARE OUTLINE he Software Concept History and Culture of Microcomputing (A) The stored program - bits and bytes (A) When, where, why (B) Algorithms in problem solving (B) Algorithms in problem solving
(C) Assemblers and high-level languages (C) Personal computing, applications of microcomputers Introduction to Programming - BASIC Digital Electronics A) Elementary programming concepts (A) Introduction to and survey of component (B) BASIC language statements (C) Simple data structures and examples (B) Common components and how to use Introduction to Assembly Language Large scale integration components (A) Registers memory input output (D) Basics of digital design (B) Data representation (C) Data movement and exchange Introduction to Microcomputer Architecture (A) Buss concept (B) Addressing, input output (D) Arithmetic and logical operations The Z-80 Microprocessor Instruction Set (C) User interface techniques How a Central Processing Unit Works

(A) Introduction to the CPU concept (A) Registers and addressing modes (B) Memory and register data transfers (B) Intel 8080 CPU Arithmetic and logical operations C) Zilog Z80 CPU (D) Bit manipulation Transfer of control, jumps (D) Interrupt architectures and uses (F) 1/0 instructions How a Microcomputer's Memory Works Assembly Language Techniques (A) Random access memory, its architecture General conventions and design (B) Data structures and types (B) Read-only memory Modular programming - subrouti (C) Mass storage (disks and tape cassettes)
(D) Bubble memories (D) Using the instruction set How TV Interfaces Work Interrupt and I/O Programming (A) Character display principles and design Interrupt structures (B) Full graphics interfaces for plotting and (B) 1/0 handlers (C) Data rates and trade-offs (C) Light pens and how to interface them Software Architecture of a Monitor How Microcomputer Peripherals Work The monitor as procedure (AT Keyboard scanners (B) Tape cassette interfaces (C) Telephone interfaces (UARTs and AT Keyboard scanners (B) Functions of a monitor (C) The jump table - vectored entry MODEMs) (D) Analysis of a monitor (D) A/D converters Loading and Debugging Hobbyist Construction Techniques (A) Getting the code in (A) Layout and technical considerations
(B) Mounting techniques
(C) Wire wrapping tools and techniques
(D) How to get started (what to buy, where (C) Breakpoints and snapshots

> Eight Monday and Wednesday **Evening Sessions** 1 May through 24 May

Each course \$110.00 or \$190.00 for both.




(D) Patching and polishing

Micro Diversions, Inc.

to buy)


7900 Westpark Drive, Suite 308 McLean, Virginia 22101 (703) 827-0888

Listing 2, continued:



In closing, I find the SOL system easy to use, fun to program, and important in our home. It provides my family with entertainment in the form of games both from Processor Technology and written by us. It also provides a mathematics tutor at home for my son. It has also given my son an interest in and understanding of computers far beyond his years and education. I definitely recommend the SOL, based on my experiences with it.

80-103A Serial I/O and FSK modem for professional and hobby communications.



Completely compatible with your IMSAI, ALTAIR SOL ** or other S-100 microcomputers. Trademarks of *MITS, **Processor Technology

- Designed for use on the dial telephone or TWX networks, or 2-wire dedicated lines, meets all FCC regulations when used with a CBT coupler.
- All digital modulation and demodulation with on board cyrstal clock and precision filter mean that NO ADJUSTMENTS ARE REQUIRED
 - Bell 103 standard frequencies
 - Automated dial (pulsed) and answer
 - Originate and answer mode
 - 110 or 300 BPS speed select
 - Complete self test capability
 - Character length, stop bit, and parity 90 day warranty and full documentation
- PRICES Bare Board and Manual

Assembled (48 hour burn in)

49.95 279.95

Hayes

P.O. Box 9884, Atlanta, Ga. 30319, 404/231-0574

This page intentionally left blank.

1 EPT 2 - 1

Chapter	2.	Processor Technology ACCESS Newsletter	
Vol	1.	No 1, February 1977	2
Vol	1,	No 2, April 1977	4
Vol	1,	No 3, June 1977	0
		No 4, November 1977	
		No 1. March 1978	

Published by Wible/Rampton Advertising, San Francisco. Volume One, Number One, February, 1977

A Letter from the Editor

"The flowers, the gorgeous, mystic multi-colored flowers are not the flowers of life, but people, yes people are the true flowers of life: and it has been a most precious pleasure to have temporarily strolled in your garden."

Lord Buckley

No, this isn't a poetry journal or philosophical tract, but we do feel that Lord Buckley elucidates the concept behind the Processor Technology newsletter: its contents will be the kind of information that allows you to expand the creative applications of your personal computing system.

ACCESS is dedicated to the creation of a personal dialog between us at PTC and you, the people using our products, because we believe that it's important for you to understand your present system well enough to use it effectively, before you become trapped in the "bigger means better" syndrome.

Hence there will be no advertising of any kind in ACCESS, and no thinly disguised pitches aimed at getting you to part with your hard earned money for the unneccessary duplication of existing hardware.

Each issue will contain articles, engineering/application bulletins, and software (PROGRAM) listings which we think will help you get more fun out of owning your computer.

All we expect from you in return is what's known in technical and psychological circles as feedback. If you have devised a neat hardware modification or written a nifty program, send it to us and you'll get no financial remuneration. You'll just get the glory of seeing your name in print. Very spiritual, eh what?

Aram Attarian II

Subscription Information

ACCESS will be published every six weeks. This first issue is being sent free to all of our customers. If you like what you see, we hope you'll send us \$4.00 for a year's subscription so we can keep the info coming. Write to us at Processor Technology, 6200 Hollis Street, Emeryville, CA 94608.

One to One Communication

Open two-way communication is our goal, and it would be great to have unlimited time to rap with you over the phone. But we can't manage that logistically, so we are instituting procedures that will get your questions answered efficiently, without eliminating the personal touch.

You can get through to our engineers and technical staff any time between 9:30 and noon or 1:30 and 4, Monday through Friday. The number is (415) 652-8080. They'll try to answer your technical questions and provide more detailed product information than you may glean from our literature. It helps a lot if you think out your questions before you call, maybe make a few notes. It helps, too, if you have the manual and/or equipment handy to the phone. The easier it is for you to figure out exactly what we're talking about (and vice versa), the more help we can give in one phone call and the more phone calls we can handle. We'll also be happy to answer your questions if you drop us a letter.

There are two or three situations in which calling us isn't the fastest way to get help. If you have a problem with a Processor

Technology product which you purchased from a local dealer, try your dealer first. They're all authorized to service the products they sell, precisely because they can give you faster and more personalized service than anybody can by mail. Our dealers all have diagnostic tapes available now, so if you need a PTC product tested it can be handled on the spot.

If you need a defective part replaced, just mail it to us with a note of explanation. There's nothing we can do about it over the phone anyway, so you might as well save yourself the time. (Naturally, it helps if yo explanation is as clear and concise as possible, but we can't all be Hemingways.)

If you need service that isn't covered by your warranty, please enclose a check for the \$20.00 minimum service charge. If the cost exceeds that (heaven forbid!) you will be notified before we proceed with the service.

If you do send in one of our products for repair, **please send only the defective board.** For obvious reasons, we cannot be responsible for the care and feeding of your monitors, keyboards or other products from other manufacturers.

MATCHMAKING-Software Division

Since most important programs are written for a particular system, modifications are sometimes in order to improve compatibility with your system. We'll be passing on more good ideas as we come across them; here are two dealing with MITS BASIC and the VDM.

MITS 12K Extended Disk and the VDM

If you don't have a 3P+S interface, you can still use the BASIC program in your VDM manual to link MITS 12K Extended Disc to your VDM driver. Simply change these six lines in the listing of VDM-1 to BASIC link appearing on page AV-18 of your VDM manual, and then run the program as explained there. Change the statements to read as follows:

0106 FOR Y=L TO L+419 0140 POKE G.195:POKE G+1.0:POKE G+2.P:POKE G+3.0 0160 DATA195.151.1001.195.156.1001.245.229.213.197 0162 DATA205.58.1000.193.209.195.147.1001.245.58 0232 DATA0.0.6.225.241.193.201.254.26.195.142

0232 DATA0,0,6,225,241,193,201,254,26,195,14 0234 DATA13,254,127,202,142,13,195,46,1000

MITS 8K or 12K BASIC and the VDM If you have I/O ports that are assigned 20 and 21 instead of 0 and 1, you'll need to make five statement changes in the VDM-1 to BASIC link-program in your VDM manual. The listing appears on pp. AV-17 to AV-19 of the manual, and should be modified as follows:


0078 IF A=219 AND B=16 GOTO 92 0080 IF A=219 AND B=17 THEN I=K:GOTO 106 0152 DATA219,255,31,210,13,1000,219,16,230,2000 0224 DATA201,219.16,230,6000,201.58,140,1001,254 0228 DATA201,219,17,230,127,254,1,202,46,1000

MATCHMAKING-Hardware Division

When you're combining equipment from different manufacturers, optimum performance often depends on specific information about the idiosyncracies of their connections. Owner's manuals can't cover every permutation and combination, so think of this feature as a running supplement that gets down to cases,

3P+S and the OP-80A

We've had a lot of inquiries about using the OP-80A high speed manual punchpaper tape reader with the 3P+S, so we asked Oliver Audio Engineering for the straight scoop on interconnecting it with the 3P+S interface. Note that the OP-80A acknowledge line must be programmed for a negative true (ack) signal. We've also heard from many of our customers that the use of black tape and rolled tape (instead of fanfold) produces more accurate data transfer, using the OP-80.



Announcing the SOL USERS GROUP!

The Sol Users Group was recently organized by members of the Homebrew Computer Club in Palo Alto; SUG is not affiliated in any way with Processor Tech-Technology. The purposes of SUG are to exchange software and other applications, and to create standards. If plenty of interest is shown, a Sol Newsletter will be published and sent to members.


If you own or have ordered a Sol, send your name, address, phone number and ideas to:

Bill Burns 4190 Maybell Way Palo Alto, CA 94306 (Please don't call.)

PT 4KRA Memory Boards and the Motorola M6800

The following diagram should help you expand your M6800 system with minimum headaches. Note that the M6800 can drive 2 4KRA cards at reduced clock rates without bus drivers; however, full buffering is recommended.

CONNECTING PROCESSOR TECHNOLOGY 4KRA MEMORY CARD FOR USE IN MOTOROLA M6800 SYSTEMS



VDM-1 and the 6800 Microprocessor

The VDM-1 can live quite happily with your 6800 if a small amount of signal processing is performed externally.

Signals which may be directly used by the 6800 system are:

ADR0-ADR15 High-active address

D00-D07, High-active data lines. They
D10-D17 may be connected in parallel
to form a bi-directional data
bus if necessary.

Signals which require conversion or re-interpretation:

PSYNC Connect to high-active VMA
(Valid Memory Address)
Φ2Connect to Φ1 clock

Pin 4 of IC 18 Break connection to Pin 3 (74LS132) and connect to Pin 2

SINP, SOUT Connect to the highestorder address bits which are "1" when registers are addressed. (Bits 14 and 15 are suggested.) Presence of a "1" on either line will cause the address decoder to switch its comparison to to the status port address. The status port will therefor respond to any address whose top six bits are set by jumpers (see your VDM-1 manual), and whose bits 8 and 9 are zero. The low-order 8 bits are not decoded during status port response.

PWR Externally generated signal consisting of VMA • Φ2 • R

MWRITE Inverted PWR

PDBIN Externally generated signal consisting of VMA • Φ2 • R

XRDY, PRDY Not used

Note that +8V, +16V and -16V are still required to operate the board, and that 6800 systems designed for all 5-volt operation may have to be augmented. Simple unregulated supplies will perform well, but care should be taken not to exceed +10V on the +8V line to avoid excessive dissipation in the +5V regulator.

What's the Best Monitor for your Sol or VDM-1?

That's one of the questions we're asked most frequently. We always recommend a black & white monitor designed for use with closed circuit TV systems or videotape recorders. Check your local Processor Technology dealer for good sources; they're up on that sort of thing.

If you want to use a regular black & white TV, try for a solid state model with an isolation transformer. In either case, remember that you don't have to spend a lot of money to get a decent picture, so let the rest of the family enjoy that big screen super color set.

A CESSORIE CHARGO CON

Editor: Aram Attarian II
Publisher: Wible/Rampton Advertising,
727 15th Avenue, San Francisco, CA 94118
ACCESS is published approximately every six

ACCESS is published approximately every six weeks. Subscription rate: \$4 per year, from Processor Technology Corp., 6800 Hollis St., Emeryville, CA 94608.

ACCESS Copyright © February 1977 by Processor Technology Corp. All Rights Reserved. Material in this publication may not be reproduced in any form without permission from Processor Technology Corp.


terfacing a Keyboard and VDM with ALS-8, using the 3P+S.

To get your keyboard connection up and running, you'll need to connect 7 data lines, the keyboard strobe, and ground to the J2 connector of your 3P+S. Figure 1 shows the typical keyboard connections.

USING A KEYBOARD AND THE VDM WITH THE ALS-8


KEYBOARD INTERFACE

TYPICAL KEYBOARD CONNECTIONS



The keyboard strobe. This circuit tells the processor when a key has been pressed. You'll need to install an additional IC (preferably in a 16 pin DIP socket) in the unused IC pad in the lower right corner of your 3P+S, and connect it to pin 7 of J2. It's used to condition the strobe. Use a 74¹ c 109 or 74109. (Figure 2)

STROBE CONDITIONING CIRCUIT



To wire the 74109:

- 1) Connect pins 2 and 3 to ground.
- Pins 16 (VCC) and 8 (GND) are already connected on board.
- 3) Connect pin 1 to pin 1 of IC 15 to provide a pull-up connection.
- 4) Connect pin 5 to pin 11 of IC 15 to reset the flip-flop when data has been accepted.
- 5) Connect pin 7 to a point on 3P+S leading to J2 pin 12. This point will go low when the strobe occurs.
- 6) Connect pin 4 to a point on 3P+S leading to J2 pin 7, the point where the strobe from the keyboard will be connected.


The data lines. Either seven or eight data lines are used to transmit the ASCII code for the key being pressed to the computer. They're connected to the B port inputs of the 3P+S in the following manner:

Keyboard Signal	3P+S J2 Connector	Data Bit
Bit 1	Z	D 0
Bit 2	Y	D1
Bit 3	X	D2
Bit 4	W	D3
Bit 5	V	D4
Bit 6	U	D 5
Bit 7	T	D6
Bit 8*	S	D 7
Pin J2-S is left	unconnected if vo	ur keyboard

*Pin J2-S is left unconnected if your keyboard doesn't have an eighth bit.

Ground, +5V, -12V. These provide power for the circuitry of the keyboard. Ground is simply connected to pin 12 of J2. +5V and -12V (regulated) should be provided by a separate power supply. Some KYBDS only require +5V. Figure 3 shows an example of one, assembled on a small piece of perf board and attached to the keyboard or main frame. Jumper it to the keyboard connector.

ASSEMBLE ON SMALL PIECE OF PERF BOARD AND ATTACH TO KYBD OR MAINFRAME AND JUMPER TO KYBD CONNECTOR



Jumper areas. Only two are important for the keyboard interface: Area A must be jumpered for address 0 (i.e., all to ground), and Area B must be jumpered from left to center, to set port A at 0 (status) and port B at 1 (data) to correspond to Processor Technology software.

Testing the interface with ALS-8.

1) Turn on the computer and examine location E000H. When you hit Run, the address lights should look like this:

A15 A14 A13 A12 A11 A10 A9 A8
• • • • • • • • • • •

- = Light on \circ = Light out
- Be sure the keyboard is sending upper case characters. Type EXEC E024, then hit the carriage return key. Address light A13 should blink instantaneously at this point.

- Type IODR/SYSIO/0 FE77, then hit the return key. Again, address light A13 should blink.
- Now hit Space, Space, Return; wait a moment and then hit Control Z. The screen should now be blank.
- 5) Hit Control S. The word SPEED? should now appear in the lower left corner of the screen. If it doesn't, you may have to adjust the horizontal and vertical controls on the VDM to get this message onto the visible portion of the screen.
- 6) Type 1; you should get an automatic carriage return, then type DUMP 0 FFFF and hit Return. Memory will now dump on the VDM display. You can hit the Escape key to stop the dump.
- 7) Now you're ready to start programming with the ALS-8! Try some of the examples from the ALS-8 manual to familiarize yourself with its operation.

Hoare's Law of Large Programs
Inside every large program is a small program struggling to get out.

Good News for our Customers in Europe: VDM-1 and the European 50 Hz Standard

The European television standard maintains the same horizontal rate as the U.S. (15,750 Hz), but it defines a raster of 625 lines at a field rate of 50 Hz. The effect is to increase the number of scan lines on the screen.

It's quite easy to modify your VDM-1 to work on this standard. Simply disconnect pin 5 of IC 8 from pin 6, and reconnect it to ground (pin 4). This increases the modulus of the counter to 8 in the VDISP time, resulting in 4 extra character lines (52 scan lines) on the display. The total is now 312 scan lines per field, the equivalent of 624 per frame.

The field rate should be close enough to 50 Hz to reduce any swim effects to less than 0.1 Hz. You may have some trouble centering the display in the frame, because the standoff time to VSYNC from the bottom of the display is still on the 60 Hz standard. If the effect is objectionable, increase Resistor R 34 in series with the VPOS control.

Rule of Accuracy

When working toward the solution of a problem it always helps you to know the answer.

Sattinger's Law

It works better if you plug it in.

Once upon a time, in a curious little

Newett Awl's Choo Choo Train Or, Idle Fantasies on a VDM Screen

place, there was a Sol system and a programmer sitting around with nothing to do. So **6666** 9555 9555 Newett Awl decided to tell his computer a 9919 5555 8828 bedtime story, and VDM-1 helped him out by 9999 ØØ3Ø drawing the pictures. 6646 8888 Try it on your system. Ol' Uncle Sol 9999 ØØ5Ø makes a great babysitter. 8868 5555 5555 6070 5571 TRAIN ONCE UPON A TIME. 5555 XRA ØØØ1 D3 C8 ØØØ3 21 84 Ø1 ØØØ6 Ø1 ØØ Ø8 ØC8H IN A CURIOUS LITTLE PLACE ØØ72 OUT H, SHED B, 2548 6886 THERE WAS LXI 5595 .. A TINY TRAIN XSI ØØØ9 36 EMPTY M, 20H 0100 MVI .. AND IT STAYED IN A .. TINY SHED ØØØB 23 Ø11Ø INX ØØØC ØB Ø12Ø DCX В .. THAT WAS ALL EMPTY ØØØD AF Ø13Ø XRA ØØØE A8 0140 XRA ØØØF C2 Ø9 ØØ ØØ12 21 F7 Ø2 2150 EMPTY Ø16Ø LXI H, CLOUD .. EXCEPT FOR A HUGE ØØ15 11 ØØ ØØ Ø17Ø LXI ØØ18 Ø6 ØF Ø18Ø MVI B, 15 B ØØ1A CD 5Ø ØØ Ø19Ø CALL SMOl ØØ1D 11 2B ØØ Ø2ØØ LXI D,43 L ØØ2Ø Ø6 ØD Ø21Ø MVI B,13 ØØ22 CD 5Ø ØØ ØØ25 11 3Ø ØØ Ø22Ø CALL SMOl Ø23Ø LXI D,48 Y ØØ28 Ø6 Ø9 0240 MVI B.9 ØØ2A CD ØØ2D 11 5Ø ØØ 34 ØØ 0250 CALL SMOl Ø26Ø LXI D,52 ØØ3Ø Ø6 Ø4 ØØ32 CD 5Ø ØØ35 11 3B Ø27Ø MVI B,4 SMO1 50 00 Ø28Ø CALL Ø29Ø LXI D,59 ØØ38 Ø6 Ø2 Ø3ØØ MVI B, 2 993A CD 50 00 Ø31Ø CALL SMOl 0 ØØ3D 11 3C ØØ Ø32Ø LXI D,60 ØØ4Ø Ø6 Ø1 Ø33Ø MVI F ØØ42 CD 5Ø ØØ ØØ45 11 3E ØØ ØØ48 Ø6 Ø1 ØØ4A CD 5Ø ØØ ØØ4D C3 59 ØØ SMO1 Ø34Ø CALL LXI Ø35Ø D,62 M Ø36Ø MVI B,1 SMO1 Ø37Ø CALL Ø38Ø JMP ENGIN ØØ5Ø Ø39Ø ØØ5Ø 19 8488 SMOl DAD ØØ51 36 MVI M. SMOKE .. COUGH 6F 8418 9953 \$428 INX .. COUGH ØØ54 Ø5 \$436 DCR B ØØ55 C2 51 00 Ø44Ø JNZ SMO₂ ØØ58 C9 \$45\$ RET COMING OUT OF THE STACK ØØ59 \$46\$ ENGINE H, SHED+322H A TINY LOCOMOTIVE ØØ59 21 A6 Ø4 8478 LXI M, 16H WITH A LITTLE SMOKESTAK ØØ5C 36 16 Ø48Ø MVI 005E 21 A9 Ø49Ø LXI H, SHED+325H AND A LITTLE BELL ØØ61 36 Ø7 Ø5ØØ MVI M, Ø7H ØØ63 21 AB Ø4 \$518 LXI H, SHED+327H .. AND A TINY DOME ØØ66 36 6E Ø52Ø MVI M, 6EH ØØ68 2A 66 Ø1 ØØ6B 22 AE Ø4 ØØ6E 2A 68 Ø1 ØØ71 22 BØ Ø4 LHLD CABl .AND A CAB Ø53Ø SHED+32AH WITH WINDOWS Ø54Ø SHLD Ø55Ø Ø56Ø Ø57Ø SO THAT YOU COULD LHLD CAB2 SHED+32CH SEE INTO WHERE THE ØØ71 22 BØ Ø4 ØØ74 2A 6A Ø1 ØØ77 22 B2 Ø4 SHLD LHLD CAB3 ENGINEER AND THE SHED+32EH FIREMAN SAT. SHLD Ø58Ø Ø1 Ø4 Ø59Ø IT HAD A BEAUTIFUL ØØ7A 2A 6C ØØ7D 22 E5 LHLD BOIL 0600 SHLD SHED+361H POLISHED ØØ8Ø 2A 6E Ø1 LHLD BOI2 BRASS Ø61Ø 22 E7 SHED+363H BOILER ØØ83 Ø62Ø SHLD 2A 7Ø Ø1 22 E9 Ø4 LHLD BOI3 WITH ØØ86 Ø63Ø SHED+365H THE NUMBER Ø64Ø SHLD ØØ89 "99" ON THE 22 EB Ø65Ø SHLD SHED+367H ØØ8C SIDE OF 2A 72 Ø1 LHLD BOI4 ØØ8F Ø66Ø 22 04 Ø67Ø SHLD SHED+369H THE CAB ØØ92 BUT YOU COULDN'T ØØ95 2A 74 Ø1 Ø68Ø LHLD BOI5 SHED+36BH SEE EITHER THE 22 EF Ø69Ø SHLD ENGINEER OR THE ØØ9B 2A 76 Ø1 Ø7ØØ LHLD BOI6 (continued on page 11)


Page 4

Ups and Downs or How to Type in Upper Case Only without Shifting

If you have a keyboard with both upper and lower case operation, the frequent shifts are a pain when you're entering alphanumeric data. Here's a simple cure that sets data bit D5 low when a lower case alphabetic character is output from the keyboard, thus presenting it to the computer as upper case.

You'll need two chips, either a 7404 and a 7408 or a 74LS04 and a 74LS08. (Either pair works fine.) Install them on a small piece of perf board as shown in the diagram, and tie all unused inputs to +5V.

The pins you'll be using on the 04 chip are 3, 5, 9, 11, and 13; on the 08 chip use 4, 5, 9, 10, 12, and 13.



FLASH -- VDM Access Flicker **Eliminated**

That blasted flicker you get whenever the VDM memory is being frequently accessed occurs because the screen is blanked for a very short time whenever the processor reads or writes to memory. You can eliminate it by modifying the timing system so that VDM memory is accessed only when the beam of the picture tube is off the visible portion of the screen. The VDM has a timing signal that indicates this condition, and you can use it to synchronize access to display memory.

Connect a jumper wire from pin 13 of IC 39 to pin 5 of IC 39. This hooks up an unused section of IC 39 to DI bit 1. Connect a wire from IC 39 pin 14 to IC 15 pin 9. (This allows programs which access the VDM memory to use the timing signal.) Now when C8 is input, bit 1 will be low whenever the display memory can be accessed.

We'll explore the implications further in the next issue, and provide an example program or two.

Murphy's Law of Thermodynamics Things get worse under pressure. Lowery's Law

If it jams-force it. If it breaks, it needed replacing anyway.



Applications News Ham Computer Based on Sol Terminal System

SYSTEM 4000 ham computer was developed by Curtis Electro Devices, Inc., Box 4090, Mountain View, Ca. 94040. The company makes ham keyers and an industrial line of PROM programmers. We asked the president, John G. Curtis, to comment on working with the Sol system; he did all of the hardware and software work himself, developing programs for the Sol Terminal on ALTAIR with ALS-8, VDM-1, 40K of RAM, 3P+1, Tarbell cassette system, Bytesaver, ASR-33 TTY, and Motorola video monitor. Jack's report was glowing:

"I had no previous experience or trainin software development. It was all learned on the fly from books and practical experience. (Try, try and try again!!!) . . . Not too much assistance was required. The ALS-8 is easy to use and the Simulator program is absolutely essential. The Editor is also absolutely necessary. (Everything is

necessary!!). . .

"The Sol went together with a minimum of effort and trouble even though it was one of the first units actually put on the line. There were things which didn't work but with the help of PTC (especially Bob Marsh and Aram) things were put in order in

a hurry.
"In my opinion, the Sol terminal is the most ideal small computer system available today (certainly at that price) and every needed feature is there. For our purposes it was absolutely ideal from every standpoint. We are now able to get the computer into the hamshack on a commercial basis. This has been predicted for some time, now it has happened."

System 4000 Ham Computer

The SYSTEM 4000 is a full scale standard desk top minicomputer specially equipped with firmware programs and interfaces for the amateur radio operator. Being a stand-alone computer, it can also run bu ness, educational, scientific or games pro-

The SYSTEM 4000 is derived from the Sol terminal Computer and can take advantage of Processor Technology's programs and accessories. System 4000 uses the standard S-100 bus for plug-in accessory boards, and the owner can add or exchange PROM integrated circuits to update the system. Features:

Morse reader, capable of receiving code at speeds of 6-250 WPM (or higher). CRT or TTY output, selectable for upper and lower

Paddle keyer, with dot and dash memory, iambic and full self completion. CRT or TTY printout.

Keyboard keyer, sends Morse from keyboard. CRT or TTY output.

ASCII terminal, half or full duplex.

Complete details can be obtained by writing to: Curtis Electro Devices, Inc., P. O. Box 4090, Mountain View, Ca. 94040.

Murphy's Third Law

In any field of scientific endeavor, anything that can go wrong will go wrong.

Sevarenid's Law

The chief cause of problems is solutions. Brooks's Law

Adding manpower to a late software project makes it later.

O'Tooles's Commentary on Murphy's Laws Murphy was an optimist.



A major purpose of this newsletter is helping you stomp out the bugs that inevitably occur even in the best of systems. Bug Squad will be a regular feature. We'll tackle the problems we've encountered most frequently, and you're also invited to send in any problems that have been bugging you. Send solutions, too, if you've found them. Share the wealth.


For starters, here's how to fix a few of the bugs that crept into early Sol systems:

Memory Protect/Unprotect Lines The bug: Erratic behavior when early Sol-PC, Sol-10, and Sol-20 units are used with S-100 bus compatible memory modules. The squasher: On early Sol circuit boards, the protect (pin 70) and unprotect (pin 20) lines are floating. Simply ground bus line 70 on the Sol PCB itself to disable the memory protect signal.

Current Loop Source

The bug: R23, a 470 ohm ½w resistor, is incorrectly tied to +5 on early Sol PC boards, producing less than a full 20mA current to teletype connections.

The squasher: Reconnect R23 to +12V, which is only ½" away. Check to make sure that R29 remains connected to +5V. We suggest that the 20mA current loop connections (such as for ASR33) be made as follows:




Accidental Avalanche

The bug: On some Sol Power Supply REG Boards, the SCR1 (MCR 106-2) in the +5 volt regulated supply will intermittently go into the avalanche mode. This draws sufficient current to drop the +5 volt to about +1V. This modification will prevent the accidental triggering, but will retain the

overvoltage protection of the crowbar circuit.

The squasher: Make the modification here by adding the components shown and cutting appropriate traces (as shown).




Law of Selective Gravity (The Buttered Side Down Law)

An object will fall so as to do the most damage.

Where the %**# is Emeryville?


Emeryville. Ca., is located at the foot of the Oakland Bay Bridge, squeezed between Oakland and Berkeley. Neither wishes to claim it. Emeryville consists largely of mudflats and factories, the principle landmarks being a highrise apartment complex called Watergate (no relation), a shoreline assemblage of driftwood sculptures, and Processor Technology. Before the rise of Processor Technology, the main industry was legal gambling clubs. We, however, plan to put Emeryville on the map.



Consol Source Listing

For those of you who haven't seen it yet, here's the source list for the minimum Sol operating System, CONSOL. It provides all necessary display routines, along with standardized calling points for input/output operations.

COPYRIGHT 1976



Page 6

KIGHT 1976				C#61 C9	0193		RET	200	EXIT FROM VDMOT
	0052 · -	Sol SYSTEM I/O ROUTINES		C#62 C#62 C#62 7E	8194 ° 8195 ° #196 7	•			
	0053 °	G CODE IS STANDARDIZED FOR ALL		C#63 #7 C#64 CA 78 C#	8196 7 8197 8198	. JACH	ORA JZ	A,M A CMAR	GET CHR PROM TABLE SERO IS THE LAST
	8855 * SOLPTWARE IT	PROVIDES COMMON ENTRY POINTS PO	OR IMPUT AND	C#67 #8 C#68 23	0199		CMP	B	TEST THE CHR
	9857 * PARALLEL I/O	OPERATIONS BECAUSE OF SPACE LI	MITATIONS.	C#69 C2 76 C#	6288 6281		INX JNZ	H MEXT	POINT PORWARD
	0059 ·			COC ES COCD CD 3D C1	6262 6263		CALL	CREM	POUND ONESAVE ADDRESS REMOVE CURSOR
	0061 ·			C070 E1 C071	0204 0205 *		POP	H	
	0063 °	P TABLE IMPUT/OUTPUT ROUTINES		C#71	8286 ° 8287 °	THIS	ROUTINE	DISPATCHES	TO THE ADDRESS POINTED TO
	8065 " THE OUTPUT DEV	OUTPUTS THE CHARACTER IN REGIST	UTPUT SELECT	C#71 C#71	0288 * 0209 *	LAST I	HL REGI	STER PAIR. THE STACK.	THE RETURN ADDRESS IS THE
	8867 *	DEVICES ARE DEFINED AS FOLLOWS:	:	C871 C871 7E	8210 °		MOV	A.M	GET LOW BYTE
	8668 * 8 - VDM 1 8669 * 1 - SERIA	AL OUTPUT PORT		C872 23 C873 66	8212 8213		INX	B . A	AND THE HIGH
	0071 * 3 - ERROI	LLEL OUTPUT PORT (NOT AVAILABLE R HANDLER	E ON CONSOL)	C074 6F C075 E9	8214 8215		MOV PCHL	L.A	WE BAVE PLACED THEN BOTH
	8872 * 80TRY AT: SC	OUT SELECTS CURRENT OUTPUT DEVIC		C876 C876	8216 ° 8217 °				
	8875 *	OUT SELECTS DEVICE IN REGISTER		C876 23 C877 23	8218 M	EXT	INX	2 2	GO TO MEXT
3A #3 C8 E6 #3	8876 SOUT LDA 8877 AOUT ANI	OPORT GET PORT NUMBER PRO 3 REEP IT IN CONTROL		C878 C3 62 C8 C878	8228 8221 *		JMP	TERCH	
21 84 C1	6878 PUSE 6879 LXI	H WE'LL RESTORE IT LA BOTAB POINT TO TABLE	ATER	C878 C878 78	8222 °		NOV	A,B	GET CHARACTER
17 15	8881 RLC	COMPUTE ADDRESS		C87C B7 C67D C8	8224 8225		ORA RI	A	RETURN IF A MULL
3 71 CO	8882 MOV 8883 JMP	L,A ME MAVE IT DISPT GO TO ML		COTE PE 7P	8226 8227		CPI RI	7PH	IS IT A DEL? GO BACK IP SO
	0684 * 0085 *			C081	8228 ° 8229 °				
	8886 * THIS ROUTINE	INPUTS A CHARACTER TO REGISTER	'A' FROM	C881 C881 CD 21 C1	8238 * 8231 O		CALL	VDADO	GPT SCREEN ADDRESS
	6088 * THE CURRENT INF	PUT DEVICE POINTED TO BY THE CUR	MENT INPUT	C#84 78 C#85 E6 7F	8232 8233	m	MOV	A,B 7PH	GET CHARACTER POR OUTPUT MO HIGH BITS GO PAST HERE
	6696 * ENTRY POINTS			C087 77 C088 3A 06 C8	6234 6235		MOV LDA	M, A MCHAR	PUT CHR ON SCREEN GET CHARACTER POSITION
	8892 * 8 - KEY	YBOARD INPUT		COSB PE 3P	6236		CPI	63	GET CHARACTER POSITION BHD OF LIME?
	8894 * 1 - SEF	RIAL INPUT RALLEL INPUT (NOT AVAILABLE ON C	CONSOL)	C08D DA AD C0 C090 3A 01 C0	8237 8238		JC LDA	TIME	
		ROR HANDLER		C093 PE 0P C095 C2 AD C0	8239 8248		CPI JNZ	OK OK	EMD OF SCREEN?
A 84 C8	0098 SINP LDA 0099 AINP ANI	IPORT GET PORT NUMBER PRO WE MUST BE REASONAB		C898	8241 ° 8242 °	EMD O	P SCREEN	BOLL UP (OME LIME
5 1 8C C1	0100 PUSH 0101 LXI	H SAVE HAL B, ITAB POINT TO TABLE		· C898 C898 AF	8243 ° 8244 Se		XRA	A	
7 5	6102 RLC 6103 ADD	THE MATH		C099 32 00 C8 C09C 4F	8245 8246 BI	ROL	STA MOV	MCHAR C,A	BACK TO FIRST CHAR POSITION
F	6164 MOV	L.A DONE		COOD CD 28 C1 COAD AP	8247 8248		ZRA	A	CALCULATE LINE TO BE BLANKED
3 71 CO	8185 JRP 8186 *	DISPT WE HAVE THE ADDRESS	GO TO BEAVEN	CBA1 CD E9 CB CBA4 3A B2 CB	8249 8258		LDA	CLIN1 BOT	CLEAR IT
		IMPUT STATUS CHECK		CBAS E6 BP	0251 0252		INR ANI	A GPH	
	8189 * SILS THIS ROUTINE T	PESTS THE REYBOARD STATUS AND RE	TURNS	CBAA C3 DD CB	8253 8254 *		JMP	ERAS 3	
	Sill . WITH THE TEST Sil2 .			COAD	0255 · 0256 ·		MENT LINE	COUNTER IF	MECESSARY
B PA 6 81	6113 KSTAT IN 6114 ANI	STAPT GET STATUS WORD EDR TEST KEYBOARD BIT		CBAD 3A BB CB CBBB 3C	8257 OI 8258	K	LDA INR	A	GET CER POSITION
9	0115 RET	. FLAGS ARE SET		C##1 32 88 C8 C##4 FL 4#	8259 8268		STA CPI	NCHAR 64	STORE THE NEW
	8117 . EEABOWED	DATA IMPUT		CHR DS	8261 8262		RC ERA	A	WE'RE PAST THE SHO REWIND THE COL
	8119 " THIS ROUTINE,	ENTRY AT RREAD, GETS THE DATA P	PROM THE	COMP 35 BB CB	8263 8264		STA LDA	MC MAR LIME	GET THE LINE COUNT
1	8121 * REYBOARD. ON	RETURN THE CHARACTER IS IN REGI	STER A.	COME 3C CUBF E6 0F	8265 8266		IMR Ani	A OPB	NOD 15 INCREMENT
1 D 22 CB	6123 RREAL POP 6124 RREAD CALL	H JUMP TABLE ENTRY PO RETAT CHECK STATUS	107	COC1 32 81 C8	8267 C		STA Ret	LINE	STORE THE NEW
2 28 C0 8 PC	0125 JN: 0126 IN	EREAD MAIT FOR INPUT EDATA GET DATA		COCS COCS	8269 · 8278 ·		E SCREEN		
9	8127 RET 8128 *	. GO BACK WITH IT		COC5 COC5 21 00 CC	8271 * 8272 P	ERSE	LXI	B, VDMEM	POINT TO SCREEN
	6129 * 6136 * SERIAL IMPUT	STATUS CHECK		COCA 36 AD	8273 8274 *		WVI	M,88H+'	THIS IS THE CURSOR
# P8	6131 * 6132 SSTAT IN	SERST GET SERIAL STATUS W	ORD	COCA 23 COCB 7C	8275 E		MOV MOV	A, H	BUMP THE COUNT GET HIGH ORDER
6 48	8133 ANI 8134 RET	SDR TEST FOR SERIAL DATA PLAGS ARE SET	A READY	CACC DE DA	8277 8278		CPI JNC	ERAS 2	THE TOP
	8135 * 8136 *			C0D3 C3 CA C0	8279 8288		MVI Jmp	ERAS1	PUT IN A BLANK
	8137 * SERIAL DATA I			CBD6 AF	8281 * 8282 E	RAS 2	ERA	A	
1 D 31 CØ	6139 SREA1 POP 614# SREAD CALL	H RESTORE HL PROM JUM SSTAT MORMAL ENTRY POINT	P TABLE ENTRY	CUD7 32 81 C8 CODA 32 80 C8	8283 8284		STA STA	LINE MCHAR	SERO LINE LEFT SIDE OF SCREEN
A 37 CØ B F9	8141 JZ 8142 IN	SREAD MAIT FOR INPUT SDATA GET DATA BYTE		CODD D3 PE	8286 E	RAS3	OUT	DETAT	BESET SCROLL PARAMETERS
9	0143 RET	. WE HAVE IT		CODF 32 B2 C8 COE2 C9	8287 9288		STA RET	BOT	BEGINNING OF TEXT OFFSET
	8145 * 8ERIAL DATA O	UTPUT		CHE3 COE3	8289 * 8298 *				
	6147 ° 6148 SEROT POP	E JUMP TABLE ENTRY PO	INT	C8E3 CD 21 C1 C8E6 3A 88 C8	8291 C. 8292	LINE	CALL LDA	VDADD BCEAR	GET CURRENT SCREEN ADDRESS CURRENT CURSOR POSITION
B F8	8149 SDROT IN 8158 RAL	SERST GET PORT STATUS PUT HIGH BIT IN CAR	LRY .	COES PE 40 COES DO	8293 C. 8294	LINI	CPI RNC	64	MO MORE THAN 63 ALL DONE
41 C#	8151 JNC 8152 MOV	SDROT LOOP UNTIL TRANSMIT	TER BUFFER IS EMPTY	COEC 36 20 CORE 23	8295 8296		NVI INX	M	ALL SPACED OUT
	8153 OUT 8154 RET	SDATA SEND IT OUT		COEP 3C CUPO C3 E9 CO	8297 8298		INR JRP	A CLIM1	LOOP TO END OF LINE
	0155 *	TO BE DONE		COP3	8299 °		CURSOR		
				C#F3	8381 °		XRA	A	
1 - 51	0156 ° 0157 °				6363		STA JMP	MCHAR CUR	
1 - 51	8157 * 6158 * 8159 *			C8F4 32 88 C8			onr		
1 - 51	8157 * 8158 * 8159 * 8168 * VIDE	CO DISPLAY DRIVER ROUTINES		CSF4 32 66 C8 CSF7 C3 C1 C6 CSFA	8384 8385 •	MOVE	UBSOP PO		
	0157 • 0158 • 0159 • 0168 • VIDE 0161 • 0162 • 0162 • 0163 • THESE ROUTINES	ALLOW FOR STANDARD VIDEO TERMI	MAL	CSF4 32 MM CS CSF7 C3 C1 C6 CSFA CSFA CSFA	8305 ° 8306 ° 8387 °	MOVE C	URSOR DO		
1 - 51	8157 * 8158 * 8159 * 8168 * 8161 * 8161 * 8162 * 8163 * THESE ROUTINES 8164 * 0PEKATIONS. 0 886157 * 886157 * 886157 * 886157 * 886157 * 886157 * 886157 *		MAL 'UT IS IN RETURN.	CSF4 32 88 C8 CSF7 C3 C1 C8 CSFA CSFA CSFA CSFA 3A 81 C8 CSFD FE SF	8385 * 8386 * 8387 * 8388 Pt 8389	NOVE C	LDA CPI	LINE 15	NOW PAR TS DOWN?
	# 158 * 8158 * 8159 * VIDE 8168 * 8161 * 8162 * 8163 * 8163 * 8164 * 0PEMATIONS. O DESTRUCTIONS. O REGISTER B AND 8166 * THE 'CONSOL	ALLOW POR STANDARD VIDEO TERMI M ENTRY, THE CHARACTER FOR OUTP ALL REGISTERS ARE UNALTERED ON VERSION OF THIS ROUTINE IS A	PUT IS IN RETURN.	C8F4 32 88 C8 C8F7 C3 C1 C8 C8FA C8FA C8FA 3A 81 C8 C8FD FE 8F C8FF C8 C8FD SC	8305 * 8346 * 9387 * 9308 PH 9309 9310 9311	MOVE C	LDA CPI RI INR	LINE 15	NOW PAR IS DONN?
	## 158 ## 258 ##	ALLOW FOR STANDARD VIDEO TERMI ON ENTRY, THE CHARACTER FOR OUTP ALL REGISTERS ARE UNALTRACO ON VERSION OF THIS ROUTINE IS A OF ROUTINES ORIGINATED BY:	PUT IS IN RETURN.	CSF4 32 SS CS CSF7 C3 C1 C8 CSFA CSFA CSFA 3A S1 CS CSFL FE SF CSFL FE SF C100 3C C101 C3 C1 C8 C104 C3 C1 C8	8385 * 8386 * 8387 * 8388 P 8309 8318 8311 8312 8313 *	MOVE C	LDA CPI RI INR JMP	LINE 15 A CUR	
	## 1515 ## 151	ALLOW FOR STANDARD VIDEO TERMI IN ENTRY, THE CHARACTER FOR OUTP ALL REGISTERS ARE UNALTEREO ON VERSION OF THIS ROUTINE IS A OF ROUTINES ORIGINATED BY: AM EXTLEBOROUGH OF	PUT IS IN RETURN.	COPTA 32 MM C8 COPTA C3 C1 C0 COPTA COPTA COPTA AN 01 C6 COPTA PE MP COPT C8 C180 3C C181 C3 C1 C8 C184 C184 C184 C184	8385 * 8386 * 9387 * 8388 P 8389 9 8311 8312 8313 * 8314 * 8315 *	MOVE C	LDA CPI RI INR JMP E TO MOVI	LINE 15 A CUR E THE CURSON	UP OME LIME
	## 158 * VIDE ## 158 * ## 158 * VIDE ## 158 * VIDE ## 158 * VIDE ## 158 * ## 158 * VIDE ## 158 * VIDE ## 158 * VIDE ## 158 *	ALLOW FOR STANDARD VIDEO TERMIN ENTRY, THE CHARACTER FOR OUTPOUT ALL REGISTERS ARE UNALTERED ON. VERSION OF THIS ROUTINE IS A OF ROUTINES ORIGINATED BY: AM RETTLEBORDUGH OF LEGE STATION, TEXAS	UT IS IN A RETURN.	COPT 32 SU C8 COPT C3 C1 C0 COPTA COPTA COPTA COPTA COPTA COPT C6 C100 3C C101 C3 C1 C0 C184 C184 C184 C184 C184 C186 C187 AP 1 C8 C100 C1 C1 C100 C1 C0 C100 C1 C100	8305 * 8306 * 8307 * 8308 P 8309 8311 8312 8313 * 8314 * 8315 P 8317	MOVE C	LDA CPI RI IMR JMP E TO MOVI LDA ORA	LINE 15 A CUR	UP ONE LINE
	## 157 * ## 158 * ##	ALLOW FOR STANDARD VIDEO TERMIN ENTRY, THE CHARACTER FOR OUTPO ALL REGISTERS ARE UNALTERED ON VISION OF THIS ROUTINE IS A OF ROUTINES ORIGINATED BY: AM RETTLEBOROUGH OF LEGE STATION, TEXAS LD CONTAIN THE ESC SEQUENCES AM	UT IS IN A RETURN.	CBFA 32 88 C8 CBFA C3 C1 C8 CBFA CBFA CBFA 3A 81 C8 CBFA 5A 81 C8 CBFA 5C C181 C3 C1 C8 C181 C3 C1 C8 C184 C184 C184 C184 C184 C186 C8	8305 * 8346 * 8346 * 8346 * 8348 * 8348 * 8348 * 8348 * 8314 * 8315 * 8316 * 83	MOVE C	LDA CPI RI INR JMP E TO MOVI LDA ORA RI	LINE 15 A CUR E THE CURSON	UP OME LIME
,	## 157 * ## 158 * ##	ALLOW FOR STANDARD VIDEO TERMIN ENTRY, THE CHARACTER FOR OUTPO ALL REGISTERS ARE UNALTERED ON VISION OF THIS ROUTINE IS A OF ROUTINES ORIGINATED BY: AM RETTLEBOROUGH OF LEGE STATION, TEXAS LD CONTAIN THE ESC SEQUENCES AM ATION FEATURES.	UT IS IN A RETURN.	COPT 32 SU C8 COPT C3 C1 C8 COPT C3 C1 C8 COPT C4 COPT C4 COPT C5 C180 3C C180 3C C180 3C C180 4 C184 C184 C184 C184 C186 C189 3D C188 C8 C189 3D C188 C3 C1 C188 C3 C189 3D	0305 0 0306 0 0307 0 0308 P 0310 0311 0312 0313 0 0315 0 0315 0 0315 0 0315 0 0315 0 0315 0	MOVE C	LDA CPI RI INR JMP E TO MOVI LDA ORA RI DCR JMP	LINE 15 A CUR E THE CURSON	UP ONE LINE
9 · · · · · · · · · · · · · · · · · · ·	## 1515 ## 151	ALLOW FOR STANDARD VIDEO TERMIN ENTRY, THE CHARACTER FOR OUTPO ALL REGISTERS ARE UNALTERED ON VERSION OF THIS ROUTINE IS A OF ROUTINES ORIGINATED BY: AM RETTLEBOROUGH OF LEGE STATION, TEXAS LED CONTAIN THE ESC SEQUENCES AN ATION FEATURES. B SAVE EVERYBODY D ENTRY FROM DEVICE S	POT 15 IN FRETURN. MINIMUM ID OTSER	COPT 32 SU C8 COPT C C3 C1 C8 COPT C C3 C1 C8 COPT C C3 COPT C8 COPT C8 C180 3C C181 C3 C1 C8 C184 C3 C184 C3 C184 C3 C186 C5 C189 C5 C189 C3	8385 ° 8387 ° 8388 ° 8387 ° 8388 ° 8318 ° 8311 ° 8314 ° 8315 ° 8316 ° 8316 ° 8316 ° 8312 ° 8322 ° 8322 ° 8322 ° 8322 ° 8322 °	MOVE C	LDA CPI RI INR JMP E TO MOVI LDA ORA RI DCR JMP	LINE 15 A CUR E THE CURSON LINE A	E UP ONE LINE GET LINE COUNT DOB'? GO RORE UP THAN UP
5 5 5 5	## 1515 ## 151	ALLOW FOR STANDARD VIDEO TERMIN ENTRY, THE CHARACTER FOR OUTPO ALL REGISTERS ARE UNALTERED ON .' VERSION OF THIS ROUTINE IS A OF ROUTINES ORIGINATED BY: AN RETTLEBOROUGH OF CLEEN CONTAIN THE ESC SEQUENCES AN ATION FEATURES. H SAVE EVERYBODY D ENTRY FROM DEVICE B B PSM	POT IS IN CRETON. MINIMUM DOTHER SELECT	COPT 32 SU C8 COPT C C3 C1 C8 COPT C C3 C1 C8 COPT C C3 C1 C8 COPT C8 COPT C8 C180 3C C181 C3 C1 C8 C184 C3 C184 C3 C184 C3 C185 C8 C189 3D C188 C3 C189 3D C188 C3 C1 C8 C189 C3 C189 C3 C1 C8 C189 C3 C189 C3 C1 C8 C189 C3 C189 C3 C1 C8 C189	8305 ° 8307 ° 9308 P 9309 ° 9310 ° 9311 ° 9311 ° 9315 ° 9315 ° 9318 ° 9319 ° 9328 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 9323 ° 9324 ° 93	MOVE C	LDA CPI RI IMR JMP E TO MOVI LDA ORA RI ECR JMP CURSOR LE	LIBE 15 A CUR E THE CURSON LIBE A A CUR PT OME POSIT	E UP ONE LINE GET LINE COUNT DOB'? GO RORE UP THAN UP
5 5 5 5 5 5 5	## 157 * ## 158 * ##	ALLOW FOR STANDARD VIDEO TERMIN ENTRY, THE CHARACTER FOR OUTPO ALL REGISTERS ARE UNALTERED ON VIVESION OF THIS ROUTINE IS A OF ROUTINES ORIGINATED BY: AM RETTLEBOROUGH OF LEGE STATION, TEXAS ED CONTAIN THE ESC SEQUENCES AM ATION FEATURES. H SAVE EVERYBODY D ENTRY FROM DEVICE B B PSM A,B SAVE IN BSTRIP P M,TBL	POT 15 IN FRETURN. MINIMUM ID OTSER	COPT 32 SU C8 COPT C C3 C1 C8 COPT C C3 C1 C8 COPT C C3 COPT C8 COPT C8 COPT C8 C180 C3 C1 C8 C181 C3 C1 C8 C184 C104 C104 C104 C104 C108 C8 C109 C109 C100 C109 C100 C109 C100 C109 C100 C109 C100 C100 C100 C100 C100 C100 C100 C100	8305 0 8307 0 8307 0 8307 0 8307 0 8307 0 8311 0 83	MOVE C	LDA CPI RI IIMR JMP E TO MOVI LDA ORA RI GURSOR LE LDA ORA RI RI URSOR LE	LIME 15 A CUR E THE CURSON LIME A A CUR FT OME POSI	E UP ONE LINE GET LINE COUNT DON'T GO MORE UP THAN UP
5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	## 1515 * ## 151	ALLOW FOR STANDARD VIDEO TERMIN ENTRY. THE CHARACTER FOR OUTPO ALL REGISTERS ARE UNALTERED ON VIVESION OF THIS ROUTINE IS A OF ROUTINES ORIGINATED BY: AM RETTLEBORDOUGH OF COMMINISTRATION OF THE SCHOOL OF	POT IS IN CRETON. MINIMUM DOTHER SELECT	COPT 32 SU C8 COPT C C3 C1 C8 COPT C C3 C1 C8 COPT C C3 COPT C8 COPT C8 COPT C8 C180 C3 C1 C8 C181 C3 C1 C8 C184 C3 C184 C3 C184 C3 C186 C8 C189 C3 C188 C3 C189 C3 C180 C3 C1	0305 - 0308 P 0309 0311 0311 0311 0311 0311 0311 0311	MOVE C	LDA CPI RI RI RI RI RI RI RI LDA ORA RI CURSOR LE LDA ORA RI DCR RI DCR RI DCR RI STA	LIBE 15 A CUR E THE CURSON LIBE A A CUR PT OME POSIT	E UP ONE LINE GET LINE COUNT DOW'T GO MORE UP THAN UP
5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	## 1515 * ## 151	ALLOW FOR STANDARD VIDEO TERMIN ENTRY. THE CHARACTER FOR OUTPO ALL REGISTERS ARE UNALTERED ON VIVESION OF THIS ROUTINE IS A OF ROUTINES ORIGINATED BY: AM RETTLEBORDOUGH OF COMMINION OF C	POT IS IN CRETON. MINIMUM DOTHER SELECT	COPT 32 SU C8 COPT C C3 C1 C8 COPT C C3 C1 C8 COPT C C3 COPT C8 COPT C8 COPT C8 C180 C3 C1 C8 C181 C3 C1 C8 C184 C3 C184 C3 C184 C3 C186 C8 C189 C3 C188 C3 C189 C3 C189 C3 C189 C3 C180 C3 C1	0365 • 0366 • 0367 • 03687 • 03687 • 03687 • 03687 • 03687 • 03687 • 03687 • 0316 • 0311 • 0312 • 0313 • 0313 • 0315 • 0316 • 0315 • 0316 • 0315 • 0316 • 0315 • 0316 • 0315 • 0316 • 0317 • 0318 • 03	MOVE C DOWN BOUTIN FUP MOVE C	LDA CPI RI IMR JRP E TO MOVI LDA ORA RI DCR JRP URBOR LE LDA ORA RI DCR DCR DCR DCR DCR DCR DCR DCR DCR DCR	LINE 15 A CUR E THE CURSON LINE A A CUR ETHE CURSON HICHAR A HICHAR	E UP ONE LINE GET LINE COUPT DON'T GO RORE UP THAN UP TION DON'T GO RORE BACK THAN BACK
5 C1 C2 C6 DD 21 C1 E 6 88	## 157 * ## 158 * ##	ALLOW FOR STANDARD VIDEO TERMIN ENTRY, THE CHARACTER FOR OUTPO ALL REGISTERS ARE UNALTERED ON VIVESION OF THIS ROUTINE IS A OF ROUTINES ORIGINATED BY: AM RETTLEBOROUGH OF LEGE STATION, TEXAS ED CONTAIN THE ESC SEQUENCES AN ATION FEATURES. H SAVE EVERYBODY D EMTRY FROM DEVICE B B PSM A,B SAVE IN BSTRIP P M,TEL TSRCH GO PROCESS VDADO GET SCREEN ADDRESS A,H 88H M,A CURSOR IS BACK ON	POT IS IN CRETON. MINIMUM DOTHER SELECT	COPT 32 MM C8 COPT C C3 C1 C6 COPT C C3 C1 C6 COPT C C6 COPT C6 COPT C6 COPT C6 C180 C3 C1 C6 C180 C1 C6 C1 C6 C1 C7 C1 C7 C1 C7 C1 C1 C7 C1	0365 • 0366 • 0367 • 03687 • 03687 • 03687 • 03687 • 03687 • 03687 • 0316 • 0311 • 031	MOVE C BOUTIN HOVE C HOVE C	LDA CPI RI IMR RI IMR JRP E TO MOVI LORA RI DORA RI SURSOR LS LDA ORA RI DORA RI LDA ORA	LINE 15 A CUR E THE CURSON LINE A CUR CUR FFT ONE POSIT MCHAR A MCHAR T OME POSIT	E UP ONE LINE GET LINE COUPT DON'T GO RORE UP THAN UP TION DON'T GO RORE BACK THAN BACK
5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5	## 157 * ## 158 * ##	ALLOW FOR STANDARD VIDEO TERMIN ENTRY, THE CHARACTER FOR OUTPO ALL REGISTERS ARE UNALTREED ON VERSION OF THIS ROUTIRE IS A OF ROUTINES ORIGINATED BY: AN EETTLEBOROUGH OF COMMINION OF ROUTINES ORIGINATED BY: AN EETTLEBOROUGH OF ROUTINES ORIGINATED BY: AN EXTLEBOROUGH OF ROUTINES ORIGINATED BY: AND EVERYBODY DE ENTRY FROM DEVICE BY BOTH THE BOOK BY BOTH BY BOOK BY BOTH BY BOOK	POT IS IN CRETON. MINIMUM DOTHER SELECT	COPT 43 2 88 C8 C8P7 C3 C1 C8 C8P7 C8P7 C8P7 C8P7 A3 81 C8 C8P7 C8P7 C8P7 C8P7 C8P7 C8P7 C8P7 C	8346 - 8347 - 8346 - 8346 - 8346 - 8347 - 83	MOVE C BOUTIN HOVE C HOVE C	LDA CPI RI IMR JRP E TO MOVI LDA ORA RI DCR JRP URBOR LE LDA ORA RI DCR DCR DCR DCR DCR DCR DCR DCR DCR DCR	LINE 15 A CUR E THE CURSON LINE A A CUR ETHE CURSON HICHAR A HICHAR	E UP ONE LINE GET LINE COUPT DON'T GO RORE UP THAN UP TION DON'T GO RORE BACK THAN BACK

1E C3 13 C1 21	8337 8338 *	JMP	BCUR		CIC	3		048 648	1 .			
21 21	8348 *			CREEN ADDRESS	CIC	3			3 . I	wis ROUTI	NE READS A	COMMAND LINE FROM THE SYSTEM
	8341 * EM 8342 * 6343 *	TRY AT:	RETURNS:		CIC	3		848	5 .			IT TO THE SCREEN.
	8344 ·	VDAD2	ADDRESS OF	CREEN ADDRESS CURRENT LINE, CHAR 'C'	CIC	3		048 048	6 · C/	RIGHT	OF THE CURS	QUENCE ERASING ALL CHARS TO THE
CB	8345 * 8346 * 8347 VDADO	VDAD		CHARACTER POSITION 'C'	CIC	3		948	9 º NO.		RTS THE COMM	
25 3A 81 C8	8348 8349 VDAD2	VON AGJ	NCMAR C,A LIME	GET CHARACTER POSITION 'C' REEPS IT			28 C8	849 849 849	1 GCLIN	CALL	EREAD 20H	MEAD REYBOARD
18 6P 19 3A 82 C8	8358 VDAD 8351	MOV	L.A	LINE POSITION	CIC	8 47	D2 C1	849	3	MOV	B, A	
C 85	0352 0353	ADO RRC	L	GET TEXT OFFSET ADD IT TO THE LINE POSITION TIMES TWO	ClC	C CD	48 C8 C3 C1	849 849	5 CONT	JC CALL JMP	PROCS VDMOT GCLIN	PROCESS CONTROL CHARACTER
67 67	8354 8355	BRC NOV	i.A	MAKES POUR L MAS IT	CID	2	., .,	849	7 .		STROL KEYS	
0 E6 03 2 57	8356 8357	AMI	3 D. A	MOD THREE FOR LATER	Clu		#D	849			CR	
3 3E CC 5 82	0358 0359	MV1 ADD	A, CVDMEN	LOW SCREEN OPPSET	ClDe		DD C1	858. 858.	1	J2 CPI	CRPRC	ERASE THE REMAINING LINE PRIOR
6 67 7 7D	8360 8361	MOV	B,A A.L	NOW H IS DONE TWIST L'S ARM	CID	9 C8		858. 858	3	R3 JMP	GCLIN	IF BO GO PROCESS MO CONTROL CHARS TO SCREEN
8 E6 C0 A 81	6362 6363	AMI	OC OR		Clo	D		858 858	5 .		***************************************	TO SCHOOL STATE OF SCHOOL
B 6F C C9	0364 0365	BET	L.A	H & L ARE MON PERVERTED	Clbs	D CD	E3 C6	8581 8581	7 CRPRC	CALL	CLIME	CLEAR REMAINING LINE MOW PROCESS
	8366 ° 80		REMOVE CURS		ClE	1		8589 8516	9 :			
CD 21 C1	0368 *	CALL	VDADD	GET CURRENT SCREEN ADDRESS	ClE	1		8511 8511	2 .		PROCESS CO	MAND
7£ £6 7F	0376 0371	AN I	A.M 7PH	STRIP OFF THE CURSOR	ClE	1 CD		0513 0514	3 COPRC	MVI	CREM C, 1	BET FOR CHARACTER POSITION
77 C9	#372 #373	MOV RET	M, A		Clls	9 EB	25 C1	0515 0516	5	CALL MCHG	VDAD2	GET SCREEN ADDRESS
	8374 * 8375 * 8	OUTINE TO	BACKSPACE		Clea	A CD	32 C2 8E C3	0517 0518	7	CALL	SCMR ERR1	SCAN PAST BLANKS MO COMMAND?
CD MD C1	8376 ° 8377 PBACK	CALL	PLEPT		ClFi	1 11	94 C1	0519 0526		EXI EXI	D. COMTAB	BL HAS PIRST CHR POINT TO COMMAND TABLE
CD 21 C1 36 20	6378 6379	CALL	VDADD M,	GET SCREEN ADDRESS PUT A BLANK THERE	Clr	4		8521 8522	1 •			THROUGH A TABLE, POINTED TO
C9	6386 6381 *	RET		TOTA BURNA THERE	Clr	4		0523 0524	3 . BY	DE , POI	R A DOUBLE C	HARACTER MATCH OF THE 'HL'
		OUTINE TO	PROCESS A	CARRIAGE RETURN	Clre	4		0525 0526	s . BY	PLACING A	QUESTION N	ARE WITHIN THE SEARCH STRING.
CD E3 C#	8384 PCK 8385	CALL XRA	CLINE	CLEAR FROM CURRENT CURSOR TO REWIND IT		4 1A			PDCOM	LDAX	D A	TEST FOR TABLE END
C3 13 C1	8386 8387 *	JAP	PCUR	AND STORE THE MEW VALUE		CA	BP C3	8529 8538		JI PUSH	ERR2	MOT POUNDCOMMAND ERROR SAVE START OF SCAN ADDRESS
		TIME TO P	ROCESS LINE	PEED	CIPA	A BE		9531 9532	1	CMP	M D	TEST PIRST CHR
3A B1 CB	8398 PLF 8391	LDA CPI	LINE 15	GET LINE COUNT	CIPC	C 2	88 C2	0533 0534	3	JMI	MCOM	
D2 61 C1	8392	JNC INR	SC	ARE WE AT THE BOTTOM?	C1FF C200	23		8535 8536	5	INX	E D	
3C C3 C1 C#	8393 8394	JMP	CUR	OME MORE LINE UP	C261	BE	69 C2	0537 0538		CMP	MCON	MON SECOND CHARACTER GOODNESS
AF	0395 ° 0396 SC	XRA	A		C205 C205	5	00 C2	0539 0540	•			
C3 9C C8	0397 0398 •	JMP	SROL		C206	EB		0541		POP ECHG		CLEAR THE STACK DE HAS SCAN ADDRESS
	0399 .	wi Er				C3	71 C6	8542 8543		JMP	DISPT	BL HAS COMMAND ADDRESS DISPATCH TO IT
	9462 * PROCE	SSING. I	? THE CHARA	E CHARACTERS FOR SPECIAL CTER IS NOT IN THE TABLE IT	C20B			8544 8545	•		_	100
-	0483 . GOES				C268	13		0547		INX	D	GO TO MEXT ENTRY
5 C#	0485 TBL 0486	DB DH DB	PERSE	SCREEN	C20E	El	P4 C1	0548 0549		POP Jap	D N	GET BACK ORIGINAL ADDRESS
\c1	8487 8488 8489	DM DB	PUP DOWN	CURSOR	C212		74 61	8558 8551 8552	•	JAP	PDCOM	COSTINUE SEARCH
CO	0416 0411	Dis DB	PDOWN LEFT		C212 C212			0553 0554	•	OUTPUT A	CRLP POLLOW	ED BY A PROMPT TOMS ARE ON THE SCREEN)
#D C1 93	0412 0413	DH DB	PLEFT		C212 C212		1A C2	0555			CRLP	IONS ARE ON THE SCREEN
17 C1 8E	8414 8415	D# DB	PRIT		C215 C217	96 .	3 E	8557 6558		MV I JMP	B, >	THE PROMPT PUT IT ON THE SCREEN
F3 C0	0416 0417	DN DB	PHOME	CARRIAGE RETURN	C21A C21A			8559		MVI	B, LP	LIME PEED
4E C1	8418 8419	DN DB	PCR LF	LINE PEED	C21C C21F	CD (4B C0	0561 0562		CALL	VDMOT B, CR	CARRIAGE RETURN
55 C1 5F	8428 8421	Dis DB	PLF	BACK SPACE	C221 C224			0563 0564		JAP	VDMOT	PUT IT OUT AND RETURN
45 C1	0422	Dw	PBACK		C224 C224			8565 8566	•	N OUPS 119	90 12 CHARA	CTERS LOOKING FOR A BLANK
B4 C1	0423 0424	DB DM	COMND	MODE KEY	C224 C224		•	8567		MVI	C.12	MAXIMUM COMMAND STRING
**	8425 8426 * 8427 * OUT	DB	•	END OF TABLE	C226 C227	14			SBLEI	LDAX	D BLANK	BRAINGH COMMAND SIRING
4C C#	0428 ·	PUT DEVIC			C229 C220	CA 3		8571 8572		JI IMX	SCHR	GOT A BLANK NOW SCAN PAST IT
48 CB	0429 OTAB 0438	DM	VDMO1 SEROT	VDM DRIVER SERIAL OUTPUT	C22D C22£	80	26 (2	8573 8574		DCR JHZ	C SMLK)	NO NORE THAN TWELVE
AD C1	0431 0432	Disi	ERROT	ERROR HANDLER (POR CONSOL) ERROR HANDLER	C231 C232	C9		8575 8576		RET		GO BACK WITH ZERO FLAG SET
	0433 ° 0434 ° INP	UT DEVICE	TABLE		C232 C232			8577		N BAST IID	90 10 BIANE	POSITIONS LOOKING POR
27 CØ	0435 * 0436 ITAB	DN	KREAL	KEYBOARD INPUT	C232			8579 8588	" A MON	N BLANK CE	MARACTER.	POSITIONS EXCERNIC FOR
AD C1	0437 0438	DM DM	SREA1 ERROT	SERIAL INPUT ERROR HANDLER (FOR COMSOL)	C232 C232		A	8581	SCHR	MVI	C.10	SCAN TO PIRST NON BLANK CHR WITH
AD C1	0439 8448 *	DW	ERROT	ERROR MANDLER	C234 C235	PE 2	: 6	0583	SCHR1	CPI	D SPACE	GET MEXT CHARACTER
	0441 * 0442 *	COMM	AND TABLE		C237 C238	13		8584 8585		RN I IN X	D	WE'RE PAST THEM MEXT SCAN ADDRESS
	8443 * THIS			VALID COMMANDS FOR COMSOL	C239 C23A	CB		8586 8587		DCR BI	c	COMMAND ERROR
54 45	8445 * 8446 COMTAB	ASC	TE'		C238 C23E	C3 3	4 C2	8588 8589		JMP	SCHR1	REEP LOOPING
70 C2	8447 8448	ASC	TERM		C23E C23E			0591	. COMVE	ERTS THE P	OLLOWING AD	CHARACTERS, PAST BLANKS AND DRESS TO HEX. ERRORS RETURN TO
A1 C2 45 4E	0449 0450	ASC	DUMP		C23E C23E			8593	•	RROR HAND		
07 C3 45 58	0451 0452	ASC	ENTER		C23E C241	CD 2 CA 8	4 C2 E C3	8595	SCONV	JE	ERR1	
35 C3 54 4C	0453 0454	ASC	TL		C244 C244			8596 8597	· THIS	ROUTINE	CONVERTS AS	III DIGITS INTO BINARY POLLOWING
39 C3 42 41	0455 0456	ASC	TLOAD	SPECIAL COMMAND TO EXECUTE 8	C244 C244			6599	. SPACE	IS ENCOU	MTERED. PA	THE SCAN STOPS WHEN AN ASCII
	8457 8458	DH DB	:	END OF TABLE MARK	C244 C244			9681	•			ITH A QUESTION MARK.
	8459 * 8468 *				C244 C247	1A		9682 9683	SHE 1	LDAX	B. 0	CLEAR H & L GET CHARACTER
	8461 * 8462 *	COL	ISOL PORT E	ROR MANDLER	C248 C24A	PE 2 C8	•	0684 0685		CPI	20 H	IS IT A SPACE? IF SO
AF 32 84 C6	8463 ERROT 8464	STA	A IPORT	DEFAULT TO SCREEN	C248 C248			8686 8687	BCONV	DAD		MAKE BOOK FOR THE HEW ONE
32 #3 C8	8465 8466 *	STA	OPORT	DEPAULT TO SCREEN	C24C C24D	29 29		8688 8689		DAD	M M	
	8467 °				C24E C24F	29	B C2	9619 9611		DAD	M MCOV1	BO THE CONVERSION
	8469 * 8478 *		COMMAND NO	300	C252 C255	D2 8		8612 8613		JHC ADD	ERR1	BOT VALID BEXIDECIMAL VALUE
	0471 ° 0472 °	•	COMPAND NO		C256	6P		8614 8615		MOV	L.A	MOVE IT IN BUMP THE POINTER
		ROUTINE	GETS AND P	OCESSES COMMANDS	C258	C3 4		8616		JAP	SME1	
31 ## CC	8475 COMND	LXI	SP, SYSTP	SET STACK POINTER	C258 C250	D6 3		8618 8619	BCOV1	SU1 CPI	48	BEROVE ASCII BIAS
CD 12 C2 CD C3 C1	8476	CALL	PROMPT GCLIN	PUT PHOMPT ON SCREEN GET COMMAND LINE	C25F	DB		8628 8621		BC SUI	;	IF LESS THAN 9 IT'S A LETTER??
	0478	CALL	COPRC	PROCESS THE LINE	C269	PE 1		9622		CPI	101	
CO E1 C1	8479	JMP	COMND	OVER AND OVER								

C9	9623 RET	WITH TEST IN BAND	C38A E5	8766 8767 *	PUSE R	SAVE ADDRESS
	9625 ° 9626 ° SYSTEM START UP, C 8627 ° POINTER, PALLING TERC	LEAR PART OF MAN AND SET STACK UGE TO TERMINAL MODE.	C30B CD 1A C2 C30E 06 3A C310 CD CC C1	8768 EMLOP 8769 8778	CALL CRLP HVI B, : CALL CONT	GET LINE OF IMPUT
1 88 CB	0628 * 0629 STRTA ERA A 0639 MOV C.A 0631 LKI B.SYS	ME CLEAR THE FIRST 256 BYTES BAR POINT TO SYSTEM BAR	C316 8E 81 C318 CD 25 C1 C318 EB	9772 9773 9775	CALL CREM HVI C.1 CALL VDAD2 ECBG .	REMOVE THE CURSOR START SCAN GET ADDRESS TO DE
7 3 C	0632 ° 8633 CLERA MOV N.A 8634 INX H		C31C 8E 83 C31E CD 34 C2	0000	MVI C.3 CALL SCHR1 SCAN	NO MORE THAN THREE SPACES BETWEEN VALUES
6A C2	0635 ZMR C 0636 JMI CLERA 0637 °	CLEAR FIRST 256 SYTES	C324 1A C325 FB 2F	9778 9779 BMLO2 8788	JI BULOP	LAST ENTRY POUND START NEW LINE GET THE CHR COMMAND TERMINATOR?
	0638 * 0639 *	COMMAND	C327 CA 84 C1 C32A CD 44 C2	8781 8782	CALL SEEX	IP BO COMVERT VALUE
	8641 0		C326 B1	8783 8784 8785	HOV A,L POP B HOV H,A	GET LOW PART AS CONVERTED GET MEMORY ADDRESS PUT IN THE VALUE
	8643 * AND OUTPUTS THEN TO 8644 * INTENDED TO COMPIGUI	BARACTERS PROM THE SYSTEM REYBOARD THE SERIAL OUTPUT PORT. IT IS IE THE SOL AS A STANDARD VIDBO	C330 23 C331 E5	8787	INX M PUSH B	BACE GOES THE ADDRESS
	8645 * TERMINAL. COMMAND I	EYS ARE BOT OUTPUT TO THE OUTPUT	C335	9788 8789 * 8798 *	JMP EMLO1	CONTINUE THE SCAN
	8649 °	CCEIVED BY THE REYBOARD, PUTS THE	C335	8791 * 8792 *	EXECUTE COMM	MID.
ee CC ED C3	9659 * 9651 TERM LNI SP.ST 8652 CALL TOPP	STP SET STACK POINTER SLOW DOWN THE TAPES	C335	8793 * THIS	MOUTINE GETS THE PO	DLLOWING PARAMETER AND DOES A ON GIVEN BY IT. IF PROPER
C5 C6	8653 CALL PERSI	CLEAR THE SCREEN	C335	8796 * STACK C	PERATIONS ARE USED	MITHIN THE EXTERNAL PROGRAM URN TO THE CONSOL COMMAND MODE.
22 C0 98 C2 FC	9655 KIN CALL ESTAT 9656 JN2 TIN 9657 IN EDAT/		C335	8798 * 8799 * 8886 EXEC	CALL SCORV	SCAN PAST BLANKS AND GET PARAMETER
80	8658 MOV B.A 8659 ANI 88H	COMMAND REY?	C338 E9	0801 0802 *	CALL SCONV PCHL .	GO (ARD TAKE NOTE)
8D C2 4B C8	8668 JS TOUT 8661 CALL VDMOT	PROCESS IT	C339 C339	8883 * 8884 *		
90 C2 41 CU	8662 JMP TIN 8663 * 8664 TOUT CALL SDROT	OUTPUT IT TO THE SERIAL PORT	C339	0805 * 0806 *	TAPE LOAD COMMAN	
31 CØ 79 C2	9665 TIN CALL SSTAT	GET SERIAL STATUS	C339	SAGE . THE REA	D DATA INTO MEMORY.	I SITHER TAPE UNIT PLACING WHILE SPACE WITHIN CONSOL UND TAPE ROUTINES THIS
P 9 7 F	9667 IN SDATA 9668 ANI 7PH 9669 MOV B.A	GET DATA BO HIGH BITS FROM HERE IT'S OUTPUT FROM 'B'	C339	0811 * SYSTEM	WILL LOAD SOL- BAS SOLPTHARE FOR DIRECT	IRD TAPE ROUTINES THIS ICS AND OTHER STANDARD SOL T EXECUTION.
IB C0	9669 MOV B,A 9678 CALL VDMOT 9671 JMP KIN	IT S OUTPUT FROM B PUT IT ON THE SCREEN LOOP OVER AND OVER	C339	8812 * 8813 * 8814 TLOAD	CALL SELE	SCAN TO SPEED PARAMETER
-	8672 * 8673 *		C33C CA 4A C3 C33F CD 44 C2	8815 8816	J2 DPLT CALL SHEX	DEFAULT TO HIGH SPEED IF MONE CONVERT IT
	8674 * BUMP COMMAN 8675 * DUMP COMMAN	D	C342 7D C343 E6 01	6817 6818	MOV A,L ANI 1	GET VALUE ONLY BIT SERO COUNTS
	9677 * THIS ROUTINE DUNI	S CHARACTERS FROM MEMORY TO THE E. (WITH CONSOL ALL OUTPUT GOES TO	C347 C2 4B C3		MVI A,32 JNZ SETSP	PRETEND ITS SLOW
	9679 * THE SCREEN). ALL VA	LUES ARE DESPLAYED AS ASCII HEX.	C34A AP	6822 DPLT 6823 SETSP	KRA A ORI TAPE1+TAPE	MARE IT FAST 2 CONSOL STARTS BOTH TAPES
	9681 * THE COMMAND PORM IS 9682 * 9683 * DUmp addrl 4		C34F CD F1 C3	8825	OUT STAPT CALL DELAY	START TAPES AND SELECT SPEED WAIT WHILE THE TAPE UNIT WINDS UP
	8684 * THE VALUES PROM AS	DR1 TO ADDR2 ARE THEN OUTPUT TO THE	C354	0827 ·	IN TOATA	CLEAR THE UART PLAGS READ PAST HEADER
	9686 * OUTPUT DEVICE. IP C	MLY ADDRI IS SPECIFIED THEN THE	C357 C2 54 C3 (8829 8838 *	JNZ TLOD1	IP ERROR START OVER
C2	8688 * 8689 DUMP CALL SCONV	SCAN TO FIRST ADDRESS AND CONVERT I SAVE THE VALUE	IT C350 EB	8832	LELD BLOCK	GET BLOCK SIZETO DE
2 C2	9691 CALL SCHR 8692 POP B	GET THE WEXT	C361	0833 0834 * 0835 LOLOOP	MOV A,D	GET LOAD ADDRESS GET COUNT
. C2	9693 JI POVEI 9694 PUSH H 9695 CALL SHEX	MO SECOND VALUE GET SECOND	C362 B3 C363 CA ED C3	0836 9837	DRA E JZ TOPP	COUNT 15 SERO-TURN OFF TAPE AND RETURN
6 62	0696 POP D 0097 JMP NPASS	THIS IS THE PIRST	C369 EB	8839	LXI B,-256 XCHG . DAD B	THIS MANY PRIOR TO CRC TEST COUNT TO HL A LITTLE MATH
	8696 * 8699 POVEK MOV D.H 8788 MOV E.L	NO SECOND PARAMETER COPY FIRST TO D	DE C368 D2 E1 C3	0641	JNC LBLK NVI B,6	MO CARRY, IT'S THE LAST BLOCK 256 TO READ
	8781 NPASS XCHG .	HL HAS START, DE HAS END	C370 dE 80	0844 RDBLK	MVI C.B	SERO THE CRC BOUND ROBIN
A C2	6763 DLOOP CALL CRLF 6764 IN EDATA		C373	. 8888	CALL TAPIN	GET CHARACTER
64 C1 05 C2	8785 CPI MODE 9786 J2 COMNI 8787 CALL ADOUT	'MODE REY' WILL ESCAPE THE DUMP OUTPUT ADDRESS	C377 23	8847 8848	MOV M,A	STORE IT BUMP MEMORY LOCATION UPDATE THE CRC
5 C2	8788 CALL BOUT 8789 NVI C,16	ANOTHER SPACE TO KEEP IT PRETTY VALUES PER LINE	C379 2F	8849 8858 8851	XRA C CRA SUB C	OPDATE THE CAC
	6716 * 6711 DLP1 MOV A,M	GET THE CHR	C37B 4F	9852 8853	MOV C,A DCR B	STORE THE NEW COUNT DOWN
2 02	9712 PUSH B 9713 CALL MBOUT 9714 CALL ACOME	SAVE VALUE COUNT SEND IT OUT WITH A BLANK COMPARE ADDRESSES	C37D C2 73 C3 C388	6855 °	JNI RTBYT CALL CRCCK	STILL MORE IF NOT SERO CHECK CRC AND FALL THROUGH TO ERROR IF NO GOO
64 C1	8715 JMC COMME 8716 POP B	ALL DONE VALUES PER LINE	C383 CA 61 C3	9856 9857 9858 *	JI LOLOOP	TEST OR
9 C2	6717 INX H 6718 DCR C 6719 JN2 DLP1	BUMP THE LINE COUNT MOT ZERO IF MORE FOR THIS LINE	C386 86 87 C388 CD 4B C6	0859 TERR 0860	CALL VDMOT	BELL CHARACTER PUT IT ON THE SCREEN
7 C2	8728 JMP DLOOF 8721 *		CRE	8861 8862 * 8863 *	JRP COMND	
	8722 * OUTPUT HL AS HEX 1 8723 * 8724 ADOUT MOV A.H	6 BIT VALUE	C38E	8864 * COME	SOL ERROR HANDLER	COR ACLU ADDRESS
A C2	8724 ADOUT MOV A,H 8725 CALL HEOUT 8726 NOV A,L		C38F 36 3F	8866 ERR1 8867 ERR2 8868	NCHG . NVI N,'7' JMP COMMD	GET SCAN ADDRESS PUT A QUESTION MARK THERE AND GO TO COMMAND MODE
A C2	8727 * 8728 HBOUT CALL HEOUT		C394 C394	8869 * BEAD	THE HEADER	
6 6 Ce	8729 BOUT NVI B, 9738 JMP VDMO1	CONSOL PUTS IT ON THE SCREEN	C394 C394 86 8A	0871 * 0872 RHEAD	MVI B,10	PIND 18 MULLS GET A BYTE
	8732 HEOUT MOV C.A - 9733 RRC	GET THE CHARACTER	C398 £6 48	6873 RHEA1 6874 6875	IN STAPT ANI TOR JZ RHEAL	Y 146 MARY 756
	6734 RRC . 6735 RRC	MOVE THE HIGH FOUR DOWN	C39D DB FB C39F 67	8876 8877	IN TDATA	IGNORE ERROR COMDITIONS SERO?
3 C2	8736 BRC 8737 CALL MEOU 8738 MOV A,C	PUT THEN OUT THIS TIME THE LOW FOUR	C3A8 C2 94 C3 C3A3 85	8878 8879 8888	JNZ RHEAD DCR B JMZ RHEA1	LOOP UNTIL 10 IN A ROW
F	8739 ° 8748 BEOUL AMI 6FH	POUR ON THE PLOOR	C3A7	6881 * MAIS	JEZ BHEAL POR THE START CHAI	
e A	8741 ADI 48 8742 CPI 58	WE WORK WITH ASCII HERE 6-9?	C3A7 C3A7 CD C6 C3	9883 * 9884 SONL	CALL TAPIN	
PE C2	8743 JC OUTH 8744 ADI 7 8745 OUTH MOV B,A	YUP! MAKE IT A LETTER OUTPUT IT PROM REGISTER 'B'	C3AA 3D C3AB C2 A7 C3	6885 6886 6887 *	DCR A JMI SOHL	MAIT POR A '1'
E CS	8746 JRP VDMC1	SULFUL AL LEGG ABUSERS &	CBAE	888 * NON 8889 *	GET THE HEADER	
	9748 ° COMPARE DE AMD EL 8749 °		C3AE 21 85 C8 C3B1 81 88 18	9891 8898	LEI B, SLEN* 25	POINT TO BUPPER LENGTH OF HEADER IN 'B',C<8
	8758 ACOMP BOV A,L 8751 BUB E 8752 BOV A,B		C384 CD C6 C3	0892 * 0893 RHED1 0894	CALL TAPIN	GET BYTE STORE IT
	8753 888 D 8754 RET .	PLAGS ARE SET	C388 23 C389 A9	8895 8896	INX B	INCREMENT ADDRESS NOW CALCULATE THE CRG
	8755 * 8756 *		C3BA 2F C3BB 91	0897 0898	CMA . SUB C	INSIDE OUT AND UPSIDE DOWN SQUEEZE IT
	8757 * ENTER COMMU 8758 * 8759 * THIS ROUTINE GETS V	MD VALUES PROM THE ERYBOARD AND ENTERS	C3BD #5	0899 0988	MOV C.A DCR B JN2 BHED1	AND SAVE AGAIN WHOLE HEADER YET? LOOP UNTIL DONE
	8768 * THEM INTO MEMORY. TO 8761 * A STANDARD GCLIN' II	IE INPUT VALUES ARE SCANNED POLLOWING IPUT SO ON SCREEN EDITING MAY TAKE	C3BE C2 B4 C3 C3C1 C3C1	8981 8982 * 8983 * THIS	ROUTINE GETS THE M	EXT BYTE AND COMPARES IT
	8762 * PLACE PRIOR TO THE LE 8763 * ENDS THE ROUTINE AND	ME TERMINATOR. A BACK SLASH '/' RETURNS CONTROL TO THE COMMAND MODE.	C3C1 C3C1	8984 ° TO THE	VALUE IN REGISTER	C. THE PLAGS ARE SET ON
BE C2	8764 * 8765 ENTER CALL SCON		C3C1	8986 °	CALL TAPIN	GET CRC BYTE
						Page 9

C2DD C881 C2E5 C8E9 C1CC

9#18 C2B7

097E C30B C800 C315 C05D C273 C812

ADOUT #GIN BOUT CLIM1

CONT

CX DLOOP

DISTATE SHILLIP SEASON SEASON

AINP BLANK CHAR CLINE COPRC CKLP

DELAY
DUMPI
DUMPI
EMTIER
FDCOM
MEOUT
MEOUT
MEOUT
MEOUT
MEOUT
LIM
MODE
MPASS
OF
FDCOM
MPASS
SELS
SCHIM
SOSS
SELS
SCHIM
SOSS
SELS
SCHIM
SOSS
SELS
SCHIM
TOATA
TTAPE1
TOATA
TTAPE1
TOATA
TTARED
YOMOO

C816 8828 C878 C8E3

C1E1 C21A

C3F1 C3F4 C2A1 C387 C38E C1F4 C2E2 C2EA

8981 C622 C841 9988 C286 C184 C113 C6C5 C284 C194 C224 C232

AOUT BLOCK CLEAR COMND CR CRPRC

DFLT DLP1 ENLO1 ERAS1 ERR2 GCLIN HCONV HLEN IPORT KIN LBLK

LOADK NCHAR OCHAR OUTH PDATA PHOME PRIT PXDR RMED1 SBLK1 SCHK1

SDATA SENSE SPE SOŁ SPACE SROL STRTA TAPE2 TDR THEAD TOE TSRCH VDAD2 VDMOT C88C 888B C184

CIDD

C34A C2C9 C31C C8CA C38F C1C3 C24B #818 C8#4 C279 C3E1

```
C
                                                                                                                                                                                                                                                        COMPARE IT WITH CALCULATED
                                                                                                                                                                                                                                                                                                                                                                                                                                                                              C382
885P
C882
C26A
C194
C3C1
                                                                                                                                                                                                                                                                                                                                                                                                                                                ACORP
BACES
BUT
CLERA
                                                                                                                                     THIS ROUTINE GETS THE MEXT AVAILABLE BYTE FROM THE TAPE. MHILE MAITING FOR THE BYTE THE KEYGOARD IS TESTED FOR A "ROOK" COMMAND. IF RECEIVED THE TAPE LOAD IS TERMINATED AND A RETURN TO THE COMMAND MODE IS MADE.
                                                                                                                                                                                                                                                                                                                                                                                                                                                 CACCE
                                                                                                                                                                                                                                                                                                                                                                                                                                                 CUR
                                                                                                                                                                                                                                                                                                                                                                                                                                                                             C#C1
C#71
C#71
W#9AA
C1304
C2006
C250
W#88
C18C
C2007
C2007
C8AD
C1407
C14
                                                                                                                                                                                                        STAPT
TOR
TREDY
EDATA
HODE
COMMO
TAPIN
                                                                                                                                                                                                                                                                                                                                                                                                                                                  DOWN
ENLO2
                                                                                                                                                                                                                                                                                                                                                                                                                                                 EMAS2
ERBOT
GOMAC
MCOV1
MOME
ITAB
EMEA1
                                                                                                                                                                                                                                                          OME IS AVAILABLE
CRECK FOR MODE WHILE WE'RE WAITING
                                                                                                                                                                                                                                                          NODE WAS GIVEN...ABORT OPERATION NOT HODE...STAY IN LOOP
                                                                                                                                                                                                        STAPT
TPE+TOE
TERR
TDATA
                                                                                                                                                                                                                                                        DATA ERROR?
IF PRAMING OR OVERRUM ERROR
GET THE DATA
                                                                                                                                                                                                                                                                                                                                                                                                                                                LLF'I
WADK
SCOM
OK
PBACE
                                                                                                                                                                                                                                                                                                                                                                                                                                                 PDOWN
PLEFT
PHOCS
RDMLE
HIGHT
SC
                                                                                                                                                                                          CALCULATES THE LENGTH OF THE LAST BLOCE
                                                                                                                                                                                                     B,-1
B
B,L
B,S
RDBLE
                                                                                                                                                                                                                                                      COMPLEMENT BL
.....TMO'S
LENGTH TO REGISTER B
TELL DE WE'RE DONE
ORMARD TO THE END
                                                                                                                                                                                                                                                                                                                                                                                                                                                  >CUMV
                                                                                                                                                                                                                                                                                                                                                                                                                                                SDR
SEMUT
SME1
JOLL
SPE
SSTAT
                                                                                                                                                                                                        A
STAPT
                                                                                                                                                                                                                                                        GIVE COMMAND
AND GRIND TO A SLOW STOP
                                                                                                                                                                                                                                                                                                                                                                                                                                                SYSRA
TAPIN
TEMM
TIM
TOFF
TIME
VDADD
XEQAD
                                                                                                                                                                                                       D,6
D
A,D
E
DLOP1
                                                                                                                                                                                                                                                       START LOOP
DOWN COUNT
                                                                                                                                                                                                                                                        TEST POR IERO
                                                                                                                                                                                                         << SOL SYSTEM EQUATES >>
                                                                                                                                                                       VOM PAHAMETERS
                                                                                                                                                                                                       OCC BUH
                                                                                                                                                                                                                                                       VOM SCREEN MEMORY
                                                                                                                                                                        REYBOARD SPECIAL REY ASSIGNMENTS
                                                                                                                                                                                                     9AH
97H
81H
93H
8CH
8BH
8BH
48EH
5FH
18
                                                                                                                                                                                                                                                       LOAD KEY
 BACKSPACE
                                                                                                                                                                                                       LANK
X -48H
                                                                                                                                                                                              ASSIGNMENTS
                                                                                                                                                                                                     #FAH
#F8H
#FCH
#FCH
#FCH
#FCH
#FCH
#FCH
                                                                                                                                                                                                                                                      STATUS PORT GENERAL
SERIAL STATUS PORT
SERIAL DATA
TAPE DATA
KEYBOARD DATA
PARALLEL DATA
VDM DISPLAY PARAMETER PORT
SENSE SWITCHES
                                                                                                                                                                                       ASSIGNMENT MASKS
                                                                                                                                                                                                                                                     SERIAL CARMIER DETECT
SERIAL DATA SET READY
SERIAL PARITY ERROR
SUNIAL FRANING ERROR
SERIAL OVERSUM ERROR
SERIAL CLEAR TO SEMD
SERIAL DATA READY
MERIAL TRANSMITTER BUPPER EMPTY
                                                                                                                                                                                                   1
2
4
8
16
32
64
128
REYBOARD DATA READY
PARALLEL DATA READY
PARALLEL DEVICE READY
TAPE TRAINING ERROR
TAPE OVERFLOW ERROR
TAPE DATA READY
TAPE TRANSMITTER BUPFER EMPTY
                                                                                                                                                                                                    1
2
4
8
16
64
128
                                                                                                                                                                                                   1
                                                                                                                                                                                                                                                     SCROLL OK PLAG
                                                                                                                                                                                                                                                     TAPE ONE 'ON' BIT
                                                                                                                                                                                            SOL SYSTEM GLOBAL AREA
                                                                                                                                                                                                                                                     START OF 1K RAM AREA
                                                                                                                                                                                                                                                      START OF SYSTEM HAM
STACK IS AT THE TOP
                                                                                                                                                                                                     $
$+1#24
                                                                                                                                                                          CONSOL PARAMETER AREA
                                                                                                                                                                                                                                                    CURRENT CHARACTER POSITION
CURRENT LINE POSITION
BEGINNING OF TEXT DISPLACEMENT
CUTPUT PORT
INPUT PORT
                                                                                                                                                                                                                                                     MAME
THIS BYTE MUST BE ZERO
TYPE
BLOCK SIZE
   C80C
C816
C812
C815
C815
C815
C815
                                                                                                                                                                                                                                                     LOAD ADDRESS
AUTO EXECUTE ADDRESS
SPARES
                                                                                                                                                                                                    2 2 3
                                                                                                                                                                                                                                                     LENGTH OF HEADER
                                                                                                                                                                                                    S-THEAD
```

```
(continued from page 4)
ØØ0= 22 F1 Ø4
                    Ø71Ø
                                    SHLD
                                            SHED+36DH FIREMAN
      2A 78 Ø1
                    Ø72Ø
                                    LHLD
                                            FRA1
                                                   .. THE LITTLE ENGINE
Øk.
      22 24 $5
                    Ø73Ø
                                    SHLD
                                            SHED+3AØH ALSO
ØØA7 2A 7A Ø1
                    Ø74Ø
                                    LHLD
                                            FRA2
                                                   .. HAD A COWCATCHER
ØØAA 22 26 Ø5
                    Ø75Ø
                                    SHLD
                                            SHED+3A2H AND LOTS OF FUNNY
ØØAD 22 28 Ø5
                    Ø76Ø
                                    SHLD
                                            SHED+3A4H WHEELS AND THE
ØØBØ 22 2A Ø5
                    Ø77Ø
                                    SHLD
                                            SHED+3A6H THINGS THAT CONNECTED
ØØB3 2A 7C Ø1
                    Ø78Ø
                                    LHLD
                                            FRA3
                                                  .. AND TWO VERY TINY
ØØB6 22 2C Ø5
                    578$
                                    SHLD
                                            SHED+3A8H WHEELS AT THE VERY
ØØB9 2A 7E Ø1
                    6866
                                    LHLD
                                            FRA4
                                                  .. VERY BACK
003C
     22 2E Ø5
                    6810
                                    SHLD
                                            SHED+3AAH ALTOGETHER IT LOOKED
88BF 2A 88 81
                    Ø82Ø
                                    LHLD
                                            FRA5
                                                   .. QUITE LONELY AND YET
ØØC2 22 3Ø Ø5
ØØC5 Ø1 DF FF
                                           SHED+3ACH IT APPEARED VERY
B,-21H . FUNNY JUST SITTING
H,SHED+3DEH THERE ON THE
                    Ø83Ø
                                    SHLD
                    ₽84₽
                                    LXI
ØØC8 21 62 Ø5
                    $85₿
                                    LXT
ØØCB 36 19
                    ₿86Ø
                          RATLS
                                    MVT
                                           M,19H .. RAILS
                                                   .. WITH NOTHING AT ALL
BBCD B3
                    6876
                                    INX
                                           B
ØØCE 23
                                                   .. EVER
                    6886
                                    INX
                                           Н
BOCF AF
                    Ø89Ø
                                                   .. TO DO .. WELL!
                                    XRA
                                            A
ØØDØ A8
                    6966
                                    XRA
                                           В
                                                   .. LET'S RUN IT JUST FOR
ØØD1 C2 CB ØØ
                    Ø91Ø
                                           RAILS
                                    JNZ
88D4 21 88 CC
                    6926
                                           H, RRY
                                                   GET TRAIN OUT OF SHED
                          HOSTL
                                    LXI
ØØD7 EB
                    Ø93Ø
                                    XCHG
                                                   MOVE IT FROM SHED
                                           H, SHED
ØØD8 21 84 Ø1
                    $94$
                                    LXI
ØØ DB
                    Ø95Ø
                          FIRE
                                    MOV
                                           A,M
                                                   LIGHT FIRE
90DC 23
                    Ø96Ø
                                   INX
                                           H
ØØDD EB
                    $97$
                                    XCHG
ØØDE
     77
                    Ø98Ø
                                   MOV
                                                   .. MOVE IT
                                           M,A
ØØDF
     23
                    Ø99Ø
                                    INX
                                           H
                                           A,H
ØØEØ
     7C
                    1000
                                    MOV
ØØE1 EB
                    1010
                                   XCHG
ØØE2 FE DØ
                    1020
                                   CPI
                                           ØDØH
                                                   END OF YARD?
                                                   NO, MAKE MORE STEAM!
00E4 C2 DB 00
                    1030
                                    JNZ.
                                           FIRE
ØØE7 CD ED ØØ
                    1040
                                                   GO TAKE TRIP
                                   CALL
                                           TRAVL
00EA C3 D4 00
                    1050
                                                    NO ROUND TRIPS, JUST DO
                                   JMP
                                           HOSTLE
                                                    AGAIN
ØØED
                    1060
ØØED Ø1 40 Ø3
                    1070
                          TRAVL
                                   LXI
                                           B,64.13 MAKE TRIP 13 MILES
ØØFØ C5
                    1080
                           CHOO
                                    PUSH
                                                   CHUFF ONCE
                                            B
ør
Ø.
     CD FF 55
                    1090
                                    CALL
                                            STROK
                                                   MAKE FORWARD MOTION
                    1100
     CD ØF Ø1
                                    CALL
                                            TURN
                                                   TURN WHEELS
80r / Cl
                                    POP
                                            B
ØØF8 ØB
                    1120
                                    DCX
                                                   CLICK ODOMETER
                                           В
ØØF9 AF
                    1130
                                    XRA
                                            A
ØØFA A8
                    1140
                                    XRA
                                                   13 MILES YET?
                                            В
ØØFB C2 FØ ØØ
                    115Ø
                                    JNZ
                                           CHOO
                                                   NO
ØØFE C9
                    1160
                                                   DO NEXT TRIP
                                    RET
ØØFF
                    1170
     21 Ø1 CC
ØØFF
                    1180
                          STROK
                                    LXI
                                           H, ØCCØ1H MOVE DOWN THE TRACK
                                           C,ØDØH
A,M
Ø1Ø2 ØE DØ
                    1190
                                    MVI
0104
     7E
                    1200
                          COAL
                                    MOV
                                                   ADD MORE COAL
Ø1Ø5 2B
                    1210
                                   DCX
                                           H
Ø1Ø6
                    1220
                                    MOV
                                           M.A
Ø1Ø7 23
                    1230
                                    INX
                                           H
Ø1Ø8
     23
                    1240
                                    INX
                                           H
                    1250
Ø1Ø9 7C
                                    MOV
                                           A,H
Ø1ØA B9
                    1260
                                    CMP
                                            C
                                                   ENOUGH COAL?
                    1270
                                                   NO, PUT MORE ON!
Ø1Ø3 C2 Ø4 Ø1
                                    JNZ
                                            COAL
Ø1ØE C9
                    128Ø
                                    RET
ØlØF
                    1290
ØlØF
     21 ØØ CC
                    1300
                          TURN
                                    LXI
                                           H, ØCCØØH TURN WHEELS
Ø112 7E
                    1310
                                    MOV
                          HISS
                                           A,M
Ø113 23
                    1320
                                    INX
                                           H
Ø114 FE Ø6
                    133Ø
                                    CPI
                                                   FIND COWCATCHER
                                            6
Ø116 C2
        12 Ø1
                    1340
                                    JNZ
                                           HISS
                                                   LOOK AGAIN
Ø119 23
                    135Ø
                          FOUND
                                    INX
                                           H
ØllA 7E
                    136Ø
                          AXLE
                                    MOV
                                           A.M
Ø11B FE 11
                    1370
                                    CPI
                                            lін
                                                   WHAT QUARTER TURN?
Ø11D C2 31 Ø1
                    1380
                                    JNZ
                                           NXTl
Ø12Ø 11 7E 14
                    1390
                                           D, 147EH NEXT QUARTER TURN
                                    LXI
Ø123
                    1400
Ø123 Ø6 Ø7
                    1410
                          AXL1
                                    MVT
                                            B. 7
                                                   DO 4 AXLES
Ø125
                    1420
                                    MOV
                                                   WHEELS MOVED HERE
                           AXL2
                                           M,D
Ø126 Ø5
                    1430
                                    DCR
                                            В
                                                   LAST WHEEL?
                    1440
Ø127 CA 52 Ø1
                                    JZ
                                            WORK
                                                   I'VE BEEN WORKIN' ...
Ø12A 23
                    1450
                                    INX
                                            H
                                                    ..ON THE RAILROAD ..
Ø12B
                    1460
                                    MOV
                                           M.E
                                                   (SIDE RODS MOVED HERE)
                                                   .. ALL THE LIVE ..
Ø12C 23
                    1470
                                    INX
                                           Н
Ø-
     Ø5
                    1480
                                                    ..LONG DAY....
                                   DCR
                                            В
     C2 25 Ø1
Ø.
                    1490
                                           AXL2
                                    JNZ
Ø131
                    1500
Ø131 FE 14
                    151Ø
                          NXTl
                                    CPI
                                            14H
                                                   QUARTER TURN
Ø133 C2 3C Ø1
                    1520
                                           NXT 2
                                    JNZ
Ø136 11 2D 13
                    153Ø
                                           D,132DH
                                    LXI
Ø139 C3 23 Ø1
                    1540
                                    JMP
                                            AXLI
Ø13C FE 13
                    1550
                          NXT 2
                                    CPI
                                            13H
                                                   QUARTER TURN
```

								2.000	
5 13E	C2	47	6 1	156#		JNZ	MIXT 3	1 EPT 2 - 1	3
6 141	11	5F	12	1575		LXI	D.125FF		
8144				1586		JMP	AXLI		
8147				1595	HXT3	CPI	12H	QUARTER TURN	
6 149	C2	14	5 1	1655		JNZ	AXLE		
514C				1615		LXI	D, 112DH	i	
7'4F	C3	23	51	162		JMP	AXLI		
				1635	•				
	51	88	B B	1645	WORK	TXI.	B, 3555		
1-00	B B			165#	OIL	DCX	В,		
£156	DB	55		1665		IN		DID THE CONDUCTOR	
\$158	E6	45		1675		ANI	RDA	FLAG US DOWN?	
\$15A	C2	63	51	1685		JNZ		-QUITTIN' TIME	
B15D	AF			169#		XRA	λ	NO, THEN HIGHBALL	
#15E				1766		XRA	В		
#15F	C2	55	51	1715		JNZ	OIL	NO SQUEEKS, PLEASE!	
\$162	C9			172#		RET			
\$163				1735	•				
\$ 163				1746	. PUT	A JUMP		VER YOU NEED TO RETURN IN THE NEXT	
#1C3			-6	175₿	Ottom	JMP	ALS8	YOUR RETURN LINK GOES	
\$ 163	C3	09	EP		QUIT	OMP	ALISO	HERE	
\$166				1766	•				
6 166				1776	RDA	EQU	4 5 H	PUT YOUR DATA READY PLAG HERE	
\$166				1786	RRY	EQU	S CC S SH		
\$166				1796		EQU	6PH	SMOKE CHARACTER	
5 166	61	18		1866	CABl	DW	1551H	CAB DESCRIPTION	
\$168					CAB2	DW	5D1#H	• •	
\$16A				1826	CAB3	DW	2 5 7EH		
6 16C					BOIL	DW		BOILER DESCRIPTION	
#16E				1846	BOI2	DW	19 8A H		
\$170				185		DW	BABAH		
9 172				1866		DW	5B/BAH		
\$174				1875	BOI5	DW	3939H		
6 176				1886	BOI6	DW	2#5DH		
6 178				189#	PRAL	DW	2 55 6H	FRAME DESCRIPTION	
517A				1988	FRA2	DW	2D11H		
6 17C				1918	FRA3	DW	2 5 11H		
617E				1926	FRA4	DW	2D6FH	61 01	
5 18 6				1936	FRA5	DW	2 6 6FH		
6 182		19		1946		DW	1919н	TIES DESCRIPTION	
6 184	øø				SHED	NOP	•	THIS IS SHED AREA	
5 185				196	Crond	EQU	\$+\$172	H BEGINNING OF CLOUD	
6 185				197∅	•				
\$185									



Processor Technology Corp. 6800 Hollis Street Emeryville, CA 94608 Vol. 1, No. 1

Bulk flore
U.S. Postage
PAID
Parmit No. 3729
Oakland Cah!

Stanley M Sokolow 1690 Woodside Rd Redwood City, CA 94061

1 EPT 2 - 14

THIS PAGE HAS BEEN INTENTIONALLY LEFT BLANK.

75¢ per issue

Published by Wible/Rampton Advertising, San Francisco. Volume One, Number Two, April 197

A Letter from the Editor

"Everyone should believe in something. I believe I'll have another drink."-Steele's Plagiarism of Somebody's Philosophy

Welcome to issue #2 of ACCESS. I hope the first one was able to provide you with something useful, after waiting so patiently for delivery. Wasn't entirely our fault this time, honest; we now know from personal experience that mailing services have their gremlins too. Anyway, issue #2 is now here and filled with goodies we hope you can use on your pet project.

One thing issue #2 isn't filled with is feedback from you. No way it could be, since it went to press before most of you ever got your hands on #1. We really do want to facilitate an exchange of ideas, comments, gripes, what have you, so please get those cards and letters into us. Are you more interested in hardware stuff than software stuff? Vice versa? What bugs bug you? What do you do with your Sol anyway? Got any hot tips on interfacing with exotic equipment? Just want to sound off about something? Or maybe even say something nice about us? We definitely want issue #3 to have more of you in it, instead of just us talking to the walls.

Speaking of us, you'll be reading this just about the time of the 1st West Coast Computer Faire. Come give us some feedback in person; we'll be there along with all the competition, and we'll have some good stuff to show you. You might even get to see me if you look closely; I'm the one wearing the red suspenders. For those of you who can't make it to San Francisco, we'll have a report in ACCESS #3.

Got to sign off now and fix that Sol PCB that just came in for warranty repair. (Probably sabotage - whoever heard of a SOL not working?)

Aram Attarian II

Subscription Information

ACCESS is published every six weeks. If you like what you see, we hope you'll send us \$4.00 for a year's subscription so we can keep the info coming. Write to us at Processor Technology, 6200 Hollis Street, Emeryville, CA 94608.



Inside Emeryville!

ne to One Communication

We're going to make this column a regular feature, under the peerless direction of our Customer Service Manager, the world renowned Ralph I. Palsson (applause). He'll keep you informed on what's happening in the world of availability, delivery dates, and other such precious tidbits, and do his best to keep the lines of communication open. Good luck, Ralph. (A.A.II, Editor)

A Customer Service Department has only one reason for its existence: to fix the responsibility on someone for keeping the communication lines open, so the company doesn't become just another faceless entity, vaguely malevolent to your attempts to pursue the love and lore of computing. The someone's me, Ralph Palsson; I'm here to welcome your telephone and letter inquiries and provide you with immediate, personal service. Whether it be pre-sales information, placing an order, finding the nearest Processor Technology dealer, checking on the availability of existing or forthcoming products—we'll do our best to help.

Are you interested in more information about a product than you could glean from the catalog description? How about the VDM-1 kit you ordered way back when and still haven't received? Even the best of us make occasional errors, and letting us know about your problems is the first step towards their solution. Letters are now being sent regularly to advise you, our customers, of anticipated production and delivery schedules. PTC dealers are being kept informed too, so you can call them for on-going status reports. We're trying continually to expand and improve the Customer Service Department with the aim of giving even more efficient, reliable service. Some of the ways we're doing it:

Teletroubleshooting. Having a problem with a PTC kit? Is your Sol-20 displaying 0's and 9's and nothing else? Need technical advice on interfacing? One of our applications engineers is available daily for phone consultation and technical assistance. Call (415) 652-8080 between 9:30 am and noon or 1:30 and 4:00 pm Pacific Time. Technically oriented software questions (continued on page 2)

One to One Communication (continued from page 1)

should go to our new division, Software Technology, at (415) 349-8080. (That's

right, 8080!)

When you make a technical call about a malfunctioning kit, it helps if you take time to think out your questions first, maybe make a few notes. It's also a good idea to have your kit manual handy, and if possible, the recalcitrant piece of equipment. All calls are taken on a first come, first serve basis, so if you do have to hold for a few minutes, please be assured that you're not running up your bill for the benefit of someone who called in later. If you do run into a wait, you can also ask us to call you back collect. We will.

Again, let us remind you that if you purchased your PTC product through a dealer, try him/her first. They're all authorized to service the equipment they sell, precisely because they can give you more personalized, faster service than any-

one can by mail or phone.

Need a defective part replaced? Again, the best way to handle this is through your dealer. If he's out of stock, or if you purchased directly from us, send us the defective part for replacement. Similarly, if you're missing a part from a kit, call your dealer or write to us, giving as complete a description as you can of what's missing.

Finally. We are always interested in improving our one-to-one communication, and we're open to your comments, criticisms, and suggestions. Please feel free to contact us if we can be of service in

any way.

Error, Error, Does Not Compute

Errors do appear from time to time in all high class publications. ACCESS is no exception—our score for the first issue was

three unfortunate oversights.

1. The instructions for wiring the 3P+S for a keyboard interface (page 3). At Step 5, we told you to connect pin 7 to a point on 3P+S leading to J2 pin 12. Pin 12 is a ground point, and you don't really want to do that. Pin 7 should be connected to a point on the 3P+S leading to IC 14 pin 13.

2. The article on interfacing PT 4KRA memory boards with the Motorola M6800 (page 2). It's all right as far as it goes, but we neglected to give proper credit to the contributor. Our apologies and thanks to J. W. Schook, P.O. Box 185, Rocky Point,

N.Y.

3. Last, but not least, those everpresent gremlins managed to alter our mailing address to 6800 Hollis St. Now, that's really adding insult to injury. Our correct address is 6200 Hollis St., Emeryville, CA 94608:

Introducing Software Technology Corporation

We've pulled a protozoan trip and split in two: Software Technology Corp. is a separate new company formed to take over software development from Processor Technology. The idea is to give you more and better software support by not scattering our energies about, randomly.

Software Technology is three people with an impressively vast reservoir of experience in operating systems, time sharing, real time systems, compilers, interpreters, simulators, business systems, and software development. Did we leave anything out? During this transitional period, they'll be maintaining, supporting and producing all the current PTC software, plus developing some of their own. Later (not too much later), they'll be coming out with lots of good stuff designed to get the most out of Sol.

You should have your first chance to see the caliber of Software Technology developments at the Computer Faire in San Francisco. But we're not going you what, because one fundamental of Software Technology is not to announce anything that isn't ready. Nobody likes a tease.

Meanwhile, Software is in business and even has a phone. If you have any problems with Processor Technology software you're using now, you can call their 24-hour phone line. When nobody's there, there's an answering machine to take your message, and they will get back to you promptly. The number is (415) 349-8080. You're also welcome to write your questions: P.O. Box 5260, San Mateo, CA 94402

For the time being, orders, questions about delivery and of course hardware questions should still be directed to Proces sor Technology. (See One to One Com-

munication)

Read on for your first example of Software Technology software.

Announcing the SOL USERS GROUP!

The Sol Users Group was recently organized by members of the Homebrew Computer Club in Palo Alto; SUG is not affiliated in any way with Processor Tech-Technology. The purposes of SUG are to exchange software and other applications, and to create standards. If plenty of interest is shown, a Sol Newsletter will be published and sent to members.

If you own or have ordered a Sol, send your name, address, phone number and ideas to:

Bill Burns 4190 Maybell Way Palo Alto, CA 94306 (Please don't call.)

Attention, CONSOL Users

All Processor Technology software has recently been modified in a very important way that encourages standardization. If you've been looking forward to having some Sol software for your CONSOL Proms, you'll have to let us reprogram for you. There's no charge. Just mail your CONSOL Proms, suitably packaged, to Processor Technology; we'll take care of the rest. Turn-around time is about 2 weeks, dependent on the vagaries of the U.S. Postal Service, natch.

If you're planning to upgrade to SOLOS anyway, don't worry about it.

Clarkes third law: Any sufficiently advanced technology is indistinguishable from magic.

CUTE, CUTEST, CUTER

Below is the complete source listing for the control and monitor programs for the CUTS board. This program, CUT 2, was made available with the CUTS module in the form of a cassette sellin for \$11.

The CUTER cassette contains object code along with a relocating loader for loading the program in any 256-byte boundary of available RAM. A new version of BASIC-5 for use with CUTER and SOLOS is also on the cassette, followed by the complete source code of CUTER. Not a bad deal for \$11.

So why buy the cassette now that we're giving you the listing? It's not that we're mercenary, but consider: if you want to use PTC's software packages on cassettes, then CUTER is going to be a tremendous asset in loading those tapes, right? Right—otherwise you could spend 3 or 4 hours toggling it in from the front panel of your A#\$%&R or I(*@I.

A CCESSOR TECHNOLOGY

Editor: Aram Attarian II
Publisher: Wible/Rampton Advertising,
727 15th Avenue, San Francisco, CA 94118
ACCESS is published approximately every six
weeks, Subscription rate: 94 per year, from

Processor Technology Corp., 6200 Hollis St., Emeryville, CA 94608.

ACCESS Copyright © April 1977 by Processa Technology Corp. All Rights Reserved. Material in this publication may not be reproduced in any form without permission from Processor Technology Corp.

Double Your Pleasure, Double Your Fun, Jr. How to Use Both Parallel Ports on the 3P+S

You can take maximum advantage of the 3P+S's versatility by making a simple modification that gives you simultaneous access to both parallel ports. Then you'll be able to use one port for a keyboard input, the other for paper tape input/output. The serial port is available for an RS232 or TTY, with status and control available at Port 0 for Processor Technology software compatibility.

The change procedure is as follows:

1. Cut the existing trace from IC 22 pin 3 to IC 20 pin 13; at IC 22 pin 3

2. Cut the existing trace from IC 23 pin 12 to IC 21 pins 1 and 2; at IC 23 pin 12

3. Run a jumper from IC 23 pin 12 to IC 20 pin 13

4. Run a jumper from IC 22 pin 3 to IC 21 pins 1 and 2

5. Select area "B" option; jumper from left to right

Assuming that area "A" board address options "00" have been selected, the ports will now be set up as follows:


Port 0 = Channel C. Control and status Port 1 = Channel A.* Parallel data (keyboard)

ort 2 = Channel D. UART (RS232 or TTY)

Port 3 = Channel B* Parallel data (paper tape reader)

*The strobe latches for the parallel ports remain with their respective channels.

Changing the data available status. The 3P+S interface is laid out to respond to a negative strobe input pulse with low active status (i.e., FA, FB). For compatibility with Processor software, you'll want to select a high active data available status. Run a jumper from the \bar{Q} output of the respective strobe latch (i.e., AKA, AKB) to the correct status bit input in area "G." In the above configuration, this amounts to jumpering keyboard data available IC 15 pin 7 to area "G" point C6.



Osborns Law: Variables won't. Constants aren't.

FLASH-VDM Access Flicker Eliminated, Part 2

In the last issue, we gave you a hardware modification to take care of the flicker produced whenever the VDM memory is being accessed. We also promised to explore the implications a bit further this time. So here's a subroutine for the VDM driver program that implements

One thing to remember: if reads from the screen memory are needed by the driver, they have to be synchronized by a

the modification via software.

And now, the VDM-1/2! Or, Modifying Your VDM-1 for 32-character Display

We're pleased to announce that unceasing technical progress has now made possible a reduction in the number of characters per line of the VDM-1 display from 64 to 32! Seriously, the modification is quite handy if you want to work with large type display, or feed RF modulated signals to a TV antenna input.

The hardware modifications are shown in the schematic drawing below. One word of caution: since we're tying the loworder address bit to ground, only character locations with bit 0 equal to 0 (i.e., even-numbered addresses), will be displayed. So if you use the modified VDM

with unmodified software, you'll end up with only alternate characters on the screen and a rather cryptic message! In the next issue of ACCESS, we'll


have some spiffy software routines to use with the "VDM-1/2". Meanwhile, you can probably come up with some of your own. (Drop us a line if you run across anything interesting.) Just remember that a left shift of a 64-character address will give you the 32-character address, providing that you shift in a 0 to bit 0. Good luck!

subroutine similar to this. This one only takes care of flickerless access to the memory.

Next issue, we'll continue the flicker saga by providing a version of the Processor PATTERN program which contains this routine for flickerless display.

```
THIS ROUTINE MOVES A CHAR- IN REGISTER B TO VDM DISPLAY MEMORY
1005
     *
**** ASSUMPTIONS:
1828
1025
              THE CALLER HAS SET UP A STACK
1838 *
              REGISTER PAIR H&L CONTAIN THE VDM DISPLAY MEMORY ADDRESS
1242 +
1845
              THE ROUTINE IS RUNNING IN MEMORY
1858
              WITH NO (0) WAIT STATES.
1065 +
1075
      START
                       B
C.2
                                SYNC BIT MASK (BIT 1)
1885
              MVI
         CATCH FALLING EDGE OF SYNC
1095
1144
1135 HILP
1110
                                ONLY BIT I REMAINS
              JZ
                       HILP
                               UNTIL SYNC IS HI
1128
         SYNC IS HI. NOW WALT
1130
                               UDM STATUS PORT
      LOLP
              IN
                       SCSH
1140
              ANA
                                ONLY BIT I REMAINS
                       LOLP
1150
              JNZ
1155
         DISPLAY SWEEP IS NOW AT LEFT MARGIN
                                SO SWEEP CAN MOVE TO
1173
                                RIGHT MARGIN
1185
         NOW THAT SWEEP IS OFF THE SCREEN:
                               ACCESS DISPLAY MEMORY
1195
1205
                               GIVE IT BACK
              RET
1226 +
         THIS ROUTINE DELAYS FOR JUST ENOUGH TIME
TO ALLOW THE SWEEP TO CROSS THE SCREEN
*** ALTER IT WITH CARE ***
1225 +
1238 .
1240
      WAIT
1256
              PUSH
              POP
              PUSH
```

Cann's Axiom: When all else fails, read the instructions.



PROGRAM DEVELOPMENT SYSTEM

```
0129 0
0130 0
0131 0
0132 0 CUTER SYSTEM I/O ROUTINES
0133 0
0138 0
                                                                                                                       SOFTWARE TECHNOLOGY CORP.
P.O. BOX 5260
SAN MATEO, CA 94402
  CUTER (TM) 77-03-27
COPYRIGHT (C) 1977
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  THIS ROUTIME IS A MODEL OF ALL INPUT ROUTIMES WITHIN CUTER. THE FIRST ROUTIME "KREAI" PERFORMS THE IN" FROM THE STANDARD KEIBOARD ON PARALLEL PORT 3.
ALL STANDARD INPUT DRIVERS RETURN EITHER THE CHAMITH A MON-ZERO FLAG, OR JUST A ZERO FLAG INDICATIAT BO CHARACTER IS AVAILABLE YET. IT WILL BE RESPONSIBILITY OF THE USER TO LOOP WAITING FOR A CHARACTER, OR TO USE THE INPUT AS A STATUS REQUEST. WHEN A CHARACTER IS AVAILABLE, IT IS RETURNED IN REG A.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                0135 0 THIS ROI
0136 0 CUTER. TO
0137 0 FPOM THE:
0138 0 ALL STANDI
0139 0 MITH A ROI
0140 0 THAT HO CI
0141 0 RESPONSIBLE
0143 0 MEEN A CHA
0143 0 THE FOLLOI
0146 0 OP HOW TO
0148 0 THE FOLLOI
0146 0 OP HOW TO
0147 0 RET
0152 0 REA1 EQU
0151 IM
0152 0 REA1 EQU
0155 0 RET
0155 0 RET
0155 0 RET
0155 0 RET
0156 IM
0157 RET
0158 0 RET
0159 0 RET
0159 0 RET
0159 0 RET
0159 0 RET
0150 0 RET
0151 0 RET
0155 0 RET
0157 RET
                                                                                           9999
0002 **
0003 **
0004 **
0005 **
0006 **
                                                                                                                                           COPY CUTER 1/1
                                                                                                                                                    CUTER(TH)
                                                                                                                                                                                       COPYRIGHT (C) 1977
SOFTWARE TECHNOLOGY CORP.
P.O. BOX 5260
SAR MATEO, CA 94402
(415) 349-8080
                                                                                            0008
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  THE FOLLOWING REYBOARD ROUTINE MAY BE USED AS A SAMPLE OF HOW TO WRITE A USER INPUT ROUTINE.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                KETBOARD INPUT ROUTINE
                                                                                                                                  ALL RIGHTS RESERVEDIII
                                                                                                                                                                                                                                                                                                                                                                                      C035
C035 DB 00
C037 2F
C038 E6 01
C03A C8
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               $ KETBOARD READ ROUTINE
STAPT GET STATUS WORD
. INVERT IT FOR PROPER RETURN
EDR TEST NOT KEYBOARD DATA READY
. ZERO IF NO CHARACTER RECEIVED
                                                                                                                                                   VERSION 1.3
77-03-27
                                                                                                                          THIS PROGRAM IS DESIGNED TO BE A STANDALONE CUTS
OPERATING SISTEM. CUTER IS DESIGNED TO BE READ IN PROM
CASSETTE TAPE OR TO BE RESIDENT IN READ-ONLY-MEMORY.
CUTER SUPPORTS VARIOUS DEVICES INCLUDING SERIAL,
PARALLEL, THE PROCESSOR TECHNOLOGY VDM(TM) AND UP TO
TWO CUTS TAPE DRIVES.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                EDATA GET CHARACTER
GO BACK WITH IT
                                                                                                                                                                                                                                                                                                                                                                                        CO3B DB 03
CO3D C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      SERIAL INPUT ROUTINE
                                                                                            0026
                                                                                                                           CUTER(TM) HAS BEEN WRITTEN SO AS TO BE COMPATIBLE WITH SOLOS(TM). THE FOLLOWING KEYS ARE USED BY CUTER(TM) IN PLACE OF THE SPECIAL KEYS ON THE SOL KEYBOARD:
                                                                                                                                                                                                                                                                                                                                                                                        C03E
C03E DB 00
C040 E6 40
C042 C8
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              $ SERIAL INPUT ROUTINE
STAPT GET STATUS
SDR TEST FOR SERIAL DATA READY
FLAGS ARE SET
                                                                                            0029
                                                                                                                                        CURSOR UP
CURSOR LEFT
CURSOR RIGHT
CURSOR DOWN
CURSOR HOME
CLEAR SCREEN
MODE
                                                                                                                                                                                                          CTL-W
CTL-A
CTL-S
CTL-Z
CTL-W
CTL-K
CTL-E
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  0168 IN SDATA GET DATA BYTE
0169 ° IT IS UP TO THE CALLER TO STRIP PARITY IP DESIRED
0170 RET . WE HAVE IT
                                                                                                                                                                                                                                                                                                                                                                                        C043 DB 01
                                                                                                                                                                                                                                                                                                                                                                                        C045 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  0170
0171 •
0172 •
0173 •
0174 •
                                                                                                                                                                                                                                                                                                                                                                                                                                                                              0173 SERIAL DATA OUTPUT
0175 SEROT EQU $ SERIAL OUTPUT ROUTINE
0175 SEROT EQU $ SERIAL OUTPUT ROUTINE
0176 IN STAPT GET STATUS
0177 RAL
0178 JNC SEROT LOOP UNTIL TRANSHITTER BUFFER
0180 OUT SDATA SEND IT OUT
0181 RET AND WE'RE DONE
0183 PARALLEL DATA INPUT
0185 PARALLEL DATA INPUT
0186 IN STAPT STATUS
0187 CMA INVERT FOR PROPER PETURN
0188 ANI POR IS DATA READY?
0198 RZ NO-JUST EXIT
0190 IN PDATA YES-CET CHAR THEN
0191 RET THEN EXIT
0192 POR STAPT STATUS
0193 PARALLEL DATA OUTPUT ROUTINE
0193 OUTPUT CHAR TO PARALLEL PORT
0194 OUTPUT ROUTINE
0195 PAROT EQU $ OUTPUT COUTINE
0195 JNZ NO-JUST EXIT
0196 JNZ STAPT STATUS
0197 PARALLEL DATA OUTPUT ROUTINE
0198 PARALLEL DATA OUTPUT ROUTINE
0199 JNZ STAPT STATUS
0199 PARALLEL DATA OUTPUT ROUTINE
0196 JNZ PAROT FOU S OUTPUT CHAR TO PARALLEL PORT
0197 ANI PIDT S EXTERNAL DEVICE PEADY?
0198 JNZ PAROT NO--WAIT TIL IT IS
0199 JNZ PAROT NO--WAIT TIL IT IS
0190 OUT PDATA SEND DATA MOW
0200 OUT PDATA SEND DATA MOW
0201 RET DONE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    SERIAL DATA OUTPUT
                                                                                                                                                                                                                                                                                                                                                                                      C046
C046 DB 00
C048 17
C049 D2 46 C0
C04C 78
C04D D3 01
C04F C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              SERIAL OUTPUT ROUTINE
STATE
GET STATUS
PUT HIGH BIT IN CARRY
SEROT LOOP UNTIL TRANSHITTER BUFFER IS EMPTY
A,B
GET THE CHARACTER BACK
SDATA
SDATA
AND ME'RE DONE
                                                                                          0040 0
0041 0
0042 0
0043 0
                                                                                                                             AUTO-STARTUP CODE
                                                                                            0045 START MOV A.A SHOW THIS IS CUTER (SOLOS=00)
0046 ° THIS BYTE ALLOWS AUTOMATIC POWER ON FHYRY
0047 ° WHEN IN ROW SUPPORTING THIS HARDWARE FFATURE.
0048 INIT JMP STRTA SYSTEM RESTART ENTRY POINT
C000 7F
                                                                                             0048 INIT
C001 C3 D7 C1
                                                                                                                                                                                                                                                                                                                                                                                      C050
C050 DB 00
C052 2F
C053 E6 02
C055 C8
C056 DB 02
C058 C9
                                                                                                              THESE JUMP POINTS ARE PROVIDED TO ALLOW COMMON ENTRY
LOCATIONS FOR ALL VERSIONS OF CUTER. THEY ARE USED
EXTENSIVELT BY CUTS STSTEM PROGRAMS AND IT IS RECOMMENDED
THAT USER ROUTINES ACCESS CUTER ROUTINES THROUGH THESE
POINTS ONLY!
                                                                                          0051 • LOCATIONS
0052 • EXTENSIVE
0053 • THAT USER
0058 • POINTS ON
0056 • POINTS ON
0057 FOPEN JMP
0058 FCLOS JMP
0059 ROBYT JMP
0060 WRBYT JMP
C00# C3 18 C2
C007 C3 DC C5
C00# C3 FF C5
C00D C3 #2 C6
C010 C3 7F C6
C013 C3 C7 C6
C016 C3 7B C7
                                                                                                                                                                      COMMO RETURN TO CUTER COMMAND PROCESSOR BOPEN CASSETTE OPEN FILE ENTRY PCLOS CASSETTE READ BYTE ENTRY CASSETTE READ BYTE ENTRY CASSETTE READ BYTE ENTRY RTAPE CASSETTE READ RICCR ENTRY MTAPE CASSETTE READ RICCR ENTRY
                                                                                                                                                                                                                                                                                                                                                                                      C059
C059 DB 00
C05B E6 04
C05D C2 59 C0
C060 78
C061 D3 02
C063 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                0196
0197
0198
0199
0200
0201
0202 •
0203 •
0204 • USER
0205 ERRIT
0206
0207
0208
0209 •
0209 •
0209 0210
                                                                                           0062
0063
0064
0065
0066
0067
0068
0069
0070
0071
                                                                                                                                               SYSTEM I/O ENTRY POINTS
                                                                                                                          THESE POUR ENTRY POINTS ARE USED TO EITHER INPUT OR OUTPUT TO CUTER PSUEDO PORTS.
THESE PSUEDO PORTS ARE AS FOLLOWS:
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 DEFINED INPUT/OUTPUT ROUTINES
EQU $ USER IMPUT ROUTINE
PUSH H SAVE ORIG HL
LHLD UIPRT CET USER'S RTN ADDR
JMP ERRO1 MERGE TO VERIFY THE ADDR
                                                                                                                                                                                                                                                                                                                                                                                       C064 E5
C065 2A 00 C8
C068 C3 6F C0
                                                                                                                          PORT INPUT
                                                                                                                                                                                                                                      OUTPUT
                                                                                                                                                                                                                                    BUILT-IN YOM DRIVER
PORT C8, MEMORY FROM CCOO
SERIAL PORT
ACTUAL PORT 1
PARALLEL PORT
ACTUAL PORT 2
USER'S OUTPUT ROUTINE
                                                                                                                                                       KEYBOARD INPUT
ACTUAL PORT 3
SERIAL PORT 1
ACTUAL PORT 1
PARALLEL PORT 2
USER'S INPUT RTM
                                                                                                                              0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        C06B
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                EQU
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              $
                                                                                          0074 0075 0076 0077 0078 0079 0080 0081 0082 0082
                                                                                                                                                                                                                                                                                                                                                                                      C06B E5
C06C 2A 02 C8
C06F TD
C070 B4
C071 C2 8B C2
C074 C3 0F C2
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  PUSH
LHLD
EQU
MOV
ORA
JNZ
JMP
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                2211
2212
2213
2214
2215
2214
2215
2216
2217
2218
2219
2221
2223
2223
2223
2223
2232
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
2233
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              H
UOPRT
$
A,L
                                                                                                                           3
                                                                                                                         STATUS FOR ACTUAL PORTS 1, 2 AND 3 IS VIA ACTUAL PORT 0. THE RITS OF PORT ZERO ARE DEFINED AS FOLLOWS:
                                                                                           VIDEO DISPLAY ROUTINES
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                THESE ROUTINES ALLOW FOR STANDARD VIDEO TERMINAL OPERATIONS. ON ENTRY, THE CHARACTER FOR OUTPUT IS IN REGISTER B AND ALL REGISTERS ARE LVALTERED ON RETURN.
                                                                                                                                    TBE
                                                                                                                                                                  1=TRANSMITTER BUPFER EMPTY (SERIAL)
1=READER DATA AVAILABLE (SERIAL)
                                                                                           0088 0089 0090 0091 0092 0093 0094 0095 0096
                                                                                                                                    PXDR
                                                                                                                                                             O=PARALLEL EXTERNAL DEVICE READY
                                                                                                                                  PDR
                                                                                                                                                             O=PARALLEL DATA READY
                                                                                                                                                                                                                                                                                                                                                                                       C077
C077 E5
C078 D5
C079 C5
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            VDM OUTPUT DRIVER
SAVE HL
SAVE DE
                                                                                                                                   KDR
                                                                                                                                                             O=KEYBOARD DATA READY
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  PROCESS ESC SEQUENCE IF ANY
                                                                                                                           NOTE: SOUT AND SIMP ARE "LDA" INSTRUCTIONS.
THIS FACT IS USED TO ALLOW ACCESS TO THE
BYTES "OPORT" AND "IPORT" DYNAMICALLY.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 0236 0
0237
0238
0239
0240
0240
0241
0243
0244
0245
0246
0247
                                                                                                                                                                                                                                                                                                                                                                                        COTA 3A OC C8
COTD B7
COTE C2 87 C1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   LDA
ORA
JNZ
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              ESCFL GET ESCAPE FLAG
                                                                                                                                                                                                                               "LDA" INSTRUCTIONS!!!!!
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                ESCS IF NON ZERO GO PROCESS THE REST OF THE S
                                                                                                                                                                       OPORT OUTPUT VIA STANDARD OUTPUT PSUEDO PORT
OUTPR OUTPUT VIA PSUEDO PORT SPECIFIED IN REG A
IPORT IMPUT VIA STANDARD IMPUT PSUEDO PORT
2 IMPUT VIA PSUEDO PORT SPECIFIED IN REG A
END OF SYSTEM ENTRY POINTS-----
                                                                                                                                                                                                                                                                                                                                                                                       C081 78
C082 E6 7F
C084 47
C085 CA 9F C0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   MOV
ANI
MOV
JZ
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              A,B
7FH
B,A
GOBK
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          GET CHAR
CLR HI BIT IN CASE
USE CHAR STRIPPED OF HI BIT FOR COMPATAR
MAKE A QUICK EXIT FOR A NULL
C019 3A 07 C8
C01C C3 2E C0
C01F 3A 06 C8
C022
                                                                                                                                                                                                                                                                                                                                                                                        C088 21 E2 C2
C08B CD A5 C0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   LXI
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                H.TBL
TSRCH GO PROCESS
                                                                                         0111 • 0112 • AIMP 0112 • 0113 • 0114 0115 • 0116 • T 0116 10PRC 0119 0120 0121 0122 • 0123 • 0125 017PR 0125 0127 0128
                                                                                                                                          CONTINUES MERE (IT COULD HAVE BEEN A "JMP" THOUGH)
PUSH H SAVE HL FM ENTRY
LXI H,ITAB
                                                                                                                                                                                                                                                                                                                                                                                       COSE CD 49 C1
CO92 F6 80
CO92 F6 80
CO99 77
CO95 24 OA C8
CO99 AF
CO99 AF
CO99 BC
CO96 C2
CO97 C1
COA1 E1
COA2 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          GO FROCESS

GET SCHA ADDR

GET CHAR

INVERSE VIDEO
CURSOR IS MON THERE
1 GET DELAY SPEED
MAKE IT DEFINITELY NON-ZERO
DELAY ENDS WHEN H=ZERO
LOOP FOR DELAY ANT
IS IT DOME YET
MO-KEEP DELAYING
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Color | Colo
 C022 E5
C023 21 09 C3
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  0250
0251
0252
0253
0255
0255
0255
0257
0257
0259
0259
0260
0261
0262
0263
0264
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 VDADD
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               A,M SOH I
M,A SPEED-1
                                                                                                                                    THIS ROUTINE PROCESSES THE I/O REQUESTS
                                                                                                                                                                                                      KEEP REGISTER "A" TO POUR VALUES COMPUTE ENTRY ADDRESS
C026 E6 03
C028 07
C029 85
C024 6F
C02B C3 87 C2
                                                                                                                                                                        L.A WE HAVE ADDRESS
DISPT DISPATCH TO IT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            RESTORE ALL REGISTERS
                                                                                                                                          PUSH
LXI
JMP
                                                                                                                                                                                                      PROCESS OUTPUT REQUESTS
                     COZE
CO2E E5
CO2F 21 01 C3
CO32 C3 26 C0
                                                                                                                                                                          H SAVE REGS
H,OTAB POINT TO OUTPUT DISPATCH TABLE
IOPRC DISPATCH FOR PROPER PSUEDO PORT
```

	COA3 COA3 23 COA4 23	0265 0266 0267 0268 0269	NEXT	EQU INX INX	\$ H H	GO TO NEXT CHR	C14F (C150 (C151 (C152 (C153)	OF OF	03	04 0 1 04 0 2 04 0 3 04 0 4 04 0 5		ADD RRC RRC MOV ANI	L L, A	ADD IT TO THE LINE POSITION TIMES TWO MAKES FOUR L HAS IT MOD THREE FOR LATER
	1	0270 0271	o THIS	ROUTI	NE SEAR	RCHES FOR A MATCH OF THE CHAR IN "B"	C155 (C6 (ic c	0406		ADI	CYDME H.A	M LOW SCREEN OFFSET WOW H IS DONE
	A5 7E COA6 B7	0272 0273 0274	TSRCH	MOV	A,H	GET CHR FROM TABLE SEE IF END OF TBL	C158 1 C159 I	E6 0	:0	04 08 04 09 04 10		MOV	A,L OCOH	TWIST L'S ARM
	COAT CA B7 CO	0275 0276		JZ CMP	CHAR	ZERO IS THE LAST TEST THE CHR	C15C (6F		0411		MOV RET	C L, A	H & L ARE NOW PERVERTED
	COAD 23 CO	0277 0278		INX	H	POINT FORWARD		• ,		0414			TO REM	OVE CURSOR
	COAF E5 COBO CD 5E C1	0279 0280		PUSH	H	FOUND ONESAVE ADDRESS REMOVE CURSOR	C15E (CD 4	A C1	0415	•	CALL	VDADD	
	COB4 C3 B7 C2	0281 0282		JMP	DISPT	RESTORE ADDR OF CHAR ENTRY IN TBL DISPATCH FOR CURSOR CONTROL	C161 1	7E		0417		MOV	A.M	STRIP OFF THE CURSOR
	CORT	0283 0284 0285	•	POU		WE HAVE A CHAR	C164 7			0419		RET	M, A	
	COB7 COB7 78 COB8 FE 7F	0286 0287	CHAR	MOV CPI	S A,B 7FH	GET CHARACTER IS IT A DEL?				0421	•	ROUTIN	E TO BA	CKSPACE
	COBA C8	0288		RZ		GO BACK IF SO	C166	CD :	33 C1	0423 0424 0425	PBACK	CALL	PLEFT	
		0290	:				C16C	36 2		0426		MVI	M,	PUT A BLANK THERE
	COBE CD 44 C1 COBE 70	0293	OCHAR	MOV	WDADD M, B	GET SCREEN ADDRESS PUT CHR ON SCREEN		-,		0428	:		E TO PR	OCESS A CARRIAGE RETURN
	COBF 3A 08 C8	0294		CPI	NCHAR 63	GET CHARACTER POSITION END OF LINE?	C16F	CD '	IC C1	0431	PCR	CALL	CLINE	CLEAR FROM CURRENT CURSOR TO END OF LINE
	COC4 DA E4 CO COC7 3A 09 C8 COCA FE OF	0296 0297 0298		LDA CPI	LINE 15	END OF SCREEM?	C172	С3 :	37 C1	0433		E THAT		S BACK=64 WHICH WILL BE CLEAPED AT POUR AND STORE THE NEW VALUE
	COCC C2 E4 CO	0299		JNZ	OK	or senser.				0434 0435 0436	· RO	UTINE	TO PROC	ESS LINEFEED
		0301	. ENI	OF SC	REEN	ROLL UP ONE LINE	C175	3A (9 C8	0437		LDA INR	LINE	GET LINE COUNT NEXT LINE
	COCF AF CODO 32 08 C8	0303	SCROLL	STA		BACK TO FIRST CHAR POSITION	C179 I	E6 0		0439		ANI	15 CUR	SEE IF IT WRAPPED AROUND IT DID NOTNO SCROLL
	COD3 4F COD4 CD 4B C1	0306	SROL	CALL	C, A	CALCULATE LINE TO BE BLANKED	C17E			0441		JMP	SROL	SCROLL ONE LINECURSOR SOME POSITION
	COD7 AF COD8 CD 22 C1	0307		CALL	CLIN1	CLEAR IT				0444	•	SET ES	CAPE PR	OCESS FLAG
	CODE 3A OA C8 CODE 3C CODF E6 OF	0309 0310		LDA INR ANI	BOT A OFH		C181			0445		MVI	A,-1	SPT PLAC
	COE1 C3 11 C1	0311 0312 0313		JMP	ERAS3	كاللبدرة فكأنط	C183			0447 0448 0449		RET	ESCFL	SET FLAG
		0314	. INC	REMENT		COUNTER IF NECESSARY				0450	•	PROC	ESS ESC	APE SEQUENCE
	COE4 3A 08 C8 COE7 3C	0316 0317	OK	LDA INR	A	GET CHR POSITION	C187	CD 9	0 C1	0452		CALL	CREM ESCSP	
	COE8 E6 3F COEA 32 08 C8	0318 0319		STA	3FH NCHAR	MOD 64 STORE THE NEW	C18D	C3 8	BE CO	0454		JMP	GOBAC	ĸ
	COED CO COEE COEE 3A 09 C8	0320 0321 0322		EQU	S LINE	MORE CHARS THIS LINE MOVE CURSOR DOWN ONE LINE	C 190 C 193	FE F	F	0457	ESCSP	CPI	ESCFL -1	TEST FLAG
	COF1 3C COF2 E6 OF	0323		LDA INR ANI	A	GET THE LINE COUNT MOD 15 INCREMENT	C195	CA	18 (1	0458 0459 0460		JZ CESS T	SECON	R OF ESC SEQUENCE
	COF4 32 09 C8 COF7 C9	0325 0326		STA	LINE	STORE THE NEW	C198	21 (oc c8	0461	•	LXI	H.ESC	
		0327	. E	ASE SC	REEN		C19B	36 0	00	0463		MVI	M, 0	Alleder House Committee
_	OF8 21 00 CC		PERSE		H, VDME	M POINT TO SCREEN	C19F	DA E	30 C1	0465		JC JZ	SETY	SET X SET Y
	FB 36 A0	0331 0332 0333	•	INX	M,80∏→	THIS IS THE CONSOR	CIA7	CA	94 C5	0467		JZ	STSPD	SPECIAL SET SPEED YESSET THE SPEED WITH IT THEN
	COFE COFE 36 20	0334		EQU	\$ H. · ·	MEXT CHAR LOOP TO CLR SCRN BLANK IT OUT	CIAA I	DA E		0469 0470 0471		JC RNZ	OCHAR	PUT IT ON THE SCREEN
	C100 23 C101 7C	0336 0337		INX	H A,H	NEXT SCRN LOC SEE IF DONE	CIAI			0472			UTE TO	VALUE IN REG B
	C102 FE DO C104 DA FE CO	0338		JC JC	ODOH ERAS 1	DID IT GO ABOVE VDM NOMORE	C180	78		0474	•	HOY	A,B	
	C107 37	0340		STC		SAY WE WANT TO DROP THRU TO ERAS3	C1B1 (C3 3	7 C1	0476		JMP	PCUR	
	C108 - C108 3E 00 C10A 32 09 C8	0343		MVI STA	A,O LINE	RESET CURSOR TO HOME CLEAR, LEAVE CARRY AS IS		- 0		0478	•		TO LI	ME "B"
	C10D 32 08 C8	0345		STA	NCHAR	ZERO LINE LEFT SIDE OF SCREEN THIS IS JUST A HOME OPERATION	C184		'2 CO	0480 0481 0482		JMP	A,B CURSC	
	C111 D3 C8	0347	•	OUT	DSTAT	RESET SCHOLL PARAMETERS				0483		ocess s	SECOND	CHR OF ESC SEQUENCE
	C113 32 0A C8 C116 C9	0349		STA RET	BOT	BEGINNING OF TEXT OFFSET	C1B8	78		0485	SECOND		A,B	
		0351					C1B9 1	FE C		0487 0488		CPI JZ	CURET	
	C117 C117 3A 07 C8	0354		LDA		HERE TO SEE IF VDM OUTPUT GET CRNT OUTPUT PORT	C1BE E			0489	_	CPI	ARET2	
	C11A B7 C11B C0 C11C CD 44 C1	0355 0356 . 0357		ORA RNZ CALL	VDADD	NOT VDMDONE THEN GET CURRENT SCREEN ADDRESS	C1C3	44		0491		HOV	B. H	DECEMB CUBICA INCODES DO DO DOS DECIMA
	C11F 3A 08 C8 C122 FE 40	0358		LDA CPI	NCHAR 64	CURRENT CURSOR POSITION NO MORE THAN 63	C1C4 F C1C5 I C1C6 I	E 1		0493 0494 0495	ARET 1	POP POP	C,L H D	PRESENT SCREEN ADDRESS TO BC FOR RETURN RETURN ADDRESS OLD B
	C124 D0 C125 36 20	0360 0361		RNC	Ĥ, · · ·	ALL DONE ALL SPACED OUT	C1C7 (C5		0496		PUSH	B	
	C127 23 C128 3C	0362		INX	H A		C1C9	AF 32 (c c8	0498	ARET2	STA	A ESCFL	
	C129 C3 22 C1	0364	•	JMP	ÇLIW1	LOOP TO END OF LINE	CICD	C9		0500 0501	•	RET		
		0366 0367 0368	e ROUT	INE TO	MOVE TI	HE CURSOR UP ONE LINE				0502	•	RETURN	PRESEN	T SCREEN PARAMETERS IN BC
	C12C 3A 09 C8	0369	PUP	LDA DCR	LIME	GET LINE COUNT	CICE :		8 C8	0504 0505 0506	CURET	LXI	H, MCH	AR CHARACTER POSITION
	C130 C3 P2 C0	0371		JMP	CURSC	MERGE	C1D2 2	23		0507 0508		INX	H C.M	LINE POSITION
		0373	. MOVE	CURSOR	LEFT (ONE POSITION	C1D4	C3 C	5 C1	0509		JMP	ARETI	
-	C133 3A 08 C8 C136 3D	0375 1	PLEFT	LDA DCR	MCHAR A					0511	•			
	C137 C137 E6 3F	0377	PCUR	EQU	8 03FH	TAKE CARE OF CURSOR SAME LINE LET CURSOR WRAP AROUND				0513	:			ART UP SYSTEM
1	C139 32 08 C8 C13C C9	0379 0380 0381	1	RET	NCHAR	UPDATED CURSOR				0515 0516 0517	· THE	N ENTE	R THE C	D THE FIRST 256 BYTES OF GLOBAL RAM OMHAND MODE.
		0381 0382 0383	• C	URSOR R	RIGHT OF	NE POSITION	C1D7 /	AF		0517 0518 0519	STRTA	XRA	A. C. A	
- 1	C13D 3A 08 C8 C140 3C	0384 1	PRIT	LDA INR	NCHAR A		C1D9		14 C8	0520		LXI	H, DFL	TS CLEAR AFTER USER PORT ADDRESSES
•	C141 C3 37 C1	0386		JMP	PCUR		C 1DC	23		0522	CLERA	MOV	M, A	
		0388	ROU			LATE SCREEN ADDRESS	CIDE (00	DC C1	0524		INR	CLERA	
		0390	ENT	RY AT:		URNS:				0526 0527	· DETE	RMINE	THE DEF	AULT PORTS
		0392		VDAD	2 ADDE	RENT SCREEN ADDRESS RESS OF CURRENT LINE, CHAR 'C.'	C1E2	DB F	F	0528 0529		THIS CO		COME "MVI A.XX" FOR YOUR SPECIFIC PORTS GET SWITCHES
		0394	-	VDAD						0530				
,	144 34 08 C8	0395	•			E 'A', CHARACTER POSITION 'C'	CIEN		,	0531		MOV	B, A	SAVE IT
(C144 3A 08 C8 C147 4F C148 3A 09 C8 C148 6F	0395 0396 0397 0398	VDADD I	LDA		GET CHARACTER POSITION CC REEPS IT LINE POSITION	C1E4 C1E5 S	E6 0		0531 0532 0533		MOV ANI STA	B, A 3 DFLTS	SAVE IT MAKE IT A VALID PORT +1 SET DEFAULT OUTPUT PORT



This issue's Bug Squad focuses on the Sol PC board Revision D, the one you have. All the fixes described are aimed at worst case conditions, so hopefully you've never encountered the problems. But we do recommend making the changes now to forestall future headaches that might crop up if you use demanding peripherals such as discs. All the modifications described will be incorporated in the forthcoming Revision E board, so in the future we'll be designing on the assumption that all boards in the field have these fixes.

Now, you may wonder where we get the gall to blurt out that our product is not the ultimate in all respects. Quite simply, we have too much experience in product design to let ourselves get away with the attitude that goes, "We're perfect. Something must be wrong with you." So things can be better, and here's how.

1. Clock Width Fix

The bug: Currently the width of the phase 1 (01) clock pulse is 70 nanoseconds. If you want to bring it into spec with existing 8080 chips, you should increase it to 140 nanoseconds. (8080A or 9080A are OK at 70 nsec.)

The squasher: On the top (component) side of the board, cut the trace between jumpers D and E of (U90 and U91) of the clock generator. On the bottom (solder) side of the board, connect the jumper from pin E to the feedthrough which leads to pin 5 of U91.

2. Phantom Glitch Fix

The bug: Occasionally a Sol will power up with three "phantom" cycles instead of the necessary four, causing a "crash." These are the cycles which use the "four phase wonder" software in the monitor.

The squasher: Connect a jumper on the solder side of the board as shown in Figure B. It goes from pin 4 of U76 to the feedthrough immediately below pin 1 of U76.

3. Ground Noise Fix

The bug: The paths from the bus drivers to the bus ground are too long, producing occasional ground noise.

The Squasher: Shorten them by connecting jumpers on the solder side of the board as shown in Figure B. They go from pin 8 of IC's U33, U50, U68, and U81 to the ground feedthrough leading to C45.

27

4. Protect Fix

The bug: The protect line is floating, which allows noise pulses to set a memory board "protected" at the most inconvenient times.

The squasher: Connect a jumper wire on the solder side as shown in Figure B. It goes from the ground terminal of C11 to pin 70 of the 100-pin bus connector J11.

5. DMA/Interrupt Unscramble

This fix has probably been included in your kit or preassembled board, but better check the connections just to make sure.

The bug: PINT (pin 73), PHOLD (pin 74), and PINTE (pin 26) got scrambled at an early stage in development and weren't noticed until too late.

The squasher: On the component side of the board, cut the trace leading to pin 73 on J11; on the solder side, cut the trace leading to pin 1 of U45, and also the second trace to the right of U64. (Refer to Figure B). Now connect three jumpers: From pin 73 of J11 to pin 1 of U45. From pin 28 of J11 to the feedthrough indicated (the one that was isolated by the cut on the component side). From the feedthrough directly below pin 1 of U45 to the feedthrough to the right of pin 3 of U64.

6 MWRITE Fix

The bug: If you want to operate with DMA devices which write into memory, such as discs, you need to be able to egenerate the MWRITE pulse externally.

The squasher: You accomplish this by connecting the signals which generate MWRITE directly to the bus. On the solder side of the board, cut the trace which leads to pin 7 of U93. Now connect a jumper from the trace which has been isolated, to the feedthrough leading to pin 9 of U94. Now, still on the solder side, locate the feedthrough immediately below pin 1 of U92 and break the trace leading to it; do NOT break the trace leading to pin 1 of U92. Connect a jumper from that feedthrough to pin 13 of U107.

Further Remarks on D and E

The other major change between the D and E revision Sol boards involves reversing the order of the parallel input data lines as connected to the parallel connector J2. The schematic is correct for the D board, and the list of signals in the manual is correct for the E board. The change will simplify future connections to J2 by placing the POD lines adjacent to the PID lines; that way, you can create a bidirectional input/output bus with a simple jumpering scheme at the connector.

We're planning an adaptor connector to convert Rev. D J2 into Rev. E J2. It will have a 25-pin plug, a PC board which reverses the connections from pins 6 to 13, and a 25-pin socket connector. If you're developing a device which plugs into the Sol J2, reverse the order of pins 6 through 13 and use this adapter (PTC pt. 900011)

to ensure that your plug-in device will be compatible with E revision Sol's.

7. Current Loop Fix


The bug: R23 and R24 should 1. nected to +12 volts instead of +5 vol

The squasher: Break the large trace on the solder side of the board which lead to these two resistors. Still on the solder side, connect a jumper from the isolated end of R23 to the ± 12 volt feedthrough as shown. Be sure that you do not accidentall connect to the ± 12 volt feedthrough, which is slightly higher than the ± 12 volt one.

And a Bug in 5K(pre-Sol)

The bug: Our attention has been called to some problems with the integer function in BASIC-5—the non-Sol version.

The squasher: Page 32 of the 5K BASIC manual (Software #2) should be changed to read as follows:



Ninety-Ninety 'Rule of Project Schedules: The first ninety percent of the task takes ninety percent of the time and the last ten percent takes the other ninety percent.


Your ALS-8 Applications Notes are on the Way!


After a seemingly interminable delay, the first batch of Application notes are really and truly in the mail to all you ALS-Users' Group members. Once the material is in your hot little hands (in a very fancy binder, no less), you'll be better able to appreciate the power and versatility of your ALS-8, and you should have some very happy hours of computing.

If you haven't received your notes by the time you read this, please drop us a note right now, so we can track down what ever clerical or shipping errors crossed you up.


Our sincerest apologies for the d-lay.


Weinberg's Law: If builders built buildings the way programmers wrote programs then the first woodpecker that came along would destroy civilization.





Sol-PC (Rev. D)—Solder Side Figure B





MT 6-21-76	ROBERT M MARSH	9 -19-7

MWRITE Fix

The column	(continued from page 5)		C297 C2 A3 C2	0670 JWZ WCOM	
The column	C1F: 37 053		C29A 23	0671 * INX H	
The color of the	C PF CB 053 C1: _D F8 CO 053	6 LXI SP, SYSTP SET UP THE STACK FOR CALL 7 CALL PERSE (REG A ASSUMED TO COME BACK ZERO)	C29D C2 A3 C2	0674 CMP M 0675 JNZ NCOM	
COL 2017 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	C1F4 21 00 00 053 C1F7 FE 03 054	9 LXI W,O USE FOR CLEARING USER ADDRESSES 0 CPI 3 IS IT A USER PORT	C2A0 E1 C2A1 B7	0677 POP H 0678 ORA A	PORCE TO NON-ZERO FLAG
	C1FC 22 02 C8 054 C1FF 054	2 SHLD UOPRT MOCLEAR ADDR 3 STRTC EQU \$ OUTPUT PORT ALL SET		0680 ° 0681 °	
Column C	C200 1F 054 C201 1F 054	5 RAR . 6 RAR . MEXT 2 BITS ARE INPUT PORT	C2A4 13	0683 INX D	GO TO MEXT ENTRY
Column C	C204 32 04 C8 054	8 STA DFLTS THIS IS DEPAULT INPUT PORT	C2A7 C3 91 C2	0686 JMP PDCOM	
Column	C209 CA OF C2 055 C20C 22 00 C8 055	O JZ STRTD YESDO NOT CLEAR IT THEN SHLD UIPRT WOFORCE USER ADDRESS ZPRO		0688 * 0689 * SET UP TO PROCESS	AN IMPUT LINE
10 10 10 10 10 10 10 10	C20F 2A 04 C8 055 C212 22 06 C8 055	3 LHLD DFLTS PICK UP DEFAULT PORTS 4 SHLD IPORT PORCE PORTS TO DEFAULT	C2AA 21 64 CA C2AD 22 OE C8	0691 LXI M, INL 0692 SHLD INPTR	IN ASSUME NON-VDM INPUT ALSO RESET PTR FOR NOW
Company Comp	C215 AF 055 C216 D3 FA 055	6 XRA A 7 OUT TAPPT BE SURE TAPES ARE OFF	C2B3 B7 C2B4 C0	0694 ORA A 0695 RNZ .	IS IT THE VDM PORT WOHL ARE SET PROPERLY
The control late Processed Commands	055 056	9 •	C2B8 OE O1 (C2BA C3 48 C1	0697 MVI C,1 0698 JMP VDAD2	GET VDM ADDR PM POSITION ONE
Column C	056 056	2 • 3 •		0700 • COMMAND	
Column C	C218 31 FF CB 056	5 ° 6 COMND LXI SP,SYSTP SPT STACE POINTER		0703 0 0704 CONTAB EQU \$	
C234 C) 16 C) 50 C	C21E CD 27 C2 056	7 CALL PROMPT PUT PROMPT ON SCREEN 8 CALL GCLIO INIT TO GET COMMAND LINE	C2BD 44 55 C2BF AD C3	0705 ASC 'DU' 0706 DW DUMP	DUMP
THE NOTICE MANY ACCOUNTS THE SECRET	C224 C3 18 C2 057 057	O JMP COMNO OVER AND OVER	C2C3 14 C4 (C2C5 45 58'	0708 DW ENTER 0709 ASC EX	
Column	057 057	3 ° THIS ROUTINE READS A COMMAND LINE FROM THE SYSTEM	- C2C9 47 45 C2CB A1 C4	0711 ASC GE' 0712 DW TLOAD	
Color Colo	057 057	6 ° 7 ° C/R TERMINATES THE SEQUENCE ERASING ALL CHARS TO THE	C2CF E0 C4	0714 DW TSAVE	
Color Colo	057 058	9 L/F TERMINATES THE SEQUENCE 0 ESC RESETS TO COMMAND MODE.	C2D5 43 41	0717 ASC 'CA'	CAT
Column	C227 058	2 GCLIO EQU \$ HERE TO INIT POR GCLIM	C2D9 53 45 C2DB 76 C5	0719 ASC 'SE' 0720 DW SET	
CASE DISC CONTROL OF THE PROPERTY OF THE STATE OF THE PROPERTY	C22A 36 07 058 C22C 23 058	MVI M.7 MAKE SURE IT IS "RELL" TO KEEP FM DEL'ING TOO INX H NOW PT TO IMPUT RER	C2E1 00 C	0722 DW CUSET 0723 DB 0	
Color Colo	C230 3E 50 058 C232 058	7 MYI A,80 NUMBER OF CHARS IN LINE (MAX) 8 GCLI1 EQU \$ LOOP TO BLANK OUT LINE BER		0725 0 0726 DIS	PLAY DRIVER COMMAND TABLE
CATA CAN COLUMN CALL SLAW SECURITY SECURITY STATES AND LAWS SECURITY STATES AND COLUMN CALL	C234 23 059 C235 3D 059	O INX H WEXT CHAR 1 DCR A FOR THIS COUNT	0	0728 THIS TABLE DE	THE CHARACTER IS NOT IN THE TABLE IT
CATT OF CO	C239 CD 1F C0 059 C23C CA 39 C2 059	3 GCLIN CALL SINP READ INPUT DEVICE 4 JZ GCLIN		0731 •	
CAN FO CAN FOR	C23F F 7F 059 C' 1 0F C2 059	6 JZ STRTD IF EITHER MODE (OR CTL-#)	C2E3 F8 C0 C2E5 17	0733 DW PRRSE 0734 DB UP	
CASE	C24, CA 17 C1 059	B CPI CR IS IT CR? 9 JZ CLIN2 YESTERMINATE LINE HERE (CLR IF VDM)	C2E8 1A C2E9 EE CO	0736 DB DOWN 0737 DW PDOWN	
C250	C24D 2A OE C8 060	2 LHLD INPTR CRNT LINE PTR	C2EC 33 C1 C	0739 DW PLEFT 0740 DB RIGHT	
Comparison	C252 C2 5F C2 060 C255 06 5F 060	JNZ GCLI2 NOOK B.BACKS REPLACE IT	C2F1 0E 0 C2F2 08 C1 0	DT42 DB HOME DT43 DW PHOME	
C254 C25	C258 3E 07 060 C25A BE 060	7 MVI A, C'-NOH SEE IF A RELL 8 CMP M IS IT?	C2F5 6F C1 0 C2F7 0A 0	0745 DW PCR 0746 DB LP	
C240 23	C25E 47 061 C25F 061	O MOV B.A YESRING THE BELL THEN 1 GCLI2 EQU \$ STORE CHAR IN INPUT AREA	C2FA 5F 0	D748 DB BACKS	BACK SPACE
C264 CD 10 CD 0615 ONT CALL BOOK DITTO CALL BOOK DO CONTROL CO	C260 23 061	3 INX H WEXT CHAP	C2FE 81 C1 0	D751 DW PESC	
C261 C 3 S C 2	C261 22 DE C8 061	5 SHLD INPTR SAVE PTR	0	0753 • OUTPUT DEVICE TA	
Cold	C267 C3 39 C2 061 061	8 JMP GCLIN	C301 77 C0 0 C303 46 C0 0	0756 OTAB DW VDM01 0757 DW SEROT	SERIAL OUTPUT
C264 C	062 062	1 •	C307 6B C0 0	0759 DW ERROT	ERROR OR USER DRIVER HANDLER
Dec	C26A 062	5 COPRC BQU \$ PROCESS THIS COMMAND LINE	C309 35 C0 0	D762 TAB DW KREA1	REYBOARD INPUT
C275 CA 6C 33	C26D EB 062 C26E 21 00 C0 062	7 XCHG . DE=ADDR 8 LYI H.START PREP SO THAT HL WILL PT TO CUTER LATER	C30D 50 C0 0 C30F 64 C0 0	0765 DW PARIT 0766 DW ERRIT	PARALLEL INPUT
C286 E8	C272 CD 6C C3 063 C275 CA 6B C4 063	O CALL SCHR SCAN PAST BLANKS 1 JZ ERR1 NO COMMAND?	0	768 •	NHAND TABLE FOR SET COMMAND
C28C CA SC C	C279 11 BD C2 063	3 LXI D, COMTAB POINT TO COMMAND TARLE	C311 54 41 0	0770 ° 0771 SETAB ASC 'TA'	
C285 13	C27F CC 8E C2 063 C282 063	5 CZ FDCOU TRY CUSTOM ONLY IF NOT PRIMARY COMMAND 6 DISPO EQU \$ HERE TO EITHER DISPATCH OR DO ERROR	C315 53 3D 0 C317 95 C5 0	0773 ASC 'SE' 0774 DW DISPD	
0642 * THIS ROUTINE DISPTACHES TO THE ADDR AT CONTENTS OF RL. 0642 * THIS ROUTINE DISPTACHES TO THE ADDR AT CONTENTS OF RL. 0642 * THIS ROUTINE DISPTACHES TO THE ADDR AT CONTENTS OF RL. 0643 * H. LARE RESTORED FRIOR TO GOING TO ROUTINE. C257 AS C5 O 768 DW STITC C267 * O645 DISPT EOU \$ DISPATCH C259 58 C7 O768 DW STITC C268 C7 O646 HOV A, H. LOW BITE C259 58 C7 O768 DW STITC C268 C6 O646 HOV A, H. LOW DITE C259 58 C7 O768 DW STITC C268 C6 O646 HOV A, H. H. BITE C259 58 C7 O768 DW STITC C268 C6 O646 HOV A, H. H. BITE C259 58 C7 O768 DW STITC C268 C6 O646 HOV A, H. ARD LO, H. HOW COMPLETE C331 AR DD 768 DW STITC C268 C6 O647 THIS ROUTINE SEARCHES THROUGH A TABLE, FOIRTED TO O655 * O769 DW STITC C268 C7 D O655 * DF TO ROUTINE C334 DW STITC C268 C7 D O656 * O769 DW STITC C268 C7 D O657 THIS ROUTINE SEARCHES THROUGH A TABLE, FOIRTED TO O655 * DF TO ROUTINE C334 DW STITC C268 C268 C7 D O656 * DF TO ROUTINE C334 DW STITC C268 C268 C7 D O657 THIS ROUTINE SEARCHES THROUGH A TABLE, FOIRTED TO O657 * THIS ROUTINE SEARCHES THROUGH A TABLE, FOIRTED TO O655 * DF TO ROUTINE C334 DW STITC C268 C268 DW DY LALL ALWAYS PASS LIN "A" (PRIMARILY POR SET'S) C334 DW STITC C268 C34 C7 D O655 * DF TO TABLE CASE DW STITC C268 C35 D O659 * HEADER THE DATE OF THE 'HL' C268 C35 D O659 * DF TO	C285 13 063 C286 EB 063	8 INX D PT DE TO ADDR OF RTN 9 XCHC HI. ADDR OF ADDR OF RTN	C31B 99 C5 0 C31D 4F 3D 0	0776 DW SETIN 0777 ASC 'O='	
C287 C287 C287 C287 C287 C287 C287 C287 C288 C287 C287 C288 C287 C288 C287 C288 C287 C288 C287 C288 C287 C288 C288 C287 C288 C287 C288	064 064	1 ° 2 ° THIS ROUTINE DISPTACHES TO THE ADDR AT CONTENTS OF HL.	C321 43 49 0 C323 A1 C5 0	0779 ASC 'CI'	
C287 7E	064 064	3 * HL ARE RESTORED PRIOR TO GOING TO ROUTINE.	C327 A5 C5 0	D782 DW SETCO	
C28B 6F C28B 0650 DISPI EQU 8 HERE TO GO OFF TO HL DIRECTLY C333 NE 3D 0787 DS DISPI EQU 8 HERE TO GO OFF TO HL DIRECTLY C335 N 3 52 0789 DS C787 D650 DS DISPI EQU 8 HERE TO GO OFF TO HL DIRECTLY C335 N 3 52 0789 DS C787 D650 DS DISPI EQU 8 HERE TO GO OFF TO HL DIRECTLY C335 N 3 52 0789 DS C787 D650 DS DISPI EQU 8 HERE TO GO OFF TO HL DIRECTLY C335 N 3 52 0789 DS C787 D650 DS DISPI EQU 8 HERE TO GO DOTHER C787 DF TO ROUTINE C336 DS DISPI EQU 8 HERE TO GO DOTHER C787 DF TO ROUTINE C336 DS DISPI EQU 8 HERE TO SCAN CUSTOM THE SCAN ENDS D650 DS DISPI EQU 8 HERE TO SCAN CUSTOM TABLE C337 D6 3E 0798 DF DOTHER C338 DF DO	C287 7E 064 C288 23 064	6 MOV A,H LOW BYTE 7 INX H	C32B AD C5 0 C32D 54 59 0	0784 DW SETXQ 0785 ASC 'TY'	
C28C 7D	C28A 6F 064 C28B 065	9 MOV L,A AND LO, HL NOW COMPLETE 0 DISP1 EQU \$ HERE TO GO OFF TO HL DIRECTLY	C331 4E 3D 0 C333 B1 C5 0	0787 ASC 'N='	
0655 0 0656 0 0656 0 0793 0 0795 0 0 0795 0 0 0795 0 0 0795 0 0 0795 0 0 0795 0 0 0795 0 0 0795 0 0 0795 0 0 0795 0 0 0795 0 0 0795 0 0 0795 0 0 0795 0 0 0795 0 0 0 0795 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	C28C 7D 065 C28D C9 065	MOV A,L ALWAYS PASS L IN "A" (PRIMARILY FOR SET'S) RET . OFF TO ROUTINE	C337 B5 C5 0 C339 00 0	0790 DW SETCR	
0657 * TRIS ROUTINE SEARCRES TRADUCH A TABLE, POINTED TO 0658 * BY 10E', FOR A DOUBLE CHARACTER HATCH OF THE 'PL' 0659 * MEMORY CONTENT. IF WO MATCH IS POUND THE SCAN ENDS 0660 * WITH THE ZERO FLAG SET, ELSE MON-ZERO SET. 0661 * C28	065 065	5 0 6 0	,	9999 COPY CUTER	2 0F 3 ****
C28E 0660 WITH THE ZERO FLAG SET, ELSE HON-ZERO SET. C33A CD A2 C3 C797 PROMPT CALL CRLF C84F C33D 06 3E C	065	8 " BY 'DE', POR A DOUBLE CHARACTER MATCH OF THE 'HL'	0	0794 ° OUTPUT A CRL!	POLLOWED BY A PROMPT
C28E 11 3C C8	066 066	0 ° WITH THE ZERO FLAG SET, ELSE NON-ZERO SET. 1 °	C33A CD 42 C3 C	0797 PROMPT CALL CRLF 0798 NVI B, >	
C292 B7 0665 ORA A TEST FOR TABLE END C34% CD 19 CO 0802 CALL SOUT C293 C8 0666 RZ . NOT FOUND POST THAT AND RETURN C34% TO 6 DD 0803 MVI B.CR CARRIAGE RETURN C294 E5 0667 PUSH H SAVE START OF SCAN ADDRESS C349 CD 19 CD 080% CALL SOUT C295 BE 0668 CMP H TEST FIRST CHR C34C 3A 10 C8 0805 LDA NUCHT GET COUNT OF NULLS TO OUTPUT C296 13 0669 INX D C34C 3A 10 C8 0806 MOV C, A SAVE COUNT IR C	C28E 11 3C C8 066 C291 1A 066	3 LXI D, CUTAB PT TO CUSTOM RTW TRL	C342 06 DA	0800 * 0801 CRLF MVI B,LF	
C295 BE 0668 CMP M TEST FIRST CHR C34C 3A 10 C8 0805 LDA WUCHT GET COUNT OF NULLS TO OUTPUT C296 13 0669 INX D C34F AF 0806 MOV C.A SAVE COUNT IN C	C293 C8 066 C294 E5 066	6 RZ . NOT FOUND POST THAT AND RETURN 7 PUSH H SAVE START OF SCAN ADDRESS	C344 CD 19 CO 0 C347 06 OD 0	0802 CALL SOUT 0803 MVI B,CR	CARRIAGE RETURN
	C296 13 066	6 CMP M TEST FIRST CHR	C34C 3A 10 C8 0	0805 LDA WUCHT	

Page 10

350 DD 351 F8 352 AF 353 CF - C4 356 1 23

36C 0E 0A 36E 1A 36F FE 20 371 C0 373 0D 374 C6 375 C3 6E C3

378 CD 59 C3 378 CA 68 C4

37E 21 00 00 361 1A 382 FE 20 384 C8 385 FE 2F 387 C8 388 FE 3A 388 C8

38B 29 38C 29 38C 29 38F 29 38F 29 38F CD 9B C3 395 65 396 65 397 13 398 C3 81 C3

39B 39D 38C D 38C D 382 F

C3A5 3A5 CD 59 C3 3A8 C8 3A9 CD 7E C3 3AC C9

C3AD 3AD CD 78 C3 3BO E5 3B1 CD A5 C3 3B4 D1 3B5 EB

3B6 CD 42 C3 3B9 CD D9 C3 3BC CD F7 C3 3BF OE +10

3C1 TE
3C2 C5
3C3 CD DE C3
3C6 7C
3C7 BA
3C8 DA DO C3
3C8 BB
3CD D2 18 C2

3D0 3D1 . 3D2 C 3D3 C 3D6 C

3D9 7C 3DA CD FC C3 3DD 7D

```
OSNS MBOUT CALL MEOUT
ONNO, CALL SINP SEE IF WE SWD ESCAPE PM DUMP
OSNS JZ
OSNS MIN TPH
MAKE SUME ITS CLEAR OF PAPITY
OSNS JZ
OSSS WILP1 CALL SINP ON SPACE, WAIT FOR ANY OTHER CHAP
OSSS WILP1 CALL SINP ON SPACE, WAIT FOR ANY OTHER CHAP
OSSS JZ
WILP1 CALL SINP ON SPACE, WAIT FOR ANY OTHER CHAP
OSSS JWT WILD BOUT MOUT TO SOUT ON SPACE, WAIT FOR ANY OTHER CHAP
OSSS JWT SOUT OF WILD HAVE SUME ITS CLORE OF THE CHAP
OSSS MEC
OSS
  OBO7 NULOT DCR C
OBO8 MH C COUNTED DOWN PAST ZFRO (MAY COUNT IS Y'
OBO9 XFA A HERE IS THE NULL
OB10 CALL OUTH OUTPUT IT
OB11 JMP NULOT LOOP FOR NUMBER OF NULLS
OB13 * OF C C C COUNTED DOWN PAST ZFRO (MAY COUNT IS Y'
OB14 * SCAN OVER UP TO 12 CHARACTERS LOOKING FOR A RLANK
OB15 * OF C C C COUNTED DOWN DEFT STORY
OB16 SRLY MYI C.12 MAXIMUM COMMAND STRING
DC816 CPI RLANK
OB16 JZ SCHR GOT A BLANK NOW SCAN PAST IT
OB26 INX D
OB21 CPI E A EOUAL MILL ALSO STOP US (AT NFYT CHAR
OB22 JZ SCHR FOUND, DE PT TO NEXT CHAR
OB23 DCR C NOMORE THAN TWELVE
OB24 JNZ SBLY:
OB25 * RET GO BACK MITH ZERO FLAG SET
OB26 * SCAN PAST UP TO 10 BLANK POSITIONS LOOKING FOR
OB27 * OB28 * SCAN PAST UP TO 10 BLANK POSITIONS LOOKING FOR
OB29 * A NON BLANK CHARACTER.
OB30 * OB33 SCHR MYI C,10 SCAN TO FIRST NON BLANK CHP WITPIN 10
OB35 SCHR MYI C,10 SCAN TO FIRST NON BLANK CHP WITPIN 10
OB36 SCHR MYZ ME'RE PAST THEM
DB37 CPI SPACE
OB38 NNZ MET SCAN ADDRESS
OB39 * THIS ROUTINE SCANS OVER CHARACTERS, PAST BLANKS AND
OB41 * CONVERTS THE FOLLOWING ADDRESS TO HEX. ERRORS RETURN TO
OB42 THE ERROR HANDLEN.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              C3DE CD FC C3
C3E1 CD IF C0
C3E4 CA F7 C3E7 C6 F7 C3E9 CA 18 C2
C3EC FE C0
C3EC C2 F7 C3
C3E1 CD IF C0
C3F4 CA F1 C3
C3F7 C6 C0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     SEE IF WE SHD ESCAPE PM DUMP
MO-ADD THE SPACE THEN
MAKE SURE ITS CLEAR OF PARITY
EITHER MODE (OR CTL-0)
IS IT SPACE .
MO--IONORE THE CHAR
ON SPACE, MAIT FOR ANY OTHER CHAP
JUST LOOP AFTER A SPACE UNTIL ANY FFY PRESSED
                                                                                                                                                                                                                     C. COUNTED DOWN PAST ZFRO (MAY COUNT IS Y'7F')
A HERE IS THE NULL
OUTHUL IT
NULD LOOP FOR NUMBER OF NULLS
                                                                                                                                                                                                                C.12 MAXIMUM COMMAND STRING
D
RLANK
SCHR GOT A BLANK NOW SCAN PAST IT
D
T
A EQUAL WILL ALSO STOP US (AT NEYT CHAR)
FOUND, DE PT TO NEXT CHAR
MO MORE THAN TWELVE
GO BACK WITH ZERO FLAG SET
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   C3FC 4F
C3FD 0F
C3FE 0F
C3FF 0F
C400 0F
C401 CD 05 C4
C404 79
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   C405 E6 OF
C407 C6 30
C409 FE 3A
C408 DA 10 C4
C40E C6 O7
C410 47
C411 C3 19 C0
0840 * THIS ROUTINE SCANS OVER CHARACTERS, PAST BLANKS AND
0841 * COMVERTS THE FOLLOWING ADDRESS TO HEX. ERRORS RETURN TO
0842 * THE REROR HANDLER.
0843 * COMPANDED THE FOLLOWING ADDRESS TO HEX. ERRORS RETURN TO
0842 * THE REROR HANDLER.
0843 * JZ ERRI
0846 * A STANDARD MEX CONVERSION, THE SCAN STOPS WHEN AN ASTIT
0848 * JZ ERRI
0848 * A STANDARD MEX CONVERSION, THE SCAN STOPS WHEN AN ASTIT
0848 * JZ STANDARD MEX CONVERSION, THE SCAN STOPS WHEN AN ASTIT
0849 * CHARACTER ON THE SCREEN WITH A QUESTION HARK.
0850 * CHARACTER ON THE SCREEN WITH A QUESTION HARK.
0851 * CR27 CR26 EB
0852 SHEX LXI #,0 CLEAR H & L CA26 EB
0853 SHEY LDAX D GET CHARACTER
0854 CPI 20H IS IT A SPACE?
0855 CPI 20H IS IT A SPACE?
0856 CPI 7/ CA26 CB
0855 CPI 7/ CA26 CB
0856 CPI 7/ CA26 CB
0856 CPI 7/ CA26 CB
0857 RZ
0850 CPI 1 * CA27 CP CA26 CB
0850 MCONV DAD H HARK ROOM FOR THE NEW ONE CA37 CP CA38 CD TE C3
0850 CB
0860 DAD H CA37 CB
0866 CALL HCOVI DO THE CONVERSION CA38 CD TE C3
0866 DAD H CA37 CB
0866 CPI 10 D THE CONVERSION CA38 CB
0867 ADD L CA37 CB
0868 PSCAN CB
087 CPI 10 D THE CONVERSION CA38 CB
087 CA27 CB
087 CPI 10 D
0880 CP
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              C,3 HO MORE THAN THREE SPACES BETWEEN VALUES SCHR1 SCAN TO WEXT VALUE ENLOP LAST ENTRY FOUND START NEW LINE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      CPI
JZ
CALL
CPI
JZ
MOV
POP
MOV
INX
PUSH
JMP
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              ':' ADDRESS TERMINATOR?
EMILO3 GO PROCESS IF SO
A,L GET LOW PART AS COMPERS
R GET MEMORI ADDRESS
H,A PUT IN THE VALUE
H
BACK GOES THE ADDRESS
ENLO1 CONTINUE THE SCAM
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              1001 JZ EMIO3 GO PROCESS IF SO
1003 POP B GET LOW PART AS COMPETED
1004 POP B GET HEMORY ADDRESS
1005 INX H
1006 PUSH H BACK GOES THE ADDRESS
1007 JMP ENLO1 CONTINUE THE SCAN
1008 POP B GET HEMORY ADDRESS
1009 EMIO3 XTHL
1010 INX D MOVE SCAN PAST TERMINATOR
1011 JMP ENLO1
1011 JMP ENLO1
1011 JMP ENLO1
1012 PELECUTE COMMAND
1015 THIS ROUTINE GETS THE POLLOWING PARAMETER AND DOES A
1016 PROGRAM JUMP TO THE LOCATION GIVEN RY IT. IF PROPER
1018 STACK OPERATIONS ARE USED WITHIN THE EXTERNAL PROCRAM
1019 IT CAN DO A STANDARD RET UNN TO THE CUTER COMMAND MODE.
1020 POST OF THE STANDARD RET ON STACK
1021 PUSH H SAVE ON STACK
1022 EXECT EQU S HERE TO GO TO HL
1023 EXECT EQU S HERE TO GO TO HL
1024 PUSH H SAVE ON STACK
1025 LXI H,START LET USER KNOW WHERE WE RE
1026 PUSH H SAVE ON STACK
1027 PROM THE IMPUT STRING. IF THE TERMINATOR IS A
1033 SLASH (//) THEN THE CHARACTER FOLLOWING IS TAFFN
1035 PROM THE IMPUT STRING. IF THE TERMINATOR IS A
1036 PROM THE IMPUT STRING. IF THE TERMINATOR IS A
1037 NAMEO EQU S ENTER HERE TO PUT NAME
1038 LXI H,THEAD PT WHERE TO PUT NAME
1039 NAME CALL SBLK SCAN OVER TO FIRST CHRS
1030 NAMEO EQU S ENTER HERE TO SET HL TO THEAD
1031 FILL
1035 CPI 'NO UNIT DELIMITER
1036 JX WILL HAME IS OK, FALL THRU TO 'PPRI' IP NOT
1036 PROM THE IMPUT STRING IS TAFFN
1037 NAMEO EQU S ENTER HERE TO SET HL TO THEAD
1038 LXI H,THEAD PT WHERE TO PUT NAME
1039 NAME CALL SBLK SCAN OVER TO FIRST CHRS
1041 JX WILL
1055 LXI H, MAND I BE SON, FALL THRU TO 'PPRI' IP NOT
1050 DER B
1051 JWZ MAND I DAY
1051 JWZ MAND I DELIMITER
1055 ERRI KORG
1056 ERRI KORG
1057 LDA OPORT SEE IF VIA VON DRIVER
1058 ERRI KORG
1059 CUTER ERROR NAMBULER
1059 CUTER ERROR NAMBULER
1059 CUTER ERROR NAMBULER
1059 CUTER ERROR NAMBULER
1050 COMPA
1050 COMPA
1050 COMPA
1050 COMPA
1051 JWZ MAND I PRE 2222
  THIS MOUTINE DUMPS CHARACTERS FROM MEMORY TO THE

0896 | 0896 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0897 | 0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        C451
C451 21 1C C8
C454 CD 59 C3
C457 06 06
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C459 1A
C45A FE 20
C45C CA 80 CA
C45F FE 2F
C461 CA 80 CA
C465 13
C466 23
C466 23
C466 C2 59 C4
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   NAME! NAME IS OR, FALL THRU TO "PPR!" IP NOT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           C46B EB
C46C 36 3F
C46E 3A D7 C8
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     C471 B7
C472 CA 18 C2
C475 CD 42 C3
C478 O6 3F
C47A CD 19 C0
C47D C3 18 C2
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        1060 • NAMI

1069 • NAMI

1070 NFIL

1071

1072

1073

1074 • 1075

1076

1077

1078

1079

1080

1080

1081 • EFLT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      MVI M,O PUT IN AT LEAST ONE ZERO
INI M
DCR B
JNZ MFIL LOOP UNTIL B IS ZERO
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        C480 36 00
C482 23
C483 05
C484 C2 80 C4
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   A, 1
DEFLT
D
SCHR
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        C487 PE 2F
C489 3E 01
C488 C2 94 C4
C48E 13
C48F CD 6C C3
C492 D6 30
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         CPI
MVI
JNZ
INX
CALL
SUI
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          IS THERE A UNIT SPECIFICATION? PRETEND NOT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             MOVE PAST THE TERMINATOR
GO GET IT
REMOVE ASCII BIAS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     CHART TO INTERNAL BIT POR TAPE CONTROL
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                1082 DEFLT EOU
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                C494
```

```
1218 * 1219 * 1220 NLOOP HOY A, M GET CHARACTER 1220 NLOOP HOY A, M GET CHARACTER 1220 NLOOP HOY A, M GET CHARACTER 1221 OPA A SPACE OTHERWISE 1222 WIL A SPACE OTHERWISE 1223 WIL A CHAP IS OK TO SEE 1224 CHRLI EOU $ CHAP IS OK TO SEE 1226 JWZ BLOOP 1226 JWZ BLOOP 1227 DER 1230 * 1231 * 1232 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1233 * 1234 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 1235 * 12
C494 E6 01
C496 3E 80
C498 C2 9C C4
C4r
                                                                                                                                                                                                     1 JUST BIT ZERO
A.TAPE1 ASSUME TAPE ONE
STUNT IF NON ZERO, IT IS ONE
ELSE MAKE IT TAPE TWO
FNUMF SET IT IN
                                                                                                          C566 7E
C567 B7
C568 C2 6D C5
C56B 3E 20
C56D C5 10 C4
C570 23
C571 15
C572 C2 66 C5
C575 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        A,M GET CHARACTER
A
CHRLI
IF IT ISN'T A ZERO
A,' SPACE OTHERNISE
S CHAR IS OK TO SEND
OUTH OUTPUT IT PROM A REC
                                                                                                                                                     THIS ROUTINE PROCESSES THE REQ AND GET COMMANDS
                                                                                                                                                                                                     3EH THIS BEGINS "NYI" OF THE "YRA" FOLLOWING A A-O TLOAD, A-AF (#0) THEN IND PSW SAVE FLAG TO SAY WHETHER LOAD OR YFO H, DHEAD PLACE DUMMY ROR HERE FOR COMPARES NAME SET IN NAME AND UNIT H, O ASUME LOAD ADDR NOT GIVEN PSCAN HL EITHER ±0, OR OVERRIDE LOAD ADDR
    C4A0 3E
C4A1 AF
C4A2 F5
C4A3 21 2C C8
C4A6 CD 54 C4
C4A9 21 00 00
C4AC CD A5 C3
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          THIS ROUTINE GETS THE ASSOCIATED PARAMETER AND DISPATCHES TO THE PROPER ROUTINE FOR SETTING MEMORY VALUES.
                                                                                                                                                                                                    PUT ADDRESS IN DE
M.DMEAD PT TO NORMAL MDR
A,M GET IST CHAR OF NAME
A,M GET IST CHAR OF NAME
TLOAS TERE A MAME?
TLOAS TES-LOOK FOR IT
M.THEAD PT TO SAME HOR TO LOAD METT FILE
M. SAYE FTR TO MEICH HOR TO USE
ALOAD GET UNIT AND SPEED
M. RESTORE FTR TO PROPER HOR TO USE
TAPER READ IN THE TAPE
TAPE TAPE ERROR?
   C4AF EB
C4B0 21 2C C8
C4B0 37 E
C4B4 B7
C4B4 B7
C4B5 C2 BB C4
C4B6 21 1C C8
C4B6 E1
C4B6 CD 44 C5
C4B6 CD 46 C5
C4C0 CD C7 C6
C4C3 DA 10 C5
                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C576 CD 59 C3
C579 CA 6B C4
C57C D5
C57D CD 78 C3
C580 E3
C581 11 11 C3
C584 CD 91 C2
C587 C3 82 C2
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        SBLT SCAN TO SECONDARY COMMAND
ERRI MUST HAVE AT LEAST SOMETHING!
D SAVE SCAN ADDRESS
SCONV CONVERT FOLLOWING VALUE
N.ELSAVED SCAN ADDREAM DISTACT-VALUE
D.SETAR SECONDARY COMMAND TARLE
PDCOM TRY TO LOCATE IT
DISPO OFF TO IT OR ERROR IF NOT IN TRL
   CACC CD 4C C5
C4C9 F1
C4C4 E7
C4C8 C6
C4CC 3A 22 C8
C4CC 3A 22 C8
C4CF B7
C4DC FA 10 C5
C4D3 3A 21 C8
C4D5 B7
C4D7 C2 10 C5
C4D8 C7 C8
C4D0 C3 4C C4
                                                                                                                                                                                                     NAOUT PUT OUT THE HEADER PARAMETERS
PSW RESTORE PLAG SAYING WHETHER IT WAS LOAD OR FRO
                                                                                                                                                                                                  AUTO XEQ NOT WANTED
MTYPE CHECK TYPE
A SET FLAGS
TAERR TYPE IS NON XEQ
THEAD+5
                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C58A
C58A B7
C58B CA 90 C5
C58E 3E 20
C590 32 DD C8
C593 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      GET CONVERTED VALUE
IS IT ZERO?
YES--THAT IS A PROPER SPEED
NO--SET SPEED PROPERLY THEN
                                                                                                                                                                                                    TARRY THE BYTE MUST BE ZERO FOR AUTO XEO XEOAD GET THE TAPE ADDRESS EXEC1 AND GO OFF TO IT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                     C594
C594
78
C595
C595
C595 32 0B C8
C598 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         # TOM ESCAPE SEQUENCE COMES HE
A,B GET CHAR FOR FOLLOWING DISPO
SET DISPLAY SPEED
                                                                                                                                                       THIS ROUTINE IS USED TO SAVE PROGRAMS AND DATA ON THE CASSETTE UNIT.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         S SET AN IMPUT PSUEDO PORTIPORT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C599
C599 32 06 C8
  SAVE MEMORY IMAGE TO TAPE

OET NAME AND UNIT
OET START ADDRESS
SAVE START ADDRESS
SAVE START ADDR FOR SIZE COMPUTATION LATER
GET END ADDR (REOUIRED)
HLESTART ADDR MOW, STACK-END ADDR
STACK "START FOLLOWED BY PND
SEE IF RETRIEVE FROM ANDR
EITHER ACTUAL START, OR OVERRIDE INTO HOR
HLESTART ADDR
DE-FND ADDR
PUT START ADDR
DET START BACK ONTO STACK
SIZE=END-START+1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              S WAMED
SCONV
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         $ SET AN OUTPUT PSUEDO PORT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C59D
C59D 32 07 C8
C5AO C9
                                                                                                                                                                                                     SCONV
                                                                                                                                                                                                     H
PSCAN
LOADR
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        S DEFINE USER INPUT RTH ADDR
                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C5A1
C5A1 22 DO C8
C5A4 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      SET I EQU
SHLD
RET
                                                                                                                                                                                                     D
H
A,E
L
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         $ DEFINE USER OUTPUT RTW ADDR
                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C5A5
C5A5 22 02 C8
C5A8 C9
                                                                                                                                                                                                    L.A
0 H
1.A
                                                                                                                                                                                                                                      THIS EQUALS A "SRB H"
THIS IS NEEDED
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         S SET TAPE HOR TYPE HTYPE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C5A9
C5A9 32 22 C8
C5AC C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      SETTY EQU
STA
RET
                                                                                                                                                                                                     BLOCK STORE THE SIZE
H SAVE AS THE BLOCK SIZE
                                                                                                          1155 PUSH
1157 CALL
1158 LX!
1159 CALL
1159 CALL
1160 POP
1161 POP
1161 POP
1162 LXI
1164 OUTPUT EI
1165 CALL
1167 HVI
1169 CALL
1171 JMP
1172 ERRH ASC
                                                                                                                                                                                                  ALOAD CET UNIT AND SPEED
H,THEAD PT TO MEADER TO WRITE
MHEAD TURN TAPE ON, THEN WRITE HEADER
D CET BACK THE SIZE
H AND GET RACK THE ACTUAL START ADDR
WTAP1 WRITE THE BLK (M/EXTRA PUSH)
   C502 CD 44 C5
C505 21 1C C8
C508 CD AB C7
C508 D1
C50C E1
C50C E1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         $ SET TAPE EXECUTE ADDDR FOR HDR
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   EQU
SHLD
RET
                                                                                                                                                                                                                                                                                                                                                                                                                                                                        C5AD
C5AD 22 27 C8
C5BO C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               7 SETNU EQU
STA
                                                                                                                                                                                                                                                                                                                                                                                                                                                                        C5B1 .
C5B1 32 10 C8
C5B4 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         # HERE TO SET NUMBER OF NULLS NUCHT THIS IS IT
                                                                                                                                                OUTPUT ERROR AND HEADER
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  1299
1300
1301
   C510 CD 42 C3
C513 16 06
C515 21 21 C5
C518 CD 66 C5
C51B CD 4C C5
C51E C3 15 C2
                                                                                                                                                                                              CRLF
D,6
H,ERRM
NLOOP OUTPUT ERROR
NAOUT THEN THE HEADER
COMN1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                C5B5
C5B5 32 11 C8
C5B8 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             TRY TO SET/CLEAR CUSTOM ROUTINE ADDR
MAMED GET A MAME (S/R 2 CHARS OR MORE)
H, COMNUM PT HERE IN CASE ADDR MOT GIVEN
PSCAN GET OFTIONAL OFFRAMO IF ANY
H, THEAD PT TO MAN IS
FOOD SET IN MAME IS KNOWN IN CUST TABLE
CUSSE2 NO--PROCEED TO KNOW IT
D DE PT TO 1ST CHAR OF MAME IN TEL
M, O (HL CAME BACK PT'ING TO THEAD) CLR THIS NAME
A, M GET 1ST CHAR OF MAME
D PUT MAME INTO TABLE
H A.M GET 1ST CHAR OF MAME
D PUT MAME INTO TABLE
H A.M GET 1ST CHAR OF MAME
A.M GET 1ST CHAR OF MAME
D PUT MAME INTO TABLE
H A.M GET 1ST CHAR OF MAME
A.M GET 1ST CHAR OF MAME
D PUT MAME INTO TABLE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         $ SET CRC TO BE WORMAL, OF IGNORE CRC ERRORS IGNOR FF=IGNORE CRC ERRORS, ELSE=NORMAL
                                                                                                                                                                                                                                                                                                                                                                                                                                                                      EQU
CALL
LXI
CALL
PUSH
LXI
CALL
JZ
DCX
   C521 45 52 52 4F
52 20
                                                                                                                                                                                                  PERROR !
                                                                                                            1174 •
1175 •
1176 •
1177 •
1178 •
1179 •
1180 •
1181 •
                                                                                                                                                 THIS ROUTINE READS HEADERS FROM THE TAPE AND OUTPUTS THEM TO THE OUTPUT DEVICE. IT CONTINUES UNTIL THE MODE KEY IS DEPRESSED.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      MVI
EQU
MOV
STAX
INX
MOV
STAX
INX
POP
XCHG
MOV
RET
                                                                                                           1182 | LIST | EQU | 1182 | LIST | CALL | 1185 | CALL | 1186 | CALL | 1187 | CALL | 1189 | CALL | 1190 | LIST | CALL | 1191 | JC | JP | 1192 | JW2 | JW2 | JW2 | JW2 | JW3 | JW4 | JW
   C527
C527 CD 51 C4
C52A CD 42 C3
                                                                                                                                                                                                  $ PRODUCE A LIST OF FILES ON A TAPF NAMEO GET UNIT IP ANY (NAME IS IGNORED) CRLF START ON A PRESH LINE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          GET 2ND CHAR OF NAME
NAME IS NOW POSTED
PI TO 1ST BITE OF ADDR
RESTORE SAVED RTN ADDR
DE=RTN ADDR, HL=THIS CU ENTRY
LO BITE
                                                                                                                                LLIST CALL
MVI
CALL
LIST1 CALL
JC
JNZ
CALL
JMP
 C52D CD 44 C5
C530 06 01
C532 CD EB C7
C535 CD 1F C7
C538 DA 15 C2
C53B C2 35 C5
C53E CD 4C C5
C541 C3 2D C5
                                                                                                                                                                                                  ALOAD
                                                                                                                                                                                                  ALOAD
B,1
TON TURN ON THE TAPE
RHEAD
COMNI TRUN OPF THE TAPE UNIT
LISTI
MAOUT OUTPUT THE READER
LLIST
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         M,E
H
M,D
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           AND HI BYTE
                                                                                                                                                  THIS ROUTINE GETS THE CASSETT UNIT NUMBER AND SPEED TO REGISTER "A" FOR THE TAPE CALLS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 3 OF 3 .....
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     COPY CUTER3/1
                                                                                                          1196 SPEED 1
1200 ALOAD LXI
1201 LDA
1202 ORA
1203 RET
1204 THEAD T
1205 THEAD T
1206 THEAD T
1207 LXI
1207 LXI
1210 CALL
1211 CALL
1212 CALL
1213 LHLE
1214 CALL
1215 LHLE
1215 LHLE
1216 CALL
1217 JMP
                                                                                                                                                                                                H.PHUMF POINT TO THE UNIT SPECIFICATION TSPD GET THE TAPE SPEED M PUT THEM TOGETHER AND GO BACK
   C544 21 54 C8
C547 3A OD C8
C54A B6
C54B C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      THE FOLLOWING ROUTINES PROVIDE "RYTE RY RYTE" ACCESS TO THE CASSETTE TAPES ON EITHER A READ OR WRITE BASIS.
                                                                                                                                                   THIS ROUTINE OUTPUTS THE NAME AND PARAMETERS OF THEAD TO THE OUTPUT DEVICE.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      THE TAPE IS READ ONE BLOCK AT A TIME AND INDIVIDUAL TRANSFERS OF DATA MANDLED BY MANAGING A RUFFEP AREA
  C54
C54E 21
C551 CD
C554 CD
C557 2A
C55A CD
C55D 2A
C560 CD
C563 C3
                                       J8
1B C8
66 C5
F7 C3
25 C8
D9 C3
23 C8
D9 C3
42 C3
                                                                                                                                                                 MVI
LXI
CALL
CALL
LHLD
CALL
LHLD
                                                                                                                                                                                                  D,8
H,THEAD-1 POINT TO THE HEADER
ROUT ANOTHER BLANK
LOAD MOUT HE LOAD ADDRESS
ADOUT 1T OUT
BLOCK AND THE RLOCK 517F
ADOUT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        THE BUFFER AREA IS CONTROLLED BY A FILE CONTROL BLOCK (FCB) WHOSE STRUCTURE IS:
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          7 RYTES FOR EACH OF THE TWO FILES STRUCTURED AS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            FOLLOWS:
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     1 BYTE - ACCESS CONTROL
```

:5DC E5 :5DD CD 2F C6 :5E0 C2 F6 C5 :5E3 36 01 :5E5 23 :5E6 77 :5E7 23 :5E8 77

35F1 C1 35F2 B7 35F3 C3 B2 C6

05F6 E1 05F7 D1 05F8 AF 05F9 37 05FA C9

C5FB 3D C5FC 37 C5FD D1 C5FE C9

C5FF CL C602 C8 C603 B7 C604 3C C605 36 00 C607 C8

C608 23 C609 23 C60A 7E C60B 7E C60C CD BB C6 C60F C5 C61C 21 07 00 C613 09 C614 B7 C615 CA 27 C6

C618 E5 C619 77 C61A 23 C61B 36 00 C61D 23 C61F 73 C61F 73 C61F 23 C627 72 C621 60 C622 69 C623 CD 78 C7

C627 AF C628 77 -C629 23 C62A 77 C62B E1 C62C C3 78 C7

```
1 BITE - READ COUNTER
1 BITE - BUFFER POSITION POINTER
2 BITE - CONTROL HEADER ADDRESS
2 BITE - BUFFER LOCATION ADDRESS
                                                          THIS ROUTINE "OPENS" THE CASSETTE UNIT FOR ACCESS
                                                                                                                                                                                                                                                                                                                                                                                                                                                              READ -TAPE BYTE ROUTINE
                                                                                                                                                                                                                                                                                                                                                                                                                                                             ENTRY: - A - HAS FILE NUMBER

EXIT: MORHAL - A - MAS BITE

ERROR

CARRY SET - IF FILE NOT OPEN OR

PREVIOUS OPERATIONS WERE WRITE

CARRY & MINUS - END OF FILE ENCOUNTERED
                                    ON ENTRY: A - HAS THE TAPE UNIT NUMBER (1 OR 2)
HL - HAS USER SUPPLIED HEADER FOR TAPE FILE
                                   MORMAL RETURN:
                                                                                                              ALL REGISTERS ARE ALTERED BLOCK IS READY FOR ACCESS
                                    ERROR RETURN: CARRY BIT IS SET
                                    ERRORS: BLOCK ALREADY OPEN
                                                                                                                                                                                                                                                                                                                                                                                                                                    RTBYT CALL LPCR LOCATE THE PILE CONTROL BLOCK
RZ PILE NOT OPEN
INF AT TEST IF FF
INT HEREO
RNUI M.-1 SETITAS READ (IN CASE IT WAS JUST OPPNED)
NOV A.M. GFT READ COUNT
PUSH H SAVE COUNT ADDRESS
INV H
CALL PLOAD
GET THE OTHER PARAMETERS
POP H
ORA A
JUZ GTBYT IF NOT EMPTY GO GET BYTE
                                                                                                                                                                                                                                                                                                                  C642 CD 2F C6
C645 C8
C647 FA F8 C5
C644 36 FF
C644 25
C642 E5
C647 E5
C647 E7
C653 E1
C653 E7
C655 C2 71 C6
 1373 • BOPEN PUSH
1375 • CALL
1377 • WZ
1378 • WZ
1377 • WZ
1378 • WY
1379 • INX
1380 • MOV
1381 • MOV
1381 • LDA
1385 • ALLOCATE
1385 • ADD
1389 • MOV
1391 • UBUF • POP
1399 • GENERAL
1395 • GENERAL
1395 • GENERAL
1396 • TERE1 POP
1399 • TERE POP
1399 
                                                                                                               SAVE HEADER ADDRESS
GET ADDRESS OF FILE CONTROL
FILE WAS ALREADY OPEN
HOW IT IS
POINT TO READ COUNT
ZERO
POINT TO BUFFER CURSOR
PUT IN THE ZERO COUNT
                                                                                 H
LPCB
TERE2
M, 1
H
M, A
H
M, A
                                                                                  D, FBUF 1 POINT TO BUPFER AREA PNUMF GET WHICH ONE WE ARE GOING TO USF
                                                                                   D.A 256 BIT ADD
                                                                                                                                                                                                                                                                                                                C658 D5
C659 E5
C658 CD A2 C6
C65B CD A2 C6
C65E CD C4 C6
C661 DA F6 C5
C664 E1
C665 TB
C665 TB
C666 B2
C667 CA FB C5
C668 C36 O0
C66E 28
C668 C36 O0
C665 TB
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  BUFFER POINTER
TABLE ADDRESS
                                                                                  B MEADER ADDRESS
A CLEAR CARRY AND RETURN AFTER STORING PARAMS
PSTOR STORE THE VALUES
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   H
PHEAD PREPARE THE HEADER FOR READ
RFBLK READ IN THE BLOCK
TERE2 ERROR POP OFF STACK BEFORE RETURN
                                            GENERAL ERROR RETURN POINTS FOR STACK CONTROL
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   A,E
DEOFER
M,E
H,O
H,O
A,E
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  LOW BYTE OF COUNT (MILL BE ZERO IF 256)
SEE IF BOTH ARE ZERO
BYTE COUNT MAS ZERO...EMD OF FILE
NEW COUNT ( ZERO IS 256 AT THIS POINT)
BUFFER LOCATION POINTER
                                                                                                                 CLEAR ALL FLAGS
SET ERROR
                     EOFER DCR
STC
POP
RET
                                                                                                                 SET MINUS FLAGS'
AND CARRY
CLEAR THE STACK
THE FLAGS TELL ALL
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    COUNT TO A
GET BACK BUFFER ADDRESS
                                                                                                                                                                                                                                                                                                                                                                                                                                                   THIS ROUTINE GETS ONE BYTE FROM THE BUFFER AND RETURNS IT IN REGISTER "A". IF THE END OF THE BUFFER IS REACHED IT MOVES THE POINTER TO THE BEGINNING OF THE BUFFER FOR THE MEXT LOAD.
                                      THIS ROUTINE CLOSES THE FILE RUFFER TO ALLOW ACCESS FOR A DIFFERENT CASSETTE OR PROGRAM. IF THE FILE OPPRATIONS WERE "WHITE" THEN THE LAST BLOCK IS WRITTED OUT AND AN "END OF FILE" WHITTEN TO THE TAPF. IF THE OPERATIONS WERE "READS" THEN THE FILE IS JUST MADE READY FOR NEW USE.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    A
H, A
H
A, M
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   BUMP THE COUNT
RESTORE IT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   GET BUFFER POSITION BUMP IT
                                  ON ENTRY: A - HAS WHICH UNIT (1 OR 2)
                                                                                                                                                                                                                                                                                                                  C676 83
C677 5F
C678 D2 7C C6
C678 14
C67C 1A
C67D B7
C67E C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 E.A.
RT1
D
                                    ERROR RETURNS: FILE WASN'T OPEN
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   DE NOW POINT TO CORRECT BUFFER POSITION
                                                                                                                GET CONTROL BLOCK ADDRESS
MASN'T OPEN, CARRY IS SET FROM LFCB
CLEAR CARRY
SET CONDITION FLAGS
CLOSE THE CONTROL BYTE
WE WERE READING...NOTHING MORE TO DO
                                                    RZ .
ORA A
INR A
MVI M,O
RZ .
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   GET CHARACTER FROM RUFFER CLEAP CARRY
  1427
1428
1429
1430
1431
1432
1433
                                                                                  A
M, O
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     ALL DONE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                       THIS ROUTINE IS USED TO WRITE A BYTE TO THE FILE
                                  PUT THE CURRENT BLOCK ON THE TAPE
(EVEN IF ONLY ONE BYTE!!)
THEN WRITE AN END OF FILE TO THE TAPE
THAMMENT THAMENT THAME
                                                                                                                                                                                                                                                                                                                                                                                                                                                                   CALL LPCB GET CONTROL BLOCK
RZ - FILE WASN'T OPEN
RZ - FILE WAS READ
MYI M.OFEH SET IT TO WRITE
INX H
INX H
HOV A.B GET CHARACTER
PUSH PSW
PUSH H SAVE CONTROL ADDRE
                                                                                                                                                                                                                                                                                                                 C67F CD 2F C6
C682 C8
C683 3C
C684 C8
C685 36 FE
C687 23
C688 23
C689 78
C688 F5
C688 E5
                                                     INX
INX
MOV
                                                                                  H
H
A,M GET CURSOR POSITION
                                                                                  PLOAD BC GET HEADER ADDRESS, DE RUFFER ADDRESS
B HEADER TO STACK
H,BLKOF OFFSET TO BLOCK SIZE
B
A TEST COUNT
                                                                                   A TEST COUNT
EOFW NO BYTES...JUST WRITE BOF
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  SAVE CONTROL ADDRESS+2
                                             WRITE LAST BLOCK
                                                                                                                                                                                                                                                                                                                                                                                                                                                          NOW DO THE WRITE
                                                                                 C68C CD BB C6
C68F E1
C690 7E
C691 83
C692 5F
C693 D2 97 C6
C696 14
C697 F1
C698 12
C699 B7
C699 B7
C698 C0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    PLOAD BC GETS HEADER ADDR, DE BUFFER ADDRESS A.M. COUNT BYTE E.A. WIT1
                                                  PUSH
MOV
INX
MVI
INX
MOV
INX
MOV
MOV
CALL
POP
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     D
PSW
D
A
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  CHARACTER
PUT CHP IN BUFFER
CLEAR FLACE
INCREMENT THE COUNT
RETURN IF COUNT DIDN'T ROLL OVER
                                      NOW WRITE END OF FILE TO CASSETTE
                                                                                                                                                                                                                                                                                                                                                                                                                                                    THE BUFFER IS FULL. WRITE IT TO TAPE AND RESET CONTROL BLOCK.
                                                                                  A PUT IN ZEROS FOR SIZE: ROF MAPF IS ZFRO RYTFS
M, A
M, A
M H
MEADER ADDRESS
MFBLK WRITE IT OUT AND RETURN
                                              XRA
                                                    MOV
INX
MOV
POP
JMP
                                                                                                                                                                                                                                                                                                                                                                                                                                                                       CALL PHEAD PREPARE THE HEADER
JMP WFBLK WRITE IT OUT AND RETURN
                                                                                                                                                                                                                                                                                                                                                                                                                                                     THIS ROUTINE PUTS THE BLOCK SIZF (254) AND RUFFER ADDRESS IN THE FILE HEADER.
                                                                                                                                                                                                                                                                                                                   C6A2 CD BB C6
C6A5 C5
C6A6 21 06 00
C6A9 09
C6AA 01 00 01
C6AD CD B2 C6
C6B0 E1
C6B1 C9
                                        THIS ROUTINE LOCATES THE FILE CONTROL BLOCK POINTED TO BY REGISTER "A". ON RETURN HL POINT TO THE CONTROL WIT AND RECISTER "A" HAS THE CONTROL WORD WITH THE FLAGS SET FOR IMMEDIATE CONDITION DECISIONS.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    PLOAD GET HEADER AND BUFFER ADDRESSES
B WEADER ADDRESS
H,RLKGE-1 PSTOR DOES AN INCREMENT
R HL POINT TO BLOCKSIZE ENTPY
B,256
PSTOR
HL RETURN WITH HEADER ADDRESS
    H,FCBAS POINT TO THE BASE OF IT
. MOVE THE 1 & 2 TO 0 & 1 LIFE COMPUTERS LIFE
1 SMALL NUMBERS ARE THE RULF
FNUMF CURRENT ACCESS FILE NUMBER
LFCB1 UNIT ONE (VALUE OF ZERO)
H,FCBA2 UNIT TWO—PT TO ITS FCB
8 HL FT TO PROPER FCB
                                                    LXI
RAR
ANI
STA
JZ
LXI
EQU
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  HL RETURN WITH HEADER ADDRESS
```

CABA 70 1625 MOV M.B CABA 73 1626 INY H CABA 73 1627 MOV M.E	1762 * C73B 21 1C C8 1763 LXI H, THEAD POINT TO RUFFER C73E 06 10 1764 MVI B, HLEN LENGTH TO READ
C688 23 1628 INX H 1629 MOV M,D	1765 C74Q 1766 RHED1 EQU # RD A BLOCK INTO ML FOR R RYTES
1630 RET 1631 • 1632 •	C740 0E 00 1767 MVI C.O INIT THE CRC C742 1768 RHED2 EQU \$ LOOP HERE C742 CD 65 C7 1769 CALL TAPIN GET A RYTE
CABE 23 1633 PLOAD INX H CABC 46 1634 MOV C.M	C745 DE 1770 RC C746 77 1771 MOV M.A STORE IT
CARS 23 1635 INX H CARS 46 1636 MOV B,M	C747 23 1772 INX H INCREMENT ADDRESS C748 CD A4 C7 1773 CALL DOCKC GC COMPUTE THE CRC
CABE D2 1637 INX H CACC FE 1638 MOV E,M CACC 23 1639 INX H	C74B 05 1774 DCR B MMOLE HEADER YET? C74C C2 42 C7 1775 JNZ RHED2 DO ALL THE TITES 1776 *
C6C1 23 1639 INX H C6C2 56 1640 MOV D, M C6C3 C9 1641 RET D, M	1777 • THIS ROUTINE GRTS THE MEXT RYTE AND COMPAPES IT 1776 • TO THE VALUE IN REGISTER C. THE PLACS ARE SET ON 1770 • RETURN.
1643 ° 1644 ° 1645 °	1780 P C74F CD 68 C7 1781 CALL TAPIN GET CRC PYTE . C752 A9 1782 XRA C CLR CARRY AND SET ZERG IF MATCH, ELSE NON-TERG
1646 • THIS ROUTINE SETS THE CORRECT UNIT FOR SYSTEM R	C753 C8 1783 RZ . CRC IS FINE EADS C754 3A 11 C8 1784 LDA IGNOR BAD CRC, SHO WE STILL ACCEPT IT
C6C4 CD DA C7 1648 RFBLK CALL GTUNT SET UP A±UNIT WITH SPEED 1649 *	C757 3C INP A SEE IF IT WAS FF, IF FF THEN ZERO SAYS ION PRO 1786 * HOW, CRC ERR DETECTION DEPENDS ON IGNOR,
1650 * 1651 * 1652 *	C758 C9 1787 RET 1788 • 1788 • THIS ROUTINE GETS THE NEXT AVAILABLE BYTE FROM THE
1653 TAPE READ ROUTINES	1790 * TAPE. WHILE WAITING FOR THE BYTE THE KEYPCARD IS TESTED 1791 * FOR AN ESC COMMAND. IF RECEIVED THE TAPE LOAD IS
1655 ° ON ENTRY: A HAS UNIT AND SPEED 1656 ° HL POINT TO HEADER BLOCK 1657 ° DE HAVE OPTIONAL PUT ADDRESS	1792 * TERMINATED AND A RETURN TO THE COMMAND MODE IS MADE. 1793 ** C759 DB FA 179% STAT IN TAPPT TAPE STATUS PORT
1657 DE HAVE OPTIONAL PUT ADDRESS 1658 ON EXIT: CARRY IS SET IF ERROR OCCURED	C75B E6 40 1795 ANI TDR C75D C0 1796 RNZ
1660 TAPE UNITS ARE OFF	C75E CD 1F CO 1797 CALL SINP CHECK IMPUT C761 CA 59 C7 1798 JZ STAT MOTHING THERE YET
1662 P C6C7 D5 1663 RTAPE PUSH D SAVE OPTIONAL ADDRESS C6C6 06 03 1664 MVI R,3 SMORT DELAY	C764 E6 7F 1799 ANI 7FH CLEAR PARITY 1ST C766 C2 59 C7 1800 JM2 STAT EITHER MODE OR CTL-P C769 37 1801 STC SET ERROR FLAG
C6CA CI ER C7 1665 CALL TON C6CD DP FB 1666 IN TDATA CLEAR THE UART FLAGS	C764 C9 1802 RET AND RETURN 1803 *
C6CF E5 1668 PTAP1 PUSH H HEADEF ADDRESS	1804 • 1805 •
C6D0 CD 1F C7 1669 CALL RHEAD GO READ HEADER C6D3 E1 1670 POP H C6D4 DA 02 C7 1671 JC TERP IF AN ERROR OR ESC WAS RECEIVE	C768 CD 59 C7 1806 TAPIN CALL STAT WAIT UNTIL A CHARACTER IS AVAILABLE. D 1807 RC 1808 *
C6D7 C2 CF C6 1672 JNZ PTAP1 IF VALID HEADEP NOT POUND	C76F DB FA 1809 TREDY IN TAPPT TAPE STATUS C771 E6 18 1810 ANI TFE-TOE DATA ERROR?
1674 P FOUND A VALID HEADER NOW DO COMPAPE 1675 B	C773 DE FB 1811 IN TDATA GET THE DATA C775 C8 1812 RZ . IF NO ERPORS
C6DA E5 1676 PUSH H GET BACK AND RENAVE ADDRESS C6DB 11 1C C8 1677 LXI D,THEAD	C776 37 1813 STC . SET ERROR FLAG C777 C9 1814 RET 1815 *
CALL BHCMP COMPARE DE-HL HEADEPS C6E1 E1 1679 POP H C6E2 C2 CF C6 1680 JNZ PTAP1	1816 • 1817 • THIS ROUTINE GETS THE CORRECT UNIT FOR SYSTEM WRITES
1681 • 1682 •	C776 CD DA C7 1818 WEBLE CALL GIVNT SET UP A WITH UNIT AND SPEED 1819 *
C6E5 D1 1683 POP D OPTIONAL "PUT" ADDRESS C6E6 7A 1684 MOV A,D	1820 * 1821 * 1822 * WRITE TAPE BLOCK ROUTINF
C6E7 B3 16B5 ORA E SET IF DF IS ZFRO C6E8 2A 23 C8 16B6 LHLD BLOCK GET BLOCK SIZE C6EB ER 16B7 XCMGTO DE	1822 • WRITE TAPE BLOCK ROUTINF 1823 • 1824 • ON ENTRY: A HAS UNIT AND SPEED
1688 DE MAS MBLOCKHL MAS USER OPTION C6EC C2 F2 C6 1689 JNZ RTAP IP DE MAS ZERO GET TAPE LOAD A	nnpecs 1826 • ML MAS POINTER TO HEADER
C6FF 2A 25 C8 1690 LNLD LOADR GET TAPE LOAD ADDRESS 1691 0 1692 0	- 1827 * 1828 WTAPE EOU \$ HERE TO WPITE TAPF C778 85 1829 PUSH # SAVE HEADER ADDRESS C77C CD AB C7 1830 CALL WHEAD TURN ON, THEW MWFITE HDP
1693 THIS ROUTINE READS "DE" RYTES FROM THE TAPE 1694 TO ADDRESS HL. THE BYTES MUST BP FROM ONE	C77F E1 1831 POP H
1695 ° CONTIGUOUS PRYSICAL BLOCK ON THE TAPE. 1696 ° 1697 ° HL HAS "PUT" ADDRESS	C780 11 07 00 1832 LXI D.BLKOF OFFSET TO BLOCK SIZE IN HEADER C783 19 1833 DAD D HL POINT TO BLOCK SIZE C784 5E 1834 MOV E.M
1698 DE HAS SIZE OF TAPE BLOCK	C785 23 1835 INX M C786 56 1836 MOV D.M DE MAYE SIZE
C6F2 D5 1700 RTAP PUSH D SAVE SIZE FOR RETURN TO CALLING	C788 7E 1838 MOV A,M
C6F3 1702 RTAP2 EOU \$ HERE TO LOOP RDING RUES C6F3 CD 11 C7 1703 CALL DCRCT DROP COUNT, R=LEN THIS BLK C6F6 CA OC C7 1704 JZ RTOFF ZERO=ALL DONE	C780 23 1839 INK H C784 66 1840 MOY M,M C788 6F 1841 MOY L,A ML MAYE STARTING ADDRESS
1705 ° 1706 CALL RHED! READ THAT MANY BYTES	1843 * THIS ROUTINE WRITES ONE PHYSICAL BLOCK ON THE
C6FC DA 02 C7 1707 JC TERR IF ERROR OR ESC C6FF CA F3 C6 1708 JZ RTAP2 RD OFREAD SOME MORE 1709 9	1844 • TAPE "DE" BYTES LONG FROM ADDRESS "HL". 1845 • 1846 •
1710 • ERROR RETURN 1711 •	C78C 1847 WTAP1 EQU \$ HERE FOR THE EXTRA PUSH C78C E5 1848 PUSH H A DUMMY PUSH FOR LATER FXIT
C702 AF 1712 TERR XRA A C703 37 1713 STC . SET ERROR FLAGS	C78D C78D CD 11 C7 1850 CALL DCRCT DROP COUNT IN DE AND SET UP B W/LER THIS BLK
C704 C3 00 C7 1714 JMP RT0F1 1715 • 1716 •	C790 CA 07 C7 1851 JZ TOFF RETURNS ZERO IF ALL DONE C793 CD BF C7 1852 CALL WIBL WRITE BLOCK FOR BYTES IN B (256)
C707 06 01 1717 TOFF MVJ B,1 C709 CD ED C7 1718 CALL DELAY	C796 C3 8D C7 1853 JMP WTAP2 LOOP UNTIL ALL DONE 1854 • 1855 •
C70C AF 1719 PTOFF XRA A C70D D3 FA 1720 RTOF1 OUT TAPPT	CT99 P5 1856 WRTAP PUSH PSW CT9A DB PA 1857 WRWAT IN TAPPT TAPE STATUS
C70F D1 1721 POP D RETURN BYTE COUNT C710 C9 1722 RET 1723 **	C79C E6 80 1858 ANI TRE IS TAPE READY FOR A CHAR YET C79C CA 9A C7 1859 JZ WANAT BOWAIT C7A1 F1 1860 POP PSW TESRESTORE CHAR TO OUTPUT
1724 0 1724 0 C711 1725 DERET BOU \$ COMMON RIN TO COUNT DOWN PLK LE	C7A2 D3 FB 1861 OUT TDATA SEND CHAR TO TAPE
C711 AF 1726 XRA A CLR FOR LATER TESTS C712 A7 1727 MOV B,A SET THIS BLK LEN=256	C7A4 1863 DOCRC EQU S A COMMON CRC COMPUTATION ROUTINE C7A4 91 1864 SUB C
C713 B2 1728 ORA D IS AMMILEFT < 756 C714 C2 1C C7 1729 JM2 DCRC2 NOREDUCE AMMIRY 256 C717 B3 1730 ORA E IS ENTIFE COUNT ZERO	C7A5 AP 1865 MOV C,A C7A6 A9 1866 XRA C C7AT 2F 1867 CMA
C717 B3	C7A8 91 1868 SUB C
C71A 5A 1733 MOV E, D MAKE ENTIRE COUNT ZERO NOW C71B C9 1734 RET . ALL DONE (NON-ZERO FLAG)	C7AA C9 1870 RET . ONE BYTE NOW WRITTEN
C71C 1735 DCRC2 EQU \$ BEDUCE COUNT BY 256 C71C 15 1736 DCR D DROP BY 256 C71D B7 1737 ORA A FORCE MON-ZERO FLAG	1873 * THIS ROUTINE WRITES THE WEADER POINTED TO BY 1878 * HL TO THE TAPE.
C71D B7 1737 ORA A FORCE MON-ZERO FLAG C71E C9 1738 RET . MON-ZERO-NOT DONE YET (RLF LPM- 1739 F	
1740 * READ THE HEADER	CTAB CD E9 CT 1877 CALL WITH TURN IT ON, THEN WRITE MEADER CTAE 16 32 1878 MVI D,50 WRITE 50 ZEROS
1742 0 C71F 06 0A 1743 RHEAD MVI B,10 FIND 10 NULLS	C7B0 AF 1879 NULOF IRA A C7B1 CD 99 C7 1880 CALL WRTAP
C721 CD 59 C7 1948 RHEA1 CALL STAT C724 D8 1745 RC . IF ESCAPE C725 DB FB 1746 IN TDATA IOWORE ERROR CONDITIONS	C7BA 15 1881 DCR D C7B5 C2 B0 C7 1882 JM2 MUTLOP 1883 *
C727 B7 1747 ORA A ZERO? C728 C2 1F C7 1748 JNZ RMEAD	CTBS 3E 01 1884 MVI A,1 CTBS CD 99 C7 1885 CALL WRTSP
C72B 05 1749 DCR B C72C C2 21 C7 1750 JMZ RMEA1 LOOP UNTIL 10 IN A ROW	C7BD 06 10 1886 MVI B, HLEN LENGTH TO WRITE OUT 1887 *
1751 • WAIT FOR THE START CHARACTER 1753 •	CTC1 TE 1889 WLOOP MOV A,M GET CHARACTER CTC2 CD 99 C7 1890 CALL WRTAP WRITE IT TO THE TAPF
C72F UD 6B C7 1754 SOHL CALL TAPIN C732 D8 1755 RC . ERROR OR ESCAPE	C7C5 05 1891 DCR B C7C6 23 1892 IWX H
C733 FE 01 1756 CPI 1 ARE WE AT THE 01 YET (START CHA C735 DA 2F C7 1757 JC SOHL NO, BUT STIL ZEROES	C7CA 79 1894 MOV A,C GET CRC
C738 C2 1F C7 1758 JNZ RHEAD NO, LOOK FOR ANOTHER 10 NULLS 1759 WE HAVE 10 (OR MORE) NULLS POLLOWED IMMEDIATELY	1896 *
1761 BY AN DI. NOW READ THE HEADER.	1898 • THIS ROUTINE COMPARES THE HEADER IN THEAD TO

```
1899 ° THE USER SUPPLIED HEADER IN ADDRESS HL.
1900 ° ON RETURN IF ZERO IS SET THE TWO MAMES COMPARED
1901 PURCHP
1902 DHCMP
1903 DHLOP
1903 DHLOP
1903 DHLOP
1904 DAX
1905 DHLOP
                                                                                                                                                                                                                                                                                                                                                                                                                     C81C
C821
C822
C823
C825
C827
C829
C7DA 3A 54 C8
C7DA 3A 54 C8
C7DD B7
C7DE 3A 0D C8
C7E1 C2 E6 C7
C7E4 C6 40
C7E6 C6 40
C7E6 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   S SET A-SPEED - UNIT
PNUMF CET UNIT
A SEE WHICH UNIT
TSPD BUT IST CET SPEED
GTUN2 MAKE IT UNIT TWO
TAPE2 THIS ONCE-UNIT 2, TWICE-UNIT 1
TAPE2 UNIT AND SPEED NOW SET IN A
ALL DONE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C82C
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     1 POR CURRENT FILE OPERATIONS
7 IST FILE CONTROL BLOCK
7 ZMD FILE CONTROL BLOCK
20256 SISTEM FILE BUFFER BASE
1 "BELL" (X'07') FLAGS START OF IMPUT BPR
80 BOOM POR THE IMPUT LINE
$ START OF USER AREA
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   R,4 SET LOOP DELAY (RIT LONGER ON A WRITE)
8 HERE TO TURN A TAPE ON THEM DELAY
TAPPT GET TAPE MOVING, THEM DELAY
C7E9 06 04
C7EB
C7EB D3 FA
C7ED 11 00 00
C7F0 1B
C7F1 7A
C7F2 B3
C7F3 C2 F0 C7
C7F6 05
C7F7 C2 ED C7
C7FA C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                CABA
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             AOUT
BACTES
BACTES
BACTES
BACTES
BACTES
BACTES
CONTA
CONTA
CONTA
CONTA
CONTA
DELLOP
DISTIPUTENTE
ENTES
DELLOP
DISTIPUTENTE
ENTES
DELLOP
DISTIPUTENTE
ENTES
POPEN
GONTA
HENCH
H
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   001C 0050C 0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            AIRP ARETINE BLOOF COMMING COPPEC COMMING CO
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         C3D20 AC C3D
                                                                                     CCOO
                                                                                          0013
000B
000E
0000
005F
000A
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              STATUS PORT GENERAL
SERIAL DATA
PARALLEL DATA
KEYBOARD DATA
VDM CONTROL PORT
TAPE STATUS PORT
TAPE DATA PORT
SENSE SWITCHES
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           EQU
EQU
EQU
EQU
EQU
EQU
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        0
1
2
3
0C8H
0FAH
0FBH
0FFH
                                                                                                                                                                                                                                                                                                                                                                                                                               1971 STAPT
1971 SDATA
1972 SDATA
1972 SDATA
1973 DATA
1975 DATA
1975 DATA
1976 TAPT
1977 TDATA
1976 TAPT
1977 TDATA
1978 SEMSE
1978 *
1988 SCD
1988 SCD
1988 SCD
1988 SCD
1988 SCD
1988 SCD
1989 SCTS
1988 SCB
1989 SCTS
1999 STBE
1999 STBE
1999 STBE
1997 TOE
1999 TDB
1999 TDB
1999 TDB
1998 TDB
1998 TDB
1998 TDB
1998 TDB
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         0020
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            SDATA
SENSE
SETCI
SETNU
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              SDR SEROT SETTO SETTO SETTO SETTO SETTO SETTO SETTO SETTO STATE STATE TARRETTOR TARRETTOR TARRETTOR TO STATE TO SETTO SE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      0002
C576
C596
C194
C019
C039
C759
C174
0080
C558
C407
C797
C7978
C7778
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     C1B8
C35999
C05A8
C05A8
C05A8
C05A8
C05B0
C05B1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     00406
C054D
C554D
C5570
C5570
C0000
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             SDSR
SETICR
SETSP
SETSP
SETSP
SOUT
STAT
STAT
STAT
STAT
TASPD
TERE
TOFF
TOFF
UBUR
USARE
VDM01
WLOOP
WRWAT
WTON
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               BIT ASSIGNMENT MASKS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              SEPIAL CARRIER DETECT
SEPIAL DATA SET READY
SEPIAL PARITY EPROP
SEPIAL OVERPUN ERROR
SEPIAL OVERPUN ERROR
SEPIAL CLEAR TO SEND
SEPIAL DATA READY
SEPIAL DATA READY
SEPIAL TRANSMITTER RUPFER EMPTY
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   1
2
4
8
16
32
64
128
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 SETX
SHE1
SOHL
SPE
STAPT
STRIA
STSPD
SYSTP
TAPIN
TDATA
TERE2
TIMER
TLOAD
TREDY
TTBE
UOPRT
UOPRT
UOPRT
UOPRT
WFBLK
WRBYT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              REYBOARD DATA READY
PARALLEL DATA READY
PARALLEL DEVICE READY
TAPE FRAMING ERROR
TAPE OVERFLOW ERROR
TAPE DATA READY
TAPE TRANSMITTER BUPFFF EMPTY
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       TBL
TERE1
THEAD
TLOA3
TON
TSRCH
UIPRT
VDAD
VDAD
WRBLK
WT1
WTBL
XEOAD
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         EQU
EQU
EQU
EQU
EQU
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        1
2
4
8
16
64
128
                                                                                          0080
                                                                                                                                                                                                                                                                                                                                                                                                                               1999 TTBE EQU

2000 **EQU

2001 SOK EQU

2002 **EQU

2003 TAPE1 EQU

2004 TAPE2 EQU

2006 **EQU

2008 **EQU

2009 **EQU

2010 **EQU

2011 ORC
                                                                                     0001
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               1 .
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              SCROLL OK FLAG
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   1=TURN TAPE ONE ON
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            STSTEM GLOBAL ARFA
                                                                                                                                                                                                                                                                                                                                                                                                  2010 0
2011 0 ORC
2012 0
2013 SYSRAM EQU
2013 SYSRAM EQU
2014 SYSTP EQU
2015 0
2016 0
2017 0 PARAMET
2018 0
2019 UIPRT DS
2020 UOPRT DS
2021 DFLTS DS
2022 IPORT DS
2023 OPORT DS
2023 OPORT DS
2024 NCHAR DS
2025 LINE DS
2026 ESCH DS
2027 SPEED DS
2029 TSPED DS
2029 TSPED DS
2029 TSPED DS
2029 TSPED DS
2021 DIPPT DS
2031 NUCRT DS
2031 NUCRT DS
2033 0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              ORG START+0800H RAM STARTS JUST AFTER ROM
C800
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    $ START OF SYSTEM RAM
SYSRAM+3PFH STACK WORKS PM TOP DOWN
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         DIN RAM

USER DEFINED INPUT RTN IF NON ZERO

USER DEFINED OUTFUT RTN IF NON ZERO

DEFAULT PSUEDO I/O PORTS

CRNT INPUT PSUEDO PORT

CURRENT OUTFUT PSUEDO PORT

CURRENT LINE POSITION

CURRENT LINE POSITION

BEGINNING OF TEXT DISPLACEMENT

SPEED CONTROL BITE

ESCAPE FLAG CONTROL BYTE

CURRENT TAPE SPEED

PTR TO MEXT CHAR POSITION IN UNLIN

HUMBER OF WILLS AFTER CRLF

ION CRC ERR FLAG, FF=ION CRC ERRS, ELSE-WORMAL
```

BOOM FOR PUTURE REPAIRSTON

C812


Waiting for BASIC-5

A lot of people have asked why Sol BASIC-5 took so long to be released. The main reason is Processor's policy con-

ning the release of new products: we up to the advertising claims, and we intend to live up to our reputation. (Note: we've never been forced to recall a product.)

We could have provided you with a version of our original BASIC-5 a long time ago, with a modification of only 12 instructions. But that wasn't what we advertised Sol BASIC-5 to be. And in getting it to be what we wanted, we kept thinking it would be neat to add just a couple more nifty features and then just one more and one more and . . . So as with all fanatics, one thing led to another 'til somebody remembered that this is a business and there are customers out there who could only stand so much "neat stuff" (especially if they had to wait until the year 2000).

Anyway, by now you will have received said BASIC-5, so load it in and run it for a while. We think you'll agree that it was almost worth the wait.



Computer of the Future

Contributions Welcome!

Drawing by Brian Marsh, Age 6.



Processor Technology Corp. 6200 Hollis Street Emeryville, CA 94608 Vol. 1, No. 2

Bulk Rate
U.S. Postage
PAID
Permit No. 3729
Oakland, Calif.

75¢ per issue Published by Processor Technology Corp., Emeryville. Volume One, Number Three, June 1977


In This Issue



A Photo Essay of the First Annual West Coast Computer Faire, by our own multi-talented Rick Meyer. Lots of people, lots of excitement. Take a look for yourself page 4 & 5.

Software Technology debuts! An informative article on the care and choosing of your cassette tape system.....page 11.

How to stop your Sol and see what's happenin'. The first in a series of articles on creating a Run/Stop circuit for your Sol.....page 7



Letter from the Editor.....page 3.

Testing your audio cassette hardware; a useful matching language routine.....page 8.

> Reader Feedback page 6 & 7.

The Newest from Newett Awl: swapping

Bug Squad.....page 9.



delivery. Since the last ACCESS, we've pretty well completed deliveries on BASIC/5 and CUTER software packages. GAMEPAC 1, MATHPACK, and TREK 80 on cassette are next in line; deliveries on them will begin in July, and much of our other software will be forthcoming later this summer.

Deliveries of Helios II. our dual-drive floppy disc system, are targeted to begin in mid-to-late July. We'll ship the earliest orders first, but due to the large number of back orders on file, it will be some time before we're totally caught up on deliveries.

We've already begun deliveries of our 16KRA dynamic memory board although slowly. If you have one on order, you can be assured of receiving it

Specifications sheets for the new GPM (General Purpose Memory) Module will be available in July. You can get them from our Customer Service Department or your local PTC dealer.

Sol Users' Group. If you currently own a Sol computer, you may be interested in the Sol Users' Group. The Group was created to provide a

dialogue among Sol owners, by sharing applications, software, and other information for mutual member benefit. The Sol Users' Group (not affiliated officially with Processor Technology) can be contacted through Bill Buras, 4190 Maybell Way, Palo Alto, CA 94306.

We need you! In the interest of providing continued informational support, especially in connection with interfacing Processor Technology hardware with other manufacturers' software, we'd like to hear your ideas, see your programs, whatever you've got. We will be happy to publish useful information that you might contribute. Mom will finally see your name in print!

PTC dealers. New ones are continually added to our ever-growing list. They're all authorized to both sell and service Processor Technology products, and to act as distributors for Processor/Software Technology software. To keep you up to date, the current dealer roster is listed in this issue of ACCESS. Of course, your dealer's always interested in hearing from PTC customers, so why not pay him a visit?

ACCESS subscriptions. Let us know if you've subscribed and are having trouble receiving your copy regularly. Is your mailing address correct as printed on the label? Have any suggestions for improvement?

ACCESS Issue No. 1 is now out of print; no back copies are available. (continued on page 2)

Subscription Information

ACCESS is published every six weeks. If you like what you see, we hope you'll send us \$4.00 for a year's subscription so we can keep the info coming. Write to us at Processor Technology, 6200 Hollis Street, Emeryville, CA 94608.

50 Hz Operation of the So1-PC

The demand for Sols is international, and a great many countries have power systems which operate at 50 Hz (cycles per second). Sol transformers are designed to operate at this frequency without derating, and a 220, 235 or 250 volt power supply is available from the factory.

In most countries where the line frequency is 50 Hz, the television display standards have been adapted so that the vertical sweep frequency is also 50 Hz (this reduces flicker). The resulting display contains 625 scan lines per frame, or 312½ lines per frame.

The frequency of the synchronization pulses produced by the Sol can be changed to this new standard quite easily on the E revision boards, and with a little more difficulty on the D revision boards. In both cases, the change involves disconnecting pin 5 of the U62 from pin 6 and reconnecting it to pin 4 of U62. Jumper pads have been provided for this purpose on the E revision, so that the change is a simple one-cut, one-jumper modification performed on the top side of the boards. The angled trace leading from pad AF is cut and a jumper is installed between pad AF and AG.

The D revision boards requires two trace cuts. One is made on the top side of the board between U 62 and U 61 (the trace leading from pin 5 of U 61 is cut). The remaining trace cut is made on the bottom (solder) side of the board. One is between pins 4 and 5 of U 62. Two jumpers must now be installed, both on the solder side of the board. One is between pins 4 and 5 of U 62. The other connects pin 6 of U 62 with pin 5 of U 61.


The VDM-1 may also be modified to allow 625-line operation. On all revisions of the board, cut the trace connecting pins 5 and 6 of IC8. Using a

wire jumper, connect pin 5 of IC 8 pin 4 of IC 8. This is all that is required to modify the VDM-1.

These modifications will present a display of 16 visible text lines which appear somewhat more compact vertically than the 60 Hz display. This is because the time from the bottom of the display to the top has been doubled from the equivalent of four text lines to eight text lines.

INSTALL JUMPERS:

Lee Felsenstein



REVISION E PC BOARDS

REVISION D PC BOARDS

(Cont. from Page 1)



Finally, we do appreciate all the support and feedback many ACCESS readers have provided. The comments, positive, negative or otherwise, indicate your interest in PTC and help us to give you what you want. I think those of you who have contacted us on the one-to-one communication basis (by phone or letter) have found responsive follow-through on our end. Further improvement can come from your suggestions, so let us know what you're thinking. Again, the number is (415) 652-8080 for teletroubleshooting (between 9:30 am and noon or 1:30 to 4 pm Pacific Time); for technically oriented software questions, call (415) 349-8080.

See you next issue.

Ralph I. Palsson ACCESS, JUNE, 1977 • 2

Your ALS-8 Applications Notes are on the Way!

After a seemingly interminable delay, the first batch of Application notes are really and truly in the mail to all you ALS-8 Users' Group members. Once the material is in your hot little hands (in a very fancy binder, no less), you'll be better able to appreciate the power and versatility of your ALS-8, and you should have some very happy hours of computing.

If you haven't received your notes by the time you read this, please drop us a note right now, so we can track down whatever clerical or shipping errors crossed you up.

Our sincerest apologies for the delay.

Will Vern ever finish telling us the "real story" behind the VDM-1? Yes, indeed! The continuing saga of the Flickerless VDM-1 has been temporarily interrupted. It'll be back with the next issue. Stay tuned. Basic Theorem of Programming: The program is absolutely right, therefore the computer must be wrong.

Subscription Blank

Name	
Address	
City	
State	
Zip	
Enclosed is a check for \$ subscription(s)	fo



Editor: Aram Attarian II

ACCESS is published approximately every six weeks. Subscription rate: \$4 per year, from Processor Technology Corp., 6200 Hollis St., Emeryville, CA 94608.

ACCESS Copyright © April 1977 by Proc

ACCESS Copyright © April 1977 by Procy Technology Corp. All Rights Reserved. Materi in this publication may not be reproduced in any form without permission from Processor Technology Corp.



ALetter From the Editor

"Give me a cigarette, because I'm so hungry that I got nobody to sleep with tonight."

Old Russian Proverb Well, who would have thought it. e I was at 8 o'clock Saturday mo , slightly hungover, arriving at the Civic Center for the First West Coast Computer Faire - and there were already people lined up clear around the corner. (Unless I was still seeing double from the Processor Technology Dealer Banquet, which featured Peking Duck, a few Tsingtsao beers, Sweet and Sour Chicken, a few more Tsingtsao's, Manchurian Beef, a few etc.)

By the time the last plug was pulled Sunday night, more than 12,000 people had paid \$6 to \$9 a head to get a look at the latest marvels from Processor, IMSAI, Polymorphic, Apple, Byte Shops, and well over 100 other exhibitors. There were lots of neat things: programs for kids, color graphics, music (including the premiere of the Software Technology Music System - but you can read about that in our literature. No advertising here). And seminars on everything from tutorials for the complete novice to bus and interface standards. The building was basically hot, and it was rowded, and everybody was pr high.

ll in all, the impression was that .. was a very good event. The people who planned the Faire did a good job, and we'll probably draw even bigger crowds next year, what with people like Radio Shack and Heathkit getting into the act. The price probably put it out of range for a lot of people who might have come this time, but given the rate of growth in the home computer field

Aram Attarian II P.S. Now that we've got ACCESS going, and we're starting to get some feedback, we're re-evaluating our procedures. Issue No. 4 will be a little late, because we're going to make some changes to make it a better quality production, in line with some of the suggestions you've made. So long 'til then.

Attention, CONSOL Users

All Processor Technology software has recently been modified in a very important way that encourages standardization. If you've been looking forward to having some Sol software for your CONSOL Proms, you'll have to let us re-program for you. There's no charge. Just mail your CONSOL Proms, suitably packaged, to Processor Technology; we'll take care of the rest. Turn-around time is about 2 weeks, dependent on the vagaries of the U.S. Postal Service, natch.

If you're planning to upgrade to SOLOS anyway, don't worry about it.

Newett Aw1's Screen Sort

This little program does what's called a bubble sort: each byte in the sorted area is compared to the next higher byte. If the first byte has a higher value, the two are swapped in the memory. Then the same thing is done for the next two, and so on through the entire sort area. After the first pass, the last byte in the sort area will be the highest value, so when you set up to pass over the sort area again, you can shorten it by one byte at the high end. And if you keep track of what swaps take place during the sort, you can quit as soon as no swapping occurs.

I have located this routine in low memory, so you don't need much to play with it. I used the VDM screen for the sort area, so you can see exactly what's going on - if your eyes can be synched to the screen! Try putting a whole mess of garbage on the screen, then executing the program at location 0000. Your screen may never be the same!

Those of you who are adventuresome and mischievious might try modifying line 0047 to read 0047 SIZE DW, 2047 ARBITRARY LENGTH and line 0048 to read 0048 TOP EQU, 0200H USE TV DAZZLER AREA. Then if you have Lichen Wang's Kaleidoscope, assemble this program so that it is above 0900 (HEX), get Kaleidoscope running, then stop and run the sort program.

I've purposely coded the program so that it will sort any length field by manipulating the SIZE and TOP. A little practice and imagination should do the rest. I sorted the train program (naturally), but it broke my heart to see the little engine torn apart so badly and so quickly.

A couple of program notes: at line 40, the zero flag is being set or reset by

the ADD B in line 37. As we all know but often forget, the DCX H at line 39 has no effect on the accumulator flags. At line 25, I just arbitrarily stuff register B with the last byte looked at. 20 tells me that a byte in register A has I know for sure that it isn't zero and can safely use it for a simple flag.

This is an interesting use for the flag. At line 37, all I need to know is whether or not swapping occured. If the test at line a higher value than the byte in memory, Reprint Permission of Newett Awl



Eggleston's Extension Principle: Programming errors which would normally require one day to find will take five days when the programmer is in a hurry.

8816 8817

ACCESS, JUNE, 1977 • 3










Top Photo, Processor Technology's booth at the First West Coast Computer Faire, with some spacy stuff up on the big display. Yep, it really was that crowded all weekend.

Left, Kids engrossed in a game of Target. Maybe you're right about CHOO-CHOO, Joe — still, I know some big kids that got off on it. (See Reader Feedback).

Above, Kids of all ages got turned on by Sol.

At right, The Processor booth. No, that's not me in the background. Bet he plays a mean game of Target, though.







Left, Bob Marsh of Processor Technology demonstrates Sol. "You mean you can do that with a computer?"

Below, We make the big time — Glenn Tenney of Software Technology details the STC music system in an interview by NBC at the Faire.







Reader Feedback

We don't have space to print all the letters we're receiving, but we'll try to get as many in as we can. We reserve the right to edit for space and content so we can include as wide a cross-section of opinion as possible. We'll reply to all of you personally if you include a self-addressed stamped envelope.

Aram Attarian II

Sir:

As evidenced by the many excerpts in ACCESS, you obviously enjoy Conrad Schneiker's Abridged Collection of Interdisciplinary Laws. Although the Laws are not copyrighted, don't you think it would only be fair to credit the source?

Gregg Townsend Sunnyvale, CA

Dear Gregg:

My source was Logical Laws,
Accurate Axioms, Profound
Principles, Trusty Truisms, Homey
Homilies, Colorful Corollaries,
Quotable Quotes, and Rambunctious
Ruminations. This mouthful is the title
of a pamphlet "compiled by the
computer company that's out to make
life a little simpler." Happy to credit
both sources.

AA II

Dear Aram:

Enclosed check for \$4 for a year of ACCESS. Now my observations.

1. You are doing it wrong. Should be notebook-size sheets — how does one file for reference?

2. Last year I filled out a card for which I was supposed to receive something over the year, supposedly edited by Gordon French. What happened?

3. In order for ACCESS to be ACCESS, JUNE, 1977 • 6

meaningful, it should be understandable. The biggest fault I find with all publications is that someone just plunks down a program, period. There is a crying need to explain, in detail, at least a few times, the meaning of all the listings as they relate to hardware. **Nobody** to date has done this. Why do editors assume that we hobbyists know all this?

Joseph P. Chalala Willow Street, PA

Dear Joe:

Thanks for the sub. In answer to your points:

1. Our format will be changing in the near future, and we'll take your suggestion into consideration. Good point.

2. See the reference to the ALS-8 User's Group in this issue (also in last issue).

3. Most listings include comments that are supposed to explain the software, but you're right, more text is needed for a really good understanding.

AA II

Dear Gentlepersons:

As you hopefully know by now, Newett Awl's choo choo train has at least one error in it. (Vol 1, No. 1 of Access). At address OODO the listing (page 11) shows a "A8", while the dump format on page 12 shows a "AB". Now, please, I beg of you, tell me what kind of an assembler you have that generates incorrect code ... (by the way, an "AB" wipes out most of memory, I trust the "A8" to be correct). But even so, we have entered and checked the code three times, and it certainly does't seem to work on my Sol ... the front part of a steam engine does appear, and it vibrates back and forth for about 5 seconds, and then as it apparently attempts to do something else, it

crashes, writing "E9" 8S at 25, 26, A5, A6, 125, 126. Perhaps it could be a hardware problem, you will have better idea about that than I.

2) Would it be possible to provid me with a copy of SOLOS and SOLED (a listing would suffice), as I would like to find out the correct way to function the tape drives among other things. I dappreciate your relative thoroughness in design and implementation of the Sol, you did a rather professional job.

I am managing the West Lafayette Data Domain Store and I putogether a Sol-PC. In the mean time, whave lost the envelope and registration etc. Would you please either send another set of reg. cards & whatever or simply send what I was supposed to aslyou to send (other chapters of the manual, personality module exchange, whatever, I've forgotten even what it was ...)

J. Gregory Madde Mgr. Data Domain of W. Lafayett Pres. JGM Development Lal

Dear Greg:

1. Choo choo was written for VDM-1, and we'll be publishing Sol patches and updates in the next ACCESS.

2. See this issue for SOLOS

3. Customer Service has ta care of your problem by now.

AA

Dear Aram:

In the "Bug Squad," ACCESS 2. Fix No. 5, you show a cut on trace to pin 26 of J11. The descriptive matter says pin 73. Which is correct and are the other fixes as accurate?

Dr. George L. Hall Naples, Floric

Dear George:

See "Bug Squad" in this issue. The other fixes are OK.

AA

Mr. Editor:

As of this date your world renowned (sic) service mgr. is still promising heaven on earth to us (I will admit) suckers! I suggest you change "protecth" to "mana-na." That's Spain for tomorrow, capito. (sic, sic, and sic).

Anyway, in my opinion you guys are full of crabs, who in his right mind would establish a computer company in a "rundown, skid row, full of yech! God forsaken place like Emeryville."

Obviously, this company did, even the newspaper it publishes and perso a affected by the locale — it's full Care to publish this letter go ahead.

Your ads are pretty and very convincing, look who it caught with \$1000 plus to buy your A#\$!!!! Sol-20 board that won't work ME. (and a few

more sics) "Whoever heard of a Sol not working." Look for mine stupid!

If I had to do it all over again — will buy a Heathkit color TV set kit ta "goddam" Protech Sol-20. Count out as your ardent supporter of Sol—it's for the birds.

Hal Martino II

Dear Hal:

Have you hugged your kids today? Love,

AA II

Dear Ralph and Aram:

Here are some general and specific comments on ACCESS.

1. The software listings are good and useful, but they take a lot of room. Might it not be better to bind up the long ones separately and sell like No. 1 and No. 2? Actually, I do hope you will provide listings of SOLED, 8K BASIC & FOCAL, ALS-8, TREK 80, etc. I am somewhat of a software listing junky—that's why I'm a PTC customer (i.e., free software).

1A. Choo Choo Train is a bit immature, games like Life and Target are more suitable even for kids. I have a 9-year-old playing Trek.

2. I am a little concerned that you are using ACCESS to distribute errata for Sol. I think you should also empile and send out loose-leaf sheets for the instruction book — or even charge for an updated instruction set. Sol systems are likely to be around for a long time and the book is likely to remain with the system, but a stack of old ACCESS's is likely to be lost and with them the errata.

2a. Should not Errata No. 3 (Ground Noise Fix) concern itself with IC #107 and not IC #33?

2b. Any reason for not revising the 8 leads to J2 on the card (cut and jump) if I want? (i.e., is it more involved?)

3. "Waiting for BASIC-5." I do see both sides of the issue. I do expect a properly designed and debugged product, with good documentation, for my money and I will wait a reasonable time for it. And I have seen how several publications have been very critical of certain minor problems — which can really hurt a manufacturer.

But then again, it's a new product and it is intended for the sophisticated hobbyist who is capable of understanding and making fixes to PC cards and software. Sol and SW#2 are good examples. Still I cannot believe hat things take as long as they do, or nave in the past. Perhaps the answer is a system where you have two levels of customers — those who want preliminary releases and are willing to

pay for fixes or updates, and those who want a final, warranted product.

Joseph Gaffney Lyndhurst, NJ

Dear Joe:

1. See the letter from Joe Chalala.

2. This will be the case in the future, but you have to consider the amount of bookkeeping necessary for that type of project. We'll be using Helios II to handle it, but they're hard to get right now.

2a. No.

2b. No.

Thanks for a very thoughtful letter. Readers like you will help us make ACCESS a lot more responsive.

AA II

A Run/Stop Circuit for User Control of Sol's X-Ready Line

The ability to stop and examine the various state of a system as the program is executing allows the user to detect errors embedded within the system. To this end, I have written a series of articles dealing with the implementation of "Front Panel" features on an S-100 system. These should assist both hobbyist and professional with standard system maintenance.

This first installment deals with stopping or slowing the instruction execution time from tens of microsecond to a user defined time. As most S-100 bus processors follow a set of protocol, the heart of any front panel is the run/stop circuit. By holding down the ready line, the user can cause the processor to idle as long as that line is down. Thus, the toggling of the ready line will allow the slowing or stopping of the processor from machine cycle to machine cycle.

With the R/S switch, you can control the X-READY line by setting and resetting the R/S (Run/Stop) flipflop U1A. With the R/S switch in the run position, the R/S flipflop is reset on \(\Q2 \), forcing X-READY high. In the stop position, the switch NAND's together the stop value (\(\Q2 \), PSYNC) and the MI/FETCH cycle (DO5). A new fetch will then set one input high to the X-READY NAND gate.

When the R/S flipflop is set in the stop position, the state of the X-READY line is determined by the state of the single step S/S (single step) flipflop. If it's set, the \overline{Q} output applied to the other input of the X-READY NAND gate U3C will be low. And the X-READY line will be high, thus allowing the processor to run. The S/S flipflop will be reset at the next PSYNC

pulse, stopping the processor.

The inverters U2D and U2E are wired as a R/S flipflop to debounce the single step switch. SSS U6 is a multi-vibrator used to set the S/S flipflop at a variable rate. The vibrator will be inhibited by U2C until the multiple step switch is depressed; its rate is determined by the values of RA, RB, and C1:

Charge time — .685 (RA + RB) C1 Discharge time — .685 (RB)C1 Period — .685 (RA + 2R2)C1 Frequency — $\frac{1.46}{(RA + 2RB)C1}$

Parts list:

U1 74109 For approximately 10 steps per second

 $U2\ 7406\ RA = 3.3\ meg$

U3 7400 RB = 3.3 meg

U4 7420 C1 = .01

U5 555 C2 = .001 uf (C2 is a bypass capacitor of approximately .001 uf)


U6 8T97 The pull-up resistor values are 2.2K

Stop/Run switch SPDT Single Step switch SPPT

Multiple Step switch SPST Normal Open


In the next of the series, I will diagram the proper connection of indicator lights to the S-100 bus, showing use of the first two installments.

Steve Wong



OOPS!

Our kit packers made a mistake! A few Sol kits shipped in April or May '77 contain form 74LS153 integrated circuits. Do not use these chips. We will gladly replace them with the proper part, i.e., 74LS253's. Let us know, and we'll take care of it immediately.



Audio Cassette Test Routine

This is a machine language routine written to run on a Sol PC, Sol 10 or Sol 20 as a functional test of the audio cassette hardware. It uses only the ENTER, DUMP, and EXECUTE commands, and requires no additional memory.

Enter the routine through the command mode as shown in the first section of the program. At the end of this section, your Sol will return to the command mode. Then use the second section to dump memory C900 through C94F. Check that the data has been entered correctly; ignore bytes C946 through C94F.

Put good quality blank tape in your recorder and connect its aux input to the Sol Audio Out J6, using audio cable. Set the recorder's volume and tone controls per Sol Manual Section 8. Push Record and Play simultaneously to move past the leader. Pure clocks will be recorded until you give the command EXEC C900.

This command will cause a 256-bit incrementing data pattern to be recorded continuously until you stop it. When you've recorded as much tape as you want, you'll have to do a restart and return to the command mode. Rewind the tape to the beginning, then attach an audio cable from Sol Audio IN J7 to the recorder's Monitor or Earphone output. With some recorders. you'll have to disconnect the Aux/Audio Out cable before you can play back. Then put the recorder in the Play mode and execute either C90E (Normal Read Entry Point) or C91C (Alternate Read Entry Point).

The Normal Read Entry causes data to be read from the tape and displayed on the screen. The display will begin when the beginning of the data is recognized, and it will occupy 6 lines of the screen. The sequence will correspond to one of the data patterns shown in Figure E, depending on the character generator used. Visually inspect the display for correctness: the pattern should begin at the left margin of the screen and continue for two full lines, then repeat with reversed screen polarity for another two lines. The last two lines will repeat the original pattern to fill out the display. Now, data will continue to be read from the tape and written over the previous display: only the character polarity should change, causing the display to alternate from white-on-black to black-on-white. Neither the horizontal nor vertical position should change; a shift in position indicates either the loss or addition of random characters.

To discover where read errors might be expected to occur, experiment with the volume and tone controls, audio cables, or phase-locked loop ACCESS, JUNE, 1977 • 8

adjustments.


You can realign the received data display at any time by doing a restart to command mode and then executing C90E again. Careful examination of the display will reveal any out-of-sequence


characters, which indicate read errors.

If the beginning of the pattern
can't be found, use the Alternate
Entry Point to display whatever
read.

display will reveal any out-of-sequence Pat Tue 8010 0011 Figure 3-1A. MCM6574 pattern. 20 . Figure 3-1B. MCM6575 pattern. 8891 START 8882 RD1 8883 RD1 8883 RD4 8885 RD4 8885 RD4 8887 TBI 8887 TBI 8887 TBI 8887 BD1 8887 TBI 8813 8813 8813 8815 8817 8818 RD1 8818 RD1 8818 RD1 8818 RD1 8828 RD2 C936 GA 32 C9 C939 DB FB C938 77 C93C 2C C93D 7D EQU EQU EQU EQU EQU IN AMI JZ INR A.L SSH RD4 RD2 GET MORE DA GET TAPE STATUS RD2 START FL
STAN.
C
ALC
DAT
START FOREVA.
STS GET TAPE
RDA
AND VALT FO.
RDI
DAT
SFFH VALT FOR START
SIZ
RDI
CALL
STS GET TAPE DATA
SIZ
RDI
CALL
STS GET TAPE DATA
RDA
AND VALT FOR RDA
AND VALT FOR RDA
GET TAPE DATA
PUT IT ON THE ST
VAPUTE SCREEN

"SE DATA
PUT IT ON THE ST TRE PEXEC COOR NORMAL READ ENTRY POINT. READS FROM WAITS FOR BEGINNING OF PATTERN, AND D DATA READ FROM CASSETTE ON THE SCREEN PERFE CORE ALTERNATE READ ENTRY POINT. READS FRO AND DISPLAYS DATA ON THE SCREEN PEXEC COIC e-- VISUALLY INSPECT DATA ON SCREEN. YOU S INCREMENTING PATTERS FOR SIX LINES. THE HOR-OF EACH CHARACTER HUST NOT CHANGE. YOU WILL CHARACTER ALTERNATE FROM WHITE-OM-BLACK TO BL AT A BREE BR 1200 BAUD MATE. CHECK FOR CHARAC SEUDENCE. GET TAPE DATA PUT IT ON THE SCREEN COMPUTE SCREEN POSITION MOV SBI JHZ HVI IN ANI CHECK FOR CHARACTERS OU GO GET MORE DATA SET SCREEN OVERFLOW GET TAPE STATUS AND WALT FOR RDA






© 1975

PROCESSOR TECHNOLOGY CORP.

BERKELEY, CALIF. 94710

Figure A




How to Jumper the 3P+S for Use with CUTER

Figure A shows the 3P+S jumpered for use with the CUTER* operating system with a parallel keyboard and ASR-33 teletype.

The teletype is accessed as the serial pseudoport, PORT #1.

The keyboard is the normal pseudoport #Ø input device. Note that keyboard strobe signal is high until a key is pressed, then goes low for approximately 1 microsecond. If the pulse width of the strobe is greate that the time it takes to process the keyboard information (about 20 microseconds), the system will not worlied.



Software Techniques: The Care and Feeding of Cassette Tape Systems

Dropped bits! Yes, the symptoms of a malnourished cassettte system can be pretty ugly, but they can be avoided by paying proper attention to all three basic elements of your setup — the cassette, the tape machine, and the most important of all, the human element. Follow these tips, and you'll find that the handling and maintenance routine for 'assette system is fairly simple — bu — ch out if it isn't observed!

he cassette. Blank cassettes range in price from under 50¢ to well over \$2. The more expensive ones have better audio fidelity, but that may or

may not be relevant to your needs for recording digital data. Only trial and error will give you the experience for selecting the most suitable tape, so run some tests using inexpensive cassettes; if cost is no object, you may want to try some of the more expensive ones as well. Record a few long files (program or data) and then check for read errors. (Pat Tuell's program is designed for just this.) If you have friends with experience in recording programs, by all means ask them for brand recommendations.

Length is something to consider too. A C40 cassette provides about 20 minutes of recording time per side, and at 1200 baud (120 characters per second), each minute is about 7K bytes. Think about it. Are you likely to record 140K bytes of data? If not, a C30 cassette (15 minutes a side) is quite adequate and less expensive.

Finally, a word about care. A cassette appears to be durable and impervious to the elements — quite the contrary. They can be crushed or broken, and they seem to act like a magnet for ashes, dirt and liquids. Always keep them in their protective plastic covers when they're not in use, and never leave them lying around loose.

The tape machine. Again, you may not need the high audio fidelity standards of the most expensive decks, in fact hi fi cassette units may not work as well as ordinary portable machines. You should choose a reliable, well-made machine that will keep the tape moving smoothly at a constant speed. We highly recommend the Panasonic RQ-413AS, retail list \$89.95. Some features that are especially helpful (though not absolutely necessary) for digital data recording:

An AUX recording input to facilitate hookups A tone control

A digital counter to help you locate files on the tape

A review feature for fast forward or rewind while you're listening to the tape (again, to facilitate finding files).

You. It's not just the equipment and the tape that make a good cassette memory system, but what you do and how you do it. Here are some ideas to help you get the most from your system.

After you've recorded a tape, set the digital counter to zero and issue a CAT command (tape catalog — SOLOS/CUTER command). As each file header is displayed, make a note of the reading on the digital counter, the exact file name, load address and file length. Label the cassette with this information. Then later you won't have to wonder where each file begins, where it will normally be loaded, or how much memory is required.

If you're putting more than one

file on a tape side, save a special file (we use the name END for it) at the end of the last one. It will let you know when you've gone past the recorded portion in reading back.

When you're recording data, make sure that the volume control is set at the proper level — about 2/3 of full volume on many portable machines, but you should experiment to find the best setting for yours. If the volume is too high, the signal may be distorted; but believe it or not, one of the most common causes of playback problems is simply not having the volume control turned up. If you have a tone control, it should be adjusted for maximum frequency response.

Take good care of your machine. Clean the tape heads every so often, because dirty heads are a good way to introduce random read errors. Make sure all cables are properly connected — a common source of problems.

And finally, make sure that the machine is set to "Record" when you're saving programs or data onto tape. Sounds elementary, but everybody has had the experience of forgetting and kicking himself for it at least once!

SOLOS Unveiled

Printed below is the entire 2048 byte SOLOS program which is the standard operating system for a Sol computer and its peripherals.

In this listing you will find a useful library of pre-written routines for developing your own programs. Included are input/output routines for all the ports, load and save routines for cassette tape, and string processing routines.

Furthermore, this listing is the best way we know to demystify SOLOS and give you the inside scoop on how it really works. The program is well written (if we don't say so ourselves), highly compact, and provides a standardized software and hardware interface between all of the Sol's internal circuitry and many external peripheral devices. We hope you will find the programming techniques it incorporates valuable.



ACCESS, JUNE, 1977 • 11

```
PROGRAM DEVELOPMENT SYSTEM
                                                                                                                                                                                                                                     SOFTWARE TECHNOLOGY CORP.
P.O. BOY 5260
SAN MATEC, CA 94402
 SOLOS(TM) 77-03-27
COPYRIGHT (C) 1977
                                                                                                                                                                               9999
0002 •
0003 •
0004 •
0005 •
0006 •
0007 •
                                                                                                                                                                                                                                                                             COPY SOLOS1/1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     SERIAL INPUT DRIVER
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              0152 ° 0153 SSTAT IN 0154 ANI 0155 ANI 0155 ANI 0155 ANI 0155 ANI 0156 ANI 
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     SERST GET SERIAL STATUS WORD
SDR TEST FOR SERIAL DATA PEADY
PLAGS ARE SET
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                CO47 DB F9
CO49 C9
                                                                                                                                                                     0015 * DOTE: CONSOL, SOLOS AND SOLED ARE REGISTERED OD16 * TRADEMARKS OF: PROCESSOR TECHNOLOGY CORP. OD16 * PROCESSOR TECHNOLOGY CORP. OD16 * PROPERTY TILLE, CALIF OD17 * PRESENCE OF CORP. OD17 * 
                                                                                                                                                                                                                                                             NOTE: CONSOL, SOLOS AND SOLED ARE REGISTERED TRADEMARKS OF:
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              SERIAL DATA OUTPUT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   SERST GET PORT STATUS
PUT HIGH BIT IN CARRY
SOROT LOOP UNTIL TRANSMITTER RUFFER IS EMPTY
A,B GET THE CHARACTER BACK
SEND IT OUT
AND WE'RE DONE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                COMA DB F8
COMC 17
COMD D2 MA CO
CO50 78
CO51 D3 F9
CO53 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               WIDEO DISPLAY ROUTINES
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              THESE ROUTINES ALLOW FOR STANDARD VIDEO TERMINAL OPERATIONS. ON ENTRY, THE CHARACTER FOR OUTPUT IS IN REGISTER B AND ALL REGISTERS EXCEPT "A" AND FLAGS APFUNALTERED ON RETURN.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          0183 * 0183 * 0183 * 0183 * 0183 * 0185 * 0185 * 0185 * 0185 * 0186 * 0187 * 0186 * 0187 * 0186 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 0187 * 01
 C000 00
C001 C3 AF C1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                C054 E5
C055 D5
C056 C5
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             SAVE MOST REGISTERS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              TEST IF ESC SEQUENCE HAS BEEN STARTED
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  C057 3A 0C C8
C05A B7
C05B C2 5F C1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     ESCFL GET ESCAPE FLAG
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       ESCS IF NON ZERO GO PROCESS THE REST OF THE SPOUFNCE
C004 C3 C9 C1
C007 C3 E0 C5
C00A C3 O3 C6
C00D C3 46 C6
C010 C3 83 C6
C013 C3 CB C6
C016 C3 7F C7
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     A.B SAVE IN B...STRIP PARITY REFORE SCREEN:
TEH CLP PARITY TO LOCATE IN THE
B.A REPORT TWO PARITY IN B TOO
GORK DO A OUICE EXIT IF A NULL
H.TBL POINT TO SPECIAL CHARACTER TABLE
TSRCH GO PROCESS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                C05E 78
C05F E6 7F
C061 47
C062 CA 7C C0
C065 21 73 C2
C068 CD 82 C0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              COGB CD 1C C1
COGE 7E
COGF 76
CO71 77
COT2 2A OA CB
CO75 2C
CO76 AF
CO77 2B
CO76 BC
CO76 C2 77 CO
CO7C C1
CO7D D1
CO7F C9
CO7F C9
CO7F C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             VDADD GET SCREFN ADDRESS
ALM GET PRESENT CURSOP CHARACTEP
BOH
GET GET DELAY SPEED
L MAKE SUPF, 77 12 MON-ZEPO
A DELAY WILL END WHEN H-O
H THEP DELAY SIFEP,
H DONE WITH DELAY SIFEP
BD RESTORE PROISTERS
H
EXIT FROM YDMOT
                                                                                                                                                                     OOS - AIMP/AOUT REC -A" MUST BE SET PT THE USER AND W. OOS - OOS - SPECIFY THE DESIPED PSEUDO POPT.

OOS - SPECIFY THE DESIPED PSEUDO POPT.

OOT - PORT DESCRIPTION

OOT - PORT DESCRIPTION

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KTOOL WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KTOOL WHEN OUTPUT

OOT - O KTOOL WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KETBOARD WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KTOOL WHEN IND WHEN INPUT, AND VDM WHEN OUTPUT

OOT - O KTOOL WHEN INDUT, AND 
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         EXIT FROM VDMOT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    THIS ROUTINE SEARCHES THROUGH A SINGLE CHARACTER TABLE FOR A MATCH TO THE CHARACTER IN THE TERM A DISPARCH IS MADE TO THE ADDRESS FOLLOWING THE WATCHARACTER. IF NOT FOUND THE CHARACTER IS DISPLAYED THE MONITOR.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          0225 THE MONITOR
0226 THE MONITOR
0227 TSRCH MOV
0228
0230 ORA
0231 INX
0232 CMP
0233 PUSH
0235 CALL
0235 INH
0236 PUT CPI
0236 PUT CPI
0242 RZ
0243 PUT CPI
0242 RZ
0243 PUT CPI
0242 RZ
0243 PUT CPI
0255 CHAP MOV
0246 MOV
0246 CALL
0255 CHAP CALL
0256 SCROLL XRA
0256 SCROLL XRA
0257 END OF SI
0258 SCROLL XRA
0260 SROLL 
 C022 E5
C023 21 9A C2
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                C082 7E
C083 87
C084 CA 94 CO
C087 88
C088 23
C089 C2 80 CO
C08C E5
C08D CD 36 C1
C090 E3
C090 C3 27 C2
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   A.M GET CHR FROM TAB!
A CHAR ZERO IS THE LAST
B TEST THE CHP
POINT FORMARD
MEXT
H FOUND ONE SAVE
                                                                                                                                                                                                                                         THIS ROUTINE PROCESSES THE I/O REDUESTS BY DISPATCHING TO THE DRIVE" REQUESTED IN REGISTER "A". ON ENTRY HL HAVE THE PROPER DISPATCH TABLE.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     MEXT
H FOUND ONE...SAVE ADDRESS
CREM PEMOVE CURSOR
GET DISPATCH ADDRESS TO HL
DISPT DISPATCH NOW
C026 E6 03
C028 07
C029 85
C024 6F
C02B C3 27 C2
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            PUT CHARACTER TO SCREEN
                                                                                                                                                                             U102 *

THIS ROUTINE IS A MODEL OF ALL INPUT ROUTINES WITHIN O104 *

SOLOS. EACH ROUTINE FIRST TESTS THE STATUS IMPUT FOR D105 *

DATA AVAILABLE. IF NO CHARACTER HAS BEEN RECIIVED THE O106 *

ROUTINE RETURNS WITH THE ZERO FLAG SET. OTHERWIST THE O107 *

CHARACTER IS IMPUT AND A RETURN MADE WITH THE CHARACTER O108 *

IN THE ACCUMULATOR AND THE ZERO FLAG RESET.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       # ACTUALLY PUT CHAP TO SCREEN NOW WDADD GET SCREEN ADDRESS M.B PUT CHE ON SCREEN
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          EQU
CALL
MOV
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  C098
C098 CD 1C C1
C09B 70
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     NCHAR
63
OK
LINE
15
OK
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                CO9C 3A 08 C8
CO9F FE 3F
COA1 DA C1 C0
COA4 3A 09 C8
COA7 FE 0F
COA9 C2 C1 C0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             END OF SCREEN?
                                                                                                                                                                                                                                                                                                                                   STAPT GET STATUS WORD
. INVERT IT FOR PROPER RETURN
KDR TEST KEYBOARD BIT
. ZERO IF NO CHARACTER RECEIVED
                                                                                                                                                                                                                       KSTAT IN CMA ANI RZ
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        END OF SCREEN... ROLL UP ONE LINE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                COAC AF
COAD 32 08 C8
COBC AF
COB1 CD 23 C1
COB4 AF
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         C.A VDAD CALCULATE LINE TO BE BLANKE
                                                                                                                                                                                                                                                                                                                                     KDATA GET CHARACTER
GO BACK WITH IT
 C034 DB FC
C036 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                COB4 AF
COB5 CD FA CO
COB8 3A OA C8
COBB 3C
COBC E6 OF
COBE C3 EE CO
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                CALL
LDA
INP
ANI
JMP
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       CLIN1 CLEAR IT
                                                                                                                                                                                                                                                             THIS JUMP IS PART OF THE AUTO START UP CODE
                                                                                                                                                                                                                                                                                                                                                                             WERIFY ADDR=C037 SO WEXT INSTRUCTION IS AT C038
                                             3 01 CO
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      INCREMENT LINE COUNTER IF NECESSARY
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                COC1 3A 08 C8
COC4 3C
COC5 E6 3F
COC7 32 08 C8
COCA C0
COCB
COCB C8
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  0271 °
0272 OK
0273
0274
0275
0276
0277 PDOWN
0278
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       MCHAR GET CHR POSITION
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            LDA
INR
ANI
STA
RNZ
                                                                                                                                                                                                                                       THIS ROUTINE SETS UP THE DISPATCH TABLE FOR OUTPUT ROUTINES. THE CHARACTER FOR OUTPUT IS IN REGISTER "A". OUTPUT IS MADE TO THE DRIVER POINTED TO BY THE REGISTER "A". THE DEVICE DRIVERS ARE DEFINED AS FOLLOWS:
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           DIDN'T HIT END OF LINE, O
CURSOR DOWN ONE LINE HERE
GET THE LINE COUNT
```

ACCESS, JUNE, 1977 • 12

9	m	-	4 2
	EPT	,	43

0423 * TAB ABSOLUTE TO VALUE IN REG B

COD1 32 09 C8 028 COD4 C9 028 028	O CURSC ANI OPH MOD 15 INCREMENT 1 CUR STA LINE STORE THE NEW 2 RET 3 9 4 REASE SCREEN	C188 78 0425 C189 C3 OF C1 0426 0427	5 SETX MOV A,B GET CHARACTER 5 JMP PCUR 7 8 3 ° SET CURSOR TO LINE "B"
	8 •	C18C 78 0430 C18D C3 CP C0 0431 0432 0432	D SETY MOV A,B JMP CURSC
CODE 23 029 CODE 7C 029 CODE 7C 029 CODE 1A DB CO 029 COE1 DA DB CO 029 COE4 37 029	O ERASI EQU S LOOPS HERE TO ERASE SCREEN MY M, M, BLANK IT OUT 1 INX H WEXT 3 MOV A, H SEE IF EWD OF SCREEN YET 4 CPI ODOH 7 5 JC ERASI NOKEEP BLANKING	04 34 04 35 04 35 04 35 04 35 04 35 04 35 04 36 04 36 04 36 04 37 04 38 04 37 04 38 04 39	N PROCESS SECOND CHR OF ESC SEQUENCE SECOND MOV A,B GET WHICH C CFI 3 JZ CURET RETURN CURSOP PARAMETERS C CFI 4 J JMZ ARET2
029	7 0 6 PHOME MYI A, C RESET CURSORCARRY-ERASE, ELSE HOME 9 STA LINE ZERO LINE 10 0 STA BCHAR LEFT SIDE OF SCREEN	0441 0442 0443 C19B 44 0444 C19C 4D 0445	P ESC (4) RETURN ABSOLUTE SCREEN ADDRESS ARET MOV B,H
COEE D3 FE 030 COFO 32 OA C8 030 COF3 C9 030	2 6 3 ERAS3 OUT DETAT RESET SCHOLL PARAMETERS 4 STA BOT BEGINNING OF TEXT OFFSET 5 RET	0446	ARETI POP H RETURN ADDRESS A POP D OLD B PUSH B
030 030 030 0077 3A 08 C8 030 COFA FE 40 031 COFC DO 031	7 8 CLIME CALL VDADD GET CUPRENT SCREEN ADDRESS 9 LDA MCHAR CUPRENT CUPSOR POSITION 0 CLIN1 CPI 68 MO MORE THAN 63	C1A1 AF 0451 C1A2 32 OC C8 0452 C1A5 C9 0A53 0A54 0A55	XRA A 2 ARET2 STA ESCFL 3 RET
COFE 36 2D 031 COFF 23 031 C100 3C 031 C101 C3 FA C0 031	2 MYI M, ALL SPACED OUT 3 INX M 4 INP A 5 JMP CLIN1 LOOP TO END OF LINE 6 *	C1A9 46 0459 C1AA 23 0460	S CURET LXI H. MCHAR O NOV B. H CHARACTER POSITION INX H
C1D4 3A D9 C8 032 C1D7 3D 032	8 * ROUTINE TO MOVE THE CURSOR UP ONE LINE 9 * 0 PUP LDA LINE GET LINE COUNT 1 DCR A	C1AB 4E 0461 C1AC C3 9D C1 0462 0463 0464 0465	JMP ÅRET1
C108 C3 CF C0 032 032 032 032	2 JMP CURSC MERGE TO MANDLE CURSOR 3 * MOVE CURSOR LEFT ONE POSITION	0469	CLEAR SCREEN AND THE FIRST 256 BYTES OF GLORAL RAM THEN ENTER THE COMMAND MODE.
C10E 3D 032 C10F 032 C10F E6 3F 032 C111 32 08 C8 033	7 DCF A 8 PCUR EOU \$ CURSOR ON SAME LINE 9 ANI 3FH LET CURSOR WRAP 0 STA MCHAR UPDATED CURSOR	C1B0 4F 0471 C1B1 21 00 C8 0472 0473	MOV C.A. 9 III H.SYSRAM CLEAR THE FIRST PAGE 1 CLERA MOV M.A.
033 033 033	2 6 3 CURSOR RIGHT ONE POSITION 4 6 5 PRIT LDA MCHAR	C1B6 OC	6 IMP C 7 JM2 CLERA 8 LXI SP.SYSTP SET UP THE STACP FOR CALL
C118 3C 033 C119 C3 OF C1 033 033 034	7 JMP PCUR 6 POUTINE TO CALCULATE SCREEN ADDRESS 0 POUTINE TO CALCULATE SCREEN ADDRESS	C1C1 D3 FA	1 COMMI XRA A OUT STAPT BE SURE TAPES ARE OFF 3 STA OPORT 4 STA IPORT
034 034 034 034 034	2 0 3 0 VDADD CURRENT SCREEN ADDRESS 4 0 VDAD2 ADDRESS OF CURRENT LINE, CHAR 'C'	0485 0486 0486 0488	6 0 7 0 8 0 s COMMAND MODE= 9 0
C1' 29 CB 034	7 VDADL LDA MCHAP GET CHARACTER POSITION 8 VDADP LDA LINE LINE POSITION 10 VDAD HOV L.A LINE POSITION 11 LDA BOT GET TEXT OFFSET 12 ADD L ACTIVES TO THE LINE POSITION 13 ADD L TIMES TO THE LINE POSITION 14 BEC . MAKES FOUR 15 HOV L.A L HAS IT 16 ANI 3 HOD THREE FOR LATER 17 ADI «VDMEH LOW SCREEN OFFSET 18 HOV H.A NOW H IS DONE 19 MOV A.I TWIST L'S ARM	0 A90	THIS ROUTIME GETS AND PROCESSES COMMANDS THIS ROUTIME GETS AND PROCESSES COMMANDS THIS PROPERTY OF THE PROPE
C133 81 036 C134 6F 036 C135 C9 036 036	1 ADD C 2 MOV L.A 3 RET . H & L ARE NOW PERVERTED 4 ** ROUTINE TO REMOVE CURSOR	0505 0506 0507 0508	5 • 6 • THIS ROUTINE READS A COMMAND LINE FROM THE SYSTEM 8 • KEYBOARD
C139 7E 036 C13A E6 7F 036 C13C 77 0370	7 CRE CALL VOADD GET CUPRENT SCREEN ADDRESS 6 6 ANI 7FH STRIP OFF THE CUPSOR 0 MOV M.A.	0510 0511 0512 0513 0514	O * C/F TERMINATES THE SEQUENCE ERASING ALL CHARS TO THE 1 * RIGHT OF THE CURSOR 2 * L/F TERMINATES THE SEQUENCE 3 * MODE RESTARTS THE COMMAND LINE. 6 **
C13D C9 037: 037: 037: 037: 037: 037: 037: 037:	PBACK CALL PLEFT CALL VEDOD GET SCREEN ADDRESS HVI M, PUT A RLAWK THERE	C1E2 CD 1F CO 0515 C1E7 CA E4 C1 0516 C1EA E6 7F 0517 C1EC CA CO C1 0518 C1EF 47 0519 C1F0 FE 0D 052C C1F2 CA F4 CO 0521 C1F7 CB 0522 C1F7 CB 0522	7 ANI TER CLEAR PARITY BIT B JZ COMNI THIS WAS A MODE (OR EVEN CTL-#! 9 MOV B.A 0 CPI CR CARRIAGE RETURN 1 JZ CLINE YESDOME WITH LIME 2 CPI LFW FEEE
C14A C3 OF C1 0384 0385	PCR CALL CLINE CLEAR FROM CURRENT CURSOR TO END OF LINE PEG A COMES BACK W/6% AND WILL BE CLEARED BY PCUR JMP PCUR AND STORE THE NEW VALUE	C1F8 FE 7F 0524 C1FA C2 FF C1 0525 C1FD 06 5F 0526 C1FF CD 19 C0 0528 C202 C3 E4 C1 0529	5 JNZ CONT 6 MVI B, BACKS REPLACE IT 7 B 6 CONT CALL SOUT
0366 0367 0367 0367 0367 0367 0367 0367	PLF LDA LINE GET LINE COUNT INR A ANI 15 SEE IF IT WRAPPED AROUND JNZ CUR MONO MEED TO SCROLL JMP SROL YESTHEN SCROLL	0530 0531 0533 0533 0533 0533 0533 0533	0 0 1 0 2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
C159 3E FF 0396 C15B 32 OC C8 0397 C15E C9 0398	PESC MYI A1 STA ESCFL SET FLAG RET	C20E 21 00 C0 0538 C211 E5 0538 C212 CD 2E C3 0540 C215 CA 80 C4 0541 C218 EB 0542	9 PUSH H SAVE IT FOR LATER DISPT 0 CALL SCHR SCAN PAST BLANKS 1 JZ ERR! HO COMMAND? 2 XCHG HL MAS FIRST CHR
C162 CD 68 C1	ESCS CALL CREM REMOVE CURSOR CALL SCSP PROCESS THE WEXT PART OF SEQUENCE GOBACK ESCSP LDA ESCPL GET ESCAPE FLAG CPI -1 TEST FLAG	C219 11 4A C2 0544 C21C CD 31 C2 0545 C21F CC 2E C2 0546	E LXI D.COMTAR POINT TO COMMAND TARLE 5 CALL FDCOM SEE IF IN PRIMARY COMMAND TARLE 6 CZ FDCOU IF MOT, TRY CUSTOM TABLE MEXT 7 DISPO EQU S MEME TO SEE IF ERROR OR DISP 8 JZ ERR2 MOT VALID, ERROR 9 INX D BOWP TO PTR OF RTN 0 XCRG . HL PT TO RTN ADDR
C16D CA 90 C1 0408 0409 0410 C17 C8 0412	JZ SECOND PROCESS THIRD CHR OF ESC SEQUENCE	0552 0553 0554	2 • 3 • THIS IS THE DISPATCH ROUTINE. A • HL PT TO BTN ADDRESS, ML WILL BE RESTORED PM STACK 5 • 30 THAT HL ARE RESTORED BEFORE DISPATCH.
C172	WYI M.O. NO MORE PAPTS TO THE SEQUENCE CPI 2 JC SETX SET X IF IS ONE JZ SETY SET Y IF IS TWO CPI 8 JZ STSPD SET NEW DISPLAY SPEED IF "8" CPI 9 JC OCHAP PUT IT ON THE SCREEN	C227 0557 C227 7E 0558 C228 23 0559 C229 66 0560 C22A 6F 0561	7 DISPT EQU \$ OFF TO A ROUTIME MOV A,M LO ADDR 0 MOV H,M HI ADDR 1 MOV L,A HI MOV COMPLETE 2 DISP1 EQU \$ MERE TO GO OFF TO HL 3 XTHL . XCMC HL W/HL ON STACK 4 MOV A,L ALSO COPY HERE FOR SFTS

```
| OSA 
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | OTTO | 
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 C2DE E3
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   ADDRESS TO STACK ... OLD HL TO HL
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                :
                                                                                                                                                                                                                                          THIS ROUTINE SEARCHES THROUGH A TABLE, POINTED TO BY 'DE', FOR A DOUBLE CHARACTER MATCH OF THE 'HL' MEMORY CONTENT. IF NO MATCH IS FOUND THE SCAN EMDS WITH HL POINTING TO ORIGINAL VALUE AND ZERO PLAG SET.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       COPY
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              S0L032/1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    THIS ROUTINE IS THE PARALLEL DEVICE HANDLER NO PROVISION IS MADE FOR CONTROLLING THE PORT CONTROL BIT.
                                                                                                                                                                                                                                                                                                                                  D. CUTAB HERE TO SCAN CUSTOM THE ONLY
     C22E 11 3C C8
 C231 1A
C232 B7
C233 C8
C234 E5
C235 BE
C236 13
C237 C2 43 C2
                                                                                                                                                                                                                                                                                                                                                                                         TEST FOR TABLE END
NOT FOUND...COMMAND ERROR
SAVE START OF SCAN ADDRESS
TEST FIRST CHR
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               PARALLEL IMPUT DRIVER
                                                                                                                                                                                                                                                                                                                                H
M
D
NCOM
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             C2DD DB FA
C2DF 2F
C2EO E6 O2
C2E2 C8
C2E3 DB FD
C2E5 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        STAPT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        INVERT STATUS PLACS
PDR TEST BIT
WITH PLAC SET
PDATA GET DATA
 C23A 23
C23B 1A
C23C BE
C23D C2 43 C2
                                                                                                                                                                                                                                                                                                                                H
D
W
WCOM
                                                                                                                                                                                                                                                                                                                                                                                       NOW SECOND CHARACTER GOODNESS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      PARALLEL OUTPUT HANDLER
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             C2E6 DB FA
C2E8 E6 04
C2EA C2 E6 C2
C2ED 78
C2EE D3 FD
C2F0 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        STAPT GET STATUS
PXDR TEST IF DEVICE IS READY
PROUT LOOP UNTIL SO
A, B
PDATA
 C240 E1
C241 B7
C242 C9
                                                                                                                                                                                                                                                                                                                                                                                       RESTORE ORIGINAL SCAN ADDR
SET NON-ZERO FLAG SAYING FOUND
WITH NON-ZERO SET
C243 13
C244 13
C245 13
C246 E1
C247 C3 31 C2
                                                                                                                                                                                                                                                                                                                                000:
                                                                                                                                                                                                                                                                                                                                                                                       GO TO NEXT ENTRY
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     OUTPUT A CRLF POLLOWED BY A PROMPT
                                                                                                                                                                                                                                                                                                                                  H GET BACK ORIGINAL ADDRESS
FDCOM CONTINUE SEARCH
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             PROMPT CALL CRLP
MVI B,'>' THE PROMPT
JMP SOUT PUT IT ON THE SCREEN
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           C2F1 CD F9 C2
C2F4 06 3E
C2F6 C3 19 C0
                                                                                                                                                                                                                                                                                                                                                                     COMMAND TABLE
                                                                                                                                                                                                                                        THIS TABLE DESCRIBES THE VALID COMMANDS FOR SOLOS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               MVI
CALL
CALL
OUTPUT
LDA
MOV
DCR
RM
XRA
CALL
JMP
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      R.LF LIME FEED
SOUT
B.CR CARFIAGF RETURN
SOUT
THE NULLS
NUCHT GET DESIRED COUNT
C.A STORE IN C
EPTIEN WEEN PAST
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          C2F9 06 0A
C2FB CD 19 C0
C2FE 06 0D
C300 CD 19 C0
                                                                                                                                                                                                                                                                                                                            TE TERMINAL MOD
TERM
DU DUMP
DUMP
ENTE
ENTE
EXEC
GE GET A FILE
TLOAD
SA SAVE A FILE
TXEO
XE YEE (KECUTE
TXEO
C303 3A 10 C8
C306 4F
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          C307 OD
C308 F8
C309 AF
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        A
OUTH
NULOT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             RETURN WHEN PAST 7580
GET A NULL
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           C30A CD 1F C4
C30D C3 07 C3
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        OTSS SCAN OFF OPTIONAL PREMETTS. IT PRECENT SCHIBM WITH OTSS SCAN OFF OPTIONAL PREMETTS. IT PRECENT SCHIBM WITH OTSS SCAN OFF OPTIONAL PREMETTS. IT PRECENT SCHIBM WITH A STATE IN "A" AND ML UNTOLOUGH.

OTSS RELL SHE CONTROL OFF OF L" IN "S" IT WIT PRECENT OTSS WILL AND COPY OF L" IN "S" IT WIT PRECENT OTSS WILL AND COPY OF L" IN "S" IT WITH OTSS WILL AND COPY OF LOWER MALE OTSS RELL AND COPY OF LOWER MALE OF LOWER MALE OTSS RELL AND COPY OF LOWER MALE OF
                                                                                                                                                                                                                                                                                                                            TSAVE
XE' XEQ (EXECUTE) A FILE
TXEO
CATALOG OF FILES
TLIST
SE' SET COMMAND
SET
CU' CUSTOM COMMAND
CUSTOM COMMAND
USTOM COMMAND
END OF TABLE MARK
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          SCAN OFF OPTIONAL PARAMETER. IF PRESENT BETHEN WITH VALUE IN HL AND COPY OF "L" IN "A". IF NOT PRESENT RETURN WITH A "1" IN "A" AND HL UNTOUCHED.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        C310 CD 1B C3
C313 3E O1
C315 C8
C316 CD 40 C3
C319 7D
C31A C9
                                                                                                                                                                                                                                                                                                                                              DISPLAY DRIVER COMMAND TABLE
                                                                                                                                                                                                                                        THIS TABLE DEFINES THE CHARACTERS FOR SPECIAL PROCESSING. IF THE CHARACTER IS NOT IN THE TARLE IT GOES TO THE SCREEN.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        C31B DE OC
C31D 1A
C31E FE 20
C32D CA 2E C3
C323 13
C324 FE 3D
C326 CA 2E C3
C329 OD
C32A C2 1D C3
C32D C9
                                                                                                                                                                                                                                                                                                                            E SCREW.

CLEAR-BOM SCREEN
PERSE
UP-BOH CURSOR
PUP-BOH
DOWN-BOH
POWN-BOH
PRIT
HOME-BOH
PRIT
CR CARFIAGE RE
PCR
LF LINE FEED
PLF BACKS PAGE
PBACK
ESCAPE REY
PESC
UND OF TARL
C273 OB C274 D5 C0 C274 D5 C0 C274 D5 C0 C275 OA C1 C277 OA C1 C277 OB C1 C277 OB C1 C277 OB C285 OD C286 OA C286 OA C286 OA C286 OA C286 OA C288 OA C
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          C32E DE DA
C330 1A
C331 FE 20
C333 C0
C334 13
C335 DD
C336 C8
C337 C3 30 C3
                                                                                                                                                                                                                                                                                                                                                                             CARRIAGE RETURN
                                                                                                                                                                                                                                                                                                                                                                                   END OF TARLE
                                                                                                                                                                                                                                                                                               OUTPUT DEVICE TABLE
C292 54 C0
C294 4A C0
C296 E6 C2
C298 D2 C2
                                                                                                                                                                                                                                                                                                                                VDMOT VDM DRIVER
SDROT SERIAL OUTPUT
PROUT PARALLEL OUTPUT
ERROT ERROR OR USER DRIVER HANDLER
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           C33A CD 1B C3
C33D CA 80 C4
                                                                                                                                                                                                                                                                                               INPUT DEVICE TABLE
                                                                                                                                                                                                                                                                                                                            KSTAT REYBOARD IMPUT
SSTAT SERIAL IMPUT
PASTAT PARALLEL IMPUT
ERRIT ERROR OR USER DRIVER HANDLER
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          C340 21 00 00
C343 1A
C344 FE 20
C346 C8
C347 FE 2F
C349 C8
C347 C8
C34C C8
                                                                                                                                                                                                                                                                                 SECONDARY COMMAND TABLE FOR SET COMMAND
C2A2 58 81
C2A4 85 53 3D
C2A6 53 3D
C2A6 99 3D
C2AC 9P C5
C2AC 9P C5
C2AC 9P C5
C2BC AF C5
C2CC BF C5
C2CC BF C5
C2CC AF 
                                                                                                                                                                                                                                                                                                                              SET DISPLAY SPEED
                                                                                                                                                                                                                                                                                                                        C34D 29
C34E 29
C34F 29
C35F 29
C35D 29
C35A D2 80 C4
C357 85
C358 6F
C359 13
C35A C3 43 C3
                                                                                                                                                                                                                                                                                                                                                                                     SET CUSTOM OUTPUT DRIVER ADDRESS
                                                                                                                                                                                                                                                                                                                                  SETCO
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          C35D D6 30
C35F FE OA
C361 D8
C362 D6 O7
C364 FE 10
C366 C9
                                                                                                                                                                                                                                                                                                                                                                                   SET HEADER KEQ ADDRESS
                                                                                                                                                                                                                                                                                                                                SETTY
SETTY
CR
                                                                                                                                                                                                                                                                                                                                                                               SET HEADER TYPE
                                                                                                                                                                                                                                                                                                                                                                                 SET CRC TO ALLOW IGNORING OF CRC ERRORS
                                                                                                                                                                                                                                                                                                                                  SETCR
0
                                                                                                                                                                                                                                      SOLOS PORT ERROR HANDLER
                                                                                                                                                                                                                                                                                                                                H SAVE HL ONCE AGAIN
UIPRT GET USER INPUT PORT ADDRESS
ERRO1 AND GO PROCESS
   C2CB E5
C2CC 2A 00 C8
C2CF C3 D6 C2
C2D2 E5
C2D3 2A 02 C8
C2D6 7D
C2D7 B4
C2D8 CA CO C1
                                                                                                                                                                                                                                                                                                                              H
DOPAT GET USER OUTPUT PORT ADDRESS
A, L
TEST HL FOR ZERO
H
COMM1 IF ZERO RETURN TO COMMAND MODE
 ACCESS, JUNE, 1977 • 14
```

```
CALL POLY PROPERTY PARAMETERS TO PROPERTY OF THE CONTROL CONTROL OF THE CONTROL CONTRO
                    C367 CD 10
C36A 32 OF
C36D CD 10
C37O 32 O7
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      ENLOP LAST ENTRY FOUND START NEW LINE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           CA4A PE 2F
CA46 CA CO C1
CA49 CD AO C3
CAAC FE 3A
CA4C FE 3A
CA55 T7
CA53 T7
CA53 T7
CA55 E5
CA56 C3 3C C4
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   CPI
JZ
CALL
CPI
JZ
MOV
POP
MOV
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          COMMAND TERMINATOR?
IF SO...RETURN TO STANDARD INPUT
CONVERT VALUE
ADDRESS TERMINATOR?
GO PROCESS IF SO
GET LOW PAPT AS CONVEPTED
GET MEMORY ADDRESS
PUT IN THE VALUE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                COMN 1
              ENLO3
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   M,A
H
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                H BACK GOES THE ADDRESS
ENLO1 CONTINUE THE SCAN
     SOUT OUTPUT IT TO THE SERIAL PORT SINP OFT INPUT STATUS
TEPM! LOOP IF NOT
TFH NO HIGH BITS FROM HERE
TEPM! A NULL IS IGNORED
TERM? NO HOR SIS THEN IS IT A CONTROL CHAR TO BE IGNORED
TERM? NO --TO YOM AS IS THEN
CR CF OR LF ARE SPECIAL CASES THOUGH
TERM? AND MUST BE PASSED STO MODE TO YOM DRIVER
LF TERM?
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           CA59 E3
CA5A 13
CA5B C3 3C CA
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             PUT NEW ADDRESS ON STACK
MOVE SCAN PAST TERMINATOR
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  EXECUTE COMMAND
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            THIS ROUTINE GETS THE FOLLOWING PARAMETER AND DOES A PROGRAM JUMP TO THE LOCATION GIVEN BY IT. IF PROPER STACK OPERATIONS ARE USED MITHIN THE ESTENNAL PROCESSAIL CAN BE STANDING ADDRESS OF SOLOS IS PASSED TO THE PROGRAM IN RECISIES PAIR H. SO IT CAN ADJUST INTERNAL PARAMETERS FOR SOLOS OPERATION.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  THIS NOUTINE CETS THE FOLLOWING PARAMETER AND DOES A
1013 * FROGRAN JUMP TO THE LOCATION GIVER BY IT. IF PROPER
1014 * STACE OPERATIONS ARE USED WITHIN THE ETTENAL PROPER
1015 * IT CAN DO A STACE OPERATION.
1016 * IT CAN DO A STACE OPERATION.
1017 * IX RECISEE PAIR H. SO IT CAN ADJUST INTERNAL PARAMETER
1018 * FOR SOLOS OPERATION.
1019 * IX RECISEE PAIR H. SO IT CAN ADJUST INTERNAL PARAMETER
1021 * EXEC.
1021 * EXEC.
1022 * LIX. H. STACE THE H. SO IT CAN ADJUST INTERNAL PARAMETER
1022 * LIX. H. STACE THE H. SO IT CAN ADJUST INTERNAL PARAMETER
1023 * LIX. H. STACE THE H. SO IT CAN ADJUST INTERNAL PARAMETER
1024 * LIX. H. STACE THE H. SO IT CAN ADJUST INTERNAL PARAMETER
1025 * LIX. H. STACE THE H. SO IT CAN ADJUST INTERNAL PARAMETER
1026 * LIX. H. STACE THE H. SO IT CAN ADJUST INTERNAL PARAMETER
1027 * THIS ROUTINE CETS AN HAME OF OUT TO CHARACTER
1028 * AND IT. STACE THE H. SO IT CAN ADDITE THE HEAD THE FROM THE CHARACTER FOLLOWING IS TAKEN
1031 * AS THE CASSETTE UNIT SPECIFICATION.
1031 * AS THE CASSETTE UNIT SPECIFICATION.
1031 * AS THE CASSETTE UNIT SPECIFICATION.
1032 * AS THE CASSETTE UNIT SPECIFICATION.
1033 * AS THE CASSETTE UNIT SPECIFICATION.
1034 * AND CASSETTE UNIT SPECIFICATION.
1035 * AND THE SECON TO FIRST CHAS
1036 * AS THE CASSETTE UNIT SPECIFICATION.
1037 * MANES LXI H. THEAD POINT TO INTERNAL MADER
1038 * AND CASSETTE UNIT SPECIFICATION.
1039 * AND THE CASSETTE UNIT SPECIFICATION.
1031 * MAY IN THE CASSETTE UNIT SPECIFICATION.
1031 * MAY IN THE CASSETTE UNIT SPECIFICATION.
1032 * FILL
1034 * MAY IN THE CASSETTE UNIT SPECIFICATION.
1034 * MAY IN THE CASSETTE UNIT SPECIFICATION.
1037 * AT THE CASSETTE UNIT SPECIFICATION.
1038 * AND THE CASSETTE UNIT SPECIFICATION.
1039 * MANES LESS THAN FILE CHARACTER.
1039 * MANE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             TERM2
ESCFL A CTL CHAR---ARE WF W/IN AN ESC SPOURMCFO
A IF YES, THEN OUTPUT CTL CHAR DIRECTLY TO VDM
TERM2 WE SURE ARE, LET VDM DYIVER HANDLE IT
B SAVE THE CHAR
B,ESC CTL CHAR TO VDM VIA FSC SEQUENCE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        C45E CD 3A C3
C461 E5
C462 21 00 C0
C465 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     C46E 1A
C46F FE 20
C471 CA 86 C4
C474 FE 2F
C476 C7 68 6 C4
C479 77
C47A 13
C47B 23
C47C 05
C47D C2 6E C4
     C3BF CD 3A C3
C3C2 E5
C3C3 CD 10 C3
C3C6 D1
C3C7 EB
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          NAME 1 FALL THROUGH TO ERR1 IF TOO MANY CHRS IN NA
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     C480 EB
C481 36 3F
C483 C3 C0 C1
     C3C8 CD F9 C2
C3CB CD E6 C3
C3CE CD 06 C4
C3D1 0E 10
C3D2 7E
C3D2 7E
C3D4 C5 ED C3
C3D6 7D
C3D7 7D
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     C486 36 00
C488 23
C489 05
C48A C2 86 C4
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  C48D FE 2F
C48F 3E 01
C491 C2 9A C4
C494 13
C495 CD 2E C3
C498 D6 30
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  C49A
C49A E6 01
C49C 3E 80
C49E C2 A2 C4
C4A1 1F
C4A2 32 54 C8
C4A5 C9
  C3E8 7C
C3E9 CD OB C4
C3EC 7D
C3EC 7D

C3EC CD 0B C4

C3F0 CD 1F C0

C3F3 CA 06 C4

C3F6 E6 7F

C3F6 E6 7F

C3F6 EA C9 C1

C3FB FE 20

C3FD C2 06 C4

C400 CD 1F C0

C403 CA 0C C4

C406 C3 19 C0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  C4A6 3E
C4A7 AF
C4A8 F5
C4A8 F5
C4A9 21 2C C8
C4AC CD 69 C4
C4AF 21 00 00
C4B2 CD 10 C3
C40B 4F
C40C 0F
C40D 0F
C40E 0F
C40F 0F
C410 CD 14 C4
C413 79
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               C4B5 EB
C4B6 21 2C C8
C4B9 7E
C4B8 B7
C4BB C2 C1 C4
C4BE 21 1C<sup>2</sup>C8
C4C1 E5
C4C2 CD 48 C5
C4C5 E1
C4C6 CD CB C6
C4C9 DA 14 C5
  CA14 E6 OF
CA16 C6 30
CA18 PE 3A
CA1A DA 1F CA
CA1D C6 O7
CA1F A7
CA20 C3 19 C0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            CACC CD 50 C5
CACF F1
CADD B7
CAD1 C6
CAD2 B7
CAD5 B7
CAD5 B7
CAD6 B7 18 C5
CAD6 B7 CAD6 C5
CAD6 B7 CAD6 C5
CAD6 B7 C
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 1120 • TP
1121 • TP
1122 •
1123 •
1124 TSAVE
1125
1126
1127
1128
1129
1130
1131
1132 •
  CA2B CD F9 C2
CA7 3A
CA FF C1
CA3 16 C1
CA3 C1
CA3
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               CAE6 CD 66 CA
CAE9 CD 3A C3
CAEC E5
CAED CD 3A C3
CAF0 E3
CAF1 E5
CAF2 CD 10 C3
CAF5 22 25 C8
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     NAMES
SCONV
H
SCONV
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         GET MAME AND UNIT
GET START ADDRESS
USE THE STACK AS A PROISTER
GET END ADDRESS
PUT END ON STACK, GET BACK STAPT
SAVE START ON TOP OF STACK
SEE IF OPTIONAL WEADER ADDRESS WAS GIVEN
PUT HEADER ADDRESS IN PLACE
     C43C OE 03
C43E CD 30 C3
                                                                                                                                                                                                                                                                       0989 ENLO1 MVI
0990 CALL
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        C,3 BO MORE THAN THREE SPACES BETWEEN VALUES SCHR1 SCAN TO WEXT VALUE
```

1 EPT 2 - 46

```
CAF8 E1
CAF9 D1
CAF9 D1
CAF8 F5
CAFC 95
CAFC 95
CAFC 6F
CAFE 7A
CAFF 9C
C500 67
C501 23
C502 22 23 C8
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               1273 RET
1274 SET TYPE BYTE INTO HEADER
1276 SET TYPE BYTE INTO HEADER
1276 RET
1278 RET
1279 SET EXECUTE ADDRESS INTO HEADER
1280 SET EXECUTE ADDRESS INTO HEADER
                                                                                                                                                                                                                                                                                                                         "FROM" ADDRESS TO HL
GET BACK "END" ADDRESS
SAVE FROM AGAIN FOR LATER
MOW CALCULATE SIZE
SIZE=END-START+1
                                                                                                                                                                                                                                                                            H
A,E
L,A
A,D
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   CSAC C9
                                                                                                                                                                                                                                                                               H,A
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 1281 9
1282 SETXQ SHLD
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                C5B1 22 27 C8
C5B4 C9
                                                                                                                                                                                                                                                                          BLOCK STORE THE SIZE
H SAVE IT FOR THE READ ALSO
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | 1286 | RET | 1286 | RET | 1286 | RET | 1288 | RET | 1288 | RET | 1288 | RET | 1289 | RET | 1289 | RET | 1289 | RET | 1299 | RET | 1299 | RET | 1299 | RET | 1298 | RET | 1299 | RET | 1298 | RET | 1298 | RET | 1298 | RET | 1298 | RET | 1300 | RET | 130
      C506 CD 48 C5
C509 21 1C C8
C50C CD AF C7
                                                                                                                                                                                                             CALL
LXII H.THEAD POINT TO HEADER
CALL WHEAD AND WRITE IT OUT
NOW WRITE OUT THE DATA
POP D GET SIZE TO DE
POP H GET BACK "FROM" ADDRESS
JMP WRICO WRITE OUT THE DATA AND RETURN
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                C585 32 10 C8
C588 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        NUCHT SET THE NULL COUNT . THAT'S DONE
        C50F D1
C510 E1
C511 C3 90 C7
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                C5B9
C5B9 32 11 C8
C5BC C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    SET TO IGNORE CRC ERRORS
IGNOR FFEIGNORE ERRORS, ELSEENOPHAL
                                                                                                                                                      13 • 00TPUT b 156 • 00TPUT b 156 • 157 TAERR CALL 1158 WYI 1159 LXI CALL CALL JMP
                                                                                                                                                                                                        OUTPUT ERROR AND HEADER
                                                                                                                                                                                                                                                                       CRLF
D,6
H,ERRH POINT TO ERROR MESSAGE
NLOOP OUTPUT ERROP
HAGOUT THEN THE HEADER
COMM1 AND BE SURE THE TAPE UNITS ARE OFF
      C514 CD F9 C2
C517 16 06
C519 21 25 C5
C51C CD 6A C5
C51F CD 50 C5
C522 C3 C0 C1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       CUSTOM COMMAND NAME AND ADDRESS INTO CUSTOM COMMAND
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             . C5BD CD 66 CN C5CO 21 C9 C1 C5CO 21 C9 C1 C5CO 25 CC 25 CC
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    NAMES CUSTOM COMMAND ENTRY/PEROVAL H, COMMD DEFAULT ADDR IF MONE CIVEN PSCAN COET PTN ADDR H SAVE TEN ADDR H SAVE TEN ADDR H SAVE TEN ADDR TO SCAROU SCAROU IT IN CUSTOM TABLE CUSE? NOT IN TABLE. FEMBRE IT D IN TABLE, REMOVE IT M, O CHANGE NEW NAME TO BE ZEBO A, M GET 1ST CHAR OF NAME D RIFER IT INTO TIBLE D AND THE PIT INTO TIBLE D AND THE PIT ON NAME
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         CALL
LXI
CALL
PUSH
LXI
CALL
JZ
DCX
MVI
MOV
STAX
INX
| STATE | STAT
        C525 45 52 52 4P
52 20
                                                                                                                                                                                                          THIS ROUTINE READS HEADERS FROM THE TAPE AND OUTPUTS THEM TO THE OUTPUT DEVICE. IT CONTINUES UNTIL THE MODE KEY IS DEPRESSED.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   MAME NOW ENTERED
GET SET TO ENTER ADDRESS
PESTORE BIN ADDR
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    H,E
H,D
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 SET ADDR IN NOW AND HI BYTE OF ADDR
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   NAME IS NOW ENTERED OR CLEARED
                                                                                                                                                                                                                                                                         RHEAD
COMMITURN OFF THE TAPE UNIT
LISTI
MAGUT
OUTPUT THE HEADER
LISTI LOOP UNTIL MODE IS DEPRESSED
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        COPY SOLOS3/1
                                                                                                                                                                                                          THIS ROUTINE GETS THE CASSETTE UNIT NUMBER AND SPEED TO REGISTER "A" FOR THE TAPE CALLS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               THE FOLLOWING ROUTINES PROVIDE "RYTE BY BYTE" ACCESS TO THE CASSETTE TAPES ON EITHER A READ OR WRITE BASIS
                                                                                                                                                                                                                                                                            H,FNUMF POINT TO THE UNIT SPECIFICATION TSPD GET THE TAPE SPEED H PUT THEM TOGETHER . AND GO BACK
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            THE RUFFER AREA IS CONTROLLED BY A FILE CONTROL BLO (FCB) WHOSE STRUCTURE IS:
                                                                                                                                                                                                               THIS ROUTINE OUTPUTS THE NAME AND PARAMETERS OF THEAD TO THE OUTPUT DEVICE.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      7 BYTES FOR EACH OF THE TWO FILES STRUCTURED AS FOLLOWS:
                                                                                                                                                                                                                                                                          D,8
H,THEAD-1 POINT TO THE HEADER
NLOOP OUTPUT THE HEADER
BOUT ANOTHER BLANK
LOADR NOW THE LOAD ADDRESS
ADOUT PUT IT OUT
BLOCK AND THE BLOCK SIZE
ADDIT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           1 PYTE - READ COUNTER
1 BYTE - RUFFER POSITION POINTER
2 BYTE - CONTROL HEADER ADDRESS
2 BYTE - RUFFER LOCATION ADDRESS
                                                                                                                                                                                                                                                                                                                 DO THE CRLF AND RETURN
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   THIS ROUTINE "OPENS" THE CASSETTE UNIT FOR ACCESS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   ON ENTRY: A - HAS THE TAPE UNIT NUMBER (1 OP 2)
HL - HAS USER SUPPLIED HEADER FOR TAPE FILE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      NORMAL RETURN: ALL REGISTERS ARE ALTERED BLOCK IS READY FOR ACCESS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   ERROR RETURN: CARRY BIT IS SET
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      ERRORS: BLOCK ALREADY OPEN
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              SAVE HEADER ADDRESS
GET ADDRESS OF FILE CONTROL
FILE MAS ALMEADY OPEN
HOM IT IS
POINT TO READ COUNT
ZERO
POINT TO BUFFER CUPSOR
PUT IN THE ZERO COUNT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               C5E0 E5
C5E1 CD 33 C6
C5E4 C2 FA C5
C5E7 36 O1
C5E9 23
C5EA 77
C5EB 23
C5EC 77
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 H
LFCB
TERE2
M, 1
H
M, A
H
                                                                                                                                                                                                           THIS ROUTINE CETS THE ASSOCIATED PARAMETER AND DISPATCHES TO THE PROPER ROUTINE FOR SETTING CLOBAL VALUES.
                                                                                                                                                                                                                                                                         $ THIS IS THE SET COMMAND

SBLK LOOK FOR SET NAME
ERRI HUST HAVE AT LEAST SOMETHING!!

BAYE SCAN ADDRESS

SCON CONVERT FOLLOWING VALUE

CET SCAN ADDRESS BACK. SAVE VALUE ON STACK

D, SETAB SECONDARY COMMAND TABLE

PDOM SEE IF IN TABLE

DISPO AND EITHER ERR OR OPP TO IT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              ALLOCATE THE BUFFER
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               C5ED 11 63 C8
C5F0 3A 54 C8
C5F3 82
C5F4 57
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    D.FBUF1 POINT TO BUFFER AREA
FNUMF GET WHICH ONE WE ARE GOING TO USE
D.A. 256 BIT ADD
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   B HEADER ADDRESS
A CLEAR CARRY AND RETURN AFTER STORING PARAMS
PSTOR STORE THE VALUES
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             C5F5 C1
C5F6 B7
C5F7 C3 B6 C6
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         2 0 GENERAL 18 0 GENERAL 18 0 B5 TERE2 POP 187 TEREO XRA STC RET
                                                                                                                                                                                                                                                                            A IS IT ZERO?
SETSP YES--THAT'S A VALID SPEED
A, 32 SET TO SLOW IF NON-ZERO
TSPD SPEED IS STORED HERE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            GENERAL ERROR RETURN POINTS FOR STACK CONTROL
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   CLEAR ALL FLAGS
SET ERROR
                                                                                                                                                                                                                                                                         A,B ESCAPE COMES HERE TO SET SPEED SPEED SET DISPLAY SPEED
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              1390 | 1391 EOFER DCR | 1393 | STC | 1393 | STC | 1393 | STC | 1394 | POP | RET | 1396 | POP | RET | 1396 | POP | RET | 1396 | POP | RET | 1400 | POP | RET | 1403 | OUT AND | 1405 | MADE RE | 1406 | POP | RET | 1406 | POP | RET | 1408 | POP | RET | 1408 | POP | RET | 1409 | POP | RET | 1410 | POP | POP | RET | 1410 | POP |
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   SET MINUS FLAGS
AND CARRY
CLEAR THE STACK
THE FLAGS TELL ALL
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                C5FF 3D
C600 37
C601 D1
C602 C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    THIS ROUTINE CLOSES THE FILE BUFFER TO ALLOW ACCESS FOR A DIFFERENT CASSETTE ON PROCRAM. IF THE FILE OPERATIONS WERE "MRITE" THEN THE LAST BLOKY IS WEITOUT AND AN "END OF FILE" WRITTEN TO THE TAPF. IF THE OPERATIONS WERE "PEADS" THEN THE FILE IS JUST MADE READY FOR NEW USE.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      ON ENTRY: A - HAS WHICH UNIT (1 OR 2)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       ERROR RETURNS: FILE WASN'T OPEN
```

```
THIS ROUTINE IS UNED TO WRITE A WITE TO THE FILE

THE STATE OF SETTING A. HAS FILE HOMBER
B. HAS DATA BITE
B. HAS DATA BOTTOM ADDRESS.
CALL POLDA
B. HAS DATA BITE
B. HAS DATA B
                                                                                                                                                                                                                                                                                                                                                                               GET CONTROL BLOCK ADDRESS
WASN'T OPEN, CARRY IS SET FROM LFCR
CLEAP CARRY
SET CONDITION FLACS
CLOSE THE CONTROL BYTE
WE WERE READING...WOTHING MORE TO DO
C603 CD 33 C6
C606 C8
C607 B7
C608 -
C609
C60B
                                                                                                                                                                       1812 PCLOS CALL LPCB
1813 R2 .
1816 R2 .
1816 R2 .
1816 MYI H, 0
1817 R2 .
1818 PTHE FILE OPERA
1820 PUT THE CURRENT
1822 CEVEN IF ONLY ON
1823 THEN WRITE AR EN
1825 INX H
1825 INX H
1825 INX H
1825 INX H
1826 INX H
1827 INX H
1828 POPH BBLK
1831 PUSH B
1832 LXI H, BLK
1833 DAD B
1832 LXI H, BLK
1833 DAD B
1833 PUSH B
1833 DAD B
1833 PUSH B
1833 DAD B
1833 PUSH B
1833 INX H
1844 INX H
1845 INX H
1840 MOV M, D
1851 INX H
1840 MOV M, D
1851 INX H
1840 MOV M, D
1851 INX H
1841 INX H
1842 PUSH B
1846 NOV M, D
1851 PUSH B
1846 MOV M, D
1851 PUSH B
1852 MOV M, A
1855 PUSH MOV M, A
1856 PUSH MOV M, A
1857 MOV M, A
1858 PUSH MOV M, A
1859 PUSH M
1868 PUSH MOV M, A
1859 PUSH M
1879 PUSH M
1870 PUSH M
                                                                                                                                                                                                                                                      THE FILE OPERATIONS WERE "WRITES"
                                                                                                                                                                                                                                           PUT THE CURRENT BLOCK ON THE TAPE
(EVEN IF ONLY ONE BYTE!!)
THEN WRITE AN END OF FILE TO THE TAPE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C683 CD 33 C6
C686 C8
C687 3C
C688 C8
C689 36 FE
C68B 23
C68C 23
C68C 23
C68D 78
C68E F5
C68F E5
C60C 23
C60D 23
C60E 7E
C60F 7E
C610 CD BF C6
C613 C5
C614 21 O7 O0
C617 09
C618 B7
C619 CA 2B C6
                                                                                                                                                                                                                                                                                                                          H
H
A,M GET CURSOR POSITION
                                                                                                                                                                                                                                                                                                                      PLOAD BC GET HEADER ADDRESS, DE BUFFFR ADDRESS
B HEADER TO STACK
H, BLKOF OFFSET TO BLOCK SIZE
B
                                                                                                                                                                                                                                                                                                                        B TEST COUNT EOFW NO BYTES...JUST WRITE EOF
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    C690 CD BF C6
C693 E1
C694 7E
C695 83
C696 5F
C697 D2 9B C6
C69A 14
C69B F1
C69C 12
C69D B7
                                                                                                                                                                                                                                                          WRITE LAST BLOCK
                                                                                                                                                                                                                                                                                                                    H SAVE BLOCK SIZE POINTER FOR MAA PUT IN COUNT H. H. H. H. H. BUFFER ADDRESS H. H. D. H. H. B. L.C. PUT HEADER ADDRESS IN HL. GO WRITE IT OUT H. BLOCK SIZE POINTER
C61C E5
C61D 77
C61E 23
C61F 36 00
C621 23
C622 73
C623 23
C624 72
C625 60
C627 CD 7C C7
C62A E1
                                                                                                                                                                                                                                                                                                                                                             SAVE BLOCK SIZE POINTER FOR EOF
PUT IN COUNT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          C6A0 CD A6 C6
C6A3 C3 7C C7
                                                                                                                                                                                                                                       NOW WRITE END OF FILE TO CASSETTE
                                                                                                                                                                                                                                                                                                                      A PUT IN ZEROS FOR SIZE:
H, A
H, A
H, A
HEADER ADDRESS
WFBLK WRITE IT OUT AND RETURN
C62B AF
C62C 77
C62D 23
C62E 77
C62F E1
C630 C3 7C C7
                                                                                                                                                                                                                                                                                                                                                                       PUT IN ZEROS FOR SIZE: EOF MARK IS ZERO BYTES!
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C6A6 CD BF C6
C6A9 C5
C6AA 21 06 00
C6AD 09
C6AE D1 00 01
C6B1 CD B6 C6
C6B4 E1
C6B5 C9
                                                                                                                                                                                                                                           THIS ROUTINE LOCATES THE FILE CONTROL BLOCK POINTED TO BY RECISTER "A". ON RETURN HL POINT TO THE CONTROL BYT AND RECISTER "A" HAS THE CONTROL WORD WITH THE PLAGS SET FOR IMMEDIATE CONDITION DECISIONS.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        C6B6 23
C6B7 71
C6B8 23
C6B9 70
C6BA 23
C6BE 73
C6BC 23
C6BD 72
C6BE C9
C633 21 55 C8
C636 1F
C637 E6 01
C639 32 54 C8
C632 CA 42 C6
C642 C 642
C642 7E
C643 P
                                                                                                                                                                                                                                                                                                                      H,FCBAS POINT TO THE BASE OF IT

MOVE THE 1 A 2 TO 0 A 1 LIKE COMPUTERS LIKE

MALL NUMBERS ARE THE RULE
FNUMF CURRENT ACCESS FILE NUMBER
LECR1 UNIT ONE (VALUE OF ZERO)
H,FCBA2 UNIT THO—PIT TO ITS FCR

A,M PICK UP FLACS PM FCB

A BICK UP FLACS PM FCB

A SET CARRY IN CASE OF IMMEDIATE ERROR RETURN
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        C6BF 23
C6C0 4E
C6C1 23
C6C2 46
C6C3 23
C6C4 5E
C6C5 23
C6C6 56
C6C7 C9
                                                                                                                                                                                                                                                      READ TAPE BYTE ROUTINE
                                                                                                                                                                                                                                                    ENTRY: - A - HAS FILE NUMBER
EXIT: MORMAL - A - HAS BITE
ERROR
CARRY SET - IF FILE HOT OPEN OR
PREVIOUS OPERATIONS WERE WRITE
CARRY & MINUS - END OF FILE ENCOUNTERED
                                                                                                                                                                   TABLE OF THE PROPERTY OF THE P
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        C6C8 CD DE C7
C646 CD 33 C6
C649 C8
C648 3C
C648 FA FC C5
C64E 36 FF
C651 7E
C652 E5
C653 23
C654 CD BF C6
C657 E1
C658 B7
C658 B7
                                                                                                                                                                                                                                                                                                                                                                               LOCATE THE FILE CONTROL BLOCK
FILE MOT OPEN
TEST IF FF
ERROR WAS WRITING
SET IT AS READ (IM CASE IT WAS JUST OPPNED)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C6CB D5
C6CC O6 O3
C6CE CD EF C7
C6D1 DB FB
C65C D5
C65D E5
C65E 23 AC C6
C65E 23 AC C6
C662 CD C8 C6
C665 DA FA C5
C668 E1
C669 78
C668 B2
C668 CA FF C5
C666 P3
C667 23
C667 23
C672 28
C673 78
C673 78
                                                                                                                                                                                                                                                                                                                      D BUFFER POINTER
H TABLE ADDRESS
H HAAD PREFARE THE MEADER FOR READ
PREBLE READ IN THE BLOCK
TERE2 ERROR POP OFF STACK BEFORE RFTURN
H A.E LOW BYTE OF COUNT (WILL BE ZERO IF 256)
D SE IF BOTH ARE ZERO
EOFER BYTE COUNT WAS ZERO...EMD OF FILE
H, E MW COUNT ( ZERO IS 256 AT THIS POINT)
H BUFFER LOCATION POINTER
H, O
H
COUNT TO A
GET BACK BUFFER ADDRESS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C6D3 E5
C6D4 CD 23 C7
C6D7 E1
C6D8 DA 06 C7
C6DB C2 D3 C6
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    C6DE E5
C6DF 11 1C C8
C6E2 CD D2 C7
C6E5 E1
C6E6 C2 D3 C6
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      C6E9 D1
C6EA 7A
C6EB B3
C6EC 2A 23 C8
C6EF EB
C675 3D
C676 --
C677
C678
C679
C67A 6
C67B 5F
C67C D2 80 C6
C67F 14
C680 1A
C681 B7
C682 C9
                                                                                                                                                                                                                                                                                                                                                                                     DE NOW POINT TO CORRECT RUFFER POSITION
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          C6F6 D5
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          C6F7
C6F7 CD 15 C7
C6FA CA 10 C7
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          ACCESS, JUNE, 1977 • 17
```

1 EPT 2 - 48

```
1693 • CALL PHED1
1695 JC TERR
1696 JZ TAP2
1697 • TAP2
1698 • ERROR RETURN
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          C791
C791 CD 15 C7
C794 CA OB C7
C797 CD C3 C7
C79A C3 91 C7
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  $ LOOP HERE UNTIL ENTIRE AMOUNT READ DORCT DROP COUNT IN DE AND SET UP B W/LEN THIS TOPF RETURNS ZERO IF ALL DONE WATER SLOCK FOR BITES IN B (256) WATER SLOCP WITH ALL DONE
                                                                                                                                                                                       RHED1 READ THAT MANY RYTES
TERR IF ERROR OF ESC
RTAP2 RD OK--READ SOME MORE
                                                                                                 C706 AF
C707 37
C708 C3 11 C7
                                                                                                                                                                                                                                                                                                                                                                                                                              C79D F5
C79E DB FA
C7AO E6 80
C7A2 CA 9E C7
C7A5 F1
C7A6 D3 FB
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  PSW
TAPPT TAPE STATUS
TIBE IS TAPE READY FOR A CHAR YET
WHMAT MO.-WAIT
PSW YES.-RESTORE CHAR TO OUTPUT
TDATA SEND CHAR TO TAPE
                                                                                                                                                                                        SET ERROR FLAGS
   C70B 06 01
C70D CD F1 C7
C710 AF
C711 D3 FA
C713 D1
C714 C9
                                                                                                                                                                                                                                                                                                                                                                                                                              C7A8
C7A8 91
C7A9 AF
C7AA A9
C7AB 2F
C7AC 91
C7AD 4F
C7AE C9
                                                                                                                                                                                                                     RETURN BYTE COUNT
 C715
C715 AF
C716 A7
C716 A7
C717 B2
C718 C2 20 C7
C718 B3
C71C C8
C71D A3
C71C C5
C71C C5
C71C C72
C720 B7
C722 C9
                                                                                                                                                                                     COMMON RIM TO COUNT DOWN RLY LENGTHS

A CLR FOR LATER TESTS

B.A SET THIS RLK LEN+256

DECR2 NO-REDUCE AWATE BY 256

E IS ENTIPE COUNT ZERO

ALL DOM-ZEROCHAS CONDITION

R.E SET THIS RLK LEN TO AWAT REMAINING

E.D MARE ENTIRE COUNT ZERO MON

ALL DOME-ZEROTHIS CONDITION

ALL DOME (NON-ZERO FLAG)

BEDUCE COUNT RY 256

D POP BY 256

A FORCE MON-ZERO FLAG

MON-ZERO+NOT DOME YET (RLK LEN+256)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            ONE BYTE NOW WRITTEN
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         THIS ROUTINE WRITES THE HEADER POINTED TO BY HL TO THE TAPE.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  S HERE TO 1ST TURN ON THE TAPE
MTON TURN IT ON, THEN WRITE HEADER
D, 50 WRITE 50 ZEROS
WRITAP
                                                                                                                                                                                                                                                                                                                                                                                                                              C7AF
C7AF CD ED C7
C7B2 16 32
C7B4 AF
C7B5 CD 9D C7
C7B8 15
C7B9 C2 B4 C7
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  A.1
MRTAP
B.HLEN LENGTH TO WRITE OUT
                                                                                                                                                                                                                                                                                                                                                                                                                              C7BC 3E 01
C7BE CD 9D C7
C7C1 06 10
  C723 06 0A
C725 CD 5D C7
C728 D8
C729 DB FB
C72B B7
C72C C2 23 C7
C72F 05
C730 C2 25 C7
                                                                                                                                                                                                                                                                                                                                                                                                                             C7C3 0E 00
C7C5 7E
C7C6 CD 9D C7
C7C9 05
C7CA 23
C7CB C2 C5 C7
C7CE 79
C7CF C3 9D C7
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   C,O RESET CRC BYTE A,M GET CHARACTER WRITE IT TO THE TAPE
                                                                                                                                                                                                                     IF ESCAPE
IGNORE ERROR CONDITIONS
ZERO?
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  B
H
WLOOP
A,C GET CRC
WRTAP PUT IT ON THE TAPE AND RETURN
                                                                                                                                                                            RHEAT LOOP UNTIL 10 IN A ROW
                                                                                                                                               CALL TAPIN

RC . ERROR OF ESCAPE

CPI 1 AT LEAST 10 NULLS IMMEDIATELY POLLOWED BY AW 01

JC SOHL STILL A NULL, KEEP WAITING

JNZ RHEAD NON-ZERO, START SEQUENCE OVER AGAIN
 C733 CD 6F C7
C736 D8
C737 FE 01
C739 DA 33 C7
C73C C2 23 C7
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      THIS ROUTINE COMPARES THE HEADER IN THEAD TO THE USER SUPPLIED HEADER IN ADDRESS HL. ON RETURN IF ZERO IS SET THE TWO NAMES COMPARED
                                                                                               JC SOL STILL A WILL, KEW MATING

NOW GET THE HEADPR

1749 **

1748 **

1749 **

1749 **

1749 **

1750 LXI M, THEAD POIRT TO BUPPER
1750 LXI M, THEAD POIRT TO BUPPER
1751 MRII B, MLEN LENGTH TO READ
1752 **

1752 **

1753 MEDI EOU & RD A BLOCK INTO ML FOR B RYTES
1755 RHEDZ EOU & LOOP MEET
1756 CALL TAPIN GET A BYTE
1757 RC
1758 MOV M, A STORE IT
1758 MOV M, A STORE IT
1759 CEX DECRE MOVEL MEETER THE CRC
1750 CEX DECRE MOVEL MEADER FETT
1760 CALL TAPIN GET CR THE THE CRC
1761 CAL TAPIN GET CR THE THE CRC
1762 JMZ MMEDZ DO ALL THE RYTE
1764 **

1764 THIS ROUTINE GETS THE WEXT BITE AND COMPARES IT
1765 TO THE VALUE IN RECISTER C. THE PLAGS ARE SET ON
1767 RETURN.

1767 RETURN.

1768 CALL TAPIN GET CR TYTE
1769 ZRA C. CRC CARYTE
1769 TREE WHILE WAITING FOR THE NITE THE RETEORAD IS TEST
1770 RZ C. CRC WAS FINE
1771 LDA IGNCE GET STEE MEY AVAILABLE BYTE PROM THE
1772 THIS ROUTINE GETS THE WEXT AVAILABLE BYTE PROM THE
1773 RETURN A FFIGNORE CRC CERRORS, ELSS PROCESS CI
1776 TAPE. WHILE WAITING FOR THE NITE THE RETEORAD IS TEST
1777 FOR AN ESC COMMAND. IF RECEIVED THE TAPE LOAD IS
1778 TERMINATED AND A RETURN TO THE CREE TET
1769 ZRA CALL SIMP CHECK INPUT
1769 ZRA CALL SIMP CHECK INPUT
1769 AND THE CALL STAT WAIT UNTIL A CHARACTER IS AVAILABLE
1769 TREDY IN TAPPT TAPE STATUS
1769 RETURN CALL STAT WAIT UNTIL A CHARACTER IS AVAILABLE
1769 TREDY IN TAPPT TAPE STATUS
1769 RETURN CALL STAT WAIT UNTIL A CHARACTER IS AVAILABLE
1769 TREDY IN TAPPT TAPE STATUS
1769 RETURN CALL STAT WAIT UNTIL A CHARACTER IS AVAILABLE
1769 TREDY IN TAPPT TAPE STATUS
1760 AND RETURN STATE
1760 TAPPT OR RETURN STATUS
1761 TAPPT TAPE STATUS
1762 AND RETURN STATUS
1763 TREDY IN TAPPT TAPE STATUS
1764 TREDY IN TAPPT TAPE STATUS
1765 AND RETURN STATUS
1766 TREDY IN TAPPT TAPE STATUS
1769 TREDY 
                                                                                                                                                                                                                                                                                                                                                                                                                            C7D2 06 05
C7D4 1A
C7D5 BE
C7D6 C0
C7D7 05
C7D8 C8
C7D9 23
C7D4 13
C7D8 C3 D4 C7
   C73F 21 1C C8
C742 06 10
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 IF ALL FIVE COMPARED
C7DE 3A 54 C8 C7E1 B7 C7E2 3A 0D C8 C7E5 C2 EA C7 C7E8 C6 NO C7EC C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   S SET A=SPEED + UNIT
FRUMF GET UNIT
A SE WHICH UNIT
TSPD BUT 1ST GET SPEED
GTUN2 MARE IT UNIT TWO
TAPE2 THIS ONCE-UNIT 2, TWICE-UNIT
TAPE2 UNIT AND SPEED HOW SET IN A
ALL DONE
                                                                                                                                                                                                                                                                                                                                                                                                                             C7ED 06 08
C7EF
C7EF D3 FA
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   B,4 SET LOOP DELAY (RIT LONGER ON A WHAT TAPE ON THEN DELAY TAPPT GET TAPE MOVING, THEN DELAY
                                                                                                                                                                                TAPIN GET CRC BYTE
C CLR CARRY AND SET ZERO IF MATCH, ELSE NON-ZERO CFF: 11 00 00
CRC WAS FINE CYEROPIDE CRC EPROR FLAG CFF: 13
A FF-ICHORE CRC ERRORS, ELSE PROCESS CRC FRROR CFF: 68
CFF: C2
TINE GETS THE NETT AVAILABLE BYTE FROM THE
CTFA 05
CTF C2
TILE WAITING FOR THE BYTE AVAILABLE BYTE FROM THE
CTFE C2
TILE WAITING FOR THE BYTE AVAILABLE BYTE FROM THE
CTFE C2
TFC C7
TFC C9
 C753 CD 6F C7
C756 A9
C757 C8
C758 3A 11 C8
C75B 3C
C75C C9
                                                                                                                                    THIS ROUTINE GETS THE NEXT AVAILABLE BYTE FROM THE TAPE. WHILE WAITING FOR THE BYTE THE REYBOARD IS TESTED FOR AN ESC COMMAND. IF RECEIVED THE TAPE LOAD IS TERMINATED AND A RETURN TO THE COMMAND MODE IS MADE.
 C75D DB FA
C75F E6 40
C761 C0
C762 CD 1F C0
C765 CA 5D C7
C768 E6 7F
C76A C2 5D C7
C76B 37
C76E C9
   C76F CD 5D C7
C772 D8
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 THESE DEFINITIONS ARE DESIGNED TO ALLOW COMPATABILITY WITH CUTER(TM). THESE ARE THE SAME KEYS WITH BIT 7 (X'80') STRIPPED OFF.
  C773 DB FA
C775 E6 18
C777 DB FB
C779 C8
C77A 37
C77B C9
                                                                                                                                                                                                                                                                                                                                                                                                                                                     009A
0097
0081
0093
008B
008E
0080
005F
000A
000D
0020
0018
001B
   C77C CD DE C7
  CTTP
CTTR E5
CT80 CD AP CT
CT83 E1
CT84 11 07 00
CT87 19
CT88 5E
CT89 23
CT8A 56
CT8B 23
CT8A 56
CT8B 23
CT8C 7E
CT8C 7E
CT8C 7E
CT8C 66
CT8F 6F
                                                                                                                                                                                                                                                                                                                                                                                                                                                     OOFA
OOFS
OOFD
OOFC
OOFE
OOFA
OOFB
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  SERIAL CARRIER DETECT
SERIAL DATA SET READY
SERIAL PARITY ERROR
SERIAL FRAMING ERROR
SERIAL OVERRUN ERROR
SERIAL CLEAR TO SEND
                                                                                                                                                                                                                                                                                                                                                                                                                                                     0001
     C790
C790 E5
 ACCESS, JUNE, 1977 • 18
```

				1 EPT 2 - 49
0040	1977 SDR 1978 STBE	EQU	64 128	SERIAL DATA READY SERIAL TRANSMITTER BUFFER EMPTY
0001	1979 • 1980 KDR	EQU	1	KEYBOARD DATA READY
0002	1981 PDR 1982 PXDR	EQU	2	PARALLEL DATA READY PARALLEL DEVICE READY
0008	1983 TFE 1984 TOE	EQU	16	TAPE FRAMING ERROR TAPE OVERFLOW ERROR
0040	1985 TDR 1986 TTBE 1987 •	EQU	64 128	TAPE DATA READY TAPE TRANSMITTER RUFFER EMPTY
0001	1988 SOK 1989 #	EQU	1	SCROLL OR FLAG
0080	1990 TAPE1 1991 TAPE2	EOU	80H 40H	1=TURN TAPE ONE ON 1=TURN TAPE TWO ON
	1992 •	240		
	1994 •			· ·
	1996	SYS	TEM	GLOBAL AREA
C800	1998 1999 •	ORG	START+	
C800 CBFF	2000 SYSRAM 2001 SYSTP	EQU	\$ SYSRAM	START OF SYSTEM RAM +3FFH STACK WORKS FM TOP DOWN
	2002 •			
	2005			D IN RAM
C800 C802	2006 UIPRT 2007 UOPRT	DS DS	2	USER DEFINED INPUT RTN IP NON ZERO USER DEFINED OUTPUT RTN IP NON ZERO
C804 C806	2008 DFLTS 2009 IPORT	DS DS	1	DEFAULT PSUEDO I/O PORTS (ALWAYS ZERO IN SOLOS) CRNT INPUT PSUEDO PORT
C807 C808	2010 OPORT 2011 NCHAR	DS DS	1	CRNT OUTPUT PSUEDO PORT CURRENT CHARACTER POSITION
C809 C80A C80B	2012 LINE 2013 BOT 2014 SPEED	DS DS	1	CURRENT CHARACTER POSITION CURRENT LINE POSITION BECINNING OF TEXT DISPLACEMENT SPEED CONTROL BYTE
C80C C80D	2015 ESCFL 2016 TSPD	DS DS	1	ESCAPE FLAG CONTROL BYTE CURRENT TAPE SPEED
C80E C810	2016 ISPD 2017 INPTR 2018 NUCNT	DS DS	2	FOR COMPATABILITY W/ CUTER NUMBER OF NULLS AFTER CRLF
C811	2019 IGNCR 2020 •	DS	1	FF=IGNORE CRC ERRORS, ELSE NORMAL
C812	2021	DS	10	ROOM FOR PUTURE EXPANSION
	2022 8 8 6	HIS	 I S	THE HEADER LAYOUT
	2025 • • •		• • •	THE HEADER LAYOUT
C81C C821	2027 THEAD 2028	DS DS	5	NAME THIS BYTE MUST BE ZERO
C822 C823	2029 HTYPE 2030 BLOCK	DS DS	2	TYPE BLOCK SIZE
C825 C827	2031 LOADR 2032 XEQAD	DS DS	2	LOAD ADDRESS AUTO EXECUTE ADDRESS
C829	2033 HSPR 2034 •	DS	3	SPARES
0010	2035 HLEN 2036 BLKOF	EQU EQU	S-THEA BLOCK-	D LENGTH OF HEADER THEAD OFFSET TO BLOCK SIZE
C82C	2037 DHEAD 2038 •	DS	HLEN	A DUMMY HOR POR COMPARES WHILE PD'ING
C83C	2039 • 2040 CUTAB	DS	604	ROOM FOR UP TO 6 CUSTOM USER COMMANDS
	2041 •			
.,	2083 FRUME	DS	1	FOR CURRENT FILE OPERATIONS
· ·	2043 FNUMF 2044 FCBAS 2045 FCBA2	DS DS	7 7	FOR CURRENT FILE OPERATIONS 1ST FILE CONTROL BLOCK 2ND FILE CONTROL BLOCK
	2044 FCBAS 2045 FCBA2 2046 FBUF1	DS DS	7 7 2°256	IST FILE CONTROL BLOCK 2MD FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE
TAB4	2044 FCBAS 2045 FCBA2 2046 FBUF1 2047 2048 USARE 2049 PRF	DS DS DS EQU	7 7 2°256 81 \$ THAT TH	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER MASE THIS IS AN AFEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM
TAB4	2045 FCBAS 2045 FCBAS 2046 FBUF1 2047 2048 USARE 2049 PE 2050 PTH 2051 P	DS DS DS EQU	7 7 2°256 81 \$ THAT TH	IST FILE CONTROL BLOCK 2MD FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE
-) .	2048 FCBAS 2045 FCBAS 2046 FBUF1 2047 2048 USARE 2049 PRE 2050 TH 2051 P	DS DS DS DS DS EQU MEMBER	7 7 20256 81 \$ THAT TH F THIS	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED BY CUTER START OF USER AREA E STACK MORKS ITS MAY DOWN FROM IK RAM AREA.
-) .	2045 FCBAS 2045 FCBAS 2046 FBUF1 2047 2048 USARE 2049 PE 2050 PTH 2051 P	DS DS DS DS EQU MEMBER 10 E END OF	7 7 2*256 81 \$ THAT TH F THIS	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED BY CUTER START OF USER AREA E STACK MORK ITS MAY DOWN FROM IK RAM AREA. AOUT COIC BACKS 005F
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A	204% FCBAS 2045 FCBAS 2046 FBUF1 2046 USAFE 2046 USAFE 2051 - TH 2051 - TH 2052 AINP CO22 ARET1 C19D BLYOF 0007 ROUT C406 CLEAR 008B	DS DS DS EQU MEMBER OF ALOAD APET2 RLOCK CHAR CLERA	7 7 7 2*256 81 \$ THAT TH F THIS C548 C1A2 C823 C094	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED BY CUTER START OF USER AREA E STACK MORK ITS MAY DOWN FROM IK RAM AREA. AOUT COIC BACKS 005F BOPEN CSEO CMPCK COSE
ADOUT C3E8 ARET C19B BLANK 0020	204% FCBAS 2045 FCRAS 2046 FBUF1 2047 2048 USARE 2049 * RE 2050 * TH 2051 * 2052 * -*- AINP C022 ARET1 C19D BLFOF 0007 ROUT C#06 CLEAR 008B COMM1 C1CO	DS DS DS DS EQU MEMBER E END OF ALOAD APET2 BLOCK CHAR CLERA COMND	7 7 7 2*256 81 \$ THAT TH F THIS C548 C1A2 C823 C094 C1B4 C1C9	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED BY CUTER START OF USER AREA E STACK MORK ITS MAY DOWN FROM IK RAM AREA. AOUT COIC BACKS 005F BOPEN CSEO CHPCK CO5E CLINI COFA COMTA CPA
ADOUT C3E8 ARET C19B BLAWK 0020 BOT C80A CHRLI C571 CLINE C0F4 CONT CIFF CRLF C2F9	204% FCBAS 2045 FCBAS 2046 FBUF1 2047 2048 USARE 2049 * RE 2050 * TH 2051 * 2 2052 * AINP C022 ARET1 C19D BLFOF 0007 ROUT C#06 CLEAR 008B COMN1 C1CC COPRC C205 CUR C0D1	DS DS DS DS EQU MEMPER E END OF ALOAD ARET2 RLOCK CHARA COMND CR CURET	77 729256 81 81 10000 118 118	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED BY CUTER START OF USER AREA E STACK WORKS ITS MAY DOWN FROM IK RAH AREA. AOUT COIC BACKS 005F BOPEN CSEO CHPCT C05E CLIN1 COPA COMTA CP4A CREM C136 CURSC COCF
ADOUT C3E8 ARET C19B BLANK C50A CHRLI C571 CLINE C0F4 CONT CIFF CRLF C2F9 CUSE2 C5D3 DCRC2 C720	204% FCBAS 2045 FCBAS 2046 FBUF1 2047 2048 USARE 2049 * RE 2050 * TH 2051 * 2052 ARET1 C19D BLKOF 0007 ROUT C#06 CLEAR 008B COMN1 C1CC COPRC C205 CUB C0D1 CUSET C5BD DCRCT C715	DS DS DS DS EQU MEMBER E END OF ALOAD ARET2 RLOCK CHAR CLERA CCHAR CUETA CUTAL DEFLIT	77 729256 81 \$1 \$1 \$1 \$1 \$1 \$1 \$1 \$1 \$1 \$1 \$1 \$1 \$1	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED BY CUTER START OF USER AREA E STACK WORKS ITS MAY DOWN FROM IK RAM AREA. AOUT COIC BACKS DOSP BOPEN CSEO CHPCT COSE CLINI COFA COMTA CP4A CREM C136 CUBSC COCC CX 0018 DELAY C7F1
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLIME C571 CCNT C1FF CRLF C2F9 CUSS2 C5D3 DCRC2 C720 DFLTS C80A DISPO C222	204% FCBAS 2045 FCRAS 2046 FBUF1 2047 2048 USARE 2049 * RE 2050 * TH 2051 * 2052 ARET1 C19D BLKOF 0007 ROUT C#06 CLEAR 008B COMN1 C1C0 COPRC C205 CUB COD1 CUSET C5BD DCRCT C715 DHCMP C7D2 DISP1 C22B	DS DS DS DS EQU MEMBER E END OF ALOAD ARETE CLEMAD CR CUTAB DEFLT DHEAD DEFLT DHEAD	77 729256 81 1 THAT THIS C548 C1423 C094 C184 C182 C00D C1A6 C49A C82C C899	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED BY CUTER START OF USER AREA E STACK WORKS ITS MAY DOWN FROM IK RAH AREA. AOUT COIC BACKS 005F BOPEN CSEO CUPER CO5E CLINI COFA COMTA CP4A CREM C136 CUBSC COCF CX 0018 DELAY C7F1 DHLOP C7DR DISPT C227
ADOUT C3E8 ARET C19B BLAWN 0020 BOT C80A CHRLI C571 CONT CFF CRLF C2F9 CRLF C2F9 CFLS C30A DERIS C30A DISPO G222 DLOOP C308 DOWN 009A	204% FCBAS 2045 FCRAS 2046 FBUF1 2047 2048 USARE 2049 * RE 2050 * TH 2051 * _ 2052 ARET1 C19D BLKOF D0007 BULTOF C406 CLEAR D08B COMN1 C1CC COPRC C205 CUB C0D1 CUSET C5BD DCRCT C715 DHCMP C7D2 DLOP1 C784 DSTAT OOFE	DS DS DS DS DS EQU MEMBER ALOAD APET2 RLDCC CHAR GLERA CCOMND CR CUTET DHEAD DEFLT DHEAD DLP1 DUMP	77 729256 81 1 THAT THE C1823 C094 C189 C000 C189 C0894 C189 C0894 C189 C0894 C189 C0894 C189 C0894 C189 C0894 C189 C189 C189 C189 C189 C189 C189 C189	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED BY CUTER START OF USER AREA E STACK WORKS ITS MAY DOWN FROM IK RAH AREA. AOUT COIC BACKS 005F BOPEN C5FC CHPCF C05E CLIN1 COPA COMTA CPAA CREM C136 CURSC COCF CX 0018 DELAY C7F1 DHLOP C7DR DISPT C227 DOCRC C7A8 EMULO CASC
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C0F4 CONT C1FF CRLF C2F9 CUSE2 C5D3 DCRC2 C720 DFLTS C80A DISPO C222 DLOOP C3C8	204% FCBAS 2045 FCRAS 2046 FBUF1 2047 2048 USARE 2049 * RE 2050 * TH 2051 * _ == - AINF C022 ARET1 C19D BLKOF D007 ROUT C#06 CLEAR 008B COMN1 C1CC COPRC C205 CUB C0D1 CUSET C5BD DCRCT C715 DHCMP C7D2 DLSP1 C22B DLOP1 C784 DSTAT OOFE ENLOP C42B ERASI CODB	DS D	77 729256 81 1 THAT TH F THIS C548 C1823 C094 C109 C0184 C0829 C08	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED BY CUTER START OF USER AREA E STACK WORKS ITS MAY DOWN FROM IK RAM AREA. AOUT COIC BACKS DOSP BOPEN CSEO CUPCE COSE CLINI COPA COMTA CPAA CREM C136 CUBSC COCF CX DO18 DELAY CTF1 DHLOP C7DR DISPT C227 DOCRC C786 EMULO C43C EOFER C5FF ERNI C480
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C0F4 CONT CIFF CRLF C2F9 CUSE2 C5D3 DCRC2 C720 DFLTS C80A DISPO G222 DLOOP C3C8 DOWN 000A ENLO3 C459 EOFW 662B ERR2 C881 ERROT C2D2 ESCSP C168	2044 FCBAS 2045 FCBAS 2046 FBUF1 2047 USARE 2040 - BUF1 2051 - TH 2051 - TH 2051 - TH 2051 - CH 2051 - TH 2051 - CH 2051 - TH 2052 AINP ARET1 C19D BLVOF G007 ROUT C406 CLEAR 008B COMN1 C1C0 CUPRC C205 CUR C0D1 C1SET C58D DCMCT C715 DHCMP T715 DHCMP T715 DHCMP C22B ERAS1 C0DB ERBIT C22B ERAS1 C0DB ERRIT C22B ERAS1 C0DB ERRIT C2CB	DS DS DS DS DS DS DS EQU MEMBER OF E END OF ALOAD APET2 RLOCK CUMAR CLERA CUMAR CLERA DEFEAD DISPD DILP1 DUMP ENTER OUTPET TOUTPET TOU	77 2256 81 THAT TH C 18234 THAT TH C 18234 C 1100 C 1829 C 100 C 1839 C C 100 C 1829 C	IST FILE CONTROL BLOCK 2ND FILE CONTROL BLOCK SISTEM FILE BUFFER PASE THIS IS AN AFEA USED NY CUTER START OF USER AREA E STACK BUFFER PASE AOUT COIC BACKS 005F BOPEN CSEO CHPCK CO5E CLINI COFA COMTA C24A COMTA C24A COMTA C24A COMTA C136 CUNSC COCF CX 0016 DELAY C7F DHOD C7D DISPT C227 DHOD C7D DISPT C227 DHOD C7D DISPT C26B EMAI C480 EMAI C48
ADOUT C3EB ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLIME C571 CLIME C573 DCRC2 C720 DCRC2 C720 DDFLC3 C60A DFLC3 C60A DLOP C30B DOWN 009A ENLO3 C459 ECFW C62B ERRC C801	2044 FCBAS 2045 FCBAS 2046 FBUF1 2047 2048 USAFE 2048 USAFE 2050 * TH 2051 * TH 2051 * C12 AINP C022 * -*- AINP C022 ARET1 C19D BLF0F 0007 R0UT C406 CLEAR 008B COMN1 C1C0 COPRC C205 CUR C0D1 CCSET C5BD DCRCT C715 DHCMP C7D2 DISF1 C22B DLOP1 C754 DSTAT 00FE ENLOP C42B ERAS1 C0BB ERRS1 C0BB ERRS1 C0BB	DS D	77 2256 81 THAT TH FTHIS C18294 THAT TH C514234 THAT TH C514234 THAT TH C514234 THAT TH C11C0D C11C0D C11CD	IST FILE CONTROL BLOCK 2ND FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED NY CUTER START OF USER AREA E SYACK WORKS ITS MAY DOWN FROM IK HAM AREA. AOUT COIC BACKS 005F BOPEN CSEO CHPCK CO5E CLINI COFA COMTA C24A COMTA C24A COMTA C136 CURSC COCF CX 0016 DELAY CTF1 DHCDY C7D DISPT C227 DOCRC C78 E C18 C C78 E C19
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLIME C0FM CONT CFF CRLT C2F9 DCRC2 C720 DFLTS C80A DISPO C3C8 DOOP C3C8 DOOP C3C8 DOOP C4C8 DOOP C4C8 D	2044 FCBAS 2005 FCBAS 2006 FBUF1 2007 USA FE 2000 TBUF1 2007 CBUF1 2051 2050 TBUF1 2052 2050 TBUF1 2	DS D	77 20256 81 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	IST FILE CONTROL BLOCK 2ND FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS ODSF BOPEN CSPD CHPCK COSE CLINI COFA COMTA CSPA COMTA CSPA COMTA COSE CLINI COFA COMTA COSE COCF CY ODIB DELAY CTFI DHLOP CTDR DISPT C227 DOCRC C7AB ENLOI CASC EOFER CSFP ERRI CABO ERROI C206 ESCS C15F FBUFI C863
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLIME C0F4 CONT CFF CRLT C2F9 DCNC C720 DFLTS C80A DISPO C222 DFLTS C80A DISPO C3C8 DWW 0099 E0FW C48B ERFOT C7D2 ESCSP C168 FCBA2 C65C FDCOU C22E GOBAC C06B GTUNT C7DE	2044 FCBAS 2005 FCBAS 2006 FBUF1 2007 VSAFE 2006 PT 2007 VSAFE 2009 PT 2051 PT 2051 PT 2052 PT 2051 PT 2051 PT 2051 PT 2051 PT 2052 PT	DS D	77 20256 81 81 81 THAT TH IS C18294 C1000 C183922 C1000 C183922 C1000 C18392 C1000 C1000 C18392 C1000 C1000 C1000 C1000 C1000 C1000 C18392 C1000 C18392 C1000 C1000 C1000 C1000 C1000 C1000	IST FILE CONTROL BLOCK 2ND FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED NY CUTER START OF USER AREA E SYACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS 005F BOPEN CSEO CHPCK CO5E CLINI COFA COMTA C2AA CMEM C136 CURSC COCF CX DELAY C7F1 DHLOP C7DA DISPT C227 DOCRC C7AR ENLO! C43F EOFER C5F EDF1 C863 FDCOM C231 GCLIN C128 GTURS C231 GCLIN C128 GTURS C35D HOME C7F4
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLIME C0F4 CONT CFF CRLT C2F9 DCNC C720 DFLTS C80A DISPO C222 DFLTS C80A DISPO C3C8 DWW 0099 E0FW C48B ERFOT C7D2 ESCSP C168 FCBA2 C65C FDCOU C22E GOBAC C06B GTUNT C7DE	2044 FCBAS 2005 FCBAS 2006 FBUF1 2007 USA FER 2000 FCBAS 2000 FCBA	DS D	77 20256 81 81 87 TH T TH I S C 5 A 8 2 3 4 C 11 C 8 A 8 2 2 4 C 11 C 8 A 8 2 2 9 C 12 C 8 A 8 2 C 12 C 8 A 8 C 2 C 2 C 2 C 2 C 2 C 2 C 2 C 2 C 2 C	IST FILE CONTROL BLOCK 2ND FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED DY CUTER START OF USER AREA E SYACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS 005F BOPEN CSEO CHPCK CO5E CLINI COFA COMTA C24A CMEM C136 CURSC COCF CX DELAY C7F1 DHLOP C7DA DISPT C227 DOCRC C7AC ENLO CASC ENFO! CSF EST CSF
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C0F4 CONT C1FF CRLF C2F9 CUSSE C5D3 DCRC2 C720 DFLTS C80A DISPO C3C8 DLOOP	2044 FCBAS 2005 FCBAS 2006 FBUF1 2007 VSAFE 2000 TUSAFE 2000 TOSAFE 2001 TOSAFE 2005 TOSAF	DS DS DS DS DS EQU HEMBER OF ALOAD APETCK CHAR ACOMND CLUTAR COUTET DUMP ERANS DEFLIT DUMP ERANS ESCICI FCOEM HCONV HCON	7 7 2*256 81 81 81 81 81 81 81 81 81 81 81 81 81	IST FILE CONTROL BLOCK 2ND FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS ODSP BOPEN CSEO CHPCK COSE CLINI COFA COMTA C20A COMTA C20A COMTA C136 CURSC COCF CX ODIB DELAY CTFI DHLOP C7DM DISPT C227 DOCRC C7AB ENLOI C43C EOFER C5FF ERRI C406
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C571 CLINE C5F9 CUSSE C720 DFLTS C80A DISPO C3C8 DLOOP C3C8 DLO	2044 FCBAS 2005 FCBAS 2006 FBUF1 2007 PCBUF1 2007 USA FER 2000 PTBUF1 2007 PCBUF1 2007 PCB	DS D	7 7 2*256 81 81 81 81 81 81 81 81 81 81 81 81 81	IST FILE CONTROL BLOCK 2ND FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS ODSP BOPEN CSEO CHPCK COSE CLINI COFA COMTA C20A COMTA C20A COMTA C136 CURSC COCF CX ODIB DELAY C7F1 DHLOP C7DA DISPT C227 DOCRC C7AB ENLOI C43C EOFER C5FP ERRI C206
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C571 CLINE C552 DCRC2 C720 DFLTS C80A DISPO C3C8 DLOOP C3C8 DLO	2044 FCBAS 2005 FCBAS 2006 FBUF1 2007 CBUF1 2007 USA FER 2000 FTM 2007 CBUF1	DS D	7 7 2*256 81 81 81 81 81 81 81 81 81 81 81 81 81	IST FILE CONTROL BLOCK 2ND FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS ODSP BOPEN CSEO CHPCK COSE CLINI COFA COMTA C20A COMTA C20A COMTA C136 CURSC COCF CX ODIB DELAY C7F1 DHLOP C7DA DISPT C227 DOCRC C7AB ENLOI C43C EOFER C5FF ERRI C206
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C571 CLINE C5P9 CUSSE C5D3 DCRC2 C720 DFLTS C80A DISPO C3C8 DOWN 109A ENCO3 C459 ENCO4 C414 ENCO4 C459 INPTR C806 ENCO	2044 FCBAS 2005 FCRAS 2006 FBUF1 2007 FCRAS 2006 FBUF1 2007 USA FER 2000 FTR 2001 CROSS 2000 FTR 2005	DS D	7 7 2*256 81 81 81 81 81 81 81 81 81 81 81 81 81	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS ODSP BOPEN CSEO CHPCK COSE CLINI COFA COMTA C20A COMTA C20A COMTA C136 CURSC COCF CX ODIB DELAY C7F1 DHLOP C7DR DISPT C227 DOCRC C7AB ENLOI C43C EOFER C5FF ERRI C480 ERROI C206 ERROI
ADOUT C3E8 ARET C19B BLAWN 0220 BOT C80A CHRLI C571 CCOME C0FF CRLF C2FP CRLF C2FP CRLF C2FP CRLF C3720 DCRC2 C720 DCRC2 C720 DCRC2 C720 DLOOP C3C8 DOWN 009A ENLO3 C459 EFR2 C481 EFRCT C2D2 ESCSP C168 FCBA2 C85C FDCOU C22E EFRCT C2D2 ESCSP C168 FCBA2 C85C FDCOU C2EE GTUNT C7DE BOOM LSTI C639 HAME C808 LLSTI C539 HAME C869 HCHAR C808 MLOOP C56A OCHAR C686	2044 FCBAS 2045 FCBAS 2046 FBUF1 2047 USAFE 2048 USAFE 2050 * "" 2051 * "" 2051 * "" 2051 * "" 2052 * " 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 2052 * "" 20	DS DS DS DS DS DS EQUIPMENT E END A DETECT A A PETCH A A PETCH A CCENAD CCENAD CCENAD CCENAD DHEAAD DHEAAD DHEAAD DHEAAD DHEAAD DHEAAD CCENAD	7 7 2*256 81 81 81 81 81 81 81 81 81 81 81 81 81	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER STATAT OF USER AREA E SYACK WORKS ITS MAY DOWN FROM IK RAM AREA. AOUT COIC BACKS OSSF BOPEN CSSF COPE CSSF CUPCT COSE CLINI COPA COMTA C22A COMTA C22A COMTA C22A COMTA C26A COMTA C36A CMM C36A
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C571 CLINE C5P4 CONT C1FF CRLF C2F9 CUSSE C720 DFLTS C80A DISPO G222 DLOOP C3C8 DOWN 009A ENLO3 C459 ENF C881 ERROZ C881 ERROZ C882 ERROZ C883 ERROZ C8	2044 FCBAS 2005 FCBAS 2006 FBUF1 2007 FCBAS 2006 FBUF1 2007 USA FEE 2050 FTB 2051 PTB 2051 PTB 2051 PTB 2052 PTB 2052 PTB 2051 PTB 2052 PTB 2053 PTB 2052 PTB 2053 PT	DS D	7 7 2*256 81 81 81 81 81 81 81 81 81 81 81 81 81	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS ODSF BOPEN CSED CUPIC COSE CLINI COFA COMTA C20A COMTA C20A COMTA C136 CUBSC COCF CX ODIB DELAY C7F1 DHLOP C7DR DISPT C227 DOCRC C7AB ENLO1 C43C EOFER C EOFE C5FF ERR1 C480 ERR01 C206 ERSCS C15F FBUFN C286 FFUCON C236 CC181 C36C CC30C CC40C CC50C CC50C CC50C CC70C C70C C70C C70
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C6F4 CONT C1FF CRLF C2F9 CUSSE C5D3 DCRC2 C720 DFLTS C80A DISPO G222 DLOOP C3C8 DOWN 009A ENLO3 C459 ENFO C62B ERRC C881 ERRCT C2D2 ERRC C881 ERRCT C2D2 ERRC C881 ERRCT C2D2 ERRC C881 ERRCT C2D2 ERRCT C2D2 ERRCT C2D2 ERRCT C3C8	2044 FCBAS 2005 FCBAS 2006 FBUF1 2007 FCBAS 2006 FBUF1 2007 USA FEE 2050 FTB 2051 PTB 2051 PTB 2051 PTB 2052 PTB 2052 PTB 2051 PTB 2052 PTB 2053 PTB 2052 PTB 2053 PT	DS D	7 7 2*256 81 81 81 81 81 7 7 7 7 8 81 81 81 81 81 81 81 81 81 81 81 81 8	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER STATAT OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS ODSF BOPEN CSED CLINI COFA COMTA C20A COMTA C20A COMTA C136 CURSC COCF CX ODSF BELAY C7F1 DHLOP C7DA DISPT C227 DOCRC C7AB ENLO1 C43C EOFER C366 EFFOT C256 EFFOT C367 EFFOT C367 EFFOT C368 EFFO
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C0FA CONT CFF CRLT C2F9 DDFLTS C80A DISPO C222 DDFLTS C80A DISPO C222 E5C5P C168 FCBA2 C85C FDCOU C22E EFFOT C7D2 EFFO	2044 FCBAS 2005 FCBAS 2006 FBUF1 2007 FCBAS 2006 FBUF1 2007 USA FER 2007 COST 2007 FCBUF 2008 FCBAS	DS D	7 7 2 2 2 5 6 6 6 2 2 6 2 6 2 6 2 6 2 6 2 6	IST FILE CONTROL BLOCK 2ND FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN AFEA USED BY CUTER START OF USER AREA E STACK WORKS ITS MAY DOWN FROM IK RAM AREA. AOUT COIC BACKS 005F BOPEN CSEO CHPCK COSE CLINI COFA COMTA C24A CMEM C136 CURSC COCF CX 0016 DELAY C7F1 DHLOP C7DA DISPT C227 DOCHC C7AC ENLO CASC C15F FRUTI C863 FDCOM C231 GCLIN C1ER GTUNZ C7EA HOME 008E INIT C001 ITAB C29A LEFT 0081 LINE C809 MODE MAOUT C500 RFBLT C286 PPD C10A RTBIT C646 RFBDT C286 PPD C10A RTBIT C646 RFBDT C286 PPD C10A RTBIT C646 RFBDT C10A RFBDT C10A RFBDT C266 RFBDT C20B RFBDT C30C RFBDT C
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C0F4 CONT CFF CRLF C2F9 DCNT C80A DCNTC C853 DCRC2 C720 DFLTS C80A DISPO C3C8 DLOOP C3C8 DLOOP C3C8 DLOOP C3C8 DLOOP C3C8 DCNT C80A DCNT C80A DCNT C80A DCNT C80A DCNT C80A DCNT C80A DCNT C90A DCNT C	2044 FCBAS 2005 FCBAS 2006 FBUF1 2007 FCBAS 2006 FBUF1 2007 USA FER 2005 FCBAS 2005 FCBA	DS D	7 7 2*256 81 81 81 81 7 7 115 81 81 81 81 81 81 81 81 81 81 81 81 81	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK BAM AREA. AOUT COIC BACKS ODSP BOPEN CSFD CHPCK COSE CLINI COFA COMTA C20A COMTA C20A COMTA C20A COMTA C20A COMTA C20A CREM C136 CURSC COCF CX ODIR DELAY C7F1 DHLOP C7DR DISPT C227 DOCRC C7AB ENLO1 C43C EOFER C5FF ERR1 C480 ERR01 C206 ESCS C15F FBUF1 C863 FDCOM C231 GCLIM C1ER GTUM2 C7EA HCCV1 C35D HOME C18C GCLIM C36D HOME C
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C0F4 CONT CFF CRLF C2F9 DCNC C553 DCRC2 C720 DFLTS C80A DISPO C3C8 DLOOP C3C8 DLOOP C3C8 DLOOP C3C8 DLOOP C3C8 DLOOP C3C8 DCNC C656 DCNC C656 DCNC C656 DCNC C656 CTUNT C7DE HE001 CA1A HSPR C829 INPTR C80C KDATA C606 GTUNT C7DE HC01 C3C8 LIST1 C539 MAME C469 NCHAR C808 MLOOP C56A OCHAR C908 MLO	2044 FCBAS 20045 FCBAS 20045 FCBAS 20045 FCBAS 20045 FCBAS 20045 FCBAS 20050 PT 2051 PT 2051 PT 2052 PT 2051 PT 2051 PT 2052 P	DS D	7 7 2*256 81 81 81 81 81 81 81 81 81 81 81 81 81	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS ODSF BOPEN CSEO CHPCK COSE CLINI COFA COMTA C20A COMTA C136 CURSC COCF CX OCIE DELAY C7F1 DHLOP C7DR DISPT C227 DOCRC C7AR ENLO1 C43C EOFER C5F0 EFR1 C860 ESCS C15F ERR1 C77
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C571 CLINE C572 CONT C1FF CRLF C2F9 DCNCC C720 DFLTS C80A DISPP C3C8 DLOOP	2044 FCBAS 20045 FCBAS 20045 FCBAS 20045 FCBAS 20045 FCBAS 20045 FCBAS 20050 PT 2051 PT 2051 PT 2052 P	DSS	7 7 2*256 81 84 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS ODSP BOPEN CSEO CHPCK COSE CLINI COFA COMTA C20A CREM C136 CURSC COCF CX OO18 DELAY C7F1 DHLOP C7DR DISPT C227 DOCRC C7A8 ENLOI C43C EOFER C5FF ERRI C206 ERRI C20
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C0F4 CONT CFF CRLF C2F9 DCNT C80A DCRC2 C720 DFLTS C80A DISPP C3C8 DLOOP C	2044 FCBAS 2005 FCBAS 2006 FBUF1 2007 FCBAS 2006 FBUF1 2007 USA FER 2009 FCBAS 2009 FCBA	DSS	7 7 2*256 8 8 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS ODSP BOPEN CSEO CHPCK COSE CLINI COFA COMTA C20A COMTA C20A COMTA C20A COMTA C20A COMTA C20A COMTA C20A CREM C136 CURSC COCF CX OO18 DELAY C7F1 DHLOP C7DA DISPT C227 DOCRC C7A8 ENLOI C43C EOFER C5FF ERRI C486 ERROI C256 ERROI C33A ERROI C
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C571 CLINE C579 CUSE2 C720 DFLTS C80A DISPO C3C8 DOWN 009A ENLOS C459 ENLO	2044 FCBAS 20045 FCBAS 2006 FBUF1 2007 FCBAS 2006 FBUF1 2007 USA FER 2000 FTBUF1 2007 USA FER 2000 FTBUF1 2007 CBUF1 2007	DS D	7 7 2*256 81 81 81 81 81 81 81 81 81 81 81 81 81	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS ODSP BOPEN CSEO CHPCK COSE CLINI COFA COMTA C20A CEMENT C7F1 DHLOP C7DR DISPT C227 DOCRC C7AB ENLOI C43C EOFER C5FF ERRI C48G ERROI C256 ERROI C33 FDCOM FD
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C0F4 CONT C1FF CRLF C2F9 DCNC C520 DFLTS C80A DISPO C3C8 DLOOP	2044 FCBAS 2005 FCBAS 2006 FBUF1 2007 FCBAS 2006 FBUF1 2007 USA FER 2009 FTM 2009 FT	DSS	7 7 2*256 81 81 81 81 81 81 81 81 81 81 81 81 81	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER STARFOF USER AREA AOUT COIC BACKS OSSF BOPEN CSEG CUPIC COSE CLINI COFA COMTA C24A COMTA C24A COMTA C24A COMTA C24A COMTA C26A DELAY C7F DHODY C7DH DDCFC C35 EMILY C7F DDCFC C35 EMILY C7F DDCFC C36 EMILY C7F DDCFC C36 EMILY C7F DDCFC C37 DCCFC C38 EMILY C37 DCCFC C38 EMILY C37 DCCFC C38 EMILY C37 DCCFC C38 EMILY C38
ADOUT C3E8 ARET C19B BLANK 0020 BOTI C50A CHRLI C571 CLINE C579 CUSE2 C720 DFLTS C80A DISPO C3C8 DOWN 03 C459 EDFLTS C80A DISPO C3C8 DLOOP C3C8	2044 FCBAS 20045 FCBAS 20045 FCBAS 20045 FCBAS 20045 FCBAS 20040 FCBAS 20050 F	DSS	7 7 2*256 881 881 881 881 881 881 881 881 881 88	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS ODSP BOPEN CSEO CHPCK COSE CLINI COFA COMTA C20A COMTA C20A COMTA C20A COMTA C20A COMTA C20A CEM DELAY C7F1 DHLOP C7DR DISPT C227 DOCRC C7AB ENLOI C43C EOFER C5FF ERRI C48G ERROL C25G ERROL C25G ERROL C25G ERROL C25G ERROL C33 FDCOM ERROL C33 FDCOM C33 FDCOM C33 FDCOM C33 FDCOM C33 FDCOM C34 FDCOM C35 FDCOM C35 FDCOM C36 FDCOM C37 FDCOM C37 FDCOM C37 FDCOM C38 FDCOM C38 FDCOM C38 FDCOM C39 FDCOM
ADOUT C3E8 ARET C19B BLANK 0020 BOT C80A CHRLI C571 CLINE C571 CLINE C579 CUSSE C553 DCRC2 C720 DFLTS C80A DISPO C3C8 DLOOP C3C8 DLO	2044 FCBAS 2005 FCBAS 2006 FBUF1 2007 FCBAS 2006 FCBAS 2006 FBUF1 2007 USA FEE 2000 FTB 2000	DSS	7 7 2*256 881 881 881 881 881 881 881 881 881 88	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER START OF USER AREA E STACK WORKS ITS WAY DOWN FROM IK RAM AREA. AOUT COIC BACKS ODSP BOPEN CSED CHPCK COSE CLINI COFA COMTA C20A COMTA C20A COMTA C20A COMTA C20A COMTA C20A CREM C136 CURSC COCF CX OD18 DELAY C7F1 DHLOP C7DR DISPT C227 DOCRC C7AB EMLO1 C43C EOFER C36 ERF01 C486 ERF01 C486 ERF01 C486 ERF01 C486 ERF01 C585 ERF01 C585 ERF01 C788 ERF01 C
ADOUT C3E8 ARET C198 BLANK 0320 BOT C80A CHRLI C571 CLIME C0FF CRLF C2FF CRLF C2FF CRLF C2FF CRLF C3AB DCRC C3AB CABB CABB CABB CABB CABB CABB CABB	2044 FCBAS 2045 FCBAS 2046 FBUF1 2047 FCBAS 2046 FBUF1 2047 USA FEE 2049 STUSA FEE 2049 STUSA FEE 2049 STUSA FEE 2051 STUSA 2051 STUSA 2052 STEE 2052 STEE 2052 STEE 2052 STEE 2052 STEE 2052 STEE 2053 STEE 2053 STEE 2053 STEE 2053 STEE 2053 STEE 2053 STEE 2054 STEE 2055 STEE 2055 STEE 2055 STEE 2055 STEE 2055 STEE 2056 STEE 2056 STEE 2057 STEE 2058 STEE 2	DSS	7 7 2*256 881 881 881 881 881 881 881 881 881 88	IST FILE CONTROL BLOCK SYSTEM FILE BUFFER PASE THIS IS AN APEA USED BY CUTER START OF USER AREX E STACK WORKS ITS MAY DOWN FROM IK BAM AREA. AOUT COIC BACKS 005F BOPEN CSEO CHPCK COSE CLINI COPA COMTA CPAA CO

TOE	0010	TOFF	C70B	TON	C7EF	TOUT	CARE
TREDY	C773	TSAVE	CAE6	TSPD	CBOD	TSRCH	0082
TTBE	0080	TXEQ	C4A6	UBUF	C5F5	UIPRT	C800
UOPRT	C802	UP	0097	USARE	CABA	VDAD	C123
VDAD2	C120	VDADD	CIIC	VDHEM	CCOO	VOMOT	C054
WFBLK	C77C	WHEAD	CTAF	WLOOP	C7C5	WRBLK	C014
WRBYT	C010	WRLO 1	C790	WRTAP	C79D	WRWAT	C79F
WT1	C69B	WTAP2	C791	WTAPE	C77F	WTRL	C7C3
WTBYT	C683	WTLP1	C400	WTON	C7ED	XEGAD	C827

Processor Technology Dealers

ALABAMA	
ALABAMA ICP, Computerland 1550 Montgomery Hw Birmingham, AL 35226 (205) 979-0707	
1550 Montgomery Hw	y
Birmingham, AL 35220	5
(205) 979-0707	

ARIZONA

Byte Shop Tempe 813 N. Scottsdale Rd. Tempe, AZ 85281 (602) 894-1129 Byte Shop Phoenix 12654 N. 28th Dr.

Phoenix, AZ 85029 (602) 942-7300 Byte Shop Tucson 2612 E. Broadway Tucson, AZ 85716 (602) 327-4579

CALIFORNIA

The Byte Shop 1514 University Ave. Berkeley, CA 94703 (415) 845-6366

Byte Shop Computer Store 6041 Greenback Lane Citrus Heights. CA 95610 19161 961-2983

Computer Center 1913 Harbor Blvd. Costa Mesa. CA 92627 (714) 646-0221

Data Consultants, Inc. 2350 W. Shaw, Suite 114 Fresno, CA 93711 (209) 431-6461

Bits 'N Bytes 679 S. State College Blvd. Fullerton. CA 92631 (714) 879-8386

The Byte Shop 16508 Hawthorne Blvd. Lawndale, CA 90260 (213) 371-2421

The Byte Shop 1063 El Camino Real Mountain View, CA 94040 (415) 969-5464

Digital Deli 80 W. El Camino Real Mountain View. CA 94040 (415) 961-2828

The Computer Mart 624 West Katella #10 Orange. CA 92667 (714) 633-1222 The Byte Shop 2227 El Camino Real

Palo Alto. CA 94306 (415) 327-8080 Byte Shop 496 South Lake Ave. Pasadena. CA 91101 (213) 684-3311

The Computer Store of San Francisco 1093 Mission Street San Francisco. CA 94103 (415) 431-0640

Byte Shop 321 Pacific Ave. San Francisco, CA 94111 (415) 421-8686

The Byte Shop 2626 Union Avenue San Jose. CA 95124 (408) 377-4685

The Computer Room 124H Blossom Hill Rd. San Jose. CA 95123 (408) 226-8383

The Byte Shop 509 Francisco Blvd. San Rafuel. CA 94901 (415) 457-9311

The Byte Shop 3400 El Camino Real Santa Ciara. CA 95051 (408) 249-4221

Recreational Computer Centers 1324 South Mary Ave. Sunnyvale, CA 94087 (408) 735-7480

Byte Shop of Tarzana 18424 Ventura Blvd. Tarzana, CA 91356 (213) 343-3919

The Byte Shop 2989 North Main St Walnut Creek, CA 94596 (415) 933-6252 Byte Shop 14300 Beach Blvd. Westminster. CA 92683 (714) 894-9131

COLORADO

Byte Shop 2040 30th St Boulder. CO 80301 (303) 449-6233

FLORIDA

Sunny Computer Stores University Shopping Center 1238A S. Dixie Hwy. Coral Gables, FL 33146 (305) 661-6042

Delta Electronics 2000 U.S. Hwy. 441 East Leesburg. FL 32748 (904) 357-4244

Byte Shop of Miami 7825 Bird Road Miami. FL 33155 (303) 264-2983 Microcomputer Systems Inc. 144 So. Dale Mabry Hwy. Tampa. FL 33609 (813) 879-4301

GEORGIA

Atlanta Computer Mart 5091-B Buford Hwy. Atlanta. GA 30340 (404) 455-0647

ILLINOIS

The Numbers Racket 623¹⁻² South Wright St Champaign, IL 61820 (217) 352-5435

itty bitty machine co. 1316 Chicago Ave. Evanston. IL 60201 (312) 328-6800

Reeves Communications 1550 W. Court St. Kankakee. IL 60901 (815) 937-4516.

itty bitty machine co. 42 West Roosevelt Lombard, IL 60148 (312) 620-5808

INDIANA

The Data Domain 406 So. College Ave. Bloomington, IN 47401 (812) 334-3607

The Byte Shop 5947 East 82nd St. Indianapolis, IN 46250 (317) 842-2983

The Data Domain 7027 N. Michigan Rd. Indianapolis. IN 46268 (317) 251-3139

The Data Domain 219 West Columbia West Lafayette. IN 47905 (317) 743-3951

KENTUCKY

The Data Domain 3028 Hunsinger Lane Louisville, KY 40220 (502) 456-5242

MICHIGAN

The Computer Store of Ann Arbor 310 East Washington Ann Arbor, MI 48104 (313) 995-7616 Computer Mart or Royal Oak 1800 W. 14 Mile Rd. Royal Oak, MI 48073 (313) 576-0900

Genral Computer Store 2011 Livernois Troy, MI 48084 (313) 362-0022

NEW JERSEY

Hoboken Computer Works No. 20 Hudson Place Hoboken. NJ 07030 (201) 420-1644

NEW YORK

The Computer Mart of Long Island 2072 Front Street East Meadow. L.1.. NY 11554 (516) 794-0510 Synchro Sound Enterprises 193-25 Jamaica Ave Hollis, NY 11423 (212) 359-1489

The Computer Shoppe 444 Middle Country Rd. Middle Island, NY 11953

Audio Design Electronics 487 Broadway, Ste. 512 New York, NY 10013 (212) 226-2038

The Computer Mart of New York 118 Madison Ave. New York. NY 10001 (212) 686-7923 The Computer Corner 200 Hamilton Ave. White Plains. NY 10601 (914) 949-3282

OHIO

Cybershop 1451 S. Hamilton Rd. Columbus. OH 43227 (614) 239-8081

OKLAHOMA High Technology 1020 West Wilshire Bivd. Oklahoma City. OK 73116 (405) 842-2021

OREGON

Byte Shop Computer Store 3482 S.W. Cedar Hills Blvd. Beaverton, OR 97005 (503) 644-2686 The Real Oregon Computer Co. 205 West 10th Ave. Eugene. OR 97401 (503) 484-1040

Byte Shop Computer Store 2033 S. W. 4th Ave. Portland, OR 97201 (503) 223-3496

RHODE ISLAND Computer Power. Inc M24 Airport Mail 1800 Post Rd. Warwick. RI 02886 (401) 738-4477

SOUTH CAROLINA Byte Shop 2018 Green Street Columbia, SC 29205 (803) 771-7824

TENNESSEE Microproducts & Systems 2307 E. Center St. Kingsport. TN 37664 (615) 245-8081

TEXAS

Byte Shop 3211 Fondren Houston. TX 77063 (713) 977-0664

Computertex 2300 Richmond Ave Houston, TX 77098 (713) 526-3456

Interactive Computers 764612 Dashwood Rd. Houston, TX 77036 17131772-5257 The Micro Store 6.34 So. Central Expressway Richardson, TX 75080 (214) 231-1096

VIRGINIA The Computer Systems

Store 1984 Chain Bridge Rd McLean, VA 22101 Media Reactions Inc 11303 South Shore Dr Reston, VA 22(80) (703) 471-9330

WASHINGTON

Byte Shop Computer Store 14701 N. E. 20th Ave Bellevue, WA 98007 (206) 746-0651

The Retail Computer Store 410 N.E. 72nd Seattle, WA 98115 (206) 524-4101

WISCONSIN

The Milwaukee Computer Store 6916 W North Ave. Milwaukee WI 53213 (414) 259-9140

CANADA

Trintronics 160 Elgin St. Place Bell Canada Ottawa. Ontario K2P 2C4 (613) 236-7767

First Canadian Computer Store, Ltd. 44 Eginton Ave West Toronto, Ontario M4R IAI (416) 482-8080

The Computer Place 186 Queen St. West Toronto, Ontario MSV 1Z1 (416) 598-0262

Pacific Computer Store 4509-11 Rupert St. Vancouver B C, V5R 2J4 (604) 438-3282

Dear sir, I am sending this picture to you.

My father's name;
Edwards. Miller


(I have a new father,)

Computer Art Museum





Processor Technology CIA 6200 Hollis Streets EmeryIlle, Cal. 94(0)





Vol. 1, No. 3


Bulk Rate
U.S. Postage
PAID
Permit No. 3729
Oakland, Calif.


6200 Hollis Street Emeryville, CA 94608

Processor Technology Corp.

Stanley M. Sokolow, DDS 1577 Canada Lane Woodside, CA 94062







The feedback is starting to come in at a most gratifying rate, so we'll get on to the news of note after a brief commercial for our technical troubleshooting hotline—call 415-829-2600 weekdays between 9:30 and noon or 1:30 to 4.

Software availability—good news time. Are you ready? A good portion of Processor Technology Software is. Specifically, TREK-80, ALS-8, GAMEPAC, and BASIC/5 (all on the most-wanted list) are now available and in stock at your local dealer. No paper tape versions, though—we're no longer producing any Processor Technology software on paper tape.

As for other software, you can currently look for SW#1 (Assembler) and MATHPAK in mid to late October; New 8080 FOCAL and 8K, and extended DISK BASIC on November 15. Incidentally, the two BASICS will have some capabilities we haven't advertised previously, such as complete matrix operations including matrix addition, subtraction, multiplication and inversion. Sure wish I'd had a Sol with 8K BASIC when I took linear algebra!

And look for some new software surprises turning up soon at your local dealer. We do appreciate your patience in waiting for software production and availability, and you won't be disappointed with the final product.

Software cassettes. Just a reminder that all our audio cassettes

are recorded on two sides. Side 1 is in CUTS Standard (SOLOS/CUTER compatible, recorded at 1200 baud); Side 2 is Kansas City Standard at 300 baud, in case you don't have a Sol or CUTS audio cassette interface board.

Hardware: Helios II is coming. After many frustrating engineering and software development delays, deliveries have begun on the Processor Technology Helios II dual-drive floppy disk system. If you have one on order, either through a dealer or directly from us, rest assured that it's on its way. Unfortunately, we have so many orders we probably won't get through the entire backlog until late November or early December. If you want additional information, or you'd like to see a demonstration, check your local dealer, or give us a call.

We've been emphasizing the importance of our dealers all along, and they are your best first source. They're far more able to provide the service you deserve than we are from our distant factory, and they're always happy to hear from you. They're all authorized to perform service and repairs on all our products, and we're adding new dealers rapidly. Retail computer stores are multiplying like rabbits, in case you hadn't noticed.

Lloyd's Second Law: Any program can be written in fewer commands.

ENTER THE GREAT SHOW-OFF-YOUR-SOL CONTEST

and maybe win a GPM/Sol with ALS-8 SIM-1/TXT-2 ROM set

All you have to do is tell us how you are using your Sol. The grand prize will be awarded for the most interesting and/or unusual application; runner-up gets the Software Technology MUSIC SYSTEM, an interesting way for you and your computer to make music. And all of the more interesting entries have a chance to get published in future issues of ACCESS, with full credit to your resourcefulness and imagination.

Use the form on the back page to enter, using additional paper as needed. We'd like to have as much technical information as possible; i.e., what kind of hardware support was needed to get Sol to do your thing? And please be as specific as possible about when and where you're using it—business, science, industry? At home? What's it doing? Have you interfaced it to your lawn sprinklers, burglar alarm, Chevrolet? (We've heard of Sols used in the most provocative ways!)

We reholding this contest with three motives in mind. 1) To provide us with some feedback on what Sols are doing and how they're doing it, so we can direct our future efforts accordingly. 2) To give you, the Sol user, some insight into what other Sols are up to so you can pick up some nifty ideas for yours. 3) To provide a little excitement, fun and games for everyone.

The prizes will be awarded by the most impartial judges we can scout up to objectively determine the most original, unusual and imaginative application of a Sol. Programs and developmental work you may have done are valid entries, so get those pencils going on the entry form. Mail your entry to:

Sol Applications Contest Processor Technology 7100 Johnson Industrial Drive Pleasanton, CA 94566 Closing date is December 1, 1977.

Table of Contents

Reader Feedback page 4

Sol User's Society gets into action with lots of plans and they're ready for input page 6

Colgate Spinx opinionates re the software flexibility of Helios II page 7

WINZI?!! A collection of short programs, featuring the likes of Hic, Opps, and Chase.....page 8

Save your Sol's bytes with just a few little changespage 13

Some uppercase key software to save wear and tear on your patience whenever you restart or power up Sol.....page 14

How to hear your Sol keyboard, and shape up your touchkey typing page 15

Run/Stop, Part II, tells you more about monitoring the operation of your Sol.... page 15

PLUS: A program for Home Accounting (p. 17), an 8080 Relocatable Assembler (p. 20), an ALS-8 to Sol Patch (p. 22), an Intel Tape Loader for Sol (p. 23), Newett Awl's Choo Choo Updated for Sol (p. 25), and Galaxy (p. 29).



"Any minor of order r in the adjugate determinant of a square matrix A is, on expansion, a certain polynomial in the elements of A, fixed in form whether A is singular or note."

Determinants and Matrices

"There are no Jewish midgets." Lenny Bruce

Well, how do you like our new format? Now you can keep our deathless prose (and occasionally valuable information) neatly in a 3-ring binder instead of stacked up on the floor someplace to hide the cigarette burns. (Oh, you liked having something to hide the cigarette burns?) It should prove a more useful reference format, and we'll keep working on making ACCESS responsive to your needs. May even get classy soon and go to two-color.

Notes from the show circuit: We had one display at NCC (Dallas) and another at WESCON (San Francisco). Seems like computer shows are cropping up everywhere you look, and unfortunately we just don't have time to keep up with them all. It's great to see so much interest developing though—remember back to the dark ages when you were the only computer freak in town, all of a couple of years ago?

Meanwhile, instead of going to shows we're keeping our noses to the grindstone. The first Helios shipment is out and more are on the way. ALS-8 on CUTS cassette is now

shipping, and 8K BASIC is set for mid-November. Ralph has more to say about new products, so take a look at his 1-to-1 column.

By the way, if you send us software contributions, try to give them to us on CUTS cassette. That way we can run out a listing, send it off to the printer, and it turns up in the next ACCESS in a neat standard format just the way you wrote it. If we have to have the listing typeset, there's just that much more chance of an error creeping in and turning your beautiful program into a debugger's nightmare. We are getting some nifty programs from you people -take a look at Guy Campbell's home accounting system and Melvin Schehlein's modification to avoid erasing input lines, both in this issue.

We're always interested in all forms of communication with the outside world. If you are a member of a club, or publish a newsletter yourself, I'd really like to hear about it. We might be able to exchange membership or subscription lists. That way we'd all be getting more information, and know more about each other.

Well, bye now—y'all come see us at our new home in Pleasanton, v'heah?

Aram Attarian II

Subscription Information

Access is published every six weeks. If you like what you see, we hope you'll send us \$4.00 for a year's subscription so we can keep the info coming. Write to us at Processor Technology, 7100 Johnson Industrial Way, Pleasanton, CA 94566.

Have YOU Moved?

Please notify us of your change of address. Here's a handy form:

_			
			-
N	Λ	M	-
1.4	~	IAI	┗.

NEW ADDRESS_



Gentlemen:

Having picked up a copy of #2 ACCESS at the N.C.C., I've been delighted at your fresh style of presentation.

The Texas A & M Microcomputer Club is composed of a number (about 50) of micro-computer buffs who are mainly software-development oriented. If you visited the Personal Computing Faire at N.C.C. you may have seen the APL-Core booth which is a club project. Robert Arnstein and Ian Kettleborough are former members of the club.

I was wondering if it would be possible for you to send us a few copies of ACCESS whenever it is published for distribution to interested club members. MITS does this with Computer Notes, which, of course is putting the advertising into a spot where it may potentially do the most good. However Computer Notes is rather dry on occasion.

The SOL system has been demonstrated a number of times for the club and it always draws quite a bit of interest. Several members of the faculty in various computer-related disciplines are considering a purchase.

Congratulations on a very readable publication.

Sincerely, Robert R. Weir Summer Caretaker, TAMUCC

Dear Bob:

Thanks for the strokes. We'll put you on our mailing list right away, and we'll be glad to do the same for any other clubs who care to drop us a line.

Aram

Gentlemen:

As the satisfied user of two Sol systems I have encountered a problem when using the device as a terminal. The problem occurs because of the PCR routine in the VDM section of SOLOS. The attached assembly listing should be self explanatory as a successful solution. (See p. 20, this issue.)

Secondly, how come your company wasn't directly represented at Atlantic City this year? I know by talking to friends in the computer hobby field that you are having great difficulty delivering some of your new product line. Your equipment is of such high quality across the board most of us are willing to wait. Do you have something to hide or did you opt for Boston?

Yours truly, Melvin E. Schehlein, Ass't. Director of CMS

Dear Mel:

Thanks for a good idea: being able to check the last input certainly helps. Your program appears on page 20 of this issue. As for the shows, the cost of hitting all the ones cropping up on the East Coast especially is just prohibitive. We wouldn't have any money left to produce Sol's with. But we will make the New York City show in October. Right about now in fact.

Aram

Dear Aram:

I recently purchased, assembled and am running a SOL-20 under SOLOS. As a first trial exercise (having only 4K), I entered Newett

Awl's Choo Choo Train. After much gnashing of teeth, wringing of hands and tracking of unstructured programming. I got it running. The trick was in the instruction in location 0156H; instead of an "IN 0" (DB00), SOLOS requires an "In FC" (DB FC). This is in addition to the necessary "C3 C9C1" in 0163H to return to SOLOS.

My purpose in writing this letter is not so much to relay the above software changes as to point out where I think ACCESS could play a large part in information dissemination. I received very little information with my SOL-20, regarding how to use the various devices with SOL (tape recorders, etc.). After scanning through the SOL manual and SOLOS listing, I found the skeleton references to the memory map and port addresses.

I could not locate any information of the complete hex-to-VDM character set, including all the obscure characters like ♀ and ≡. How about some examples of programs using the subroutine calls to SOLOS, particularly for animation on the VDM? In closing, I would like to compliment you on the publication of ACCESS. It is reassuring to have some further "feed-forward" from the vendor once the hardware has been sent. Keep up the good work!

Yours truly, Warren L. Harkness (In SOLOS UNUM)

Warren:

Thanks for the feedback, and we will keep supplementing the manual with helpful tips via ACCESS. Also, this issue has the Choo Choo listing modified to run on Sol.

Aram

To: Processor Technology Co. ACCESS Editor

Thanks for a fine publication and outstanding products! Thought you might include this modification to the Sol system in ACCESS.

I am presently stationed in Japan with the U.S. Air Force. The

domestic power here is on the European standard, that is 50hz at 100 olts. Now the SOL-20 power sup
/y doesn't seem to mind that at all,

bus voltages are right up there, but the "swim" effect on the display could give you a splitting headache in short order.

The answer to my problem was actually quite simple. I needed four more character rows during the blanked period of the display. To obtain the extra rows I changed the preset count of U62 during the high state of VDISP, the display blanked. This change was implemented by disconnecting pin 5 of U62 from the VDISP line and tying it to ground. This gives me a total of 16 displayed and 8 blanked character rows for a total of 24 rows with 312 scan lines, a close match for the 50hz operation.

I accomplished the MOD without cutting any P.C. foil or removing the main board from the Sol chassis. Parts needed are: one Molex Pin and a short length of flexible wire.

Remove IC 62 from its socket. Carefully scrape a small bare spot on the large ground bus running near the left of the IC socket; just remove the solder mask, don't cut ie bus. Solder the Molex Pin to a one-inch length of wire and then the wire to the ground bus. Bend pin 5 of the 93L16 IC outward 45 degrees and insert the IC in the socket leaving pin 5 projecting outwards. Now slip the Molex Socket over the protruding IC pin. . . . That's it. And no permanent disfigurement of my precious Sol when I returned to the land of 60hz.

I hope that others will profit from this modification.

Ray D. Congdon 1956 COMM GP/OLC APO San Francisco CA 96343

Ray:

Thanks much.

Aram

Dear Mr. Attarian

Enclosed you will find a check for \$4.00 for my 1-year subscription to ACCESS. Also, I have a few questions and suggestions.

1. I am a firm supporter of your company. If there is any way I can contribute to its continued success, let me know. I am presently unemployed, so most of my time is spent exploring my Sol 20 system. Unfortunately, I paid for my system via a loan. In another month or so, I won't be able to pay off this loan. If I don't find some sort of income soon, I may have to sell my Sol. I don't want to have to do this!! My being located in the center of the eastern megalopolis should open some possibilities. If there is any way possible, HELP!!

So far, I have written some original programs. One demonstrates the use of control characters and the escape sequences used by BASIC5. I have also written machine subroutines which can be used with BASIC5 to produce some special effects.

I also do some hardware design. I have completed design of

a 16K static memory board using MOSTEC 4104's. I am working on a few other things as well.


If there is any way I can help, even with nothing in return, please let me know. As far as some sort of income, if you can't help, maybe one of the readers can.

Note: I will relocate.

2. It is said that escape sequences can be used to generate characters in inverse video. I have not been able to figure out how to do this. Could you please shed some light on this subject.

3. In regard to a letter from Joseph P. Chalala, Willow Street, Pa., in Vol. 1, #3, I agree completely with his suggestion for a notebook type publication for ease of filing.

Well, that's all for now. I'm sure there will be more in the future. Remember Murphy's Law of Thermodynamics which states "Things get worse under pressure." So, take the time required to do, whatever,



Computer Art Museum

right (within reason, of course). If not, it will cost you more later.

A dedicated Sol user, David F. Wrobel

P.S. The Bayshore Amateur Computer Group, of which I am president, consists of dedicated microcomputer hobbyists. Of which, only a few are Sol owners. We would like more. We are located in central N.J. Our address is: BACG P.O. Box 132, Holmdel, N.J. 07733.

David:

There's a good reason you haven't figured out how to generate characters in inverse video—it's **not** true that it can be done. Sorry. Hope the new format meets your filing needs.

And can anybody out there help David find work and save his Sol?

Aram

Dear Editor

I am always reluctant to send one of my little masterpieces in for publication, but it seems like everyone else is a little shy also, and I know that there are a lot of Sol owners, like me, anxious to try out some of its unique features.

For whatever it's worth, I'm sending a short program that makes use of the File commands in Basic 5. It's not meant to be a finished product, but it does demonstrate one way to use commands. In fact, I hope someone will pick up the ball and make a better program out of it.

The purpose of the program is to allow the user to slip last month's data tape into one file, pay the bills, update the household accounts and store the updated accounts on the other file.

I have included a sample program for setting up the original data tape, (similar to the one in the Basic 5 manual), the actual program I use for working the accounts, and a sample run.

Sincerely yours

Guy W. Campbell 5815 Buckley Drive Jacksonville, FL 32210

Guy:

Thanks. This is the kind of creative input we really appreciate. Readers: Guy's program appears on p. 17 of this issue.

Aram

We've Moved Again!

For the same reason as last time—we ran out of space and outgrew the facilities again. We've now forsaken Emeryville for sunny Pleasanton, CA, just over the hill. If you're curious about the history of Pleasanton, or just curious, I refer you to

a book entitled "Mammy Pleasant," by Helen Holdreage.

The new address is Processor Technology Corp. 7100 Johnson Industrial Way Pleasanton, CA 94566 Phone: 415-829-2600



Join the Sol Users'Society

The Sol Users' Society got under way Sunday, July 31, when about 30-40 Sol users met for the first organizational meeting. The Society is open to everyone who has a Sol or a Sol-type compatible system, so they're hoping to see even more of you at the next meetings.

This first time out a steering committee was elected, and goals were set for the Society. These goals are:

- 1. To facilitate communication between Sol owners.
- 2. To provide feedback from Sol owners to PTC.
- 3. To provide a mechanism for exchanging Sol software.
- 4. To encourage development of Sol-compatible products by other manufacturers.

Some time was spent just getting to know one another and talking about various projects the club can tackle. Seems that most of the stuff users have to offer is software, but they're also interested in reviewing any hardware submitted to the Society, be it prototype or production. They can't supply certification, though.

One project definitely under way is a Sol Users' Society newsletter. Contributions and comments herewith solicited.

A tidbit that emerged from the first meeting: TDK Auda C-60 cassette tape performs best in a bitchopping test.

Schedule of meetings. The group is set to meet on Sundays Oct. 16, Nov. 20, and Dec. 18, at Varian Physics Lab, 2nd Floor, Stanford CA. Come meet the new steering committee: Bill Burns, Dave Fylstra, Ron Findlay, Ben Milander, Bill Holding, Stan Sokolow, David Fox.

For more information, please write to:

Bill Burns 4190 Maybell Way Palo Alto, CA 94306 (no phone calls, please . . .)

Review:

1 EPT 2 - 57

Software Capabilities of the Helios II Disk System

The Helios II system has several capabilities I haven't seen in other disk systems on the market, and one particularly notable advantage for use with the Processor Technology Disk Operating System: you can write I/O routines for the Helios which permit the use of any I/O controller in conjunction with PTDOS, including the Cromemco D to A board and just about any homebrew board you've already built. (Maybe not some that perform DMA or make use of the I/O ports as control ports by the disk controller.)

The reason for this flexibility is that Helios treats all files as data files, including the device files used for I/O routines. These differ from regular files in that data read from or to them will come or go directly to the devices controlled by the I/O routine. With Helios, the only thing you have to worry about is to make sure you follow the guidelines in the PTDOS user's manual when you write your I/O routine.

Software support is another big plus for Helios. It offers a disk assembler, two editors (one ALS-8 type, one Nova-type), library functions, a debugger, language systems, procedures (PROCS), and full interface to PTDOS on command or assembly level.

The disk assembler allows you to generate object and listing files from a source file. You have the options of specifying if the input file is ALS-8 type, if it has line numbers.

if it has form control, and a few other things.

The ALS-8 type editor is especially useful on systems with a lot of memory because you can work with text, as in the ALS-8. You have the options of scrolling forward and backward through the text, deleting characters, searching character strings, moving blocks of code, replacing string patterns with others as found. The limitation to this editor is that it requires the VDM-1.

The Nova-type editor can be run on almost any terminal, since all I/O is run through the system console routines. It will yank pages into the edit buffer, change data in the page, and write it out. If offers many of the same functions as the ALS-8 type.

Library functions allow you to assemble several source files which make up one logical program. It's done through the use of a copy verb included in the PTDOS assembler. You could expand the use of this verb to build up a library of source files which perform common functions, then concatenate these files into an object file through the assembler.

The debugger serves a function similar to that of the simulator in the ALS-8: you can run object code in a controlled environment. However, the debugger runs real time instead of the simulator's interpretive mode. You can use it to set numerous break points; examine

memory in hex, character, or instruction format, alter memory or output drivers; and do several other useful debugging tasks.

The broad spectrum of language systems available includes a DISK BASIC and DISK FOCAL; FORTRAN is rumored to be among those upcoming. Language support is definitely one of the big advantages of the Helios system.

The command interpreter gives access from the console to many of PTDOS's numerous entry points. A partial list of the commands available: SPACE, OPEN, CLOSE, KILL, RANDOM, SEEK, RENAME, REATR, RETYPE, CREATE, READ, WRITE.

With PTDOS, you can also enter procedures in ALS-8 type file formats as a series of commands which may include optional statements.

The PROCS itself is simply a list of commands which you can enter and allow to execute consecutively. Very useful for setting up, say, a 3-hour listing to print out while you get some sleep.

All in all, the Helios II disk memory system has proved well worth the time and price from this user's point of view.

Colgate Spinx



Cynic: One who is enough to make anyone a pessimist.



JINZI



WINZI is a collection of programs that were originally written last summer for VDM1 and published in D.D.J. They have been rewritten for a Sol with a SOLOS personality | tions are as shown, upper right.

module and addressed to use the 1K of RAM available on the Sol P.C. board.


> The programs are: H ic-a random walk O pps—draw a picture without returning C hase-make the turtle catch the bouncing bug L ife-the 'game' of LIFE

The speed of Hic, Opps, Chase and Life are under control of the SET command (see SOLOS manual). Before Executing C900 SET S=80. If you fail to set the speed first, the speed is so fast that you won't see it happen.

Type 'H' for Hic, 'O' for Opps, or 'C' for Chase

In Hic the beastie should be moving around leaving asterisks. If it is not moving, the random number generator might not be working. It is important not to zero memory before loading this program. In particular the Data Storage area SH should be nonzero. When you get tired of watching it, hit CR and return to the executive.

In Opps, you control the direction the beastie moves. The direc-



Type the number corresponding to the desired direction. The beastie will proceed in that direction until another direction is given. '0' will stop the beastie. '5' will cause a wipe out. '?'. If the beastie ever returns to a location where it's been a ' \(\cdot \) will appear and the program will return to the executive, hence the name: Opps. If you wish to return to the executive at any other time type CR.

Life requires that there is an initial population of asterisks on the screen. Place them there by either Hic or Opps. Then enter Life by typing L from the executive. The CR will return you to the executive. 1K of RAM 0-3FF Hex is needed by Life as a scratchpad.

C900	CD	C5	CA
C9Ø3	CD	FE	C9
C906	FE	43	
C9Ø8	CA	1 D	C9
C90B	FE	48	
C9ØD	CA	5D	C9
C910	FE	4F	
C912	CA	76	C9
C915	FE	4C	
C917	CA	09	CA
C91A	C3	03	C9
C91D	CD	C5	CA
C92Ø	CD	84	CA
C923	3A	CF	CA
C926	77		
C927	EB		
C928	CD	84	CA
C92B	3A	CE	CA
C92E	77		
C92F	CD	F1	C9
C932	CD	FE	C9
C935	36	20	
C937	CD	A3	C9

0090	CALL CS
0100	RET CALL KB
0120	CPI 'C'
0130	JZ CH
0140	CPI 'H'
0150	JZ HI
0160	CAI .O.
0170	JZ OP
0180	CPI 'L'
0190	JZ LI
0220	JMP RET
1000	CH CALL CS
1005	CALL INIT
1010	LDA FO+1
1020	MOV M.A
1030	XCHG
1040	CALL INIT
1050	LDA FO
1060	MOV M.A
1070	CI CALL DL
1075	CALL KB
1080	MVI M, 20H
1090	CALL MV

branches to chase on C,
Hic on H,
Opps on O, and
Life on L.
ChaseClear the screen. Place the bug at a random location on the screen.
Place the turtle at a random location on the screen. Wait a while.
Put a space where you are,

Clear the screen The executive routine

then move.

1		Ne il					WIIVZI, COIII.
1							
-	C93A		CF	CA	1100	LDA FO+1	If the bug is there,
	33D				1110		you've got him.
44.000	33E				1120		All the second of the second of
r	741	3A	CE	CA	1130		Place turtle at new screen
	144	77			1140	MOV M.A	location.
1	C945	EB			1150	XCHG	THE RESERVE OF THE PARTY OF THE
1	C946	CD	AØ	CA	1180	CALL RND	The bug moves at random
1	C949	36	20		1185	MVI M, 20H	Put a space where it was,
I	C94B	CD	A3	C9	1190	CALL MV	then move.
1	C94E	3A	CE	CA	1200	LDA FO	If turtle is there,
1	C951	BE			1210	CMP M	the bugs been had.
١	C952	CA	9E	C9	1220	JZ HLT	
١	C955	3A	CF	CA	1230	LDA FO+1	Place bug at new screen
1	C958	77			1240	MOV M.A	location.
1	C959	EB			1250		
1	C95A		2F	C9	1260	JMP C1	Do it all again
1	C95D					HI CALL CS	HICClear the screen
ı	C960				1305	LXI H, ØCE2ØH	Place the turtle at the
I	C963					HI MVI M.7	center of the screen.
I	C965			C9	1315		Should I return to the executive?
1	C968				1320		Wait awhile
١	C96B					CALL RND	Move the turtle at random
1	C96E				1340		The tare tare tar random
I	C97Ø			C9		CALL MV	leaving asterisk behind
1	C973				1370		Do it again.
١	C976					OP CALL CS	OppsClear the screen
١	C979			O.A.	1602		Place turtle at the center
1	C97B			CE	1605	LXI H, ØCE20H	of the screen.
	397E			02		OI MOV A, M	If you have been
	97F		24			CPI 2AH	here before,
	C981			CO	1630		halt.
1	C984			0)	1640		Put the turtle on the screen
1	C986			co	1650		wait awhile.
1	C989					02 CALL KB	Get input.
	C98C				1658	JZ 04	If none, continue
1	C98F		70	0.9	1660	MOV B, A	Thomas, continue
	C99Ø					04 MOV A, B	
	C991		ar			ANI ØFH	If it is a 'Ø', don't move.
	C993			co		JZ 02	Ti it is a b, don't move.
	C996			0,9			ace asterisk in old location
	C998			co		CALL MV	then move.
-	C99B				1690		Do it again
	C99E			07		HLT MVI M,4	HaltPlace '\(\frac{1}{2}\)' on the screen.
l				CO		JMP RET	Return to the executive
	C9AØ			69	1710		Move
1	C9A3					MV ANI ØFH	nove
	C9A5			CO.	1850		This routine uses the
	C9A7			69	1860		curser move routines
	C9AA			CO.		MVI A, 1	1
-	C9AC			69	1880		in SOLOS (PUP, PLEFT, PDOWN,
-	C9AF			00		M1 CPI 1	and PRIT) to move the
-	C9B1			69	1900		contents of the screen
-	C9B4			CO	1910		location pointed to
	C9B6			69	1920		by the address contained
\	C9B9	FE	10		1730	M2 CPI 7	in the H & L registers.

~
9080
0
6
•
-
-
197
-
*
×
묲
E
面
5
November
ž
~
ဟ
ACCESS
111
哭
ب
C
⋖
_

1 79BB	C2	CØ	C9	1940	JNZ M3	
9BE				1950		The right 4 bits of the
C9CØ					M3 MOV C.A	accumulator are used
C9C1		FØ	C9	2010		to determine the direction,
C9C4				2020		or combination of
C9C6		DU		2030		directions, of the move.
C9C7		01	CI		CNZ ØC1Ø4H	directions, or the move.
			CI			
C9CA		וש		2050		up 1f dn rt
C9CC				2055		
C9CD			CI		CNZ ØC115H	
C9DØ		02		2070		The ASCII code for
C9D2				2080		all of the digits except
C9D3			CØ	2090		6, 1, and 7 allows a
C9D6		04		2100		compass rose that
C9D8				2110	ANA C	agrees with the 10 key
C9D9				2120	CNZ ØC1ØBH	numeric pad. 6, 1 and
C9DC		10	C1	2130	CALL ØCIICH	7 are changed to agree.
C9DF				2140	RET	
C9EØ				2200	SVDA MOV A,L	This routine assumes that
C9E1	E6	3F		2210	ANI 3FH	the contents of the H, L register
C9E3	32	08	C8	2220	STA ØC8Ø8H	pair is a screen address.
C9E6	29			2230	DAD H	It then stores the line
C9E7	29			2240	DAD H	number in the data storage
C9E8	7 C			2250		location used by SOLOS
C9E9		ØF		2260		called LINE. Simiarly the
C9EB				2270		character position is stored
C9ED			CS	2280		in NCHAR for use by
,9FØ				2290	RET	PUP, PLEFT, PDOWN, and PRIT
C9F1					DL PUSH H	DelaySave address.
C9F2		an	CB	3005		Get data byte from SET
C9F5		DA	CO	3010		command: SPEED
C9F6				3020	XRA A	Command: SPEED
						Use it for a second
C9F7					D1 DCX H	Use it for a counter.
C9F8				3040		
C9F9		F7	C9	3050	JNZ D1	The latest terms of the la
C9FC				3Ø55	POP H	Restore address
C9FD				3060	RET	
C9FE		2E	CØ			Get input from keyboard.
CAØI				3110	RZ	If none return.
CA02		ØD		3120	CPI ØDH	If it is a CR restore the
CAØ4	CØ			3130	RNZ	stack and return to the
CAØ5	CI			3140	POP B	executive
CAØ6	C3	03	C9	3150	JMP RET	
CA09		00		4000	LI LXI D.Ø	Life
CAØC			The second second	4010		19.00
CAØD				4020	MOV A, D	D, E points to 1K of RAM
CAØE		03		4030	ANI 3	used as a scratch pad.
CAIØ				4040	ORI ØCCH	H, L points to the screen
CA12		55		4050	MOV H, A	location.
CA13				4060	PUSH D	Save the pointer
		aa		4070	MVI C,Ø	initialize the counter
CA14		שש		4080	DCX H	mitialize the counter
CA16		25	CA			
CA17		7E		4090	CALL CT	Court the second
CAIA		CØ	rr	4100	LXI D, ØFFCØH	Count the neighbors
CAID	19			4110	DAD D	of this location of

D
CCES
\mathbf{c}
m
šš
S
•
z
9
0
=
듗
Φ
19
97
7
•
몺
ŏ
0
-
_

CA1E CD 7E CA 4120 CALL CT the screen in the CA21 23 4130 INX H following order:	
1	
1	
122 CD 7E CA 4140 CALL CT	
A25 23 4150 INX H	
26 CD 7E CA 4160 CALL CT	
CA29 11 40 00 4170 LXI D, 40H	
CA2C 19 4180 DAD D	
CA2D CD 7E CA 4190 CALL CT	
CA30 19 4200 DAD D	
CA31 CD 7E CA 4210 CALL CT	
CA34 2B 4220 DCX H	
CA35 CD 7E CA 4230 CALL CT	
CA38 2B 4240 DCX H	
CA39 CD 7E CA 4250 CALL CT	
CA3C 23 4251 INX H	
CA3D 11 CØ FF 4252 LXI D, ØFFCØH CA4Ø 19 4253 DAD D	
CA41 D1 4260 POP D Restore RAM pointer. CA42 CD 65 CA 4270 CALL RG Determine next generation	
CA45 13 4280 INX D for this location and put	
CA46 7A 4290 MOV A,D it in the RAM.	
CA47 E6 04 4300 ANI 4 Do this to every screen	
CA49 CA ØC CA 4310 JZ L1 location.	
CA4C 21 00 CC 5000 CP LXI H, 0CC00H Copy the next generation	
CA4F 11 00 00 5010 LXI D,0 as stored in the IK of	
CA52 1A 5020 CO LDAX D scratch pad RAM	
CA53 77 5030 MOV M.A to the screen.	
CA54 23 5040 INX H	
A55 13 5050 INX D	
956 7C 5060 MOV A, H	
A57 FE DØ 5070 CPI ØDØH	
CA59 C2 52 CA 5080 JNZ C0	
CASC CD F1 C9 5090 CALL DL Wait awhile.	
CASF CD FE C9 5100 CALL KB Should I return to the exec.	?
CA62 C3 Ø9 CA 515Ø JMP LI If not do another generation	
CA65 79 7000 RG MOV A,C Follow the rules of LIFE	
CA66 FE 02 7010 CPI 2 to determine the next	
CA68 CA 7B CA 7020 JZ R3 generation for this	
CA6B D2 72 CA 7030 JNC R1 location.	
CA6E 3E 2Ø 7040 R2 MVI A,20H	
CA7Ø 12 7Ø45 STAX D	
CA71 C9 7050 RET	
CA72 FE Ø3 7060 R1 CPI 3	
CA74 C2 6E CA . 7070 JNZ R2	- 1
CA77 3E 2A 7080 MVI A,'*'	
CA79 12 7090 STAX D	
CA7A C9 7100 RET	
CA7B 7E 7110 R3 MOV A, M	
CA7C 12 7120 STAX D	
CA7D C9 7130 RET CA7E 7E 8000 CT MOV A,M Counter	
CA7E 7E 8000 CT MOV A,M Counter CA7F FE 2A 8010 CPI '*'	
CART FE 2A 8010 CFT 4 If the neighbor is	
CA82 ØC 8030 INR C	
CA83 C9 8040 RET an asterisk count it.	1

12		+ 4 4					
0	CA84	CD	Δα	CA	8500	INIT CALL RND	Initialize.
'	CA87		3F	CA	8510	ANI 3FH	THI CIGIT 20.
11	CA89				8515	ORI ØCCH	determine a random
ACCESS November, 1977	CA8B				8520	MOV H, A	screen location,
Ď			A 73	C A	8530		
E	CASC		AU	CA		CALL RND	place the line
8	CASF				8540	MOV L, A	number in the data
Z	CA9Ø		~~	00	8550	RET	storage of SOLOS
SS	CA9 1				8560	STA ØC8Ø8H	called LINE and
8	CA94		AØ	CA	8570	CALL RND	the position of the
A	CA97		ØF		8580	ANI ØFH	character in NCHAR.
	CA99		09		8590	STA ØC8Ø9H	
- 1	CA9C		EB	69	8594	CALL SVDA	
	CA9F				8595	RET	
	CAAØ					RND PUSH H	Random number generator
	CAAI			CA	8610	LXI H, SH+3	from Peoples Computer
	CAA4		08		8620	MVI B,8	Company,
	CAA6	7E			8630	MOV A,M	For it to work propertly
1	CAA7					RTOP RLC	the 4 data storage locations
	CAAB				8641	RLC	should not be zero.
-	CAA9				8642	RLC	
	CAAA				865Ø	XRA M	
1	CAAB				8660	RAL	
- 1		17			8661	RAL	
	CAAD	2D			867Ø	DCR L	
	CAAE	2D			8671	DCR L	
	CAAF	2D			8672	DCR L	
	CABØ	7E			8680	MOV A,M	
	CABI	17			8690	RAL	
1	CAB2	77			8695	MOV M.A	
	CAB3	20			8700	INR L	
-	CAB4	7E			8710	MOV A,M	
	CAB5	17			8720	RAL	12 17 16
	CAB6	77			8730	MOV M.A	
	CAB7	20			8740	INR L	
	CAB8	7E			8750	MOV A,M	
	CAB9	17			8760	RAL	11 17 19 27
	CABA				8770	MOV M.A	100 TO 10
	CABB	20			8780	INR L	100 27 20
	CABC	7E			8790	MOV A,M	
	CABD				8800	RAL	
	CABE				8810	MOV M.A	
1	CABF				8820		tm 25
	CACØ		A7	CA .	8830		4 PB *
	CACS				8840		VIII
	CAC4				8850		
	CAC5		D5	CØ			In SOLOS, the routine PERSE
	CAC8				8910		erases the screen but leaves
	CACA			CC	8920		a cursor in the corner.
	CACD			- •	8930		Erase that too and return.
	CACE					FO DB 7	The turtle font
	CACF				9001	DB ØEH	The bug font
	CADØ					SH DS 4	Storage for RND.
					, , , ,		

Bytesaver Modification for Sol

If you want to use a Chromco Bytesaver in the Sol, you'll
need to make the following modification of the Bytesaver. Data will
then be gated onto the Bus only
when PDBIN is high or active,
necessary in the Sol because the
Data IN and Data OUT busses are
connected together.

First cut the trace connecting pin 11 of IC 15 (7432) to pin 15 of IC 16 (74367). Now make these connections with small gauge insulated wire:

- 1. Connect pins 11 and 10 of IC 15.
- 2. Connect pin 8 of IC 15 to pin 15 of IC 16.
- 3. Connect pin 8 of IC 11 to pin 9 of IC 15.
- Connect S-100 Bus pin 78 (PDBIN) to IC 11 pin 9.
 Pin 78 is the 23rd from the left on the solder side of the board.

... AND A BYTESAVER ROGRAMMING ROUTINE

This short routine will program contents of any 1K block of memory into a 2708 EPROM in-

stalled in socket 1 of Bytesaver. The Bytesaver should be addressed at 6000H.

A15-L, A14-H, A13-H

The routine is used as a custom command with the Solos/Cuter operating system. Enter the program at C900H, or reassemble it elsewhere if you wish. Then create a custom command by typing: CU BURN C900 (CR)

NOTE: CR means "strike the return key;" do **not** type the letters as part of the command.

If the program has been reassembled at an arbitrary address of

NNNN, type:


CU BURN NNNN (CR)

Now to use the BURN custom com-

mand, type:

BURN AAAA (CR)

AAAA being the starting address of the 1K block you wish to program into the 2708. The programming operation takes about 5 minutes, which is in accordance with the published programming instructions for the 2708. When the programming is complete, the routine will return control to Solos/Cutter and a prompt will reappear on the screen.



			ØØØØ	**		ROUTING	
	C33A			SCONV *	EQU	Ø С33АН	GETS PARAMETERS
C9Ø4	7D B7		0000	BURN	CALL MOV ORA	SCONV A, L GET A	SOURCE ADRS. TO HL
C9Ø5	C2 Ø4	↓ CØ	0 000	*	JNZ	Ø СØØ4Н	IT MUST BE Ø
C9Ø8 C9ØB			ØØØØ ØØØØ		SHLD LXI	SAD B,Ø	KEEP SOURCE ADRS PASS COUNT = ∅
C9ØE C911		64 3 C9	0 000	BLOOP *	LXI LHLD	D,6400H SAD	H PROM ADRS SOURCE ADRS
C917 C918			8888 8888 8888 8888 8888 8888 8888 8888 8888	PLOOP	MOV STAX INX INX MOV CPI	A,M D H D A,D 68H	GET SOURCE DATA ZAP THE PROM BUMP SOURCE & PROM ADRS. CHECK HI ADRS. PASS COMPLETE ?
C91B	C2 14	+ C9	8888		JNZ	PLOOP	NOT YET

				(0000	*			
C9 1E	Ø3				8000		INX	В	BUMP PASS COUNT
C91F				(3000		MOV	A,B	
C920				(8000		CPI	4	IK PASSES ?
C922	C2	ØE	C9		0000		JNZ	BLOOP	NOT YET
				(3000	*			
C925	C3	Ø 4	CØ		0000		JMP	Ø С Ø Ø4H	ALL DONE
					0000	*			
					0000	**	RAM AREA	**	
-000				(0000	*		•	
C928					0000		DS	2	SOURCE ADRS.
					0000	*			

A Sol Keyboard Fix:

So You Won't Have to Hit the Upper Case Key Each Time You Restart

EDITOR'S NOTE: Our thanks to Jay Bell for contributing this suggestion. There are a couple of minor differences between the procedure he describes and our PTC standard modification for keyboard upper case initialization, so we're printing our version along with his.

So after days of constructing your Sol, you're finally ready to input the first command, hit the carriage return, and check the screen. WHAAT?!! All you get is some question mark nonsense. So you check the software manual again. Sure enough, it wants upper case. So, you put the keyboard into alpha-shift by pressing the upper case key.

Lateryou notice your program isn't doing what you expected, so naturally you restart the old four-phase wonder by simultaneously pressing the upper case and repeat keys. More question marks—the restart left you in lower case mode.

By now you've realized this is going to happen every time. There are three solutions: 1) Change the software to accept both upper and lower case commands. 2) Change the keyboard to come up in uppercase mode. 3) Hit the upper case key every time you restart.

Number 3 had already worn me out. I personally prefer to change software, even though I'm a hardware freak. But I figured the chances of Processor Technology changing software at this late date were subminimal.

Out with the keyboard schematics. The fix looked simple enough: just CLEAR the upper case flipflop rather than PRESETTING it. The keyboard gets preset when power is first applied through an RC circuit that is initially low and slowly comes up to +5 volts. Since the signal coming off the keyboard to restart the 8080 is driven by an open collector inverter, it could also be connected to the power-up RC circuit. Then whenever you reset the processor, you also reset the keyboard to its initial power-up state. To make that power-up state turn the upper case flipflop on, you cut the land leading to pin 4 of U15, and the land leading to pin 1 of U15. Then connect the trace that used to lead to pin 4 to pin 1 instead. Similarly, connect the pull-up resistor that was tied to pin 1 to pin 4 instead. Then connect pin 8 of U24 to pin 1 of U15. This last connection ties the restart signal to the clear input of U15 (as well as to the rest of the chips that are initialized at power-up).

There is only one remaining problem for the purists. The flipflop that sets the machine in the local mode will come up in an undetermined state, since its preset pin is

tied to pin 4 of U15. Now that you've cut the land to pin 4 and pulled it high, the local flipflop is not being properly reset. Unfortunately, you have to remove U15 in order to cut the land to the local flipflop's preset pin, because the land runs under it on the component side of the board. If you want to be sure that the machine will come up with the local mode off, cut the land between pin 4 of U15 and pin 10 of U15, then connect pin 1 of U15 to pin 10 of U15.

Now you should be able to interact with your Sol the instant you power up or restart, without the bother of hitting the upper case key first.

THE PTC MODIFICATION:

- 1. Cut trace located between U15 pin 4 and plate through ½ inches below pin on the component side.
- 2. Remove R31, 1.5K ¼ watt Carbon Film, and save for later use.
- 3. On the Solder Side of the board:
 - Insert one end of R31 in plate through adjacent to U15 pin 14 and solder.
 - b. Bend the other lead of R31 to pin 4 of U15 and solder.
 - c. Add a % inch jumper, stripped % inch from each end, to the plate through located just below U15 pin 4.
 - d. Insert the other end of the jumper through plate through located just above U24 pin 12.

A Keyclick (Audible) Circuit for Sol

Silence may be golden, but there is an advantage to making your Solkeyboard sound like a typewriter. If you're a good fast touch typist entering data from a printed source, it's easier to listen for missed keys than to glance up at the screen all the time. Thanks to Jack Kinney for this audible circuit design; he says that the sound can be altered to suit individual tastes by varying RI burst length and R3 for burst frequency. The circuit operates as follows:


The first section of the dual timer is connected in the monostable mode, and the keyboard strobe triggers a positive-going pulse approximately four milliseconds long. This pulse is connected to the reset of the second section of the timer, which is operating in the astable mode, and is set for an output frequency of approximately 1.5 Khz, ating it "on" for a four-millisecond

'st. The output transistor inverts me signal to prevent current draw in the "off" condition. The collector resistor is set for the desired loudness.

Kinney is also checking out a more complex circuit (three more IC's) which will decode the "BEL" code and produce a beep. One of the computers on the network signals for attention by transmitting the "BEL," and this will provide an audible monitor. We'll print this circuit in the next issue of ACCESS.

Katchum's Correction Corollaries: (a) In debugging any type of program, no corrections can be made correctly after 1600 hours Friday. (b) The corrections will be self-evident at 900 hours Monday, (c) When in doubt divide by (2.0).

oren's Law of Graphing: First draw curves, then plot the data.



RS SELECTED FOR PESIRED VOLUME

KEY "CLICK" CIRCUIT (SOI 10/20)

JACK KINNEY UCLA COMPUTER SCIENCE DEPT. 3413 BOELTER HALL LOS ANGELES, CA 90024

Run/Stop Circuits: Part II

In ACCESS #3, I described a Run/Stop circuit for user control of Sol's X-Ready line. Now here's the circuit that will let you monitor the operation of your S-100 system by connecting LED's to the buss lines. Each Light Emitting Diode is driven by 1/6 of a hex inverter package (74LS04), current limited by a 470-ohm ½-watt resistor for each.

To monitor the operation of your system, compare the addresses and data displayed on the LED's as you single step, with the program listing. Most malfunctions can then be seen and corrected with very little effort. A couple of examples:

Quick test for data and address lines. You can discover major failures in these by toggling the reset line while the Run/Stop circuit is

enabled in the Stop position. All the LED's should light when the reset line is enabled. All except M1, PDBIN, and PWAIT should darken when the line is disabled. Any LED's that don't respond as indicated reveal a malfunction in the corresponding lines and should be checked with a meter or scope.

Testing the Input/Output lines. Single step until an input or output instruction is executing. When the SINP or SOUT LED is lit, you can stop stepping, and start following the logic signals in the I/O section, with your troubleshooting equipment.

Next issue, this series will continue with advice on implementing traps on the front panel.

Steve Wong

Changes in Assembly Instructions for Sol:

he bug: You'll get an incorrect test result at Step 38 in the instructions: instead of the display shown in Figure 3-9, a display of random characters comes up.


The squasher: Install U93-74LS175 and U107-74LS367 at Step 35.

The bug: Your Sol doesn't work at I Step 59.

The squasher: After you do Step 28 of the assembly, perform step 73 before proceeding to Step 29.

The bug: The waveforms are incorrectly shown in Figure 3-2 on page 3-15 of your Sol manual.

The squasher: Turn your manual upside down-the waveform shown for Pin 5-U104 is inverted. Same for Pin 7-U104.



A Program Home Accounting System

Contributed by Guy Campbell for Guy's comments on his program. on for all Sol users.

We're delighted to get this kind of See the Letters to the Editor input from our readers and pass it

PROGRAM FOR HOME ACCOUNTING SYSTEM .

THIS PROGRAM WILL RECORD PAYMENTS, UPDATE BALANCE AND PROVIDE ACCUMULATED INTEREST FOR TAX PURPOSES.

NEW ACCOUNTS CAN BE ADDED ONLY BY CHANGING THE PROGRAM.

PUT OLD DATA TAPE ON FILE #2 AND SET FOR PLAY.

PUT NEW TAPE ON FILE #1 AND SET FOR RECORD.

PRESS ANY NUMBER & RETURN TO CONTINUE.

YOUR FRIENDLY FINANCE CO. 3958 TUFFLUK STREET CHICAGO, ILL 60683

ACCOUNT NUMBER - 12345A

BALANCE=\$ 51.60 TOTAL PRINC. PAID=\$ 108.00 TOTAL INT. PAID=\$ 6.39

ANNUAL INTEREST RATE= 21%

YOUR LAST PAYMENT WAS MADE ON 82877 FOR \$ 36.00

```
ENTER CHANGES TO ADJUST BALANCE. $ 25.00 ENTER CHANGES TO ADJUST BALANCE. $ 0
YOUR PRESENT BALANCE IS $ 76.60
ENTER PAYMENT TO THIS ACCT. $36.00
ENTER TODAYS DATE 90277
PRINCIPLE PAID=$34.66
                                INTEREST PAID=$ 1.34
YOUR NEW BALANCE IS $41.94
TOTAL PRINCIPLE PAID TO DATE=$ 144.00
TOTAL INTEREST PAID TO DATE=$ 7.73
ACCOUNT COMPLETE
PRESS ANY NUMBER TO GET NEXT ACCOUNT. 0
NEXT ACCOUNT COMES UP - WILL CONTINUE IN THIS FORMAT.
LIST
      SET S=05
10
      REM THE HOME ACCOUNTING PROGRAM
20
      REM CREATED BY G. W. CAMPBELL - 1977
30
      REM ORIGINAL DATA BANK (TAPE) PREPARED WITH
40
      REM SEPARATE PROGRAM.
50
      PRINT "PROGRAM FOR HOME ACCOUNTING SYSTEM."
60
      PRINT
      PRINT "THIS PROGRAM WILL RECORD PAYMENTS, UPDATE"
70
      PRINT "BALANCE AND PROVIDE ACCUMULATED INTEREST"
80
90
     PRINT "FOR TAX PURPOSES."
100
      PRINT
           "NEW ACCOUNTS CAN BE ADDED ONLY BY CHANGING"
110
      PRINT
     PRINT "THE PROGRAM."
120
130
      PRINT
140
      FOR I=1 TO 1200:NEXT
      PRINT "PUT OLD DATA TAPE ON FILE #2 AND SET FOR PLAY."
150
160
      PRINT
      PRINT "PUT NEW TAPE ON FILE #1 AND SET FOR RECORD."
180
190
      PRINT
200
      INPUT "PRESS ANY NUMBER & RETURN TO CONTINUE. "Z
210
     PRINT
      GOSUB 770
220
225
     FILE #1
230
     FILE #2
      READ #2,A,B,C,D,E,F,G: PRINT "END OF FILE";: GOTO 700
240
250
      IF A=1 THEN GOSUB 1000
      IF A=2 THEN GOSUB 1070
260
      IF A=3 THEN GOSUB 1140
270
******CONTINUE THIS SECTION FOR THE NUMBER OF ACCOUNTS NEEDED*****
```

GOSUB 770 400

PRINT "BALANCE=\$"; %Z2%; C, 410

PRINT TAB (30): "ANNUAL INTEREST RATE="; 7%; B; "7"; 722% 420

```
ACCESS • November, 1977 • page 19
```

```
PRINT "TOTAL PRINC. PAID=$";F,
430
      PRINT TAB(30); "TOTAL INT. PAID=$"; G
440
450
      GOSUB 770
      PRINT "YOUR LAST PAYMENT WAS MADE ON ": 77; D.
151
      PRINT "FOR $"; 7,22%; E
452
453
      GOSUB 770
      INPUT "ENTER CHANGES TO ADJUST BALANCE. $"C1
460
      IF C1=0 THEN 500
470
      LET C=C+C1
480
490
      GOTO 460
      PRINT "YOUR PRESENT BALANCE IS $":C
500
510
      PRINT
      INPUT "ENTER PAYMENT TO THIS ACCT. $"F1
520
521
      LET T1=T1+F1
530
      IF F1=0 THEN 583
531
      PRINT
532
      INPUT "ENTER TODAYS DATE "D1
533
      LET D=D1
550
      LET G1=((B/100)*C)/12
560
      LET G=G+G1
      LET C=C-(F1-G1)
570
      LET E=F1
580
      PRINT "PRINCIPLE PAID=$"; (E-G1),
PRINT TAB(30); "INTEREST PAID=$"; G1
581
582
583
      PRINT
      PRINT "YOUR NEW BALANCE IS $":C
590
595
      LET F=F+(E-G1)
600
      PRINT
      PRINT "TOTAL PRINCIPLE PAID TO DATE=$";F
510
      PRINT "TOTAL INTEREST PAID TO DATE=$";G
320
630
      PRINT
      PRINT "ACCOUNT COMPLETE"
640
      INPUT "PRESS ANY NUMBER TO GET NEXT ACCOUNT. "Y
650
670
      PRINT #1,A,B,C,D,E,F,G
680
      PRINT
      PRINT "***************
681
********
690
      TOTO 240
      CLOSE #2
700
710
      CLOSE #1
720
      PRINT
      PRINT "TRANSACTIONS COMPLETE"
730
740
      PRINT
      PRINT "YOUR PAYMENTS TOTALED $";T1;" THIS MONTH."
741
750
      PRINT
      PRINT "GOODBYE, SEE YOU NEXT MONTH."
751
752
      SET S=0
760
      END
770
      PRINT
780
      RETURN
```

```
1000
1010
1020
1030
1040
1050
1060
LIST
10
20
```

```
PRINT "YOUR FRIENDLY FINANCE CO."
      PRINT "3958 TUFFLUK STREET"
      PRINT "CHICAGO, ILL
                            60683"
      GOSUB 770
      PRINT "ACCOUNT NUMBER - 12345A"
      GOSUB 770
      RETURN
1070*****CONTINUE TO PUT IN ACCOUNTS IN THE SAME FORMAT.
THIS IS A SAMPLE PROGRAM THAT CAN BE USED TO ESTABLISH THE
ORIGINAL DATA BASE TAPE.
      FILE #2
      INPUT "ACCOUNT IDENTIFICATION NO. ?"A
30
      IF A=O THEN 110
35
      PRINT
            "ANNUAL INTEREST RATE (WHOLE NUMBERS) ?"B
40
      INPUT
45
      PRINT
      INPUT "BALANCE ?"C
50
55
      PRINT
      INPUT "DATE AND PAYMENT (LAST PMT MADE) ?"D,E
60
65
      PRINT
      INPUT "TOTAL PRINCIPLE PAID ?"F
70
75
      PRINT
      INPUT "TOTAL INTEREST PAID TO DATE ?"G
80
85
      PRINT
90
      PRINT #2,A,B,C,D,E,F,G
100
      GOTO 20
110
      CLOSE #2
120
      END
```

8080 Relocatable Assembler

```
+0000
                    (11, 19, 29)
+0000
                    MODIFIED SOLOS ROUTINE
                        REVISED BY:
+0000
+0000
                                       MELVIN SCHEHLEIN
                                        COMMUNICATIONS & MEDIA SERVICES
+0000
+0000
                                         TOWSON STATE UNIVERSITY
+0000
                                          TOWSON, MARYLAND 21204
+0000
                     DATE WRITTEN: AUGUST 3, 1977
+0000
+0000
                     THE PURPOSE OF THIS PROGRAM IS TO CONFIGURE THE SOL TERMINAL
+0000
                     COMPUTER AS A STANDARD VIDEO TERMINAL TO ACCEPT THE HALF-DUPLEX
+0000
                      CR. LF RESPONSE FROM COMMUNICATIONS AFTER HAVING SENT A CR
+0000
                      WITHOUT ERASING THAE LAST INPUT LINE.
+0000
                                                             THIS HAPPENS BECAUSE
                      THE SOLOS MONITOR CLEARS THE LINE FROM ITS PRESENT CHARACTER
+0000
+0000
                      POSITION TO THE END OF THAT LINE.
                                                           DURING COMMUNICATIONS
                      THE KEYBOARD SENDS OUT A CR, WHICH IS FEED BACK INTO THE SERIAL
+0000
                      INPUT PORT, AND THEN SENT TO THE VDM DRIVER TO BE PROCESSED.
+0000
                      THEN THE COMPUTER SENDS OUT A CR LF WHICH GOES TO THE VDM DRIVER
+0000
                      CLEARING THE LAST INPUT LINE (BECAUSE THE RESPONSE CR WAS IN COLUMN
+0000
                      1 ) THUS DENYING THE USER THE ABILITY TO CHECK THE ACCURACY OF
+0000
+0000
                      HIS OR HER LAST INPUT.
+0000
```

```
C900
                            DRR
                                    0C900H
C900
C900
                     THIS PROGRAM MODIFICATION WILL SIMPLY TEST THE CHARACTER POSITION
C900
                      WHENEVER A CR IS RECEIVED, IF WE ARE IN COLUMN 1 THE CR IS
0900
                      IGNORED, IF WE ARE NOT IN COLUMN 1 IT IS PROCESSED NORMALLY.
C900
                      THE ONLY CODE THAT IS DIFFERENT FROM THE STANDARD SOLOS TERM
C900
                      ROUTINE CAN BE FOUND IN LINES 63 TO 70 TO TEST THE CHARACTER
C900
                      POSITION.
C900
                      THE PROPGRAM HAS BEEN ASSEMBLED BEGINING AT ADDRESS C900
                      SO IT CAN EASILY BE STORED IN SOL SYSTEM RAM.
C900
C900
C900
                         +++++ TERMINAL UPDATE ROUTINE +++++
0.900
C900 CD 10 C3
                  TERMU:
                            CALL
                                    PSCAN
                                              FIND IF INPUT PARAMETER IS PRESET
C903 32 06 CB
                            STA
                                    IPORT
                                              #SINP WILL USE THIS DRIVER (DEFAULT IS 1)
C904 CD 10 C3
                            CALL
                                    PSCAN
                                              INON FOR THE OUTPUT DRIVER
C909 32 07 C8
                            STA
                                    OPORT
C90C
                                              FIS THERE A CHAR WAITING AT THE KEYBOARD
C90C CD 2E CO
                                    KSTAT
                  TERM1U:
                            CALL
C90F CA 24 C9
                            JZ
                                    TINU
                                              INO, THEN WHAT ABOUT THE SERIAL INPUT PORT
C912 47
                            HOV
                                    BA
                                              FTHE KEYBOARD HAD ONE, PUT IT IN B
C913
C913 FE 80
                            CPI
                                    MODE
                                              FIS IT A COMMAND MODE
C915 CA CO C1
                                              FYES--GET OUT OF TERMU>>AND GO TO SYSTEM MONT
                            JZ
                                    COMN1
C918 DA 21 C9
                            JC
                                              INON-CURSOR KEY--SEND TO TERM PORT
                                     TOUTU
C91R CD 54 CO
                            CALL
                                    VDMOT
                                              $TO THE VDM IT IS A CURBOR CONTROL
                                              IS THERE A CHAR AT THE INPUT PORT
C91E C3 24 C9
                            .IMP
                                     TINU
C921
                                              FOUTPUT IT TO THE SERIAL PORT
C921 CD 19 CO
                  TOUTU:
                            CALL
                                    BOUT
                            CALL
C924 CD 1F CO
                  TINU:
                                    SINP
                                              FIS A CHAR WAITING AT THE INPUT PORT
C927 CA OC C9
                                     TERM1U
                                              HOW ABOUT THE KEYBOARD?
                            JZ
                            ANI
                                    07FH
                                              JGET RID OF THAT HIGH ORDER PARITY BIT.
C92A E6 7F
C92C CA OC C9
                            JZ
                                     TERM1U
                                              IA NULL IS PROCESSED BY DOING NOTHING
C92F 47
                            MOV
                                             FIT IS OUTPUT FROM 'B'
                                     B.A
C930 FE 1B
                            CPI
                                     01BH
                                              FIS IT A CONTROL CHAR TO BE IGNORED
C932 D2 5E C9
                            JNC
                                     TERM2U
                                             INO IT IS >1B SEND TO THE UDM
2935
C935
                                             #CR OR LF ARE SPECIAL CHARACTERS
C935 FE OD
                            CPI
                                     CR
C937 C2 46 C9
                                     NOCR
                                              FIT WASN'T A CR. BYPASS THE COLUMN TEST
                            JNZ
C93A
C93A 3A 08 C8
                            LDA
                                     NCHAR
                                             #HAS A CR ALREADY PUT US IN COLUMN 1
C93D FE 00
                            CPI
                                     000H
                                             ITHIS WILL TELL US
C93F CA OC C9
                            JZ
                                     TERM1U
                                             FIT IS COLUMN 1, DON'T PROCESS IT
C942 78
                            MOY
                                             FLETS GET IT BACK
                                     A.B
C943 C3 5E C9
                            JMP
                                     TERM2U
                                             FIT ISN'T COLUMN 1, PROCESS IT
C946
C946 FE 0A
                  NOCR:
                            CPI
                                     LF
                                              WAS IT A LINEFEED
C948 CA 5E C9
                            JZ
                                     TERM2U
                                             PROCESS IT
C94B
C94B 3A OC CB
                            LDA
                                     ESCFL
                                             #A CTL CHAR---ARE WE IN AN ESC SEQUENCE
C94E B7
                                             FIF YES THEN DUTPUT CONTROL CHAR DIRECTLY TO
                            DRA
C94F C2 5E C9
                                     TERM2U
                                             IWE SURE ARE LET THE VDM DRIVER HANDLE IT
                            JNZ
                                              SAVE THE CHARACTER
C952 C5
                            PUSH
                                     B
                                             FCTL CHAR TO VDM VIA ESC SEQUENCE
C953 06 1B
                            MUI
                                     B.ESC
C955 CD 54 CO
                                     TOMOT
                                              PUT IT ON THE SCREEN
                            CALL
C958 06 07
                            MUI
                                     B,7
                                             #SAY TO PUT OUT NEXT CHAR AS IS
                                              FALMOST READY
                            CALL
                                     TOMOT
C95A CD 54 CO
C95D C1
                            POP
                                     B
                                              JBET IT BACK
C95E
                  TERM2U:
                            EQU
                                              FLETS PUT OUT THE CHARACTER
                                             FPUT IT ON THE SCREEN
                                     VDMOT
C95E CD 54 CO
                            CALL
C961 C3 OC C9
                            JMP
                                    TERM1U
                                              FLETS KEEP DOING IT
C964
C964
C964
C964
```

TERMU

C900

TINU

```
C964
                       SYSTEM
                                      EQUATES
C964
C964
                   8
000A
                  LF
                             EQU
                                      OOAH
                                                 FTHE LINE FEED ASCII CHAR
OOOD
                   CR
                             EQU
                                      OODH
                                                 ITHE CARRIAGE RETURN ASCII CHAR
                                                 ITHE ESCAPE ASCII CHAR
001B
                   ESC
                             EQU
                                      01BH
0080
                   MODE
                             EQU
                                      OBOH
                                                 FTHE P.T. MODE CONTROL CHAR
C964
                             EQU
                  SOUT:
                                      OC019H
                                                 #SYSTEM OUTPUT ENTRY POINT
C019
                             EQU
                                      OC01FH
                                                 #SYSTEM INPUT ENTRY POINT
CO1F
                   SINP:
C02E
                   KSTAT:
                             EQU
                                      OC02EH
                                                 !KEYBOARD INPUT ROUTINE
                                                 ITHIS ONE PUTS IT ON THE SCREEN
C054
                   TOMOT:
                             EQU
                                      0C054H
C1CO
                   COMN1:
                             EQU
                                      OC1COH
                                                 FRE-ENTRY INTO SYSTEM MONITOR
C310
                   PSCAN:
                             EQU
                                      OC310H
                                                 INPUT PARAMETER ROUTINE
C806
                   IPORT:
                             EQU
                                      00806H
                                                 CURRENT INPUT PSEUDO PORT
                   OPORT:
                             EQU
                                      OCB07H
                                                 CURRENT OUTPUT PSEUDO PORT
CB07
                                                 PRESENT VDM CHARACTER POSITION
                   NCHAR I
C808
                             EQU
                                      OCBOBH
                                                 FESCAPE FLAG CONTROL BYTE
CBOC
                   ESCFL:
                             EQU
                                      OCBOCH
C964
                             END
C964
O ERRORS DETECTED
PA
  BE 01
                                SYMBOL TABLE
                                            001B
                           0000
                                   ESC
                                                    ESCFL
                                                              CBOC
          C1C0
COMN1
                  CR
                                            000A
                                                    MODE
                                                              0080
 IPORT
          C806
                  KSTAT
                           C02E
                                   LF
NCHAR
          C808
                           C946
                                   OPORT
                                            C807
                                                    PSCAN
                                                              C310
                  NOCR
                                                    TERM2U
                                                              C95E
SINP
          CO1F
                  SOUT
                           CQ19
                                   TERM1U
                                            CPOC
```

C921

VDMOT

C054

ALS-8 to Sol Patch

C924

TOUTU

```
0000 *
                               This program alters the ALS-8 ram to
                        0002 * allow an ALS-8 that has not been updated
                        0003 *
                               to interface with a Sol-20 using Solos.
                        0004 *
                        0005 *
                        0006 * Change standard input port to Sol
                        0007 * keyboard.
                        0008 *
                        0009
                                     ORG
                                             OD09FH
D09F
DO9F FC
                        0010
                                     DB
                                            KDATA
                        0011 *
                               Alter STAT routine in ALS-8 to match Sol
                        0012 *
                               keyboard status port and compliment data
                        0014 * availible flag.
                        0015
                        0016
                                     ORG
                                            ODOA4H
DOA4
                        0017 STAT
                                     IN
                                            KSTAT
DOA4 DB FA
                                     CMA
DOA6 2F
                        0018
DOA7 E6 01
                        0019
                                     ANI
                                            KDR
                                     RET
D0A9 C9
                        0020
                        0021 *
                        0022 * This output driver saves the accumulator
                               and register B before calling SOUT in
                               Solos. It also checks the keyboard to see
                        0025 * if an escape has been hit. If so, a jump
```

```
0026 * will be made to EORMS in ALS-8. IF not,
                         registers A and B will be popped off the
                   0028 * stack after the character has been printed.
                   0029 *
                   0030 OUTP8
                               PUSH
                                       PSW
DOAA F5
                   0031
                               PUSH
                                       B
DOAB C5
                   0032
                               CALL
                                       STAT
DOAC CD A4 DO
                   0033
                               JZ
                                       NOCHR
DOAF CA BB DO
                   0034
                               IN
                                       KDATA
DOB2 DB FC
                   0035
                               ANI
                                       7FH
D0B4 E6 7F
                   0036
                               CPI
                                       ESC
DOB6 FE 1B
                   0037
                               JZ
                                       EORMS
D0B8 CA 60 E0
                   0038 NOCHR
                               CALL
                                       SOUT
D0BB CD 19 C0
                               POP
                   0039
                                       B
DOBE C1
                   0040
                               POP
                                       PSW
DOBF F1
                   0041
                               RET
DOCO C9
                   0042 *
                   0043 * Now make SYSIO and OUT8 point to this
                   0044 * version of OUTP8 as the standard output
                   0045 * driver.
                   0046 *
                   0047
                               ORG
                                       OD096H
                                                SYSIO output driver
D096
                                       OUTP8
                   0048
                               DW
D096 AA D0
                   0049 *
                   0050
                               ORG
                                       ODODOH
                                               second byte of OUT8
DODO
                   0051
                               DW
                                       OUTP8
DODO AA DO
                   0052 *
                   0053 ESC
                               EOU
                                       1BH
                                               ASCII escape
     001B
                   0054 KDR
                               EQU
                                       01H
                                               data available flag
     0001
                   0055 SOUT
                               EQU
                                       OC019H Solos output entry
     C019
                               EQU
                   0056 KDATA
                                       OFCH
                                               Sol keyboard data port
     OOFC
                   0057 KSTAT
                               EQU
                                       OFAH
                                               keyboard status port
     OOFA
                   0058 EORMS
                               EQU
                                       0E060H
                                               entry point to ALS-8
     E060
                   0059 *
                   0060 * One more thing needs to be mentioned.
                          A non-updated version of the TXT-2
                          editor does not reset the hardware
                   0063 * scrolling port on a Sol. If this is
                   0064 * not done before entering the editor
                   0065 * the first line of the file may be
                   0066 * on a line other than the first line
                   0067 * of the screen. One remedy for this
                          is to always hit the CLEAR key before
                   0069 * executing the TXT-2 editor.
                   0070 *
```


Intel Paper Tape Loader for Sol

				9999		L 31	
	1 E	FF		0000	STAK	EQU	5-1
				0000	*		
1F00	31	FF	1 E	0000		LXI	SP. STAK
1F03	CD	06	1 F	0000		CALL	READ

	600		1
1	101	1	
	management		
	2001		
	3		

HAR		1 F 2	2A	HEX	11	F3D	LOOP	1F1E	READ	1FØ6
F50	69				0000		RET			
F4E		7 F		•	0000		ANI	7F H		
F4C					0000		IN	ØF9H		
F49			1 F		0000		JZ	TTYIN		
F47			. =		0000		ANI	64		
F45						TTYIN	IN	ØF8H		
					0000					
F44	C9				0000		RET			
F42					0000		SUI	7		
F41					0000		RC			
F3F		ØA			0000		CPI	10		
F3D					0000	HEX	SUI	48		
					0000					
F3C	C9				0000		RET			
F3B					0000		ADD	Ε		
F38		3 D	1 F		8000		CALL	HEX		
F35					8888		CALL	TTYIN		
F34					9999		MOV	E, A		
F33					0000		RAL			
F32					0000		RAL			
F31					0000		RAL			
F30					0000		RLC			
F2D		3D	1 F		0000		CALL	HEX		
F2A						CHAR	CALL	TTYIN		
E0.	00				0000					
F27	US	00	I L		0000		JMP	READ		
								LOOP		
F24		15	1 F		9999		JNZ			
F23					0000		DCR	D		
F22					0000		INX	Н		
F21			•		0000		MOV	M. A		
FIE	CD	2A	1 F			LOOP	CALL	CHAR		
					0000	*				
FIB		2A	1 F		0000		CALL	CHAR		
FIA					0000		MOV	L.A		
F17		2A	1 F		0000		CALL	CHAR		
F16	67				0000		MOV	H.A		
F13		2A	1 F	1	0000		CALL	CHAR		
F12					0000		RZ			
F11	57				0000		MOV	D.A		
FØE	CD	2A	1 F		0000		CALL	CHAR		
FØB	CS	06	1 F		0000		JNZ	READ		
	FE	3B			0000		CPI	• 3 •		
F09						READ				

Newett Awl's Choo Choo



A lot of you had fun with this program when we listed it in the first issue of ACCESS. We're repeating it now with modifications to run on Sol, and we think you'll like it even better this time around.

				0000				
0100					TRAIN	XRA	A	ONCE UPON A TIME,
0101				0002		OUT	OFEH	IN A CURIOUS LITTLE
0103			02	0003		LXI	H,SHED	PLACE THERE WAS -
0106	01	00	80	0004		LXI	B,2048	
0109	36	20		0005	EMPTY	MVI	M, 20H	AND IT STAYED IN A
010B	23			0006		INX	Н	TINY SHED
0100	0B			0007		DCX	В	THAT WAS ALL EMPTY
010D				0008		XRA	A	TILL WILL HAD BITTE
010E				0009		XRA	В	
010F		0.9	01	0010		JNZ	EMPTY	
0112			03	0011		LXI	H,CLOUD	EXCEPT FOR A HUGE
0115		01	00	0011		LXI	D, 1	EXCEPT FOR A HUGE
0118		0E	00	0012		MVI		P
011A			01	0013			B,14 SMO1	B 1 2000 30 40 A
711D		2B	00	0015		CALL		
120		0C	UU			LXI	D, 43	r 3007 x0 52 V
		50	0.1	0016		MVI	B, 12	L 0000 00 00 0
0122			01	0017		CALL	SMO1	0
0125		30	00	0018		LXI	D,48	W = 300 05 5
0128		09		0019		MVI	B,9	Y
012A				0020		CALL	SMOl	
012D		34	00	0021		LXI	D,52	C
0130		04		0022		MVI	B, 4	L
0132				0023		CALL	SMOl	0
0135		3A	00	0024		LXI	D,58	n n n n n n
0138	06	02		0025		MVI	B, 2	D
013A	CD	50	01	0026		CALL	SMO1	
013D	11	3D	00	0027		LXI	D,61	0 71 0
0140	06	01		0028		MVI	B, 1	2809 F
0142	CD	50	01	0029		CALL	SMO1	'ans -
0145		3E	00	0030		LXI	D, 62	S
0148		01		0031		MVI	B, 1	*800 M
014A			01	0032		CALL	SMOl	
014D				0033		JMP	ENGIN	ĸ
				0034	*	J		R C C C C C C C C C C C C C C C C C C C
0150	19				SM01	DAD	D	
0151		6 F			SMO2	MVI	M,SMOKE	COUGH
0153		O I		0030	SPIO Z	INX	H, SMOKE	cougn
0154				0038		DCR	В	COLICH
0155		E 1	0.1					COUGH
		21	UI	0039		JNZ	SMO2	CONTROL OUR OR MUT COL
0158	09			0040		RET	•	COMING OUT OF THE STA

58	CHOO CHOO, cont.			
96 2		0047 +		OF
page	0150 21 30 05	0041 *		OF
-	0159 21 A8 05	0042 ENGIN	LXI	H,SHED+322H A TINY LOCOMOTIVE
+1	015C 36 16	0043	MVI	M, 16H WITH A LITTLE SMOKESTACK
9	015E 21 AB 05	0044	LXI	H,SHED+325H AND A LITTLE BELL
E	0161 36 07	0045	MVI	M, 07H
اقِ	0163 21 AD 05	0046	LXI	H,SHED+327HAND A TINY DOME
Sol	0166 36 6E	0047	MVI	M, 6EH
ES	0168 2A 68 02	0048	LHLD	CAB1AND A CAB
ACCESS • November,	016B 22 B0 05	0049	SHLD	SHED+32AH WITH WINDOWS
	016E 2A 6A 02	0050	LHLD	CAB 2 SO THAT YOU COULD
	0171 22 B2 05	0051	SHLD	SHED+32CH SEE INTO WHERE THE
1	0174 2A 6C 02 0177 22 B4 05	0052 0053	LHLD	CAB3ENGINEER AND THE SHED+32EH FIREMAN SAT.
	0177 22 B4 03 017A 2A 6E 02	0054	SHLD LHLD	BOILIT HAD A BEAUTIFUL
	017A 2A 6E 02 017D 22 E7 05	0055	SHLD	SHED+361H POLISHED
	017D 22 E7 03 0180 2A 70 02	0056	LHLD	BOI2BRASS
		0057	SHLD	
- 1	0183 22 E9 05 0186 2A 72 02	0057	LHLD	SHED+363H BOILER BOI3WITH
	0186 2A 72 02 0189 22 EB 05	0059	SHLD	SHED+365H THE NUMBER
	0185 22 ED 05	0060	SHLD	SHED+367H "99" ON THE
	018C 22 ED 03	0061	LHLD	BOI4SIDE OF
- 1	0197 2A 74 02 0192 22 EF 05	0062	SHLD	
- 1	0192 22 EF 05 0195 2A 76 02	0063	LHLD	SHED+369H THE CAB BOI5BUT YOU COULDN'T
- 1	0195 2A 76 02 0198 22 F1 05	0064	SHLD	BOISBUT YOU COULDN'T SHED+36BH SEE EITHER THE
1	0198 22 F1 05 019B 2A 78 02	0065	LHLD	BOI6ENGINEER OR THE
- 1	019B 2A 78 02 019E 22 F3 05	0066	SHLD	SHED+36DH FIREMAN
- 1	019E 22 F3 05 01A1 2A 7A 02	0067	LHLD	FRA1THE LITTLE ENGINE
- 1	01A1 2A 7A 02 01A4 22 26 06	0068	SHLD	SHED+3A0H ALSO
	01A4 22 20 00 01A7 2A 7C 02	0069	LHLD	FRA2HAD A COWCATCHER
1	01AA 22 28 06	0070	SHLD	SHED+3A2H AND LOTS OF FUNNY
- 1	01AD 22 2A 06	0071	SHLD	SHED+3A4H WHEELS AND THE
- 1	01B0 22 2C 06	0072	SHLD	SHED+3A6H THINGS THAT CONNECTED
1	01B3 2A 7E 02	0073	LHLD	FRA3AND TWO VERY TINY
1	01B6 22 2E 06	0074	SHLD	SHED+3A8H WHEELS AT THE VERY
1	01B9 2A 80 02	0075	LHLD	FRA 4 VERY BACK
1	01BC 22 30 06	0076	SHLD	SHED+3AAH ALTOGETHER IT LOOKED
1	01BF 2A 82 02	0077	LHLD	FRA5QUITE LONELY AND YET
	01C2 22 32 06	0078	SHLD	SHED+3ACH IT APPEARED VERY
- 1	01C5 01 DF FF	0079	LXI	B,-21HFUNNY JUST SITTING
	01C8 21 64 06	0080	LXI	H, SHED+3DEH THERE ON THE
1	01CB 36 19	0081 RAILS		M, 19HRAILS
	01CD 03	0082	INX	BWITH NOTHING AT ALL
	01CE 23	0083	INX	HEVER
	OICF AF	0084	XRA	ATO DO
1	01D0 A8	0085	XRA	B WELL!
	01D1 C2 CB 01	0086	JNZ	RAILSLET'S RUN IT JUST FOR
1		0087 *		FUN
	01D4 21 00 CC	0088 HOSTL		H, RRY GET TRAIN OUT OF SHED
1	01D7 EB	0089	XCHG	. MOVE IT FROM SHED
	01D8 21 86 02	0090	LXI	H,SHED
	01DB 7E	0091 FIRE	MOV	A,M LIGHT FIRE
	01DC 23	0092	INX	H
	Oldd EB	0093	XCHG	WALL TO THE REAL PROPERTY OF THE PARTY OF TH
i	01DE 77	0094	MOV	M,AMOVE IT
	01DF 23	0095	INX	Н

01E0				0096		MOV	А,Н
01E1				0097		XCHG	900 1810 1810
01E2			0.1	0098		CPI	ODOH END OF YARD?
01E4 (01E7				0099 0100		JNZ CALL	FIRE NO, MAKE MORE STEAM! TRAVL GO TAKE TRIP
OLEA				0101		JMP	HOSTL NO ROUND TRIPS, JUST DO
012		24	01	0102	*	Om	AGAIN
				0103			1 C 1 C 0 C 1 C 1 C 1 C 1 C 1 C 1 C 1 C
Oled		40	03		TRAVL	LXI	B,64*13 MAKE TRIP 13 MILES
01F0	_				CHOO		B CHUFF ONCE
01F1				0106		CALL	STROK MAKE FORWARD MOTION
01F4 01F7		UF	02	0107 0108		CALL POP	TURN TURN WHEELS B
01F8				0109		DCX	B CLICK ODOMETER
01F9				0110		XRA	A
OlfA				0111		XRA	B 13 MILES YET?
01FB		FΟ	01	0112		JNZ	CHOO NO
OlfE	C 9			0113		RET	. DO NEXT TRIP
01.00	21	0.1	00	0114			W AGGALW WOW DOWN THE TOLOW
01FF 0202			CC	0115	STROK	LXI MVI	H, OCC Olh MOV DOWN THE TRACK C, ODOH
0204		DU			COAL	MOV	A,M ADD MORE COAL
0205				0118	002	DCX	H
0206				0119		MOV	M,A
0207				0120		INX	H 715
0208				0121		INX	H
0209 020A				0122		MOV	A,H
020A		$\cap A$	0.2	0123 0124		CMP JNZ	C ENOUGH COAL? COAL NO, PUT MORE ON!
020E		04	02	0125		RET	COAL NO, POI MORE ON!
				0126	*	1101	
020F		00	CC		TURN	LXI	H, OCCOOH TURN WHEELS
0212					HISS	MOV	A, M
0213		0.0		0129		INX	H COMON TOWNS
0214				0130 0131		CPI JNZ	6 FIND COWCATCHER HISS LOOK AGAIN
0219			02		FOUND		H
021A					AXLE		A,M
		11				CPI	11H WHAT QUARTER TURN
021D				0135		JNZ	NXT1
0220	11	7 E	14	0136		LXI	D,147EH NEXT QUARTER TURN
0222	0.6	0.7		0137		MITT	P 7 PO A AVIEC
0223		0 /			AXL1 AXL2		B,7 DO 4 AXLES M,D WHEELS MOVED HERE
0226				0140	AALZ	DCR	B LAST WHEEL?
0227				0141		JZ	WORK I'VE BEEN WORKIN'
022A	23			0142		INX	HON THE RAILROAD
022B				0143		MOV	
022C				0144		INX	
022D 022E		25	0.2	0145 0146		DCR JNZ	BLONG DAY AXL2
1	-2	ر ے	02	0146		UNZ	RAUE
0231	FE	14			NXTl	CPI	14H QUARTER TURN
0233	C 2	3C	02			JNZ	NXT2
0236	11	2D	13	0150		LXI	D,132DH

0	L	14	1	0	1		L	4		1	^	0	n	ŧ
V				V	'	U	1	8	V	٠,	C	U		ι.

- 1				, cont.		Service (Color	Andrew Co. 200		
28	0239	C3	23	0.2	0151		JMP	AXL1	
- 1	023C			-	0152		CPI		QUARTER TURN
-				02	0153		JNZ		
19	0241				0154		LXI		
ğ	0244				0155		JMP		
Ĕ	0247		12	-		NXT3			QUARTER TURN
	0249			0.2	0157		JNZ		201111
×	024C				0158			D, 112DH	mane ibeli, but in the o
ESS	024F				0159		JMP	AXL1	
8					0160	*	7-11-		
A	0252	01	B4	14		WORK	LXI	B,5300	
1	0255				0162		DCX	В	10.00
- 1	0256		FA		0163		IN	OFAH	DID THE CONDUCTOR
	0258				0164		ANI	RDA	FLAG US DOWN
- 1	025A				0165		IN	OFCH	CLEAR INPUT PORT
- 1	025C			02	0166		JZ		QUITTIN' TIME
	025F				0167		XRA		NO, THEN HIGHBALL
- 1	0260				0168		XRA	В	1101
- 1	0261		55	02	0169		JNZ		NO SQUEEKS, PLEASE!
	0264			-	0170		RET		no become, realist.
		-			0171	*			
- 1							PUT A J	UMP TO WHI	ERE EVER YOU NEED TO
									NEXT STATION.
-	0265	C3	04	CO		QUIT			YOUR RETURN TICKET HERE
1					0175				7200
		000	01			RDA	EOU	01H	PUT YOUR DAV FLAG HERE
		CC	00				EQU	OCC 00H	VDM RAM
-		00	бF		0178	SMOKE	EQU	6FH	SMOKE CHARACTOR
1	0268	01	10		0179	CAB 1	DW	1001H	CAB DESCRIPTION
	026A	10	5D		0180	CAB 2	DW	5D10H	" "
	026C	7E	20		0181	CAB 3	DW	207EH	" "
1	026E	28	0A		0182	BOIl	DW	0A28H	BOILER DESCRIPTION
	0270	0A	19		0183	BOI2	DW	190AH	"
	0272	0A	0A		0184	BOI3	DW	HAO AO	" 12 12 12 12 12 12 12 12 12 12 12 12 12
	0274	0A	5B		0185	BOI 4	DW	5BOAH	"
- 1	0276	39	39		0186	BOI5	DW	3939H	11
	0278				0187	BOI 6	DW	205DH	Harris H. C. Control
	027A	06	20		0188	FRAl	DW	2006H	FRAME DESCRIPTION
- 1	027C	11	2D		0189	FRA 2	DW	2D11H	" "
1	027E	11	20		0190	FRA 3	DW	2011H	
	0280	6F	2D		0191	FRA 4	DW	2D6FH	" "
	0282		20		0192	FRA 5	DW	206FH	" I I I I
	0284	19	19		0193	TIES	DW	1919H	TIES DESCRIPTION
	0286				0194	SHED	NOP	•	THIS IS SHED AREA
		03	FA		0195	CLOUD	EQU	\$+0173H	BEGINNING OF CLOUD
1									



```
Galaxy
```

```
0001 *
0002 *
0003 *
       SHOOTING STARS -- A BRAIN TEASER GAME
0004 *
       AN INTERACTIVE GAME FOR 8080 COMPUTER
0005 *
       THIS VERSION IMPLEMENTED FOR Sol
0006 *
       DEVELOPED AND DEBUGGED WITH ALS-8
0007 *
       PROGRAM DEVELOPMENT SYSTEM
* 8000
0009 *
       PROGRAM ORIGINALLY SUBMITTED TO THE
       HEWLETT-PACKARD SOFTWARE LIBRARY IN BASIC
0010 *
0011 *
       SUBSEQUENTLY PUBLISHED BY PEOPLE'S COMPUTER
0012 *
       COMPANY IN SEPT 74 AS "TEASER"
0013 *
       WRITTEN IN 8008 CODE BY WILLARD I. NICO
0014 *
       IN BYTE MAY 76 AS "SHOOTING STARS"
0015 *
       ADAPTED TO 8080 CODE FOR USE WITH VDM-1
0016 *
       BY JERRY BACON
0017 *
       S.I.L. PROGRAMMING LABORATORY
0018 *
       BRASILIA, D.F. BRASIL
0019 *
0020 *
       DATE: 14 JAN 77
0021 *
0022 *
0023
     ORG 0
0024 SHSDR LXI H, HEADR POINT TO HEADER MESSAGE
     CALL SCRN DISPLAY IT
0025
0026
     CALL KBD
               CHECK IF RULES WANTED
0027 CPI 'N'
     JZ START IF NOT, START GAME
0028
     LXI H, PAGE1 OTHERWISE POINT TO 1ST PAGE
0029
```

```
0030
      CALL SCRN
0031
      CALL KBD
0032
     LXI H, PAGE2 POINT TO 2ND PAGE
     CALL SCRN
0033
0034
     CALL KBD
0035 START LXI D, VDM1
0036
     CALL CLER CLEAR THE SCREEN
0037
      LXI B, 0001H INITIALIZE UNIVERSE
0038
     MOV D,B CLEAR SHOT COUNTER
0039 CNTST INR D INCREMENT SHOT COUNTER
0040 DISP LXI H, STR1 DISPLAY UNIVERSE
     CALL TYPE
0041
     LXI H,STR2
0042
0043
     CALL TYPE
0044
     LXI H, STR3
0045
     CALL TYPE
0046
     LXI H, STR4
0047
     CALL TYPE
     LXI H,STR6
0048
0049
     CALL TYPE
     LXI H,STR7
0050
     CALL TYPE
0051
0052
     LXI H,STR8
0053
    CALL TYPE
0054
     LXI H,STR9
0055
    CALL TYPE
0056
     XRA A
     MOV A,C
0057
0058
     RRC
     LXI H,STR5
0059
0060
     CALL TYPE1
0061 WNTST MOV A,B GET UNIVERSE PATTERN
      CPI OFFH CHECK FOR FRINGE STARS
0062
      JNZ LSTST
                  IF NOT ALL PRESENT, CHECK FOR LOSS
0063
0064
     MOV A,C
0065
     ORA A
                  GET CENTER STAR
      JNZ GTSTR CONTINUE IF PRESENT
0066
      LXI H, MESS4 IF NOT, GAME IS WON. POINT TO WIN MESS
0067
0068
     CALL SCRNB
0069 *
0070 *
0071 *
0072 *
0073 *
0074 *
                 INITIALIZE BINARY TO DECIMAL CONV.
     MVI E, 'O'
0075
      MOV B, E
0076
0077
      MOV C, E
                 GET RID OF LAST SHOT
0078
      DCR D
      MVI A, '9'+1 SET OVERFLOW CHECK
0079
                      INCREMENT 1'S
 0080 MRDEC INR E
                 CHECK FOR OVERFLOW
 0081
      CMP E
      MVI E, '0' OTHERWISE, RESET 1'S
INC INCREMENT 10'S
      JNZ TALLY CONTINUE IF NOT
 0082
 0083
 0084
```

```
0085
            CMP C
0086 JNZ TALLY
0087 MVI C,'0'
0088 INR B INCREMENT 100'S
0089 TALLY DCR D DECREMENT SHOT COUNTER
0090 JNZ MRDEC
0091 MVI A,'0'
0092 CMP B CHECK FOR LEADING 0
0093 JNZ THREE IF NOT, DISPLAY 3 DIGITS
0094 CMP C
           JNZ TALLY
0095 JNZ TWO
0096
           JMP ONE
0097 THREE MOV M,B DISPLAY SCORE
0098 INX H
0099 TWO MOV M,C
0100 INX H
0100 TNX H
0101 ONE MOV M,E
0102 INX H
0103 XCHG
0104 LXI H,MESS5 POINT TO REST OF WIN MESS.
0105 CALL SCRN2
0106 PRNT1 CALL KBD
0106 PRNT1 CALL KBD
0107 CPI 'Y' CHECK FOR RESTART
0108 JZ START IF YES, START AGAIN
0109 RET . IF NOT RETURN TO ALS-8
0110 LSTST ORA A CHECK FOR NO FRINGE STARS
0111 JNZ GTSTR IF ANY ARE PRESENT CONTINUE GAME
0112 MOV A,C
0113 ORA A IF NOT, CHECK FOR CENTER STAR
0114 JNZ GTSTR IF PRESENT CONTINUE
0115 LXI H,MESS3 OTHERWISE POINT TO LOST MESS.
0116 CALL SCRNB
0117 JMP PRNT1
0118 GTSTR LXI H, MESS7 ASK FOR SHOT
0119 CALL SCRNB
0120 NXTST CALL KBD
0121 INX H
0121
           INX H
0122 MOV M,A ECHO SHOT
0123 CALL DELAY
0124 MVI E,9 SET MASK COUNTER
0125 LXI H,MASK POINT TO MASKS
0126 NXGRP CMP M CHECK FOR SHOT
0127 JZ FOUND
0128 DCR E
0129 JZ INVAL INVALID SHOT IF NOT FOUND
0130 INX H POINT TO NEXT ENTRY
0131 INX H
0132 INX H
0133 INX H
0134 JMP NXGRP
0135 FOUND INX H
0136
           MOV A,M
            ORA A CHECK STAR POSITION
JNZ UNIV2 JMP IF FRINGE STAR
MOV A,C
0137
 0138
 7139 MOV A,C
```

```
ACCESS November, 1977 page 3
```

```
CPI 1 CHECK FOR CENTER STAR
0140
0141 JNZ BDFEL IF NOT PRESENT, BAD SHOT
0142 JMP NXBYT
0143 UNIV2 MOV A,B
0144 ANA M ISOLATE STAR SHOT
0145 JZ BDFEL IF NOT PRESENT, BAD SHOT
0143 UNIV2 MOV A,B
0146 *
0147 *
0148 *
0149 *
0150 *
0151 NXBYT INX H
0152 MOV A,B
0153 XRA M ALTER GALAXY
0154 MOV B,A SAVE NEW PATTERN
0155 INX H
0156 MOV A,C
0157 XRA M CHANGE CENTER STAR, IF NECESSARY
0158 MOV C,A
0159 JMP CNTST COUNT SHOT AND DISPLAY NEW UNIVERSE
0160 INVAL CPI ESC CHECK IF INVALID SHOT WAS AN ESCAPE
0161 JNZ NTVAL
0162 LXI H, MESS6 IF SO POINT TO SURRENDER MESSAGE
0163 CALL SCRNB
0164 JMP PRNT1
0165 NTVAL LXI H, MESS2 POINT TO INVALID STAR MESSAGE
0166 CALL SCRNB
0167 JMP NXTST GO TO NEXT SHOT
0168 SCRN MOV A,D
0169 STA TEMP SAVE D (SHOT COUNTER)
0170 LXI D, VDM1 SET SCREEN ADDRESS
01/0 LX1 D, VDM1 SET SCREEN ADDRESS
0171 SCRN1 CALL CLER CLEAR & INITIALIZE SCREEN
0172 SCRN2 MOV A,M
0171 SCRNI CALL CLL.
0172 SCRN2 MOV A,M
0173 CPI EM CHECK FOR END OF MESSAGE
0175 STAX D DISPLAY CHARACTER
0176 INX H
0177 INX D
0178 JMP SCRN2
0179 END LDA TEMP GET SAVED SHOT COUNTER
0180 XCHG
0181 MOV D,A PUT IT BACK IN D
0182 RET
0183 SCRNB MOV A,D
0184 STA TEMP
0187 CLER PUSH D SAVE STARTING ADDRESS
0188 XRA A
0189 OUT VDM
0189 OUT VDM INITIALIZE VDM-1
0190 CLER1 MVI A, ' GET A SPACE
0191 STAX D
     INX D
0192
     MOV A, D
0193
0194 CPI BOTT CHECK FOR END OF SCREEN
```

```
0195
    JNZ CLER1
     POP D RESTORE STARTING ADDRESS
0196
0197 RET
0198 TYPE XRA A CLEAR A & CARRY
0199 MOV A.B GET UNIVERSE
0199
     MOV A,B GET UNIVERSE
0200
     RRC
0201
     MOV B, A
0202 TYPE1 JC STAR
     MVI M,'0' DISPLAY HOLE
0203
0204
0205 STAR MVI M, '*' DISPLAY STAR
0206
    RET
0207 KBD CALL DAV KEYBOARD INPUT ROUTINE
     JZ KBD
0208
0209
     IN DATA
0210
     ANI 127
0211
    RET
0212 DAV IN STAT
0213
    CMA . CAN BE CHANGED TO A NOP
0214 ANI DAVM
0215 RET
0216 BDFEL LXI H, MESS1 POINT TO ERROR MESSAGE
0217
    CALL SCRNB
     JMP NXTST
0218
0219 DELAY PUSH D 2 SECOND DELAY ROUTINE
0220
    PUSH PSW
0221
    MVI D, 2
0222 DLY1 MVI E,100
0223 DLY2 XRA A
7224 DLY3 DCR A
J225
     JNZ DLY3
0226
    DCR E
0227 JNZ DLY2
0228
     DCR D
0229 JNZ DLY1
0230 POP PSW
0231 POP D
    RET
0232
0233 TEMP DS 1
0234 *
0235 *
0236 *
0237 *
0238 *
0239 *
0240 *
0241 MESS1 ASC "HEY! YOU CAN ONLY SHOOT STARS, NOT BLACK HOLES."
0242 ASC "TRY AGAIN."
0243
    DB EM
0244 MESS2 ASC "THAT WASN'T A VALID STAR NUMBER. TRY AGAIN."
0245
0246 MESS3 ASC "YOU LOST THE GAME! WANT TO SHOOT SOME MORE"
0247
    ASC "STARS?"
0248
     DB EM
```


9249 MESS4 ASC "YOU WIN!! GOOD SHOOTING! YOU FIRED "

```
0250
     DB EM
0251 MESS5 ASC " SHOTS. BEST POSSIBLE
                                       SCORE IS 11 SHOTS."
     ASC "WANT TO SHOOT AGAIN, DEADEYE?"
0252
0253
     DB EM
0254 MESS6 ASC "YOU GIVE UP TOO EASILY! WANT TO SHOOT SOME MORE"
     ASC " STARS?"
0255
0256
     DB EM
0257 MESS7 ASC "YOUR SHOT?"
0258
     DB EM
0259 HEADR ASC " * * * *
                          * * * * SHOOTING STAR"
    ASC " S * * * * *
0260
0261
    ASC ". .
     ASC " .
0262
     ASC " A
0263
                BRAIN
                            TEASER GAME!!!"
0264
     ASC ". .
     ASC " . .
0265
     ASC "DO YOU WANT THE RULES? (TYPE N FOR NO)
0266
0267
     DB EM
0268 PAGE1 ASC "THERE ARE STARS: * AND THERE ARE HOLES: 0 IN"
0269
     ASC " THE UNIVERSE.
0270
     ASC
         "YOU SHOOT A STAR, (NOT A BLACK HOLE) BY TYPING "
     ASC "ITS NUMBER.
0271
     ASC " 1
0272
               2
                  3
     ASC " *
0273
                  *
     ASC " 0
0274
               0
                 0
    ASC " 4
0275
               5
                 6
     ASC " *
                 *
0276
              0
     ASC " 0
              0
                 0
0277
     ASC " 7
0278
               8
                  9
     ASC " *
0279
               *
                 *
         " 0
               0
0280
     ASC
     ASC "YOU WIN IF YOU GET THE PATTERN IN THE MIDDLE. "
0281
     ASC "YOU LOSE IF YOU GET THE PATTERN ON THE RIGHT."
0282
0283
     DB EM
0284 PAGE2 ASC "EACH STAR IS IN A GALAXY. WHEN YOU SHOOT A STAR"
     ASC " EVERYTHING IN ITS GALAXY CHANGES. ALL STARS BECO"
0285
     ASC "ME BLACK HOLES AND ALL BLACK HOLES BECOME STARS."
0286
0287
     ASC ". . .!. .
0288
     ASC "
                                                    0
             1
                                   0
                                         3
                                                 0
0289
     ASC "O
0290
0291
     ASC
         ..
                           0
                             0
                                   0
                                                 0
                        0
     ASC "*
              5
0292
     ASC "
0293
            0
                0
                   0
                        0
                           0
                             0
                                   0
                                      0
     ASC "0 *
0294
                0
     ASC "
0295
     ASC "
0296
0297
     ASC " 0
              0
                                     0
     ASC "O
0298
              0
                 0
     ASC " 0 0
                                        0
0299
                                  0
                                     0
     ASC "O
0300
      ASC " 0
0301
               0
      ASC " 0
0302
0303 ASC " READY TO PLAY. "
0304 ASC "TYPE ANY KEY TO START. GOOD LUCK!"
```

```
ACCESS November, 1977 page 35
```

```
0305
      DB EM
0306 *
0307
0308
0309
0310
0311
0312 MASK DW 0131 MASKS FOR CHANGING UNIVERSE
0313
      DW 010BH
0314
      DW 0232H
0315
      DW 0007H
0316
      DW 0433H
0317
      DW 0116H
0318
      DW 0834H
0319
      DW 0029H
0320
      DW 0035H
     DW 015AH
0321
0322
      DW 1036H
0323
     DW 0094H
0324
      DW 2037H
0325
      DW 0168H
0326
      DW 4038H
0327
      DW OOEOH
0328
      DW 8039H
0329
      DW 01D0H
0330 VDM1 EQU OCCOOH
0331 SCRBT EQU OCFOOH
0332 VDM EQU OFEH CHANGE TO 0C8H FOR USE WITH VDM-1
0333 STR1 EQU OCD1BH STAR LOCATIONS
0334 STR2 EQU OCD20H
0335 STR3 EQU 0CD25H
0336 STR4 EQU OCD9BH
0337 STR5 EQU OCDAOH
0338 STR6 EQU OCDA5H
0339 STR7 EQU OCE1BH
0340 STR8 EQU OCE20H
0341 STR9 EQU 0CE25H
0342 STAT EQU OFAH KEYBOARD STATUS PORT
0343 DATA EQU OFCH KEYBOARD DATA PORT
0344 DAVM EQU 01H DATA AVAILABLE MASK
0345 BOTT EQU ODOH
0346 EM EQU 01H
0347 ESC EQU 1BH
```





1 EPT 2 - 87

PROCESSOR TECHNOLOGY CONTROL CONTROL

75¢ per issue

Published by Processor Technology Corp., Pleasanton. Volume Two, Number One. March 197

Sol's Parallel Data Interface A New Section: ACCESS to Software Vectored Interrupt Modifications for The Sol



From The [Outgoing] Editor

"Alas poor Yorick, for I knew him well." Willie the Shake

For those of you who don't already know, this is to inform you of my departure from PTC and my abdication of the editorship of ACCESS. The reason for this change is fairly simple: I'm going to work for myself as an independent consultant (free-lance technician in plebian terminology). Sorry I can't provide any scandalous gossip about my reasons for leaving. But, if you really must ask, well, let me tell you...

Obviously I couldn't have gotten to the position of being my own boss if it hadn't been for the training, experience and contacts (not to mention confidence) I gained at PTC.

Leaving definitely creates an empty spot in my life, having grown with the company (2 years). I feel like a teenager leaving home for the first time (sob, sob!).

But enough being maudlin and on to the corn. I think old Ralph should be able to take the helm and steer the ship-of-state through the uncharted waters of the future, in a manner and style befitting one of this stature.

My God! Somebody shut this fool up. He sounds like journalistic Muzak!!

Why should I shut up, dammitt. I'm the Editor. I can say

Not any more you can't. You're just the Outgoing Editor. You don't count any more!

Well, as you can see, there are good reasons for me being locked up in this place. And, what the hell, the food's OK.

I guess it's time to go, so I'll close this chapter of history with a sentimental goodbye to y'all. And expecially to Les Solomon who could be a guru. But whoever heard of a Jewish guru?

Love and kisses to all.

Aram Attarian II (415) 534-6628 1924 - 10th Ave. Oakland, CA 94606



Volume Two. Number One March 1978

Publisher Processor Technology Corp.

> **Editor** Ralph I. Palsson

Staff Writers Lee Felsenstein Drew Rogge

Design/Production Wible/Rampton Advertising

ACCESS is published approximately every six weeks. Subscription rate: \$4 per year, from Processor Technology Corp., 7100 Johnson Industrial Way, Pleasanton, CA 94566.


ACCESS Copyright © March 1978 by Processor Technology Corp. All Rights Reserved. Material in this publication may not be reproduced in any form without permission from Processor Technology Corp.

Table of Contents

Reader Feedback page 3
A review of our Extended Cassette BASIC, now available page 6
The Sol Users' Society grows and wants you! page 6
Adjusting BASIC/5 for the new Extended Cassette BASICpage 7
Lee Felsenstein elucidates interfacing to Sol's parallel portpage 9
Having trouble with your 16KRA? Check this page 11
Vectored interrupt capability for Sol page 11
Interfacing the OP80A Paper Tape Reader to your Sol-20page 13
A selection of programs and applications contributed by our illustrious readers page 14
Warn VOII Warned

Please notify us of your change of address. Here's a handy form:

NAME	
NEW ADDRESS	



A Letter From The [New] Editor

That's me, Ralph Palsson. Remember me from One-to-One Communication? I'm changing hats because Aram Attarian II. former ACCESS editor, lead Warranty Reair Applications Engineer, cuscomer interfacer, and all-round good guy, has succumbed to the siren song of "making it" freelance. He's setting up an independent systems consultant and repair technician, and we're going to miss his red suspenders around here. He devoted a lot of creative energy and talent to making ACCESS what it is today, so I'll do my best to keep up the good work. For Aram's last words of wisdom to us, see his outgoing editorial on p. 2.

Now that I have this column to sound off in, we'll probably discontinue One-to-One Communication as separate feature. The original idea behind ACCESS was to make it a vehicle for one-to-one communication in its entirety, and that's beginning to happen, as you'll see from the many excellent reader contributions in this issue. I'll be laving it pretty heavy on you readers to keep up the good work-send us your program listings, letters, hardware modifications, applications, anyhing you think is worthwhile and would like to share.

The main change I initially hope to make in ACCESS is getting it on a somewhat more regular publication schedule, aiming at every 6 (±2) weeks. And I promise that everyone who had paid \$4.00 for a year's subscription will actually receive 8 issues, regardless of how many leaves get torn off the calendar. As for the new format-well. you people seem to be as enthusiastic about it as we are, and we'll keep adding whatever improvements we think of. Again, your suggestions are valuable, like the punched-hole idea several readers have mentioned.

I like to think of ACCESS as one proof of the pride Processor Technology takes in providing customer support. So far, we have a pretty good track record, but we aim to make it even better. We have a very user-oriented Customer Service Dept., plus the more technicallyinclined applications and product support engineers regularly available to help you with debugging and troubleshooting your kits. They're also good with advice on how to interface a Sol or 3P+S to a peripheral device. And we even have a customer service software consultant available for phone discussions. But there's one thing none of these people can do, and that's help you with support for XYZ company's floppy disk or ABC's 16K board. No matter how expert they are, our engineers can't know the personal design quirks of a product they may never have seen, and really your guess is as good as theirs many times. We'll do as much "hand-holding" as we can by phone or letter, but please understand the distinction between help with interfacing and help with someone else's product.

Our Customer Service technicians are currently available daily from 1:30 to 4:00 p.m. PST for phone consultation. The number again is (415) 829-2600. We'll increase the hours as soon as we can add more trained personnel who can give you straight answers you deserve.

I'll end with my usual plug for Processor Technology dealers. These guys can provide you with a wealth of information and assistance without running up your phone bill. Our intentions are good, and we back them up with action as much as possible, but it's a fact of life that we're way out here in Pleasanton, CA. And if you're in Manhattan, Bloomington, or even Lompoc, you will probably get more personal service from the dealer who's helped you plan your system in the first place than you can get from a voice on the phone. The idea is to give you the best support pos sible, wherever it comes from.

Well, hope you enjoy AC-CESS # 5, and in the words of AA II, y'all have a good time, y'heah?!

Ralph I. Palsson



Dear Editor:

HISTOGRAMS IN BASIC (Or how to display multiple cursors)

Attempting to use Basic 5 for plotting the results of stock analysis, I wanted to plot a graph of the derived results. An approach has been

developed, using the TAB function to start a plot, and a calculated value of a variable to end the plot. I also wanted to use reverse video to highlight data or to plot a bar made up of (aO hex) "cursors." Initially this was difficult, since many 7F masks were used in the VDM driver within CUTER to maintain a clean display. Therefore the VDM driver cannot be entered with a CALL to its entry address, since bit 7 is cleanly stripped off. The solution to this problem lies in addressing that portion of the VDM driver starting at location CØBB after having put the AØ into register B. That can be done as an immediate move in machine code necessitating a call from Basic to your machine code which in turn calls the driver, or by using the ARG command in basic before the call to the driver. This latter approach has an advantage in that the value of the ARG can also be calculated thus giving you control over the character chosen for the plot. (Incidentally, the 7F, delete character makes a nice chart due to the spacing between bars.) These ARG and CALL functions are used within a FOR-Next loop which is set up as described in the beginning of this description. That looping puts out the desired number of repeated characters and leaves VDM screen management control within the Basic/Cuter/VDM driver software management system.

In closing, let me send my praise and thanks for your product quality and utility. The PTCO additions have really enhanced my IMSAI.

Donald F. Petrie 831 Ponderosa Dr. So. Daytona, Fla. 32019

Donald also enclosed a carbon of a letter he wrote in response to Dave Wrobel's query in the last ACCESS:

January 10, 1978

Dear Dave:

Don't despair! Inverse video is attainable. I noticed your letter and Mr. Attarian's response in issue

number four of Processor Technology ACCESS.

I too was interested in the use of inverse video with my IMSAI/VDM/CUTER configuration and was frustrated when using the SOUT entry point of the VDM driver. When I use an ANI 7F in the code, a cleanup, stripping off of the parity bit (in our case the VDM inverse video bit) is performed.

There is a simple solution to the problem, however, if you will use a machine language subroutine (callable from Basic, if desired) which calls the VDM driver after the housekeeping stripping referred to above. This driver routine, identified as "OCHAR," is at CUTER location COBBH and in SOLOS at location CO98H. Calling the driver at OCHAR with bit 7 high will result in the desired inverse video display.

You have a number of options in approaching this problem. In machine code, put the character into Register B, with bit 7 high and then call OCHAR. In BASIC 5, establish the character as the value of an ARG function and use the Basic ARG/CALL routines to call OCHAR. And if you want keyboard on-off toggling control of this feature, a simple custom output driver invoked by the SOLOS/CUTER pseudo-port 3 routine can be written to sense your command choice; then either add or strip-off bit 7 as appropriate and put the character in register B before calling OCHAR and returning to your system.

I hope one of these suggestions will be of use to you if you haven't already found a solution to your desire for inverse video display.

D. F. Petrie

cc: Mr. Aram Attarian Editor, Processor Technology Access

Dear Donald,

Yes, Virginia, Inverse Video is attainable in Sol BASIC/5, thanks to your information. Reader Tom Digate has also sent us a contribution on this subject, a cassette written in BASIC/5 demonstrating the uses of SOLO's VDM driver escape

sequence. A printout of his program appears in the ACCESS to Software: section of this issue. Many thanks to you, too, Tom.

Aram is passionately hardware oriented and doesn't always realize that anything's possible with software!

Ralph

Dear Editor:

Enclosed you will find a check for \$4.00 for my 1-year subscription to ACCESS. I was at my local computer store, (Itty Bitty Machine Company, Lombard, ILL), and they gave me a copy of ACCESS to look at. I thoroughly enjoyed reading the articles in the November issue. Congratulations on your fine publication. I have a question that you or maybe your readers could help me on. I have a IMSAI 8080 Micro Computer with the following boards: a 16K Processor Tech. Memory, VDM board by PTC, and my problem, 1 Tarbell Cassette interface board. I am going to purchase your (Sol) Basic Computer and I would like to know if there is a program to convert the CUTS format to Tarbell format for my cassette interface. I would like my IMSAI to run Sol software. If anyone can help, please do.

Thank you.

Robert Bennett 2046 Louis Street Melrose Park, ILL 60164

Dear Bob.

Thanks for your letter; an ACCESS subscription has been entered for you and hopefully you're now reading this in your first copy.

Note that Sol BASIC/5 is an interpreter, not a compiler. If you're feeling any confusion about it, I'm sure your dealer can help.

About the CUTS/Tarbell matter. PTC doesn't support the Tarbell cassette interface with hardware or software, because we feel that CUTS is a superior system for several reasons. The CUTS (Computer Users Tape Systems) recording method was derived from and is

compatible with the Byte (Kansas City) standard recording method, a system that PTC helped develop at the 1975 Kansas City meeting. We

lieve strongly in promoting software standardization and have put a lot of effort into the cause. CUTS was especially designed to permit widespread dissemination and exchange of low cost software. To that end, CUTS tapes are less expensive and easier to produce than Tarbell; PTC has shipped over 30,000 of them to date with less 1% failure rate - not bad, if we do say so ourselves! And although CUTS is slightly slower than Tarbell, it requires less adjustment to work with a greater variety of tapes and cassette recorders - again facilitating standardization and exchange.

So while we can't be too encouraging about your conversion project, we hope you will continue your interest in CUTS and Sol software. We think you'll end up very happy with it.

Ralph

gentlemen.

I am enclosing a listing of a game written in BASIC called Hammurabi. I found it in one of the hobbyist magazines, Personal Computing. I think. I modified it to run in Basic 5 and I and my two boys have enjoyed playing it. I thought perhaps other Sol owners might also enjoy it. It will run in 8K and I run it on the CRT. I have enclosed a printout of a typical "year" of the game ending with a deliberate error which ends the game with a loss of kingdom. The entire successful game would have been too long a printout and I think the short example will give anyone looking at it the idea of how it's played.

I enjoyed the first issue of the new format of *Access*. Keep up the good work.

I visited your booth at the New York Coliseum and was very taken with the Sol set up to record a mailing list on tape which was en to public entry. If a copy of s program is available, I would R.F. field.

very much like to obtain one.

Best wishes for your continuing success.

John Dowd Lynn's Hair Fashions New Road, Central Ave. Linwood, N.J. 08221

Dear John,

Thanks for your comments and contributions. The mailing list program you saw in New York was just a demo version and not available in its present form. However, our software development is now shifting to an emphasis on applications, and you'll find many exciting programs forthcoming in the near future.

To our readers.

Besides the Hammurabi program, John also sent us two others, PAROL and COMM. All three appear in the ACCESS to Software section—try them out!

Ralph

RE: Sol20

Gentlemen:

I purchased my Sol20 mid December 1977. After several hours of building (72) the Sol, to explicit and well defined hardware assembly instructions, I had a letter perfect "turn on." My compliments to all connected with this portion of the manual and hardware parts staff.

I have encountered one problem which I have since corrected. This was a very heavy smearing and unstable effect on my video monitor. Distortion severe enough to force shut down manually and of course interrupting work in process. I could still "SAVE" etc. But it was very difficult to read monitor and inputs, when instability occurred. Being more familiar with R.F., video and communications equipment than logic, I found a quick and normal solution to the problem, one which is a standard practice in the R.F. field.

Solution:

The clock generator at "14.31818 MHz" is fairly open to external field excitation, by nearby C.B. and other transmitter frequencies. This unprotected portion of your circuit tends to wander if excited by an external signal and does not settle down. The reason is the XTAL can itself, floating above ground. A short jumper between the can and ground corrected the problem immediately.

I hope this assists other Sol users.

Now the bad news. I realize most people purchasing Sol's are probably more software oriented than I am. Therefore, your company did a painstaking task on the hardware. But your software write-up for a beginner (28 years communications) in computer talk and functions is very poor.

I know it is difficult and a lot of self study must be done, which I am now doing, but!

Might I suggest you acquire some unsuspecting person with no software knowledge, sit him/her in front of the machine, hand him "Console Manual" and "Solos Manual" and watch the confusion. If it is me, I apologize. But after showing your book to 3 top software experts, they agreed, it was written by a software expert.

Example:

After 10 hours of reading, re-reading, 1 trip to vendor (80 miles), no luck, re-reading, etc., trying to work out the CRC computation. Nowhere could I see it written.

"When you desire to save a file. Input SAVE (title) 5 words and press "RETURN."

N.B. "Making sure recorder is in record mode."

But most important, "File. header is then automatic."

I guess I'm saying try to use layman's language, if possible. If you re-read "SOLOS" I am sure you will agree.

I am very satisfied with the unit and want to congratulate those who worked hard on design and appearance. Well done.

B. W. Poste 17 Lonsdale Place, Barrie, Ontario

Dear B.W.,

Thanks for the compliments, and for the hardware fix. Many of our readers will find your contribution from the RF/analog world extremely useful.

Your critical points on documentation and software are very worthwhile. PTC's Technical Documentation Dept. is always looking for input that will help future publications be more clearly presented, on the appropriate level of expertise. Meanwhile, we'll try to provide some concrete followthrough in the next issue of ACCESS.

Ralph

Gentlemen:

Loved the new ACCESS format, but tell me, will my one-year subscription be extended to cover the first 8 issues (since you nominally publish every 6 weeks)? You haven't quite been able to keep up with the announced schedule for either ACCESS or ALS-8 users notes, (though the latter are not officially a product of P.T.). Also, (this may sound like a dumb question), is there any chance of re-publishing the 1st 3 issues in the new format? Even if it costs \$2-\$3 per copy? The new format is so much better, especially for my only good source of a CUTTER (or SOLOS) listing.* Thanks.

> Barry Watzman 2330 Millenium Lane Reston, VA 22091

*Besides, then I could keep a complete collection of ACCESS in a 3-ring binder!

Dear Barry,

Yes. We'll make sure you (and other ACCESS subscribers) receive 8 issues before you come up for second year billing. Also, we aim to put the journal back onto a more reasonable schedule.

As you might guess, costs of republishing out-of-print ACCESS

issues are prohibitive. However, I'm thinking of possibly doing a collection of the "Best of ACCESS" as a separate issue or reprinting the most requested articles from past issues. How do you other readers

feel? (NOTE: We still have a lot of our 2nd issue on hand; numbers 1 and 3 are out of print.)

Ralph

Extended Cassette BASIC Is Here!

Our long-promised Extended Cassette BASIC has been released and is now at your local PTC dealer. It's a powerful language, and we'll be publishing assorted program listings in future ACCESS issues to stimulate your imagination on its applications. Just for starters, note that Extended Cassette BASIC features complete string functions and matrix operations. And the documentation is excellent.

It's rumored there may be some bootleg copies floating around. Assure yourself of getting a quality tape and complete package by buying only if the cassette and manual are identical to those shown in the photograph here.

There's one slight bug we've discovered in using manual FOR/NEXT loops. The bug occurs when there is a FOR/NEXT loop within a FOR/NEXT loop which will not allow the execution of the inner loop. The squasher allows the execution of the internal loop rather than searching for a loop elsewhere in the program. It's easily fixed by following this 5-step procedure:

1) GET BASIC from the tape. Note the load address and length.

2) Type EN B3E in SOLOS.

3) Type the following numbers, separated by a space: C1 CA 2E 0B/(CR)

4) SAVE BASIC (refer to Section 3.4 in the BASIC User's Manual). Let the tape run in the RECORD mode for 10-15 seconds before re-recording. You can use a new tape if you wish, but the original one will work just as well. Use the load address and length infor-



mation you obtained in Step 1 of this procedure, and make the auto start address 0 and ending address 3F84.

If you're using the original cassette, affix scotch tape over the two holes on the back of the cartridge. Remove tape when finished; this will afford you "write protection."

The Sol Users' Society Is Up And Running

Last issue we reported on the formation and first meeting of SOLUS, the Sol Users' Society. It's an organization for owners of Sol computers or of Sol-type computers compatible with other PTC products. Specifically, if you have an 8080 or Z-80 microcomputer you're using with SOLOS, CUTER, SOL/CUTS cassette interface, or any functionally equivalent operating system, you might like to join. The membership is world-wide.

Currently, SOLUS has several good services going, beginning with their own bi-monthly (approximately!) newsletter to keep members informed on hardware, software, new products, bugs, local chapter meetings, and other items of interest. They maintain a Software Library which collects and distributes public domain programs for a nominal charge. Local chapters hold meetings to exchange software and

ideas, and the club headquarters, in convenient proximity to PTC, keeps a close communication link going with us. Finally, qualified SOLUS volunteers are testing products for Sol compatibility and reporting their experiences in the newsletter.

To refresh you on the club's goal and organization: The stated goals are to facilitate communication among SOLUS members, to provide a mechanism of exchange for Sol-compatible software, to give PTC feedback from SOLUS members, and to encourage the development and testing of Sol-compatible hardware and software produced by independent sources. Their relationship with PTC and

other manufacturers is co-operative but independent. SOLUS is primarily a personal computer users' group, but special interest groups can be formed within the club on subjects like commercial use, health care, education, scientific applications, etc. The society is supported by dues and volunteer efforts.

To join SOLUS: If you live in the U.S., Canada or Mexico, send \$10.00 in check or money order to SOLUS, P.O. Box 23471, San Jose, CA 95153. If you live anywhere else, send \$15.00. Dealers and manufacturers of Sol-compatible equipment or software should contact SOLUS at the above address for details on special memberships.

What To Do With Your BASIC/5 Programs Now That You Have Extended Cassette BASIC

Unfortunately, programs written in Sol BASIC/5 won't run with the new Extended Cassette (formerly called 8K) BASIC interpreter. But you can save yourself several thousand tedious keystrokes by sing the following assembly language program to save your BASIC/5 programs in text form on CUTS cassette. Then it will be easy

to get and run a text file on the new interpreter whenever you wish.

The program uses the byte access tape routines in the SOLOS/CUTER monitor. CLIST is written to be used as custom output diver in conjunction with pseudo port 3.

When you use the program, load the machine code at the addresses indicated in the assembly

listing below. Set the custom output port address to the beginning address of this program. Get and execute BASIC/5. Get the program you want to write to the tape. From BASIC/5, set the output port to 3 and type LIST.

After your program has been saved, this routine will set the current output port back to 0. \square

		W					
	000D 000A	CR LF	EQU EQU	ODH OAH		carriage ret line feed	urn
		* Sold	os equat	es			
	C01C C007 C00A C010 C807	FCLOS WRBYT	EQU EQU EQU EQU	OCO1CH OCOO7H OCOOAH OCO1OH OC807H			
			program s is als				
CB00		*	ORG	OCBOOH			
	CBOO	CLIST	EQU	\$			
CB00 CB01 CB02	D5		PUSH PUSH PUSH	B D H	Save	registers	
		#					

80	CB03	78			in Le	MOV	A,B	get character	1 EPT 2 - 94
1g 38ge	CB04 CB06			CB		CPI JNZ	CR CL2	Carriage return?	
ACCESS • March, 1	CB09 CB0C CB0D CB0F CB12 CB13 CB14	7E FE 01 C2 20 23 7E	D			LXI MOV CPI JNZ INX MOV	CŔ CL2 H A,M	Get last character If not two carriag in a row then r Else check if firs of carriage ret	ge returns in nothing special st set turns
	CB15 CB18 CB19 CB1A CB1D CB20 CB23	C2 41 3D 77 3A 6 21 6 CD 5 C3 4	2 (3 (E (CB CB CB		ORA JNZ DCR MOV LDA LXI CALL JMP	UNIT H, HEADE OPNOP GBACK	If not then closereset program. Else say we alreadhad first time Get unit to write Point to tape he Open the file	dy through to
	CB26 CB27 CB29 CB2C	FE 0 DA 2	F		CL2	MOV CPI JC STA	A,B LF+1 CL3 LCHAR		
	CB2F CB31			CO	CL3	MVI CALL	A,O AOUT	Reflect character	to screen
	CB34	B7				LDA ORA	FIRST A	Check if writing Return if not	yet
	CB38	78		СВ	*	JZ MOV	А,В	Return 11 not	
	CB3C CB3E	DA 4	7		*	CPI JC	LF+1 GBACK		
	CB41 CB44				*	LDA CALL	UNIT WRBYT	Get unit to write Write the byte	e to
	CB47 CB48 CB49	D1			GBACK	POP POP	H D B	Restore registers	
	CB4A	C9			*	RET		to Basic/5	
		CB4B			CLOOP	EQU	\$		
	CB4B CB4E CB51 CB52 CB55 CB58 CB5B	CD 0 AF 32 7 32 7 32 0	A 3 4 7	CO CB C8	ented to	LDA CALL XRA STA STA STA JMP	UNIT FCLOS A LCHAR FIRST OPORT GBACK	Close file Reset program fortime through Change output por	
		CDEF			# # OPMOD	EQU	\$		
	CDCD	CB5E		00	OPNOP #				
	CB5E CB61		1	CU	*	CALL RET	FOPEN		
	CB62	01			UNIT *	DB	1	Change to 2 to us	se tape unit 2
1	CB63	43 4	С	49 53	HEADR	ASC	CLIST		


Catanagastantes	CB68	54			DB	V 5.71	0	1 EPT 2 - 95
	CB69	54			DB		T	T' for TEXT
	CB6A				DW		256	Length of block
	CB6C	00	00		DW	į.	0	
	CB6E	00	00		DW		0	
1	CB70		00		DW		0	Three spares
1	CB72	00		r =	DB		0	
1								
1	CB73	00		LCHAR	DB		0	
I	CB74	00		FIRST	DB		0	
I	CB75	00		INFLG	DB		0	
1								


Interfacing To The Sol's Parallel Port

by Lee Felsenstein

The parallel input/output port on the Sol, J2, is intended to allow highspeed transfer of data between the CPU and outside devices. The circuitry was designed to be symmetrical, so that two devices having identical interfaces can communicate with each other. In contrast, the 3P+S circuit puts out a positivegoing data strobe pulse but requires either a negative-going data strobe ulse or a steady level in the return direction. As a result, two 3P+S boards cannot communicate without additional circuitry, while two Sols can communicate through their parallel ports with nothing but wires between them.

Data is transferred on eightbit-wide paths into and out of the Sol, through the pins of J2 labelled PIDO-7 (data into the CPU) and POD0-7 (data out of the processor). Polarity of the data on these pins is positive—that is, a "high" logical level is equivalent to a binary "1." Data is latched at the output side of the interface and is not latched at the input side. This means that after an output instruction to the parallel port (port FD) is issued, the new data remains present at the output pins of the connector indefinitely, until the next output instruction is issued. Similarly, the external device which provides data to the Sol through J2 must keep its data present on the PID pins long enough for it to be 'picked up" by the Sol CPU.





Supervisory signals, known as "handshaking" signals, are provided in both directions to allow the devices on each side of the interface to know when data has been accepted and when each may present the next eight bits of data. Each side

issues a negative-going "strobe pulse" when its data is ready and latched. In the direction going out from the Sol, this signal is called POL, for Parallel Output Load. The line over the signal name signifies that the signal is "active low." All of

the handshaking signals are active low, so that a disconnected plug automatically results in a "not ready" condition. Resistors connected from the in-coming handshaking signals to +5 volts will "pull up" these pins to a high level automatically when this happens. Due to the pecularities of TTL logic, it is almost impossible to "pull down" a disconnected input.

The external device sees the POL signal and immediately acknowledges it with a high level on the PXDR pin, (Parallel External Device Ready). The Sol CPU will test the level of this signal before issuing a new POL. The external device sets the PXDR low again as soon as it has accepted the data and no longer requires its presence on the POD pins. Fig. 1 shows the sequence relationship between these signals.

In the incoming direction to the Sol CPU, the signals and the seguence are the same, with only the names and pin numbers changed. The data strobe fed to the Sol is PDR, (Parallel Data Ready). The Sol circuitry immediately responds with a high level on its PIAK pin Acknowledge), (Parallel Input which continues until the CPU has accepted the data presented at

the PID pins Fig. 2 shows a suggested circuit for providing the handshaking signals from an external device. Note the provision for an "Initialize" pulse. This prevents the circuit from starting up in a "not ready" condition and "hanging up" the Sol CPU. Some external devices will not require this signal, but as an interface designer or troubleshooter, you should understand the possible pitfall. 74LS series logic is shown, but any TTL logic may be used. Each input of the parallel interface should present no more than one standard TTL equivalent load (1.6 maximum current source).

Three signals remain unexplained so far. These are PIE (Parallel Input Enable), POE (Parallel Output Enable), and PUS (Parallel Unit Select). These are direction-control signals to allow sharing of data lines among several

FIG 3 J2-VIEWED FROM REAR OF SOL BIT 1 OF INPUT PORT FA INPUT STROBE (LOW ACTIVE 500 MEMINI WIDTH) TO SOL INPUT ACKNOWLEDGE FROM SOL (HIGH = NOT READY) PARALLEL INPUT DATA PRESENTED TO SOL CPU (EXTERNALLY LATCHED) ENABLE (BIT PORT FA OUT) INITIALIZED TO HIGH PID6 PID4 PID2 PIDE PID5 PID3 PID1 PDR PIDT PIE PIAK GROUND PXDR POD7 P005 POD 3 PUS POD1 POE \$ POL P006 P004 POP2 POPO PRALLEL UNIT SELECT -ATCHED DATA (BIT 4, PORT FA OUT) FROM SOL CPU LATCHED BY OUT FD INSTRUCTION OUTPUT ENABLE (LOW : POD TRI - STATED) OUTPUT STROBE (LOW ACTIVE 500 mass DURATION DELAYED 500 miles FR DATA IS LATCHED) FROM SOL TO SOL EXTERNAL DEVICE READY (HIGH = NOT READY) TO SOL BIT 2 OF INPUT PORT FA

'tri-state" output drivers, which can be "turned off" so that another device can take over the same data lines with its own tri-state drivers. The signal which turns off the Sol drivers is POE (Parallel Output Enable). This signal is high-active, so that a low level on this pin will cause the output drivers to release. It will therefore keep the output drivers on when no connection is made to that pin of J2.

The Sol provides a signal which is intended to control the output-enable signal of an external device. This is PIE, a latched bit which is initialized to a logical "high" level and which can be set be setting bit 3 of output port FA. (The remaining bits of FA control other things, so care must be taken to keep them in the proper pattern when such an output is performed.) PIE may be used as a "direction control" bit if you want to share the data lines in both directions: for example, if you need to save wire or to use the interleaving wires of a ribbon cable for grounds to provide devices. The latches in the Sol have | shielding on long runs. PIE would |

then be connected to POE of the Sol and to a similar signal on the external device which recognized a "low" level as its output-enable signal. The PID and the POD lines may now use the same eight wires.

Note that the layout of the pins on E revision Sols and above (F, etc.) is such that the PID 0 and POD 0 lines are physically adjacent. This allows easy cross-connection of these lines in parallel when using a ribbon cable. If a 25-wire ribbon cable is used, the interleaving wires are free for use as grounds, helping to reduce the problems of "glitches" which often plague high-speed parallel interfaces

The PUS (Parallel Unit Select) pin is another latched bit, bit 4 of output port FA, which is initialized to a logical "low" level. It may be used to select two different external devices to receive or transmit data. These devices may share the same PID lines if their outputs are tri-state. Together with the PIE bit, the PUS bit allows the CPU to select four external devices, providing that appropriate decoding and response circuitry is included in the external device.

Like all logic-level signals, the parallel interface signals should be kept away from high voltages such as AC and static electricity. Cables longer than 10 feet should not be used; or if they are, precautions should be taken to accommodate the "ringing" effects which will result during signal transitions. The most typical such precaution is "ter-

minating" the line with a resistor, usually about 120 ohms connected to +5 volts. The output circuits of the Sol parallel port cannot drive a load of less than 330 ohms, so additional drivers may be necessary for such terminated lines. It is also a poor practice to connect edge-sensitive inputs such as the clock or trigger input of a flip-flop to the cable directly. Use an inverter or a Schmitt trigger circuit such as the


74LS14, 8837, or 8836 (8T380). Edge effects can be impossible to see on an oscilloscope, so precautions are usually advisable when attempting to "debug" a cranky interface.

The Sol parallel interface provides many opportunities for imaginatvie and economical interfacing, we would be interested in hearing your results in applications which you consider noteworthy. Good luck!

Important Notice To 16KRA Owners

We're currently up to Revision Level J on the 16KRA memory board in our tireless quest to improve the reliability of the circuit. Most of the earlier boards work fine, and if yours isn't exhibiting any intermittent failures, you can stop reading now. We don't recommend making the modification unless you are having trouble.

However, here's the modification procedure for those of you who need it. The assembly in question is Number 203000, shown on page VI-1 of the 16KRA manual. The portion of the drawing reproduced here, Detail A, shows the modification to increase reliability. Five jumper wires have been added to the trace side of the board, all at ground potential, in order to improve ground return paths. U30 is shown as a 75365—the alternate part 3207 should *not* be used at this location. To make the changes:



- 1) Connect pin 5 of U28 to pin 9 of U29.
- 2) Connect pin 9 of U29 to pin 9 of U30.
- 3) Connect pin 9 of U30 to pin 9 of U31.
- 4) Connect pin 9 of U31 to pin 5 of U32.
- 5) Connect pin 8 of U28 to pin 1 of U32.

These changes don't require any change in the schematic shown on page VI-2, or in the Theory of Operation, Section V.

Vectored Interrupt Capability For Sol

Although the 8080A micro-processor used in the Sol provides vectored interrupt capability, neither Sol nor Processor Technology's other S100 modules require use of this capability. However, Sol does provide a means for implementing vectored interrupt if the interrupt signal is made available by a circuit board inserted in the S100 bus. This board is connected to S100 bus pin 96, SINTA. If you want this board to


generate interrupts, you'll need to add two jumpers, shown below, to the Sol P.C. These jumpers enable the SINTA signal to reach the memory decoder circuit; they can be added after assembling the Sol P.C., or even after the entire Sol has been assembled and tested.


The jumpers should be made from #24 solid insulated wire (not provided). Their electrical effects can be seen in Drawing X-16. They

can be left in place even if no S100 board generates interrupts, and S100 bus pin 96 may float with no interference.

The necessary modifications for both Revision D and Revision E level circuit boards are as follows: Modification to Revision E board, Sol-PCB:

1) Strip .1" of insulation from one end of two 8" lengths of wire. Insert the stripped ends into pads AC and





AB (near U58), from the component side of the board. Solder and check for solder bridges.

- 2) Dress the wires as shown in the accompanying diagram, trim to the correct length, and strip .1" from the loose ends. Insert the wire from pad AB into pad AD, and the wire from pad AC into pad AE. Again, solder and inspect for solder bridges.
- 3) Attach the long runs of wire to the board with silicone compound or tape.

Modification to Revision D Board. Sol-PCB:

- 1) Strip .1" insulation from each end of a 6.25" length of wire. Connect one end to pin 96 of J10 (S100 connector); the other end goes to pin 9 of U57.
- 2) Strip .1" of insulation from each end of a 4" wire. Connect pin 8 of U57 to pin 6 of U34.
- 3) Attach the long runs of wire to the board with silicone compound or tape.



SCHEMATIC FOR

REVISION D

by Drew Rogge

Oliver Audio Engineering's excellent and inexpensive OP-80A Paper Tape reader is one of the most popular peripherals in use with the Sol-20, and Sol User's Manual does contain some information about interfacing it. However, there's an error in the manual, and hardware interfacing can be a tricky chore in any case. Especially when it comes to using the Sol's 8-bit parallel output port. (See Lee Felsenstein's article on the parallel port elsewhere in this issue.) So here's what to do about the manual error, and also some other useful tidbits.

Section VII (Operating Procedures) of the Sol Users' Manual discusses the OP-80A. The error is on page 31: pin 5 of J2 (Sol PDI connector) should be labeled IAK, not IAK. Therefore, the "input Acknowledge" jumper on the paper tape reader should be connected to

ACK, not ACK.

The intensity of the light source is also an important consideration in bringing the OP-80A up. You can allow just enough brightness to operate the tape reader, yet avoid saturating the tape, if you start by placing the light source far enough above the reader so that the SP LED indicator remains off. Then lower the light source just far enough to activate the LED, and keep it there.

Pat Tuell, of the San Jose Byte Shop, has contributed a driver routine for using the OP-80A, which we've included along with this article.

OP-80/Sol Driver

1 EPT 2 - 100

by Pat Tuell

Enter the routine from keyboard or cassette; hook up the reader as specified. Execute C900, and start pulling the tape through. Intel-formatted naper tapes will

automatically be loaded into the correct memory locations and control will automatically return to SOLOS.

Have fun getting your data loaded!

already made the correction, please note that in ACCESS #4 there is a routine to load Intel-formatted tapes from a teletype connected to the serial port. Memory location 1F0A should be "3A" instead of "3B."

Intel-formatted	paper tapes	WIII	Note: In Ca	ase you haven't				
900	0010 *			C958 77	0610	MOU MA		
900	0020 • THIS	WILL LOAD	INTEL FORMAT PAPER TAPE	C95C 23	0630	DCR D		
900			EADER CONNECTED TO SOL	C95D 15		JNZ LOOF	3	
900	0040 PARALLEL E	MIN INTERP	ALE	C95E C2 58 C9	0640 0650	JMP REAL		
900	0050 °			C961 C3 64 C9	0660 •	OHF Name		
900	9060 °	A 010H	COARTID	C964 CD 07 C9	9670 READ	CALL PTIM	4 LOOK	FOR A BLOCK
900 3E 10	0070 START MVI	A, 010H	STARTUP	C967 FL 3A	0680	CPI 03A		
902 D3 FA	0080 OUT 0090 CALL			C969 C2 64 C9	0690	JNZ HEAL		
904 CD 93 C9	0090 CALL	DALL		C96C 06 0A	0700 RD1	MVI B.OC		
907	OIIO PTIN IN	OFAH	IMPUT FROM OPEO ASC.	C96E CD 19 CO	0710	CALL SOUT		
907 DB FA	0120 ANI	002H	and I have bree here	C971 06 0D	0720	MVI B. OC		
909 E6 02 908 C2 07 C9	0130 JNZ	PTIN		C973 CD 19 CO	0730	CALL SOUT		
90E 3E 00	0140 MVI	A, 000H		C976 CD 3A C9	0740	CALL CARE		
910 D3 FA	0150 OUT		TOUGLE ACK	C979 57	0750	MOV D.A		
912 3E 10	0160 MVI	A. 010H		C97A C8	0760	RZ		
914 D3 FA	0170 OUT	DFAH		C978 06 0A	0770	MVI B. OC	JAH	
916 DB FD	0180 IN	OFDH		C97D CD 19 CO	0780	CALL SOUT	,	
918 E6 7F	0190 AN1	07FH		C980 06 0D	0790	MVI M. DO		
91A C9	0200 RET			C982 CD 19 CO	0800	CALL SOUT	ī .	
918	0210 .			C985 CD 3A C9	0810	CALL CAR	J	
918 D6 30	0220 MEX 5U1	030H	CONVERT ASC TO NEX	C988 67	0820	MOV H.A		
91D FE DA	0230 CPI	HAGO		C989 CD 3A C9	0830	CALL CARE)	
91F D8	0240 RC			C98C 6F	0640	MOV L.A		
920 D6 07	0250 SUI	007H		C98D CD 23 C9	0850	CALL CHAP		
922 C9	0260 RET			C990 C3 58 C9	0860	JMP LOOF	>	
923	0270 .			C993	0870 ·			
923 CD 07 C9	0280 CHAR CALL	PTIN	ASSEMBLE BYTE	C993 CD 07 C9	DBBU DAZL	CALL PTIN		
926 CD 18 C9	0290 CALL	. HEX		C996 FE 3A	0890	CPI 03AF		
929 CD 35 C9	0300 CALL	HULL		C998 C2 9E C9	0900	JNZ WAL	f	
92C 5F	0310 MOV	E, A		C998 C3 6C C9	0910	JMP RDI		
92D CD 07 C9	0320 CALL			C99E 47	0920 WAIT	MOV B, A		
930 CD 18 C9	0330 CALL			C99F CD 19 CO	0930	CALL SOUT		
933 83	0340 ADD	F		C9A2 C3 93 C9	0940	JMP DAZI	•	
934 C9	0350 RET			C9A5	0950 •			
935	0360 •			CPAS	0960 SOUT	EQU 0001	911	
935 07	0370 ROLL RLC			CPAS	0970 *			
936 17	0380 RAL			C9A5	0980 *			
937 17	0390 RAL			C9A5	1000 •	CABLE PINOL		
936 17	0400 RAL			C9A5	1010 •	CABLE PING	, .	
939 C9	0410 RET			C9A5		SOL	OP	80
93A CD 07 C9	0420 ° 0430 CARD CALL	PTIN	AFEH HVPF DIEN AV	C9A5		D MEN E.	PIN	SIGNAL
93D F5	0430 CARD CALL		ASSM BYTE, DISPLAY	C9A5	1040 ° 6	13	1	100
93E 47	0450 MOV	B,A		C9A5	1050 • 7	12	16	IDI
93F CD 19 CO	0460 CALL			C9A5	1060 ° 8	ii	2	1 DE
942 F1	0470 POP	. 5001 006H		C9A5	1070 * 9	10	15	1 03
943 CD 1B C9	0480 CALL			C9A5	1080 *10	. 0	3	1 D4
946 CD 35 C9	9490 CALI			C9A5	1090 •11	6	14	105
949 SF	0500 MOV	E A		C9A5	1100 -15	7	4	1 D6
94A CD 07 C9	0510 CALL			C9A5	1110 *13	6	13	1 07
94D F5	0520 PUSH			CPAS	1120 *			
94E 47	0530 MOV	BA		C9A5	1130 *14	14	5	ACK-
94F CD 19 CO	0540 CALL			CPAS	1140 * 4	4	6	RDA-
952 F1	9550 POP	906H		C9A5	1150 • 2	2	8	GND
953 CD 18 C9	8560 CALL			C9A5	1160 .		9	+5V
956 83	0570 ADD	E		C9A5	1170 .			
957 C9	9580 RET			C9A5	1180 *			
958	0590 *			C9A5	1190 *			
958 CD 23 C9	0600 LOOP CALL	. CHAR	INPUT DATA	C9A5	1200 .		THE SOI	LSURVIVOR
				C9A5	1210 .			



ACCESS, and we hope that you're I readers, many of them as submis- I meatier prose in other sections.

We hope this section is going | going to write it! All of the programs to become a regular feature of | in this issue were contributed by

sions to the Applications Contest described last issue. Naturally, they're all very much in the running we're just printing them now because they seemed too good to keep to ourselves. Keep your contributions coming—if this selection is a fair sample of the quality we can expect, ACCESS to Software may prove the most popular part of the magazine.

You'll note the miniscule size of the listings. Well, the less space they take, the more we can run, and the more space we can devote to

We're thinking that most users will only have to read the programs in once, and hoping that you'll become resigned to squinting your eyes as a one-time (per program), characterbuilding experience, worth it for the rewards of acquiring the program.

Also check the reader feedback section of this issue for additional comments by the authors of

these programs.

Again, you're encouraged to submit any and all programs you have. For purposes of accuracy and the suppression of typos, we encourage you to send either a cassette or photo-reproducible printout of the listing. If you send a cassette, we'll replace it with a blank one so you don't lose on the deal. Also try to provide as much support information as you can, like your uses for the program, where it originated, etc. It's a nice way to get your name in print!

Contributions to this issue:

Hammurabi

(game, modified

for BASIC/5) . . John Dowd

PAROL (payroll

records) John Dowd

COMM (weekly

sales/payroll

computations) . John Dowd

Inverse Video in

BASIC/5

(just that!) Tom Digate

BASIC VDM

driver fix (to

work with MITS

4.0 BASIC) Warren Saunders

Thanks, fellows!

BASIC VDM Driver Fix to Work with MITS 4.0 BASIC


This useful emendation was contributed by ACCESS reader Warren Saunders of Oakton, Virginia. Add the following statements to BASIC and you'll be in the running!

0106 FOR Y=L TO L+416 0154 DATA 195,4000,5000,241,245, 230,127,254,32,210,154 0156 DATA 1001,254,7,202,6,1000, 254,13,202,47,1000 0158 DATA 254,1,202,47,1000,254, 26,202,47,1000,241 0160 DATA 201,0,0,245,229,213,197 0233 DATA 254,127,194,47,1000, 241,201

Note: BASIC VDM DRIVER with these changes remains compatible with previous versions of MITS BASIC.

PAROL and COMM

John Dowd told us he adapted this program to work with Sol BASIC/5 from a version found in Some Common BASIC Programs, a book by Lon Poole and Mary Borcher. No data is stored on cassette -only the programs. John uses them with a printer to keep records of beauty shop income (Lynne's Carrousel of Hair Fashions in Linwood, NJ), sales analysis, employee commission and payroll. Previous balances and sales totals are entered by keyboard from cash register tapes and payroll records. He says that using Sol has cut the time required for these jobs from 4 hours to 45 minutes!



Star Ship, by Brian Marsh, age 6

UT #456ULAM PAY #+8

*5

*10

*11

*10

*11

*10

*11

*10

*11

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*10

*

1 EPT 2 - 101

| PALEST | PRINT "PAYROLL PAGGAM" | 19 PRINT "PAYROLL PAGGAM" | 34 DATA 15.61-19.13.24-192.26.220.32.297.9 | 19 DATA 15.61-19.13.22.273.25.278.28.355.32.433 | 24 DATA 15.61-19.13.22.273.25.278.28.355.32.433 | 24 DATA 17.29.1 | 28 DATA 17.20.1 | 2

PRINT "OPFRATOR NUMBER"

Bep-#10W

VPUT 0

4.1.1.1.2.1.2.1.4.4.5.1.6 — Cash register totals for day.

Boulow2 ou3 ou4 ou5 o K6

4011012013014015016

" . H 1 . H 2 . H 3 : H 4 . H 5 . H E

```
"ENTRY ENAURY ( 1. YES 0.NO 9"
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         PRINT BENTAT ENJOR? ( 1.TES 0.NO )"
                                                                                                  PHINI "ENTHY ERRON? ( TOYES BOND 9"
                                                                                                                                                                                                                                                                                                                                               BENIKY ERRON? (10 YES 150 TO BE
                                                                                                                                                                                                                                   "ENTHY EAKOAP (10 YES 20 40 3"
                                                                                                                                                                                                                                                                                                                                                                                                                                                                  PRINT MENTRY S44042 (117ES MIND )"
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          PRINT MENTAY ERROR? (1.YES 3440 )"
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            C1=INT(((41-(31-44))+148)/4)/184
IF C1>=8 THEN 2988
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             C3=1N1(((33-(D3-44))+103)/4)/130
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         C2=INI(((32-(D2-43))-100)/4)/100
                                                                                                                                                                                                                                                                                           T=11+12+13+14+15+15
P-21VI T1:12:13:14:15:16+1
14PUT #4EDVESDAY TOTALS
                                                                                                                                                                                                                                                                                                                                                                                                                                PRINT MI:W2:W3:d4:d5:d6.W
INFUT MIMURSDAY TOTALS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       F=F10F24F34F44F54F8
P21V1 F1:F2:F3:F4:F5:F60F
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    PRINT $1:52:53:54:55:56.5
                                                                                                                                                                                               41:M2:43: #4:45:#6+#
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           PRINT HI:HZ:H3:M4:H5:H6.H
                                                                  IMPUT #YTO SALSHIESHIPS
IMPUT #M31347 TOTALS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         SATURDAY TOTALS
                                                                                                                                                                                                                     "TUESDAY TOTALS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                PRINT "DAYS WORKED 31=W1+T1+K1+H1+F1+S1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           46=46+16+M6+M6+F6+58,
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        34=44+14+#4+H4+F4+54
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             36=45+15+45+H5+F5+S5
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    32=42+12+42+12+F2+52
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      43=#3+13+#3+H3+F3+S3
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               4=31+42+33++4+3+46
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              GES+4 - New YTD total
                                                                                                                                                                                                                                                                                                                                                                                                        #=#1+#2+#3+#4+#5+#6
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           MRH1+H2+H3+H4+H5+H6
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    S=51+52+53+54+56
                                                INPUT "YTO SALES" . G
                                                                                                                                          IF E=1 THEN 183
N=41+M2+M3+M4+45+46
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        INPUT "DAYS WORKED
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           CPASE THEY SAAD
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              1F E=1 THEN 1988
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   IF EE1 THEN 1200
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  IF E=1 14EN 1580
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       IF E=1 THEN 90A
                                                                                                                                                                                                                                                                                                                                                                                      IF E=1 THEN 583
                                                                                                                                                                                                                                                                           IF E=1 THEY 30K
                                                                                                                                                                               PRINT XZZX
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     INPUT E
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                INPUT E
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              INPUT
                                                                                                                                                                                                                                                         INPUT E
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            INPUT
                                                                                                                                                                                                                                                                                                                                                    PHINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         INPUT
                                                                                                                         INPUT
                                                                                                                                                                                                                     1 4PUT
                                                                                                                                                                                                                                         2 2 2
                                                                                                                                                                                                   PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       3150
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     2824
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  1530
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        1960
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          18 10
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    2130
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    1600
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              1820
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        slip for each operator showing reg pay, commission, gross pay, deductions, net pay.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                This section gives payroll totals for week and computes amount to be reserved for payment of payroll
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        This section prints out a
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     taxes, state & federal.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 16=18+11: 15=15+12: 17=17+13: 18=18+14: N1=N1+N
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   TA3(5): "FEDENAL W/TF: TA3(25): T1
TA9(5): "WEd JERSEY W/TF: TAB(25): T3
TA3(6): "SUI": TA3(25): T4
                                                                                                                           | 1 = 1 1 + (F 1 (X+1) - F 1 (X-1) 1 + F 1 (X-2) / 130
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               PRINT 184(5): "AEGULA PAY": 184(25):R
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 PRINT 183(69: "COMMISSION": 183(259:C
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 TA3(5):"GROSS PAY":TA9(25):P
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  4=141((P1020F1)0(P10.85)010180T7)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 PHINT TAB(5): "NET PAY": TAB(25): N
                                                                     IF 6>F1(x+1) THEN 428
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 IMPUT MAGAIN? (1=YES 3=42) ".A.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     PRINT WIDTAL GROSS PAYWPT PRINT WIDTAL FICAMPTS PAINT WIDTAL FED MATMATS
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      "RESERVE FOR WEEK" . R
                                                                                                                                                                                   11=11+(6-F1(x+1))+F1(x)/130
                                                                                                                                                                                                                                                            13=141((P-d-W2)-2-2-5)/130
                                                                                                                                                                   1=110(6-F1(x+1))0F1(x)/108
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              PRINT WIOTAL No.Jo M/THOTP
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                PRINT "TOTAL SUI"+18
PRINT "TOTAL NET PAY"+N1
                                                IF 6<=F1(X-1) THEN 458
                                                                                                                                                                                                                         12=1N1((PoF1)+188++5)/188
                                                                                                                                                                                                                                                                                                                                                                                        PAINT "OPERATOR NUMBER".0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  PRINT MYTO FED W/TM+Y3
PMINT MYTO N.J. W/TM+Y3
PMINT MYTO SUIM+Y4
                                                                                                                                                                                                                                                                                                                                                    11=1NT((11-140) .. 5)/100
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          PRINT MYTD WET PAYMOYS
                                                                                                                                                                                                                                                                                                                                                                                                                                                       #FED W/1#+11
                                                                                                                                                                                                                                                                                                                                                                                                            denay SSC+9m Inited
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  PRINT BYTO GROSSBOY
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    PRINT BYTO FICKBOY?
                                x=2010140(5-1)-1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                MINI WHET PAY" . N
                                                                                                                                                                                                                                                                              IF 135=0 THEY 489
                                                                                                                                                                                                                                                                                                                                    14=147 (P++5)/138
                                                                                                                                                                                                                                                                                                                                                                        N=P-11-12-13-14
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     1F A=1 14EN 138
                                                                                                                                                                                                                                                                                                                                                                                                                                       PRINT OFICA # 12
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           Paint "Sain. 14
                FOR 1=2 10 7
                                                                                                               0010 460
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        Y3=Y3+T3
Y4=Y4+T4
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        V 1= V 1+ T 1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      V2= Y2+12
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            Y5=Y5+W
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               SET 0=2
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     P4141
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                           PHINE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                              17170
1=0
                376
                                                                         968
```

EPT

" . F 1 . F 2 . F 3 . F 4 . F 5 . F 6

2

102

#S1.52.53.54.55.56

".D1.D2.D3.D4.D5.D6

Each operator's weekly sales total computed

":D1:D2:D3:D4:D5:D6

CI - C6 - Operator's Commission

Overall weekly total

```
PEACENT OF INCOME
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            103
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              EPT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           2
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            -
                                                                143(04:91:144(94:32:144(174:33:144(204:94:143(304:36:143(46):36
                                                                                                                                                                                                                                                                                                                                                                                                                          "PERCENTAGE OF WEEK'S CUSTOMERS SERVED BY EACH OPERTOR."

TA3(0):L1:1A3(0):L2:1A3(17):L3:TA3(20):L4:TA3(39):L5:TA3(48):L6

"OPERTOR'S AVERAGE SALE PER CUSTOMER"

TA3(0):A1:TA3(3):A2:TA3(17):A3:TA3(28):A4:TA3(38):A5:TA3(46):16

"SHOP'S AVERAGE SALE PER CUSTOMER"
                                                                                                                                                             TA3(8):Chita9(8):C2:Ta3(17):C3:Ta3(20):Ca1Ta3(30):C5:Ta3(46):C6
= IMDIVIDUAL SALA2IES INCLUDING COMMISSION**
Ta3(4):P1:Ta3(8):P2:Ta3(17):P3:Ta3(20):P4:Ta3(30):P5:Ta3(46):P6
                                                                                                                                                                                                                                                                                                                                                                    TA9(0): 41: TA9(0): H2: TA9(17): R3: TA9(20): R4: TA9(30): R5: TA3(40): 45
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   PRINT TA3(2):V1:TA9(8):V2:TA3(17):V3:TA9(20):V4:TAB(30):V5:TA9(48):V6
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  Compute each operator's % of salary paid to sales for week.
                                                                                                                                                                                                                                                                                                TAS(38):P+: PHINT TAS(55):H:"""
"PERCENTAGE OF TOTAL SUSINESS DONE BY EACH OPERATOR"
                                                                                                                                                                                                                                                                       TOTAL PAY INCLUDING TAXES
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 9338 PRINT WYD SALESWOG
9488 PRINT WYD SALARIESWOG
9588 PRINT WYD PERCENT OF SALARIES/SALESWORG: "E"
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             % salaries/sales YTD
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              9710 PHINT "DPERATOR'S X OF SALBAY TO SALES"
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                V5=1VI(((P5+(+12+P5))/95)+180):
IF 36>8 THEN 8745
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           VI=INT(((P1+(-12-P1))/31)-188):
IF 32>0 14EN 8725
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            V3=INT(((P3+(+12+P3))/33)+188):
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   8735 V4=141((P4+(+12+P4))/94)+188)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               V2=1NT(((P2+(+120P2))/32)+188)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       V6= INT ( ( P6+ ( . 12 . PR) ) / 86 1 . 1 . 1 .
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    RB=1N1((P9/59-100)+-5)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       PAINT : PAINT : PAINT
                                                                                                                                      COMPISSIONS"
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              8715 IF 3150 THEN 8720 9716 VIR.81 3010 9721
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                IF 35>0 THEW 9740
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               1F 93># THEN 8738
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               3731 IF 64>3 THEN 8735
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  V2=81 5010 8730
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   V4=#1 6010 8736
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   V6=81 3010 975#
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   V5=#1 5010 8741
                                                                                                      149(55):4
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           PHINT 149(8): A
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  V3=#1 3010 A731
   143(55):5
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    d+6d=6d
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           SET 0=0
   PRINT
                                                                                                                                                                                                                                       PRINT
                                                                                                                                                                                                                                                                                                                                                                          BOUR PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              SEGS PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 SESS PRINT
                                                                      PAINT
                                                                                                      PRINT
                                                                                                                                   PRINT
                                                                                                                                                                   PRINT
                                                                                                                                                                                                       PRINT
                                                                                                                                                                                                                                                                       PRINT
                                                                                                                                                                                                                                                                                                          PRINT
                                                                                                                                                                                                                                                                                                                                       THING 6567
                                                                                                                                                                                                                                                                                                                                                                                                                                              PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 PHINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              PHINI
                                                                                                                                                                                                                                                                                                                                                                                                          PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               8726
8727
9738
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   9116
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 9798
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           8120
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               1216
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   9132
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   9737
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       3745
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       8750
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       9140
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       4656
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  9722
                                                                                                                                                                                                                                                                                                                                                                                                              100
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         % of customers
served by each
operator.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     143(1):m1:144(8):42:143(17):43:149(28):W4:143(38):M5:149(48):46.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  149(19:11:164(9):12:149(179:13:143(28):14:143(38):15:149(46):16:
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               [A9(19:41:144(9):42:145(179:43:145(28):44:143(38):45:143(45):46*
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      TA-3(1):H1:TAB(9):H2:TA-3(17):H3:TA-9(28):H4:TA-9(38):H5:TA-9(46): H5
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   144(1):F1:T43(8):F2:T43(17):F3:T43(28):F4:T43(38):F5:T43(46):F6
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         TA-3(14:S1:TA-4(A):S2:TA-3(174:S3:TA-3(28):S4:TA-8(39):S5:TA-3(46):S8-
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     PRINT "ENTER 2USTOWER 20UNT (1-VI)" Enter # of customers served by each IMPUT [11-[2-L3-[4-L5-L8]
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          Each operator's average 5 val. of sale per customer
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   [l=|wi((4/x)+|wi|) | L2=|wi((42/x)+|wi|) | L3=|wi((43/x)+|wi|) | L3=|wi((46/x)+|wi|) | L
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         M1=M1+[11 M2=M2+]21 43=M3+[31 M4=M4+[41 M5=M5+[51 M6=46+[6] M=4(4+4)+42+43+M4+M5+M6 --- Total customers
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        P4=P2+P3+P4+P5+P6 Total pay for week excluding operator #1-my wife
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            - % of total sales done by each operator
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        Total pay & employer taxes (approximate)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             Average 5 val. of sale per customer
                                                                                                                                                                                                                                                                                                                                                                                                                                                                       Each operator's pay for week
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     Output to expandor printer by parallel port
                                                         C4=141(((94-(04+44)+198)/4)/184
IF C4>=4 THEN 3284
                                                                                                                                                                                                                                                                CS=1M1(((36-(D6-44))-183)/4)/183
                                                                                                                                                             5=141(((45-(05-44))-100)/41/183
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  A6=B: 3010 5160
A5=1VI((36/K8)+188)/138
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             A1=141((31/K1)+100)/100
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             A2=141((32/K2)+108)/108
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 43=147((33/43)+108)/100
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 44=141((44/K4)+148)/148
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              A5=147((35/45)+100)/100
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         5338 PAINT L1:12:13:14:15:16
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             A=1 VT ((3/4) 0 133) / 10J
                                                                                                                                                                                                                                                                                                                                                                 G=C1+02+03+04+05+06
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 1F 43>3 THEN 6020
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 1F 44 > 0 THEN 5030
IF C3>=8 THEY 3103
                                                                                                                                                                                                1F C5>= A THEN 3388
                                                                                                                                                                                                                                                                                                IF 36>=8 THEN 3488
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        R1=147 ( (31/3) 0 188)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     R2=141((32/3)-183)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     H3=1V1((33/3)+144)
R4=1V1((34/9)+100)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            45=141((35/9)+180)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         R5=1NT((36/8)-188)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              1F 45>3 THEN 534F
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 IF MESS THEN 5858
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                IF K2>8 INEN 6818
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                IF 41>3 PMEN 6888
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        R=1NT((P/3)+188)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         149(55):H
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    45=81 3010 6045
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        1A3(55): M
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  144(55):N
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         144(55):F
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             A1=81 6010 8085
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       42=31 3010 6815
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 A3=8: 8010 6#25
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         144(55):1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        P=P0+( . 12.0P0)
                                                                                                                                                                                                                                                                                                                                                                                                                                       P2=52+(02+20)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    P4=24+(34+22)
                                                                                                                                                                                                                                                                                                                                                                                                    P1=C1+(01+25)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                       P3=C3+(03-28)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        P5=35+(05+22)
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  SE1 0=2
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      INIEd
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      LNIFE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        PAIN
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     PAINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      PAINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         5934
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        4594
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             6665
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             5943
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        4638
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      5231
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         5430
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      739
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             5.954
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            1733
```

Hammurabi

```
LIST

BB PRINT "TRY YOUR HAYD AT GOVERNING ANCIENT SUMERIA"

B5 'PRINT "SUCCESSFULLY FOR A 18 YEAR TERM OF OFFICE-": PRINT

B6 LET DIBBL LET PIBB

B8 LET Z-BI LED P-95; LET S=2888; LET H=3888; LET E-M-S

110 LET Z-BI LED P-95; LET S=2888; LET H=3888; LET E-M-S

1110 LET T-3; LET A-M/Y1 LET 1=5; LET O=1

212 LET DIBB

213 PRINT : PRINT: PRINT: PRINT "MANUMASI: I BEG TO REPORT TO YOU.": LET Z=Z=1

214 LET P-P-0

215 PRINT: PRINT: PRINT: PRINT "MANUMASI: I BEG TO REPORT TO YOU.": LET Z=Z=1

216 LET P-P-0

217 IF 0>8 THEN 238

228 PRINT: "A MONHIBLE PLASUE STRUCK! MALE THE PEOPLE DIED-"

128 PRINT "POPULATION IS MOM="P;

229 PRINT "POPULATION IS MOM="P;

229 PRINT "POPULATION IS MOM="P;

229 PRINT "POU NAWVESTEOP::":" BUSHELS PEN ACRE="

230 PRINT "POU NAWVESTEOP::":" BUSHELS IN STORE=": PRINT

229 PRINT "POU NAWVESTEOP::":" BUSHELS IN STORE=": PRINT

229 PRINT "POU NAWVESTEOP::":" BUSHELS IN STORE=": PRINT

229 PRINT "POU NAWVESTEOP::":" BUSHELS PEN ACRE="

230 PRINT "POU NAWVESTEOP::":" BUSHELS IN STORE=": PRINT

231 LET C=11T THEN 958

318 LET C=11T THEN 958

319 LET C=11T THEN 339

320 PRINT "HO SEAVY ACRES DO YOU SISH TO BUT?":

321 PRINT "HO SEAVY ACRES DO YOU SISH TO SELC?":

332 PRINT "HO SEAVY ACRES DO YOU SISH TO SELC?":

341 PRINT OF THEN 358

342 FORA THEN 358

343 BOSUS 718

344 PRINT "HOS MANY ACRES DO YOU SISH TO FEED YOUR PEOPLE?":

419 PRINT "HOS MANY BUSHELS DO YOU SISH TO FEED YOUR PEOPLE?":

410 PRINT "HOS MANY BUSHELS DO YOU SISH TO FEED YOUR PEOPLE?":

411 INPUT O: IF OCC THEN 858

422 IF OCC THEN 858

423 IF OCC THEN 858

424 IF OCC THEN 858

426 BOSUS 718

427 GOSUM 718

428 BOTO 418

439 LET SS-5-1 LET C=1: PRINT

439 BOSUS 718

430 LET SS-5-1 LET C=1: PRINT

430 BOSUS 718

430 LET SS-5-1 LET C=1: PRINT

431 INPUT O: IF SS-5 LET C=1: PRINT

432 BOSUS 718

433 LET SS-5-1 LET C=1: PRINT

434 LET SS-5-1 LET C=1: PRINT

435 LET SS-5-1 LET C=1: PRINT

436 LET SS-5-1 LET C=1: PRINT

437 LET SS-7-1 LET C=1: PRINT

438 LET SS-7-1 LET C=1: PRINT

449 BOSUS 718

440 PRINT SUMMENT

450 TO THE SUMENT

           #28 IF 90=5 THEN #38
#21 605UH 778
#22 6070 418
#23 6070 418
#23 6070 418
#24 6070 418
#25 6070 418
#26 6070 418
#27 6070 418
#27 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
#28 6070 418
                       ### 5010 442

518 LET SES-INT(D/2)

511 BOSUH ###

515 LET YECT LET HEDOYT LET E=#

521 SOSUH ###
               521 505U4 8JA

522 IF INT(C/24<>2/2 THEN 530

525 LET S=INT(S/C5)

538 LET S=S-2+H

531 LET LET S=S-2+H

532 LET D=INT(O+(20+0)+0-1)

544 LET D=INT(O+(20+0)+0-1)

544 LET D=INT(O+(20+0)+0-1)

545 LET D=INT(O+(20+0)+0-1)

552 LET D=INT(O+(20+0)+0-1)

553 LET D=INT(O+(20+0)+0-1)

553 LET D=INT(O+(20+0)+0-1)

554 LET D=INT(O+(20+0)+0-1)

555 LET P=C(I LET DIEDI+0)+0-10-0

556 PAINT DUE TO TOUR EXTREME MISMANAGEMENT YOU MAVE NOT ONLT*

566 PAINT DUE TO TOUR EXTREME MISMANAGEMENT YOU MAVE NOT ONLT*

566 PAINT DUE TO TOUR EXTREME MISMANAGEMENT YOU MAVE NOT ONLT*

566 PAINT DUE TO TOUR EXTREME MISMANAGEMENT YOU MAVE NOT ONLT*

566 PAINT DUE TO TOUR EXTREME MISMANAGEMENT YOU MAVE NOT ONLT*

567 PAINT DUE TO TOUR EXTREME MISMANAGEMENT YOU MAVE NOT ONLT*

568 PAINT DUE TO TOUR EXTREME MISMANAGEMENT YOU MAVE NOT ONLT*

569 PAINT DUE TO TOUR EXTREME MISMANAGEMENT YOU MAVE NOT ONLT*

560 PAINT DUE TO TOUR EXTREME MISMANAGEMENT YOU MAVE NOT ONLT*

561 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

562 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

563 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

564 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

565 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

566 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

567 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

568 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

569 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

569 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

560 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

560 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

560 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

560 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

560 PAINT DUE TO TOUR EXTREME MISMANAGEMENT TOUR MAVE NOT ONLT*

560 PAINT DUE TO TOUR DUE TOUR DU
                                  712, YETURY
728 PRINT "HANDRASIS THING ASAIN. YOU OWN ONLY":A: " ACRES. YOU THEY."
BO RETURY
                   PRINT "MANURASI: THINK ASAIN" YOU OWN ONLY":A:" ACRES" NOW THEN

BRETURN

BRETURN

BRET PRINT "HANURASI: I CANNOT DO WHAT YOU WISH."

SSO PRINT "BET YOURSELF ANDTHER FLUNKTHINE"

BRET PRINT "HE TOURSELF ANDTHER FLUNKTHINE"

BRET PRINT "IN YOUR IS YEAR IERN OF DFFICE,":PI:" PERCENT OF THE"

BRET PRINT "IN YOUR IS YEAR IERN OF DFFICE,":PI:" PERCENT OF THE"

BRET PRINT "TOU STARTED WITH IS ACRES PER PERSON AND ENDED WITH"

BRET PRINT "TOU STARTED WITH IS ACRES PER PERSON AND ENDED WITH"

BRET PRINT "TOU STARTED WITH IS ACRES PER PERSON AND ENDED WITH"

BRET FROM EACH PERSON "I PRINT

BRET FOR THE SES

BRET LET THEN SES

BRET LET THEN SES

BRET LET THEN SES

BRET FINDS THEM 948

BRET FINDS THEM 94
```

```
945 PRINT "THE PEDPLE (REMAINING) FIND YOU AN UNDLEASANT RIJLER, AND):"
958 PRINT "FRANKLY: MATE TOUR SUITS!": 3010 M93
968 PRINT "FRANKLY: MATE TOUR SUITS!": 3010 M93
965 PRINT "PREALLY HARM' IS TO A TALL-":!ITYPO-MORNHONE MOST PRINT "PREALLY HARM TO SEE YOU ASSASSINATED BUT WE ALL MAYE DUR"
975 PRINT "TRIVIAL PROBLESS."
980 EDTO 995
980 PRINT "SO LONG FOR NOW.": PRINT
989 END
...
TRY YOUR MAYD AT GOVERNING ANCIENT SUMERIA SUCCESSFULLY FOR A 18 YEAR TERM OF DEFICE.
MAMUMABE: 1 3EG TO REPORT TO YOU.
IN YEAR 1. 8 PEOPLE STARVED. 5 JAKE TO THE CITY.
POPULATION IS NOW 188 THE CITY NOW OWNS 1866 ACRES.
TOU MARYESTED 3 SUSHELS PER ACRE.
MATS ATE 200 SUSHELS.
TOU NOW MAYE 2000 BUSHELS IN STORE.
LAND IS THADING AT 21 BUSHELS PER ACRES
                                                          -
 -104 MANY ACRES DO YOU WISH TO BUY?
 408 MANY BUSHELS DO YOU WISH TO FEED TOUR PEOPLE?
 HOW MANY ACRES DO YOU WISH TO PLANT WITH SEED?
MAMURABI: 1 BEG TO REPORT TO YOU.
IN YEAR 2. 8 PEOPLE STARVED. 3 CAME TO THE CITY.
A MORRIBLE PLABUE STRUCK! MALF THE PEOPLE DIED.
POPULATION IS NOW 51 THE CITY NOW DANS 1818 ACRES.
YOU MARVESTED I BUSHELS PER ACRE.
YOU NOW MAYE 1845 BUSHELS IN STORE.
 LAND IS TRADING AT 23 SUSHELS PER AGRE-
MOW MANY ACRES DO YOU WISH TO BUY?
70
HOW MANY AGRES DO YOU WISH TO SELL?
 HOW MANY BUSHELS DO YOU WISH TO FEED YOUR PEOPLE?
 7500
 YOU MANY ACRES DO YOU WISH TO PLANT WITH SEED?
71010
MANURABI: THINK AGAIN. YOU DWN DNLY 1888 ACRES. NOW THEN. MOW MANY ACRES DO YOU WISH TO PLANT WITH SEED?
71088
BUT YOU HAVE DNLY 51 PEDPLE TO TEND THE FIELDS. NOW THEN. HOW MANY ACRES DO YOU WISH TO PLANT WITH SEED?
 7589
YOU STARVED 26 PEOPLE IN ONE YEARIII DUE TO YOUR EXTREME MISMAMABEMENT YOU HAVE NOT ONLY SEEN IMPEACHED AND IMPORM DUT OF OFFICE. BUT YOU MAYE! ALSO HEEM DECLARED 'NATIONAL FINK'!! SO LONG FOR NOW.
SOL BASICS
READY
```

averse Video in BASIC 5

```
PRINT "This concludes no demonstration of special display" PRINT "features available in BASIC5. Happy computingiti" PRINT : PRINT : PRINT : SET S=0 END
                                                                                                                                                                         =ADDRESS OF VDM DRIVER IN SOLOS
=256 TO SHIFT CHARACTER INTO B REGISTER
=27 FOR ESCAPE CHARACTER
=05 FOR ESCAPE CODE TO SEND CHAR. TO SCREEN
WITHOUT CHANGING HIGH ORDER RIT.
                                                                                                                  REM # OUTPUT INVERSE VIDEO SURROUTINE USING SOLOS VDM REM # PASS DECIMAL VALUE OF CHARACTER REM # IN VARIABLE 'C', NOTE- 'B' IS DESTROYED.
                                                                                                                                                                                                                                                   ROUTINE ABOVE USES THE FOLLOWING VARIABLES
                                                                                                                                                                                                        B=ARG(V2*V1): B=CALL(VO): R=ARG(V3*V1): B=CALL(VO)
R=ARG(C*V1): R=CALL(VO): RETURN
                                                                                                                                                                                                                                                                 * * * *
                                                                                                                                                                                                                                   REM #
                                                                                                                                                                                                                                                    REM #
                                                                                                                                                                                                                                                                  REM #
                                                                                                                                                                                                                                                                                  REM #
                                                                                                                                                                                          REM #
                                                                                          REM
                                                                                                                   65000
                                                                                                                                                65003
                                                                                                                                                               65004
                                                                                                                                                                             620059
                                                                                                                                                                                                          65010
                                                                                                                                                                                                                        65020
                                                                                                                                                                                                                                                   05039
                                                                                                                                                                                                                                                                  01059
                                                                                                                                                                                                                                                                                  65050
                                                                                                                                                                                                                                                                                              09059
                                                                                                                                                                                                                                                                                                             65070
                                                                                         86619
                                                                                                                                                                                            90059
                                                                                                                                                                                                                                     65025
                                                                                                       66649
 440
                          450
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 SET S=15
REM * FINISH UP DEMONSTRATION
REM * PY SHOWING SPECIAL CHARACTER SET
PRINT: PRINT: PRINT "The Sol also has a special set of limited"
PRINT: PRINT: PRINT "The Sol also has a special set of limited"
PRINT: PRINT: "remained characters. They are shown below in both"
PRINT "remained and inverted video. This rives a Rasic programmer"
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          PRINT "very good flexibility when designing display formats.
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      REM # PRINT SPECIAL CHARACTER SET FOR VDM IN INVERTED VIDEO FOR I=0 TO 31
                                                                                                                                                                                                                                                                                                                                                                                                                                                          PRINT "The Sol can even chante display";
SET S=10: PRINT " speeds";: SET S=75: PRINT " dynamically!"
                                                                                                REM # INITIALIZE THE MESSAGE DATA TABLE
DATA 201,236,246,229,242,244,229,228
DATA 160,214,23,228,229,242,230
RAM # INITIALIZE VAHOUT DRIVER ADDRESS APD
REM # SHITT VALESE, V2=27: V3=5
U0=49177: V1=256: V2=27: V3=5
DIM J(30)
REM # CLEAR SCREEN
O PRINT "AFF": SET S=0
PRINT "This is a demonstration of the capabilities of"
O PRINT "Sol Pasic5 output display formatting."
                                                                                                                                                                                                                                                                                                           PRINT "The Sol can brint in upper and lower case and"
PRINT "can even print ";
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     C=I+128: GOSUB 65010: C=160: GOSUB 65010
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     REM # PRINT SPECIAL CHARACTER SET FOR VDM
SOL YOF DEMONSTRATION PROGRAM FILL DEMONSTRATE HOU TO USE THE ESCHES SEQUENCES IN THE SOLOS VOY, DRIVER.
WRITTEN BY TOW DIGATE
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    : PRINT "Pretty neat, huh!"
                                                                                                                                                                                                                                                                                                                                                                                                 REM # GET CURSOR PACK AT COLUMN
                                                                                                                                                                                                                                                                                                                                                                                                                                            REM . DEMONSTRATE SPEED CONTROL
                                                                                                                                                                                                                                                                 PRINT: PRINT
FOR I=1 TO 14: READ J(I): NEXT
REM * PRINT IUVERTED HESSAGE
                                                                                                                                                                                                                                                                                                                                                       C=J(I): GOSUP 65010
                                                                                                                                                                                                                                                                                                                                                                                                                              : PRINT : PRINT
                                                                          DECEMBER, 1977
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              GOSUR 65010
                                                                                                                                                                                                                                                                                                                                                                                                                PRINT "R[ RASA"
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   FCR I=0 TO 31
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           : PRINT
                                                                                                                                                                                                                                                                                                                                       FOR I=1 TO 14
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             SET S=18
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     S=0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      SET S=0
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  C=1
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             NEXT I
                                                         REM * *
                                                                                                                                                                                                                                                                                                                                                                                                                               PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        PHINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           PRINT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 PPINT
                                                                                                                                                                                                                                                                                                                                                                                     PRINT
                                                                                                                                                                                                                                                                                                                                                                     NEXT
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  NEXT
                               REM
               RE!
                                                                                                                                              20
```



7100 Johnson Industrial Drive Pleasanton, CA 94566 Bulk Rate U. S. Postage PAID Permit No.54

Pleasanton,CA 94566

1 EPT 3 - 1

Chapter 3. Sol	
Section 1.	Exploring the Sol System 8
	At the Controls18
	Introduction to Software22
	Loading Programs from Cassette28
	At the Keyboard (Key Functions)36
	Unpacking and Installation
	TLC for Your Sol (Light Maintenance)54
Appendix 1.	Products Available from Processor Tech59
Appendix 2.	Cassette Recorder Supplement65
	ng a Cassette Recorder65
	onnect Requirements for Two Recorders66
	Internal Controls (Switch Settings)68
	Keyboard Tables72
	Sol Specifications

Sol® TerminalComputer User's Manual


Processor Technology Corporation

7100 Johnson Drive Pleasanton, CA 94566 Telephone (415) 829-2600

Copyright © 1978, by Processor Technology Corporation First Edition, First Printing, December 1978 Manual Part No. 730021 All rights reserved.

IMPORTANT NOTICE

Sol and SolPrinter are registered trademarks, and WordWizard and Helios are trademarks of Processor Technology Corporation.



The Sol Terminal Computer

1 EPT 3 - 4



TABLE OF CONTENTS

SECTION		I	PAGE
1 E	EXPLO	ORING THE Sol SYSTEM	1-1
נ	1.1	THE SCOPE OF THIS MANUAL	1-1
]	1.2	WHAT'S A COMPUTER?	1-2
		1.2.1 Clockwork 8080	1-2
	1.3	A COMPUTER WITH A BUILT-IN TERMINAL	1-3
			1-4 1-5
1	1.4	"INTER-Sol-ar" SYSTEM COMMUNICATION	1-5
		1.4.1 The Coming of the Sol S-100 Backplane	1-7
	5	MEMORIES ARE MADE OF THIS	1-7
		1.5.1 Psychoanalyzing the Sol Personality Module	1-8
		SOLOS	1-8
		7.2 The Sol's Built-in Read/Write Memory	1-9
		CORDED SOFTWARE	1-9
		'ANDING "Sol-ar" SYSTEM	1-10
		AOLS	2-1
		INTRODUCTION	2-1
2	2.2	REQUIREMENTS NEEDED FOR THE EXPEDITION	2-1
2	2.3	POWER TO THE Sol	2-2
	2.4	THE VIDEO DISPLAY	2-3
	2.5	KEYBOARD CONTROLS AND KEYBOARD RESTART	2-3

TABLE OF CONTENTS (Continued)

1 EPT 3 - 5

SECTION					PAGE
3	INTRO	DDUCTION	N TO SOFTWARE		3-1
	3.1	WHAT IS	S SOFTWARE?		3-1
	3.2	COMPUTE	ER LANGUAGE AND LANGUAGE TRANSLATORS		3-2
	3.3	SOLOS.			3-3
			Command Mode		3-4 3-4
4	LOAD	ING PROC	GRAMS FROM CASSETTE		4-1
	4.1	INTRODU	JCTION		4-1
	4.2		CASSETTE RECORDERS minary Information)		4-1
		4.2.1	Operating A Cassette Recorder Cassette Recorder Operating Tips		4-2 4-2
			Notes on Writing to Cassette Notes on Reading from Cassette		4-2 4-3
	4.3		G INTO BASIC dure for Using A Cassette Recorder)		4-3
	4.4		PROGRAMS AND SAVING THEM		4-5
			Writing a Program		4-5 4-7 4-7
	4.5	THE Sol	ALSO RISES		4-8
5	AT TH	HE KEYBO	DARD		5-1
	5.1	THE KEY	BOARD, GENERAL INFORMATION		5-1
		5.1.1	Key Functions are Programmable		5-1
		5.1.2	Operating Features and Keyboard Indicators		5-2 5-2
	5.2	CHARACT	TER KEYS		5-3
	5.3	FUNCTION KEYS			5-3
		5.3.1 5.3.2	Cursor Control Keys		5 - 4 5 - 5

1 EPT 3 - 6

TABLE OF CONTENTS (Continued)

SECTION			PAGE
	5.4 TH	HE CONTROL KEYS	5-8
		.4.1 General Information	5-8
		of Control Keys	5-8
		Control Symbols	5-9
	5.5 AF	RITHMETIC PAD KEYS	5-8
6	UNPACKI	ING AND INSTALLATION	6-1
	6.1 RE	ECEIVING INSPECTION	6-1
	6.2 IN	NSTALLATION OF S-100 MODULES	6-2
		UTTONING UP THE SOL AND NSTALLING THE FUSE	6-4
	6.4 CC	ONNECTING THE VIDEO	6-6
	6.5 TH	HE CASSETTE CONNECTION	6-6
7	TLC FOR	R YOUR Sol	7-1
	7.1 SE	ERVICE AND ORDERING PARTS	7-1
	7.2 CA	ARE AND EXTERIOR CLEANING OF YOUR Sol	7-1
	7.3 TF	ROUBLE-SHOOTING the Sol INSTALLATION	7-2
		.3.1 Checking and Installing the Fuse.3.2 Removing The Covers Prior to	7-2
		Checkout of the Interior	7-3
		Sol-PC and Personality Module	7-3 7-4
	7.4 TF	ROUBLE-SHOOTING THE VIDEO	7-4
	7.5 TH	ROUBLE-SHOOTING CASSETTE OPERATIONS	7 – 4
		.5.1 Problems Encountered When Loading5.2 Possible Faulty Tape?	7-4 7-5

TABLE OF CONTENTS	(Continued)
-------------------	-------------

1	EPT	3	-	7
_	EFI	_		

	I EFI 3 - 1	
SECTION		PAGE

APPENDICES

1	PRODUCTS	AVAILABLE	from	Processor	Technology
2	CASSETTE	RECORDER	SUPPLE	EMENT	

- 3 INTERNAL CONTROLS
- 4 KEYBOARD TABLES
- 5 Sol SPECIFICATIONS

TABLES

6-1	Sol System Component Lists	6-8
A3-1	Sol Internal Controls in Numerical Order	A3-4
A4-1	Sol Keyboard Character and Control Keys	A4-1
A4-2	Sol Keyboard Function Keys	A4-3
A4-3	Names of Graphic Characters on Keytops	A4-4
	FIGURES	
1-1	Sol-PC Simplified Block Diagram	1-6
2-1	Sol Rear Panel	2-2
5-1	Sol Keyboard	5-4
6-1	Installing An S-100 Module	6-3
6-2	Sol System Interconnections	6-5
A1-1	Sol System IV-A	A1-2

vi Sol

SECTION 1

EXPLORING THE Sol SYSTEM

1.1 THE SCOPE OF THIS MANUAL

If you have obtained your Sol still in the shipping carton(s) please read Section 6, "Unpacking and Installation" before unpacking any further and before you start using your Sol. If you find yourself so anxious to unpack your Sol that you intend to skip the introduction, you may go directly to Section 6, but please read Section 1.1, "The Scope of this Manual".

This manual is a light operating guide and reference handbook for all Sol users. Just as the Sol is a simple yet sophisticated small computer that you can use for elementary applications such as playing video games, learning programmed lessons, as a desk-top computer system to write programs, as the host computer in a somewhat more complex business system, or as a terminal in a network of computer systems, so also, this manual can serve as a novice's learning book or as the more experienced user's introduction to the full capability of the Sol Terminal Computer.

The purpose of the first four sections is to get you quickly "up and running" with your Sol Terminal Computer. The sections and the information in them are presented in a sequence of steps especially designed for the purpose. Please follow the instructions up to the end of Section 4; then we turn you loose.

The rest of this section 1 presents a thumbnail sketch of the typical small computer system, with the spotlight on the Sol Terminal Computer System.

Section 2 is a briefing on the Sol user controls and other preliminary information on the "hardware" in your Sol system. Section 3 is an introduction to software. The object of having a computer, after all, is to run programs; therefore this manual will introduce you to the software manuals you have received with this manual. They are:

SOLOS/CUTER User's Manual, Extended Cassette BASIC User's Manual (or Extended Disk BASIC User's Manual if you have a Helios).

Once you have progressed to the end of Section 4, you will have learned to load Extended Cassette BASIC from cassette and performed a few "basic" operations, including some simple programming.

After that, you can refer to the remainder of this manual for more detailed information that you may need from time to time as you gain more experience using your Sol. For example, Section 5 is all about the Sol keyboard. Section 7 contains maintenance and trouble-shooting tips for the qualified experts who are responsible for your system.

The appendices contain brief descriptions of hardware and software products to enhance your Sol. The appendices also contain additional technical information about the Sol.

If you have need for more technical information than this manual provides, for example, theory of operation and schematic drawings, you may order a more technical manual through your dealer, who uses such a manual to help keep your Sol in top condition.

You are cordially invited to participate in the future improvement of this book by sending us your comments and suggestions. A postpaid form is provided at the back of the manual.

1.2 WHAT'S A COMPUTER?

A computer is a manmade tool that extends the powers of the human mind. It does its work by manipulating vast numbers of symbols at tremendous speeds. In a digital computer like the Sol, the smallest, most basic symbol with which the computer works is called a "bit." A bit is a unit of information that answers the question, "Yes or No." In other words, a bit is either on or off. These two states are represented in mathematical notation as "l" for on, "Ø" for off. The two states of a bit are represented in the computer by two different electrical voltage levels. The computer has a myriad of minuscule electronic circuits that can alternate from one of these voltage levels to the other. By arranging these circuits into particular formations, information, also represented in bits, can be made to flow through the computer in a controlled fashion to answer questions and make statements of a mathematical and logical nature.

There are seemingly countless "logic circuits" in even a small computer, but they are always arranged in three basic functional groups, much as the cells of our brain are organized into parts of the brain. The first group functions as the control center, comparable to our thinking center. It is called the Central Processing Unit (CPU). The CPU directs the operations of the other two functional units, the memory an the input/output (I/O), which can be compared to our own memory and to the input/output functions of our senses and organs of communication. This similarity of the computer to the human nervous system is the basis for the study of cybernetics.

1.2.1 Clockwork 8080

It is in the CPU that the user's instructions to the computer are processed. The Sol's CPU is a single large scale integrated circuit named the 8080, which has become a standard in small computer systems and microprocessor-based systems. (An integrated circuit is single "chip" of semiconductor material upon which thousands of interconnected electronic circuits are fabricated by building up alternating layers of variously conducting materials in microscopic patterns.)

The 8080 microprocessor is ensconced on a large rectangular circuit board at the base of the Sol. This circuit board is called the Sol-PC. Making up the other two functional blocks of a computer,

Memory and the Input/Output (I/O), are about a hundred other integrated circuits on the Sol-PC. Memory and I/O support the control functions of the CPU.

The Sol-PC belongs to a category of computers called "Single Board Computers." The Sol-PC is available as a separate product from Processor Technology.

A crystal-controlled clock synchronizes the 8080's operations based on a rate of 2 MHz (two million cycles per second). The Sol attains an overall speed of between 100,000 and 500,000 instructions per second, depending on the type of instruction. The instruction referred to here is a machine language instruction. The "machine" is the microprocessor, whose prefix "micro" distinguishes the species "micro-computer." The 8080 microprocessor speaks a machine language made up of 8-bit words. An 8-bit word is called a "byte."

The second functional grouping of circuits within a computer is the memory. The CPU stores data in the memory prior to and after the data has been processed. Also stored in the memory are programs" which consist of lists of machine language instructions that are executed by the CPU section. In the Sol, the bulk of the memory function is performed by S-100 plug-in modules such as the 32KRA-1. The Sol's memory will be explained further in a succeeding paragraph.

The third and final functional grouping within a computer is the input/output circuits. I/O circuits coordinate the movement of data in and out of the computer. They create a circuit path between the CPU and external devices which perform other data processing or communicating. The circuits in the Sol which form a path between the CPU and a cassette recorder are part of the I/O function. (The Sol I/O interfaces will be discussed further in 1.4). With a CPU to direct the movement of data, a memory in which to store the data, and an input/output (I/O) interface to transfer data in and out of the computer, your Sol is ready to communicate with the outside world of other devices, other computers and with you, the user.

1.3 A COMPUTER WITH A BUILT-IN TERMINAL

Perhaps the most distinctive feature of a Sol is that it is a small computer with built-in "terminal." That is why the Sol is called a "Terminal Computer." A terminal is a device that enables the user to communicate with the computer. It usually consists of a keyboard and video display. The keyboard is used to enter data and commands; the video display is used to monitor the computer operations and display the data and commands being entered and received.

Technically speaking, the terminal is not part of a computer as such; rather it an input/output device and more specifically, a control console for human interaction with the computer. Other input/output devices, such as cassette recorders, collectively are called peripherals. Peripherals are equipment which aid the computer by loading, storing or displaying data, usually under the control of a computer.

An "intelligent" terminal is one that can perform some processing of the data in addition to entering and receiving it. Terminals and computers are often connected by telephone or other telecommunications lines to "time-share" or to form a "network." The Sol can be programmed to act as an intelligent terminal or as a free-standing computer. Most computers need a separate terminal for the user to communicate with it. A terminal consisting of the keyboard, video display and a standard communications interface are already built into every Sol. The Sol is its own terminal.

Despite its sophistication, the Sol is one of the easiest computers to operate. At the beginning you will be using the Sol as a "stand alone" computer, and you will use the keyboard to communicate with your Sol system as you enter and control programs and data.



1.3.1 "Play a Little Sol Music"

Like the keyboard on a piano, the keyboard is an important part of a terminal because it is the interface through which the user communicates with the computer. The Sol's more than ample keyboard compares with keyboards supplied with larger minicomputer systems. It has a 70-key main keyboard with color-coded keys that generate all 128 ASCII code characters. (ASCII is a standard code used by most computer manufacturers.) The ASCII character set includes the standard typewriter upper and lower case characters, plus a set of control characters that are activated when the CTRL (control) key is pressed at the same time as a character key. In addition to the ASCII keys, which are programmable, there are several "hard-wired" (permanent wired) special function keys. These function keys are handy for console operation of the computer, as well as for programming and word processing.

Conveniently located to the right of the main keyboard is a separate 15-key calculator pad provided so that the user does not have to stretch for the numerical keys at the top of the keyboard, when

making lengthy numeric entries. Both keyboards are designed for ease of operation and reliability. There is a built-in memory and scanning circuit that prevents simultaneous key activation and allows you to press any number of keys as fast a you can without losing a character. There are two keyboard status indicator lights to tell you whether the keyboard is set for upper case characters or shifted upper case. A third light indicates whether a Sol being used as a terminal is set for local operation or for transmission of the keyboard entries.

1.3.2 "Sol-a-vision"

The Sol Terminal Computer is self-contained insofar as all it needs to run is to be plugged in and turned on, but we humans need to see what we are entering on its keyboard what it is communicating to us. We need to monitor its operations and its communications with other devices. It needs a "display" for the video output of the Sol. The display is provided for in a separate I/O device, a "video monitor," which is a black and white TV adapted for this use or a similar but specially designed monitor.

The Sol video display generates 16 lines of text, each line 64 characters long. The display can be reversed by the user to show white characters out of black, or black on white.

1.4 "INTER-Sol-ar" SYSTEM COMMUNICATION

(Refer to Fig. 1-1, Sol-PC Simplified Block Diagram.)

"Software" is a broad term that refers to programs that are run on a computer. These programs are lists of instructions that tell the computer how the "data" are to be manipulated. Data is the information upon which the CPU operates. Data and instructions can be intermixed throughout a program; the program keeps track of whether a given bit, byte, line or block of information is to be treated as data or executed as an instruction. In a broader sense, a program is also "data" that the computer understands as a set of instructions. Programs can be stored in various ways. They can be stored outside the computer on magnetic or other media. A record of a program on a sheet of paper is called a "listing."

Programs can be executed only when they are in the computer's memory. Since memory is limited in storage capacity, programs are often stored outside memory until the time comes to load one or more of these programs into the Sol; there must be an I/O "interface" to transfer the program from its external storage medium to the memory in the Sol. Since programs and data generated in the Sol may also have to be moved out of the Sol to more permanent media, most interfaces are bidirectional. An interface, in this instance then, is circuitry that adapts one device having a specific function to another device having a different function (or at least a different design) when both the dissimilar devices have a common boundary where they must interconnect to perform an overall system function.


Thus an interface is used when the CPU is instructed to transfer its internally stored programs and data to an external device and/or

media. The Sol is splendidly equipped with three of these input-output interfaces (in addition to the built-in terminal interfaces for the keyboard and video display). These interfaces are:

The Audio Cassette Interface (ACI)
The Serial Communications Interface (Serial Port)
The Parallel Data Interface (Parallel Port)

If the data (including programs) is to be transferred in a string of bits one at a time, the data goes in or out the Serial Communication Interface. An example of serial data transfer is the Sol communicating via a modem over telephone wires or using its serial port to send data to a SolPrinter 3. The data can also be transferred eight bits at a time, when the Sol uses the Parallel Data Interface. The Sol can use this parallel I/O port to send data to a Solprinter 2. (The serial and parallel interfaces, together with the internal keyboard interface, are called "ports," as in a "seaport" where items of trade go in and out.) The serial and parallel port connectors Jl and J2 can be readily seen on the rear panel of the Sol.

The third I/O interface is the Audio Cassette Interface, which is a specialized serial interface that can load from and store to cassette tape. Two recorders can be used at the same time, one being read from, the other being written to; or the CPU can read or write alternately to two recorders. But there is still another type of interface employed by the Sol, the "bus interface"!



1.4.1 The Coming of the Sol S-100 Backplane

One of the most significant and effective characteristics of the Sol computer is a "plug-to-plug compatible" method of interfacing. Plug-to-plug compatible refers to devices having identical connectors and performance specifications so that they are direct replacements for each other. Similarly, a bus interface provides for additional memory modules, special purpose I/O modules, peripheral devices and even other small computers, all having the same connector specifications, to be plugged into a "bus." A bus is a number of parallel wires carrying control, address and data signals in common to all devices connected to the bus. The different bus devices, each plugged into a bus connector, share access to the bus, being synchronized by common control signals, much as the bus used in human transportation enables many people to arrive at their individual destinations via the same vehicle. A big advantage of a bus is that the various devices in a bus system do not need dedicated wiring to each of the other devices with which they must communicate, just as a real bus vehicle obviates the need for many individual cars to get the riders to where they are going. Bus design coupled with the large scale integration of the CPU accounts for much of the small computer's low cost.

Sometimes buses become more or less industry standards and different manufacturers can thereby produce a host of compatible devices. The most widely used bus standard in the small computer industry is the "S-100 bus." This is the bus used by the Sol and its associated peripherals. The S-100 bus is built around the 8080, certain wires being assigned to carry certain signals. It consists of 100 parallel wires; hence its name "Standard-100."

The Sol has a built-in S-100 bus that extends upward from the main circuit board. It is in the form of a "backplane" that can accept five expansion modules. This arrangement is often called a "cardcage" or "expansion chassis." Probably you ordered your Sol with additional memory modules. These come packaged separately. The memory modules are S-100 devices that you will later plug into the Sol's backplane. If you purchased a Helios II, it has interface modules that also plug into the backplane.

1.5 MEMORIES ARE MADE OF THIS

The plug-in memory modules are easily added to the Sol cardcage as needed. Computers are made with plug-in memories because different users want different amounts of memory, because they may want to increase the amount of their memory, because they might want obtain a later model of memory module; and it is convenient to test and maintain modular memory.

But even before any S-100 memory modules are added, the Sol has a limited amount of memory that is built into the Sol-PC. This memory is required for the Sol's basic functions, one of which is to manage the add-on memory. The Sol's 4,096 byte built-in memory, is permanently addressed at reserved memory locations (consecutive

addresses). This memory is divided into 2,048 bytes of Read Only Memory (ROM) and 2,048 bytes of Random Access Memory (RAM). First we shall explore the Read Only Memory.

1.5.1 Psychoanalyzing the Sol Personality Module

The Sol's 2K Read Only Memory (a "K" is 1,024 bytes) is in the form of a plug-in memory module that rides piggy-back on the main circuit board (the Sol-PC). This little module, which should already be installed in your Sol, is the Personality Module. The size of this memory module belies its importance, for without it there would be utter chaos when data begins to stream into the computer from outside devices and is "blitzed" from one circuit to another on the Sol circuit board. For, just as our own personalities program our behavior by selecting, interpreting, and organizing the vast amounts of clamoring data impinging upon our senses from the outside world, so does the Sol Personality Module control the interaction between the user and the Sol system resources: the CPU, the memory and the I/O interfaces.

When humans wake up in the morning, somehow they find themselves with the same personality, more or less, that they had when they went to bed. They don't usually "forget" their personalities. So too, Read Only Memory has a permanent program already manufactured into it. Unlike a magnetic memory and the RAM in S-100 memory modules, ROM can only be read and not over-written or erased by the computer. There is no need to change or modify the program stored in this ROM because of the nature of the program as we shall see below.

A even more important correlary quality of ROM is the fact that it is a "non-volatile" storage medium. Non-volatility means that the program stored in the ROM is not lost when the power supply is turned off. This feature is a convenience to the user who does not have to reload the program stored in the ROM each time the Sol is turned on.

SOLOS

Just what is the program that the user would want to load each time he or she turns on the Sol? What is the Sol's personality? The program that is embodied in the Personality Module is a 2,048 byte program named SOLOS. As manager of the system resources on behalf of the user, and being instantly available when the Sol is turned on, SOLOS is like an executive who is always on the job. In fact, it is called an "executive" or "monitor" program. It is the "operating system" supplied with a Sol. The job of an operating system is to make the system resources readily accessible to the user through a set of "console commands," that you can type in from the keyboard, to engineer the transfer of data among the system resources and external devices, and to act as a "master of ceremonies" during the transition of control from one program to another.

The Sol is able to change it personality modules without becoming schizoid! One module is used by a Sol in a cassette system; another by a Sol in a diskette system, and another can be fitted with a ROM programmed for the user's application. SOLOS and the three available personality modules are described in Section 3, "Introduction to Software." The SOLOS/CUTER User's Manual which comes with the Sol will familiarize you with the SOLOS commands.

1.5.2 The Sol's Built-in Read/Write Memory

Besides its ROM memory, the other section of Sol's built-in memory is read/write memory, called Random Access Memory (RAM). (This is the type of memory used in the additional S-100 memory modules.) Unlike ROM memory, RAM memory can be altered by the CPU. RAM is more versatile than ROM because many different programs can be loaded successively into the same RAM. ROM on the other hand cannot be altered by the CPU and can contain only the information placed in it when it is manufactured.

As a converse of its alterability, however, RAM is volatile. When the power supply is turned off, poof! This property of RAM is usually no disadvantage because the Sol's RAM is really a "workspace" for the CPU to manipulate the data and to store it temporarily until it is transferred to more permanent media if necessary. Most of a computer's memory is of the read/write type because the computer is always changing the contents of its memory, either by moving different blocks of data in or out or by operating on the data stored in memory.

Sol has 2K (2,048 bytes) of built-in RAM, located on the Sol-PC. lK is used by SOLOS as a scratch pad to keep track of the ever-changing notes and records necessary for SOLOS' executive duties. While the CPU is loading data from cassette, the built-in RAM is sometimes used as a storage buffer. The second lK stores the current video image ("frame" or "page") being generated by the video display circuitry.

1.6 PRERECORDED SOFTWARE

Instructions and even whole programs can be entered by hand into the Sol through the keyboard, but it is extremely convenient and efficient to have stored programs prerecorded on audio cassettes or floppy diskettes to be fed quickly into the Sol. In conjunction with a cassette recorder or disk memory system, the Sol can load and store any compatible programs and programs or data that you yourself may write or enter on the Sol. As an example, we will be loading Extended Cassette BASIC which comes with the Sol. Section 3 discusses software in general and the Sol software in particular. Some of the games and other programs that are available from Processor Technology are described in Appendix 1.


1.7 THE EXPANDING "Sol-ar" SYSTEM

The Sol together with a 16K memory module, a video monitor and a cassette recorder constitute the most fundamental Sol System (Sol System I-A). This system can be expanded by adding plug-in modules to the Sol backplane and/or replacing the memory module(s) with one of larger capacity, available from Processor Technology. The Sol has "slots" in its backplane for five plug-in S-100 modules which can be memories, I/O modules or interface modules such as the Processor Technology Helios II floppy disk controller.

You can also expand your Sol system by adding peripherals such as a second cassette recorder, a Helios II Disk Memory System or a Solprinter. Other useful S-100 devices are available from some manufacturers: if you require additional S-100 backplane connectors, there are add-on cardcages; if you want to add a little color to your "Sol-ar" spectrum, there are S-100 color graphics modules; a modem module can be used to communicate with other Sols and other computers anywhere in the world over telephone lines and satellites.

Refer to Appendix 1 for descriptions of additional equipment for your Sol System.

For further study of small computer systems and software, refer to the bibliography in the appendices of Extended Cassette BASIC User's Manual.



SECTION 2

AT THE CONTROLS

2.1 INTRODUCTION

Information in this section will help you to become familiar with the operation of your Sol Terminal Computer. You will be given brief explanations of the requirements and the operating controls. This section and the following one, Section 3, "Introduction to Software," will acquaint you with the Sol, so that you will feel at ease when, in the Section 4 section, you proceed to load Extended Cassette BASIC and experiment with a simple program.

Certain control switches are inside the Sol; however, these controls are already set for ordinary operation of the Sol. If it becomes necessaary to reset these switches, qualified service persons may refer to Appendix 3, "Internal Controls."

2.2 REQUIREMENTS NEEDED FOR THE EXPEDITION

Available Sol and Sol System configurations are listed in Table 6-1, "Sol System Component Lists." Assemble the items in the following list. You will need these items to load and run Extended Cassette BASIC as presented in Section 4:

-) A Sol Terminal Computer connected according to Section 6, "Unpacking and Installation."
- 2) A SOLOS or BOOTLOAD personality module installed in the Sol. The instructions in this section assume that your Sol is equipped with a SOLOS or BOOTLOAD personality module, one of which is supplied as a standard item with a Sol or a Sol System.
- 3) A minimum of 16K of RAM memory addressed continuously from \emptyset . 32K is recommended. (Refer to the appropriate memory module user's manual for address settings.)
- 4) Video monitor or black and white TV converted for video input. (For TV conversion instructions, see your dealer. As a substitute, a serial output device such as a teletypewriter may be connected to the Sol's Serial Communication Interface connector on the rear panel.)
- 5) A cassette recorder with motor and audio cables. (If you have not yet selected a recorder, see the appendix, "Cassette Recorder Supplement.")
 - OR: A Helios II Disk Memory System, in which case you will be loading Extended Disk BASIC.

6) A cassette prerecorded with Extended Cassette BASIC.

OR: If you have a Helios II, the PTDOS system diskette.
(The PTDOS system diskette contains Extended Disk BASIC.)

7) Manuals:

- a) Sol Terminal Computer User's Manual (this manual).
- b) The appropriate memory module user's manual.
- c) SOLOS/CUTER User's Manual.
- d) Extended Cassette BASIC User's Manual.
- e) (and, if you have a Helios:")

Helios II User's Manual
PTDOS User's Manual
Extended Disk BASIC User's Manual

2.3 POWER TO THE Sol (Refer to Fig. 2-1, Sol Rear Panel.)

On the rear panel of the Sol is a square red button that has two positions. This switch is pushed IN to turn on the Sol. (Do not turn on the Sol yet.) In the ON position, a detent holds the switch in. To turn OFF the Sol, push the button again. The detent releases the switch and it pops out to the OFF position.

When turned on, later models of the Sol will have UPPER CASE set as indicated by the red light-emitting diode (LED) in the key.

It is recommended that you turn off your Sol if you are not using it for an extended period of time. This should help extend the life of the memory modules. The Sol needs no warmup time. When the Sol is turned off, the data contained in RAM will be lost.




Fig. 2-1. Sol Rear Panel

2.4 THE VIDEO DISPLAY

- ') Turn ON the Sol.
- 2) Turn on POWER to your video monitor by touching its power switch. (The monitor has its own manual if you need to reference it.)
- 3) The SOLOS prompt character followed by the cursor (➤) should appear at the upper left corner of the screen. The greater-than sign is the SOLOS prompt character; it means "now you can type a SOLOS command." The cursor is the solid vertical rectangle which occupies the character position in the display where the next character is to be printed or the point at which the next operation is to start. Of itself, the cursor does not affect any characters in the display. A prompt character is a distinctive symbol that reminds you which program the computer is running.
- 4) Adjust the CONTRAST and BRIGHT controls on your video monitor to optimize the display of the cursor.

The SOLOS monitor program automatically takes control in its Command Mode when the Sol is turned on. This sequence is called the power-on initialization. In the Command Mode, which is the primary mode, the Sol is waiting for a command. The two operating modes of SOLOS will be discussed in Section 3, "Introduction to Software."

If the prompt does not appear, refer to Section 7, "TLC For Your ol."

Your video display, which is controlled by the Sol, is usually set by the factory to display black characters on a white background. If you prefer, a qualified person can reverse the display by using the polarity switch inside the Sol. For details refer to Appendix 3, "Internal Controls."

The lines of program instruction or text are rolled up off the top of the display to make room for a new line at the bottom. This is action is called "scrolling."

2.5 KEYBOARD CONTROLS AND KEYBOARD RESTART

(A detailed reference to the keyboard is provided in Section 5, "At the Keyboard." This section contains only the information that you will need to perform the steps in Section 4, "Loading Programs from Cassette.")

When UPPER CASE and REPEAT are pressed simultaneously, a keyboard restart is executed with the result that UPPER CASE resets to lower case letters and the Sol is reset as if it were powered-up (power-on initialization).

Use the keyboard restart to return to SOLOS from:

- A program that does not have an exit command or does not recognize its Exit command.
- 2) A program that is caught in an endless loop as indicated by its inability to respond as it is supposed to. For example, when the program "locks up" the keyboard so that there is no response to pressing any of the keys (except UPPER CASE and REPEAT).
- 3) A program that has been otherwise rendered defective by an error.



SECTION 3

INTRODUCTION TO SOFTWARE

3.1 WHAT IS SOFTWARE?

A computer serves little purpose by itself. However complex its physical components, however ingenious the design of its circuitry, a computer is useless unless there is a way for a person to tell it what to do.

Control of a computer is achieved by means of "programs" which are lists of instructions written by people in languages that both people and computers can understand. (Actually, the computer does not "understand" anything; rather, it is designed to follow instructions that are expressed in a certain way.) The programs associated with a computer constitute its SOFTWARE. The physical components of the computer constitute its HARDWARE.

Software varies in its complexity. When you type your first BASIC program on the Sol keyboard, you will have created an example of software. The software required to orchestrate and monitor a successful lunar landing is much more complicated than your BASIC program, but it is the same in kind: a person or a group of people write instructions for the computer to follow. Some programs make it possible for other programs to run. For example, your BASIC program will run because a larger program called BASIC is interpreting it for the 8080. BASIC will run because SOLOS (or PTDOS) is regulating the operation of the Sol and its peripherals. (BASIC "makes calls" to SOLOS to perform certain functions so that the functions need not be repeated in BASIC.) When you communicate with the computer, whether by typing on its keyboard or by loading information from a cassette or disk, the computer responds according to instructions that people have given it. The apparent intelligence of the computer is determined by the care that you and other people have taken in instructing it.

A set of instructions that you type on the keyboard is not very permanent: it exists only in the volatile read-write memory of the If the power fails in your building, or if you turn the computer off, the program disappears. If a program is very short, you might not mind the time it takes to type it on the keyboard every time you want to use it. Most programs, however, are much too long for such a practice to be convenient. Entering a program manually is time-consuming and likely to introduce errors. You might spend hours typing the instructions and then execute them, only to find that you have omitted or mistyped something and accidentally destroyed a part of your program. (Remember that a computer will act only on what you have actually told it, not on what you might have meant to tell it.) Recording software on a medium like cassette tape, disk, or read-only memory is a way of giving permanence to a correct version of the software; it also reduces the amount of time required to load the program into memory. A program that would take hours to type into the computer correctly can be "read" from a cassette in minutes, from

a diskette in a second. A program recorded in read-only memory need not be "read" into memory at all, because it is already there.

oftware may be classified according to its function:

The most important program associated with a computer is its OPERATING SYSTEM. The function of an operating system is to provide an interface between all other programs and the computer hardware. Processor Technology Corporation offers two operating systems for the Sol: SOLOS for cassette systems and PTDOS for diskette systems.

A program designed to solve a specific kind of problem -- for example, to keep records of inventory, perform statistical analyses, or process text -- is called an APPLICATION PROGRAM. Most of the programs that you will write, at least at first, will fall into this category.

Programs that help a programmer to develop other programs are called PROGRAM DEVELOPMENT SOFTWARE. Programs in this category include editors, assemblers, interpreters, compilers, and debuggers.

Appendix 1 contains a partial list of prerecorded programs that you can buy for your Sol.

3.2 COMPUTER LANGUAGE AND LANGUAGE TRANSLATORS

Computers are good at arithmetic. This fact has led many people to elieve that only mathematicians can "talk" to computers. Anyone who as ever "spoken" to either a computer or a mathematician will realize that, although all computers and most mathematicians are good at arithmetic, language remains the primary vehicle for communication.

Computer languages are simpler than "natural" languages for several important reasons. When people communicate with one another, the meaning of a sentence is conveyed not only by the individual words and their order, but also by the context in which those words occur. spoken language, intonation and various physical factors also contribute to context.) A person can guess at the meaning of an unfamiliar word by looking at surrounding words, sentences, and paragraphs. The meaning of an entire sentence can be dependent on context; we have all heard people accused of "taking words out of context" to confuse or mislead others. A computer is not as well equipped to handle context as a human being is. To eliminate ambiguity, a computer language must consist of a limited number of statement types and a carefully defined vocabulary. A computer language, by contrast to a "natural" language, is "context-free," i.e., a statement must have the same meaning, regardless of its context.

In order for statements in a computer language to be understood by a computer, they must be reduced to a pattern of binary codes directly intelligible to the computer hardware. ("Binary" means "in base 2.") This binary "language" is called MACHINE LANGUAGE. Programs that translate statements from other languages into MACHINE LANGUAGE are called LANGUAGE TRANSLATORS.

1 EPT 3 - 24

The language that requires the least translation for a given processor is called its ASSEMBLY LANGUAGE. An assembly language is the symbolic form of the corresponding machine language; it uses symbols to present operations and memory addresses. Because the Sol is based on an 8080 microprocessor, its assembly language is called 8080 Assembly Language. A language translator that translates programs from assembly language to machine language is called an ASSEMBLER.

Writing programs in assembly language is more difficult than writing programs in other computer languages, because the programmer must understand how the central processor is structured and how memory is addressed. It takes longer to write a program in assembly language than in a "higher level" language, but the resulting machine language program can be shorter and more efficient.

The easiest computer languages for people to learn and use are the HIGHER-LEVEL LANGUAGES. These languages, e.g., FORTRAN, BASIC, and PILOT, are closer to natural languages than is assembly language. For example, the way to say

PRINT "HELLO"

in BASIC is

PRINT "HELLO"

The structure of a higher-level language does not reflect (or reflects only dimly) the structure of a particular computer. To write a program in FORTRAN, BASIC, or PILOT, you do not have to know anything out the 8080; you DO have to know exactly what you want to accomplish and how you are going to explain it. A language translator that translates higher-level language programs to machine language is called either an INTERPRETER or a COMPILER. For an entertaining and informative discussion of interpreters and compilers, read the article entitled "Your Personal Genie" in the May/June 1977 issue of Personal Computing Magazine.

3.3 SOLOS

SOLOS was introduced in Section 1.5 as the "personality" of the Sol. This program provides the Sol user with a convenient means of accessing and managing the system resources and controlling execution of all other programs that run on the Sol.

SOLOS is available on either of two Personality Modules. (Recall that a Personality Module is a plug-in circuit board containing a read-only memory chip.) If you have a Sol System I-A or II-A, your system has the SOLOS Personality Module; if you have a Sol System III-A, III-B, IV-A, or IV-B, your system has the BOOTLOAD Personality Module.

The two versions of SOLOS are almost identical. Each has 19 commands that allow you to examine and change the contents of memory, control one or two cassette recorders, determine the source of input and destination of output, and execute other programs. Some of the mmands perform "housekeeping" functions such as setting the rate at which data are read from tape, or the rate at which characters are

displayed on the video monitor. The respects in which the versions differ are few but important. The version of SOLOS on the SOLOS Personality Module has two possible operating modes: Command Mode, in which the Sol operates as a stand-alone computer, and Terminal Mode, in which the Sol functions as a video terminal for connection to another computer. On the BOOTLOAD Personality Module SOLOS has only one operating mode, the Command Mode; the command to enter Terminal Mode is replaced by a command that loads PTDOS, the Processor Technology Disk Operating System. (For details on PTDOS, refer to PTDOS User's Manual.)

3.3.1 Command Mode

In the SOLOS Command Mode, Sol operates as a stand-alone computer under control of the program contained in the personality module. SOLOS can "hand over" control to other programs that have been loaded into the Sol, usually from cassette tape or diskette. For detailed information about the SOLOS operating system, including a complete discussion of the commands, refer to the SOLOS/CUTER User's Manual, Second Edition.

With the SOLOS Personality Module installed, the computer is in the Command Mode when power is applied to the Sol. The > that you see on the screen is a "prompt" character; it tells you that SOLOS is waiting for you to type a command.

All of the instructions in this section refer to operations in the SOLOS Command Mode. Terminal Mode is described in the Sol technical manual.

3.3.2 "Try It"

In this section you will try out a few SOLOS commands. Follow all instructions exactly. If you make a typing error while entering a command, use the DELete key to backspace and erase characters.

- Turn on the Sol and the video monitor. Look at the keyboard; if the UPPER CASE key is not illuminated, press it once. (When you type a SOLOS command, you must always use upper case letters; otherwise the command will not be "understood.")
- 2) Type the following command:

DUMP CØØØ COEO

The DUMP command displays the contents of memory on the video monitor or other output device. The "C $\emptyset\emptyset\emptyset$ " and the "C \emptyset E \emptyset " in the command are hexadecimal numbers: that is, they are numbers in base 16. In this command, the numbers identify addresses in memory. C $\emptyset\emptyset\emptyset$ is the beginning address of SOLOS.

3) Press RETURN to show that you have finished typing the command. Lines of hexadecimal data will scroll (move) rapidly up the screen. The display will stop scrolling after the contents of all locations from CØØØ to CØEØ, inclusive, have been displayed. The numbers that you see are part of the SOLOS program, in machine language form.

4) Type the following command:

ENTR C900

The ENTR command is used to enter hexadecimal data from the keyboard into the read-write memory of the Sol. The "C9 $\emptyset\emptyset$ " in the command identifies the address at which the first entry will be stored.

- 5) Press RETURN to show that you have finished typing the command. A colon (:) prompt character will appear at the start of the next line.
- 6) Type the following data, including blanks. If you make a typing error, use the DELete key to backspace. (The data represent a little program that prints the word "Hello" on the screen. You will be typing the instructions in machine language form; the original assembly language program is printed at the end of this section.)
 - 21 11 C9 7E FE $\emptyset\emptyset$ CA $\emptyset4$ CØ 47 CD 19 CØ 23 C3 $\emptyset3$ and RETURN When the colon reappears, type
 - C9 20 20 48 45 4C 4C 4F 00/ and RETURN

(The slash (/) shows that you have finished entering the data.)

The program you have just typed should now occupy addresses C900 to C918, inclusive, in the read-write memory of the Sol.

7) To verify that the program is in memory, give the DUMP command: DUMP C900 C918

Then press RETURN key. The output should look just like what you typed in step 6, except that the entries will be arranged 16 per line, and each line will begin with the address of its first entry.

8) Type the following command:


EXEC C900

The EXEC command executes (or "runs") the program that starts at address C900.

- 9) Press RETURN to show that you have finished typing the command. The word "HELLO" should appear on the screen. If it does not appear, or if something else happens, you made a typing error in step 6. Press UPPER CASE and REPEAT together, and try again.
- 10) Using your <u>SOLOS/CUTER User's Manual</u>, experiment with the other console commands until you feel at home with your Sol.

* PROGRAM TO PRINT "HELLO" FOR Sol USER'S MANUAL

ORG ØC9ØØH
LXI H,HELO
SHOW MOV A,M
CPI Ø
JZ ØCØØ4H
MOV B,A
CALL SOUT
INX H
JMP SHOW
HELO ASC HELLO'
DB Ø
SOUT EQU ØCØ19H




SECTION 4

LOADING PROGRAMS FROM CASSETTE

4.1 INTRODUCTION

In this section you will load from cassette the program Extended Cassette BASIC that is supplied with the Sol. Then, using Extended Cassette BASIC, you will enter a miniature demonstration program, as if you had just programmed it yourself, and write it back out to cassette. Finally, you will load the program back in from cassette and run it again to complete the cycle that applies to all the programs you will compose from here on.

The instructions given in this section are intended to get you started in using your Extended Cassette BASIC User's Manual, which is a handbook for the programming language BASIC when used with a Sol and a cassette recorder. (The edition referred to in this section is the first printing, January, 1978. If you have a Helios II Disk Memory System, use the Extended Disk BASIC User's Manual.



4.2 AUDIO CASSETTE RECORDERS (Preliminary Information)

Refer to your <u>SOLOS/CUTER User's Manual</u>, Appendix 1, "About Cassette Recorders and Cassette Files," for important information related to this section.

A complete procedure for reading and writing on cassette is given in Section 4.3, "Getting into BASIC." The following paragraphs in this section are preliminary notes.

4.2.1 Operating A Cassette Recorder

This section assumes that you have the standard cassette recorder supplied with the Sol System I-A, the RQ-413A. If you do not have a recorder or have a different recorder, refer to the Appendix, "Cassette Recorder Supplement."

If you plan to operate two recorders, also refer to the Appendix, "Cassette Recorder Supplement."

If you have problems loading from or storing to cassette, refer to Section 7.5, "Trouble-shooting Cassette Operations."

4.2.2 Cassette Recorder Operating Tips

For best results when using audio cassette recorders with the Sol, observe these tips:

Set the volume control to number 6 (about 2/3 full volume). Set the tone control at number 10 (maximum). The Sol has automatic gain control that compensates for a wide range of levels; but the above settings give the most reliable results. If you have a recorder different from the one supplied in a Sol System, experiment to find the optimum setting for the volume and tone controls.

CAUTION

The MICROPHONE input can be live when you are recording through the AUXILIARY input on some recorders other than the one supplied with a Sol system. De-activate the MICROPHONE input according to the manufacturer's instructions. (In some cases, you can de-activate the MICROPHONE input by plugging a termination plug into the MICROPHONE jack.)

4.2.3 Notes on Writing to Cassette

In the case of two recorders, Unit 1 and 2 must be specified in the SAVE command in order to select the desired recorder. A default selects Unit 1. Refer to your <u>SOLOS/CUTER User's Manual</u> for instructions on how to use tape commands.

To make file retrieval much easier, keep a record of where individual files are recorded. After recording the last file on a side, rewind the tape, set the tape counter to zero, and issue a CATalog command (see SOLOS/CUTER User's Manual). As each file header is displayed, make a note of the following and mark the cassette with this information:

- 1) Tape counter reading.
- 2) Exact file name.
- 3) Load address.
- 4) File length.

4.2.4 Notes on Reading from Cassette

In order to read a specific file from tape, you must start the tape at least two seconds ahead of that file. This delay allows the Sol audio cassette interface circuitry and the recorder playback electronics to stabilize after power is turned on. Because all file searches are in the forward direction, the simplest approach is to rewind the cassette(s) completely before a read operation, unless you know that the file of interest is recorded at least two seconds into the tape from where the head is currently positioned.

4.3 GETTING INTO BASIC (Procedure for Using A Cassette Recorder)

- 1) Be sure you have connected your system according to Section 6, "Unpacking And Installation," and have familiarized yourself with the information in Section 2, "At the Controls" and Section 3, "Introduction to Software."
- 2) Turn on your Sol.
- 3) Select from your system components the cassette labeled "Extended Cassette BASIC."
- 4) Insert the cassette, label up, into the recorder.
- 5) Initially, adjust the following controls on the recorder:

(If you have a recorder other than the one supplied with the Sol System I-A, try different volume settings until you find a reliable setting.)

- a) VOLUME: Set to 6 (about 2/3 full volume).
- b) TONE: Set to 10 (maximum for sensitivity to the higher frequencies).
- c) COUNTER: Reset to Zero.
- 6) Turn on POWER to your video minitor.
- 7) The SOLOS prompt character followed by the cursor (>|) should appear on the left of the screen.
- 8) When the prompt appears, set UPPER CASE by pressing the UPPER CASE key so that its indicator light comes on. Type on the Sol keyboard the command: CA and press RETURN.

This command allows the recorder motor to operate under local control. (Alternately, you can disconnect the REMOTE plug from the recorder.)

9) Press REVIEW (REWIND) on the recorder, to rewind the cassette to the starting position. All the tape should be on the left reel of the cassette. Press STOP on the recorder.

- 10) Play the tape for about 15 seconds to advance it past the leader. (This can also be done using your index finger to turn the takeup reel before inserting the tape.)
- 11) If you have disconnected the REMOTE plug, reconnect it.
- 12) On the Sol, press MODE SELECT.

This will re-initialize SOLOS and remove local control of the recorder.

13) Press PLAY on the recorder.

The tape should not move. (If it does, continue with the next step, but afterwards refer to Section 7.5, "Trouble-shooting Cassette Operations.")

14) Type in the command: XEQ BASIC

and press RETURN.

(XEQ stands for EXECUTE; "BASIC" is the name of the file on the cassette.)

The cursor should disappear and the tape should move for about 3 minutes. The display should not otherwise change. When the program has been loaded into the Sol, a copyright notice appears followed by an announcement that BASIC is sizing up the amount of memory possessed by the computer in which it has suddenly found itself.

15) Press STOP on the recorder.

Shortly BASIC will display its findings in hexadecimal and ask that you enter the beginning address of the memory you may wish to reserve from the operations of BASIC.

For now, press RETURN. This tells BASIC that it is free to use all of memory for its work space.

- 16) BASIC presents two more questions whose purpose is to reduce the size of the program to leave the maximum amount of memory for working space. It asks if you wish to delete "matrix operations" and "extended functions." You will be able to learn about these in the Extended Cassette BASIC User's Manual, but for now, answer by typing "Y" to both questions.
- 17) BASIC should now present the message: READY.

The cursor is already at the beginning of the next line. You are now "in" BASIC.

4.4 WRITING PROGRAMS AND SAVING THEM TO CASSETTE

4.4.1 Writing a Program

Let us write a little program whose purpose is to calculate the miles per gallon you get with your motor vehicle or airplane and the cost per mile. This will be an extremely simple example so, if you already know the programming language BASIC, you can skip along to Section 5, "At the Keyboard."

- Let us call the program MPG. You could do these calculations on a calculator very easily, so you will be able to follow the steps in writing this program.
- 2) In BASIC, a "statement" is an instruction and is preceded by a line number. We will number the first statement "10" and the second "20". We skip nine line numbers in between in case we want to go back and insert other instructions as an afterthought.
- 3) Because we want the program to ask the user to enter the mileage data to be used in the calculations, we will use the PRINT statement to display a message on the screen. Enter the first statement through the keyboard as follows:

(If you make a typing error, use the DEL key to backup, and retype the entry.)

10 PRINT "ENTER MILES";

This statement will cause the program to ask the user to enter the miles traveled on a tank of fuel. The semicolon tells the computer to print the user's response to statement 20 on the same line.

4) In the next statement we want the user of the program to enter the number of miles, which we shall represent by the variable "M." Variables are described in Section 2.3.2, "Variables," of the Extended Cassette BASIC User's Manual. Enter the second statement:

20 INPUT M

This causes BASIC to accept a value entered from the keyboard and to associate that value with the name "M."

- 5) We program the entry for the gallons of fuel consumed in the same manner as the miles:
 - 30 P. "ENTER GALLONS";
 - 40 IN. G

Note that we can abbreviate to save time. "P." stands for "PRINT" and "IN." stands for "INPUT." Abbreviations are explained in your Extended Cassette BASIC User's Manual, 2.2, "Definitions of Commands and Statements."

- 6) The statements for the entry of the cost of the fuel take the same form as those for miles and gallons:
 - 50 P. "ENTER COST IN PENNIES"; 60 IN. C
- 7) Now we program the answer and calculation for the miles per gallon. Enter the statement:
 - 70 P. "MILES PER GALLON=", M/G

As described in your Extended Cassette BASIC User's Manual, 2.3.3, "Expressions," "M/G" means "the value entered for M divided by the value entered for G." The comma that follows the PRINT statement signifies that the answer to the expression is to be printed out on the same line.

- 8) The final statement takes the same form as statement 70. Enter:
 - 80 P. "COST PER MILE IN CENTS", C/M 90 END

As described in the Extended Cassette BASIC User's Manual, 4.3, "Stopping or Delaying Execution," we terminate the program with the END statement.

9) To see the program you have entered and check it over before running, enter the command: LIST and press RETURN.

(Note that commands do not need line numbers since they are not part of the program.) BASIC will list your program on the screen as follows:

- 10 PRINT "ENTER MILES";
- 20 INPUT M
- 30 PRINT "ENTER GALLONS";
- 40 INPUT G
- 50 PRINT "ENTER COST IN PENNIES";
- 60 INPUT C
- 70 PRINT "MILES PER GALLON=", M/G
- 80 PRINT "COST PER MILE IN CENTS=", C/M
- 90 END
- 10) If you wish to correct an error or change a statement in your program, you may do so by simply retyping it including the line number. To insert an additional statement, number it with one of the intervening line numbers.
- 11) To see that your program runs as it should, enter the command RUN and press RETURN. (In the process of debugging a program, you can run the program starting at any instructions by including the line number of the instruction. For example, RUN 40.)

Enter data as called for by the program to make it continue along.

4.4.2 Saving a Program To Cassette

When you are satisfied with the program, try saving it to cassette as follows:

1) Enter the BASIC command: SAVE MPG, T

and press RETURN.

"MPG" is the name of the program (to become a file on cassette).

The "T" is "Text Mode" in which the program is to be saved.

The SAVE command is described in detail in your <u>Extended</u> <u>Cassette BASIC User's Manual</u>, 3.4.3, "Read or Writing on Tape."

BASIC displays the message:

Prepare Tape Unit 1 for writing to: MPG.

- 2) Load the recorder with a blank cassette. Do not use your cassette copy of Extended Cassette BASIC.
- 3) REWIND the cassette if necessary.
- 4) Play the tape for about 5 seconds to stabilize the recorder.
- 6) Depress the RECORD and PLAY buttons on the recorder.
- 7) Press any key to tell BASIC to start recording.

When the program has been recorded, BASIC returns the cursor with the message: READY.

8) Press STOP on the recorder.

11((

11.

4.4.3 Recalling a Program from Tape

(These instructions assume you are still in BASIC, although programs can be recalled from tape while in SOLOS.)

1) Type in the command: GET MPG, T

and press RETURN.

The GET command is described in your <u>Extended Cassette Basic</u>
<u>User's Manual</u> in Section 3.4.3. (GET in BASIC is not the same command as GET in SOLOS.)

BASIC displays the message:

Prepare Tape Unit 1 for Reading: MPG.

- 2) REWIND the cassette if necessary.
- 3) Press PLAY on the recorder.

- 4) Press any key to tell BASIC to start reading.
- Check the tape to see that it is moving. When the program is loaded, BASIC displays the name of the program and its beginning and ending addresses.
- 6) Press STOP on the recorder.
- 7) Run the program by entering the command: RUN and press RETURN.

To exit from BASIC, type the command B. and press RETURN.
"B." is short for BYE. This command returns control of the computer to SOLOS.

BASIC is still in memory starting at address \emptyset . To re-enter, type the command: EXEC \emptyset

4.5 THE Sol ALSO RISES

Having read the previous four sections you are now considered a Sol fledgling and are, therefore, presented with the following choices of how to proceed with this manual. If you are anxious to start writing your own programs, you can start reading your SOLOS/CUTER and Extended Cassette BASIC manuals, using this manual as a reference as the need may arise. If you are interested in obtaining pre-recorded software, or additional equipment, you might read Appendix 1 of this manual. Or if you want more in depth background on the Sol, just read on to Section 5, which is all about the Sol keyboard.

SECTION 5

AT THE KEYBOARD

5.1 THE KEYBOARD, GENERAL INFORMATION

This section is a detailed reference for using the keyboard when the SOLOS monitor program is resident in the Sol, for the display of characters and symbols associated with SOLOS, and for programming the Sol's response to the keyboard output.

The keyboard is an input device that produces ASCII encoded data. (ASCII = American Standard Code for Information Interchange.) The keyboard output is hardwired to the Sol keyboard port. Under the direction of SOLOS or another program currently in control, the ASCII code generated by the keyboard is decoded by a 6574 character generator ROM which generates a dot pattern for the video display.

The Sol Terminal Computer has an ASCII 96-character keyboard. Its key arrangement conforms to the standard typewriter format. The ASCII character set, which includes alphanumerics, punctuation marks and control codes is shown in Appendix 4, Table A4-1, "Sol Keyboard Characters Keys." There are 22 function keys (including ASCII functions and five cursor controls); these are given in Table A4-2, "Sol Keyboard Function Keys." A separate 15-key arithmetic pad is also provided.

5.1.1 Key Functions are Programmable

The exact function of most keys on the Sol keyboard is determined by the software used (for example, the program contained in the Personality Module). Except for the keys that are "hardwired," any other program can also control the response of the system to the codes produced by the keyboard. Any key that generates a code can be redefined by a program to perform a specific function. (The codes are given in the tables in Appendix 4.) However, the high order bit of the binary code (the eighth bit) of some of the function keys is set by the Sol keyboard as determined by the Sol rather than by the ASCII standard. For example, the function key RETURN generates the code 8D, whereas the control character CTRL/M generates ØD. (Control keys and the transmission of keyboard codes are explained in 5.4.)

In this section, each key function is described in terms of its role in the SOLOS Terminal Mode unless otherwise specified. SOLOS in the LOCAL Terminal Mode allows most of the symbols generated by the character generator to be seen when their corresponding keys are activated, whereas SOLOS in the Command Mode is programmed to recognize the keyboard codes according to its own purposes. Many keys, especially control keys, do not serve the same functions in Terminal Mode that they serve in SOLOS Command Mode, or in BASIC, PTDOS, ALS-8, etc. Control keys are discussed in Section 5.4.

For purposes of exposition in this section, the Sol keyboard keys are ivided into three categories:

- Character keys which are similar to typewriter keys which print characters.
- Function keys which primarily perform functions rather than print characters.
- 3) Control keys which are the character keys generating a different code when pressed with the key CTRL.

A separate subsection is devoted to each. Regardless of their type, nearly all the keys generate an ASCII code. Keys that are hard-wired (internally connected) do not generate ASCII codes. As will be seen in this section, some of the keys in one category generate the same ASCII code as some keys in another category. This overlap is especially the case with control keys and function keys.

5.1.2 Operating Features and Keyboard Indicators

The Sol keyboard features N-key rollover. That is, several keys can be pressed at the same time without loss of characters or commands; key entries are made in the order of actual key closures. (A scanning circuit prevents simultaneous key operation.)

Three keys (SHIFT LOCK, UPPER CASE and LOCAL) have indicator lights to indicate keyboard/terminal status. When any of these keys is pressed to turn an indicator light on, the light remains on after the key is released to show that the status persists. Pressing UPPER CASE and LOCAL again turns the light out to indicate the alternate status. SHIFT LOCK is turned off by pressing SHIFT. The indicators are further described under the individual key description.

5.1.3 Using Table A4-1

In Table A4-1, there are three major columns, one for the key when UNSHIFTED (lower case), one for the key UPPER CASE or SHIFTED (shifted dual character) and one labeled "CONTROL" for when CTRL is pressed simultaneously with a character key. Each of these three columns is broken down into two sub-headings. The column headed by "KEY/SYMBOL" gives the labels marked on top of the character keys, in the sequence found on the keyboard. (In the case of control keys, only the symbol "HEX CODE" gives the hexadecimal form of the displayed is given.) code generated by the keyboard when the key is pressed while being shifted, unshifted or "control." In response to the code, the Sol character generator can provide for the display circuitry, a symbol given in the columns "KEY/SYMBOL" and "SYMBOL." Except for control characters, the symbol displayed is generally the same as that on the (Some keys are programmed by SOLOS to move the cursor without displaying a symbol.)

Looking at the "W" entry in Table A4-1, and reading across the table, we see that:

- Pressing "w" unshifted generates the code 77 producing a lower case "w."
- 2) Pressing "W" shifted generates the code 57 producing an upper case "W."
- 3) Pressing CTRL (control) and "W" together, whether shifted or unshifted, generates the code 17 producing the control character graphic symbol for the ASCII "end of transmission block:" (4)

5.2 CHARACTER KEYS (Refer to Table A4-1.)

The character keys include upper and lower case alphanumerics, punctuation marks, and special graphic symbols. They are arranged for the most part as on a standard typewriter. Pressing one of these keys causes the associated character to be entered into the Sol. They can be activated in either the unshifted, shifted, or control modes. If there are two characters labeled on a key, the upper character is typed when the key is pressed simultaneously with the SHIFT key. When unshifted, the keyboard generates the lower character. (See also Section 5.3.2, "Upper Case.")

If you wish to see the character set displayed at this time, use the procedure at Section 5.4.3, "Familiarization with the Control Symbols," but press each of the alphanumeric, punctuation and symbol keys without pressing the control key. As each is pressed, the corresponding character in Table A4-1 should appear on the screen.

5.3 FUNCTION KEYS

11

(Refer to Table A4-2, "Sol Keyboard Function Keys.")

The primary purpose of the function keys is to perform special functions rather than print characters; however, many functions keys do generate standard codes which can be transmitted in Terminal Mode and can print or display their associated graphic symbol, if they are so directed by the program that controls them. (Refer to Table A4-2 to see whether a code and symbol are generated.) An example of a function key that is similar to the carriage return on a typewriter is the RETURN key. Except for DEL, the function keys are unaffected by the SHIFT key.

The function keys generally are distinguished from the character keys by their size and color. They are either black or white, whereas the character keys are grey. The function keys are also mostly larger than the character keys. (There are a few exceptions.)

The ASCII codes of some function keys overlap the codes of some control keys. Control keys are discussed in Section 5.4.




Fig. 5-1. Sol Keyboard

5.3.1 Cursor Control Keys

The cursor is the solid vertical rectangle that occupies the character position in the display where the next character is to be printed or the point at which the next operation is to start. In itself, the cursor does not affect any characters in the display. (The display of the cursor is controlled by internal switches described in the appendix "Internal Controls.")

Five keys control the movement of the cursor (excluding the space bar). They are: HOME CURSOR and the four small black keys marked with directional arrows. They are located in the lowest row of the keyboard, on either side of the space bar.

To move the cursor up, down, left or right, press the applicable cursor control key. Each time you press a key, the cursor moves one unit in the direction you indicate—one space horizontally or one line vertically. These keys may be used with REPEAT to continuously move the cursor. In the Terminal Mode, when the cursor comes to the end of a 64-character line, it moves to the extreme edge of the adjoining line, above or below depending on its direction. In the Command Mode, the cursor returns to the beginning of the same line.

Pressing HOME CURSOR moves the cursor to its home position—the first character position in the upper left corner of the screen; it does not otherwise affect the display.

None of the cursor control keys are affected by SHIFT status. None are displayed or transmitted. (Refer to Section 5.4.2, "Transmission and Display of Control Keys.")

5-4

Sol

5.3.2 Individual Descriptions of Function Keys

Keys are described here generally in the order found on the keyboard, first in a group on the left side, then in a group on the right side.

SPACE BAR

Pressing the Space Bar moves the cursor one space to the right; a character occupying a position from which the cursor moves is replaced with a space.

ESCAPE

The display of the ESCAPE symbol is masked off (not displayed) in SOLOS. (Refer to SOLOS/CUTER User's Manual.)

BREAK

Pressing BREAK forces the Serial Communication Interface (SCI) output line to a space level for as long as the key is depressed. (Some communications systems use this feature.)

TAB (See Table A4-2.)

CTRL (Control) See the special section on Control Keys, 5.4.

SHIFT LOCK and SHIFT LOCK Key/Indicator

This large grey key on the left of the keyboard works like the LOCK key on a standard typewriter. The SHIFT key is a direct internal operation (hardwired). When pressed it shifts lower case letters to upper case letters and lower dual characters to upper dual characters. The keyboard remains in upper case as long as SHIFT is held down. SHIFT is active independently of the status of UPPER CASE.

Pressing SHIFT LOCK so that the indicator light goes on, locks the SHIFT key electronically in the upper dual character position. Pressing SHIFT again returns the keyboard to lower dual character position and causes the SHIFT LOCK indicator to go out.

UPPER CASE Key/Indicator

This is a large white key on the lower left side of the keyboard. Pressing this key so that the indicator light goes on activates the upper case keyboard function so that all alphabetic characters entered from the keyboard, regardless of SHIFT key status, are produced as upper case characters. Dual character keys are not shifted. (Dual character keys, however, do respond to the SHIFT key.) With the indicator light on, the Sol keyboard essentially simulates a Teletype (TTY ASR 33) keyboard. ("Teletype" is a registered trademark of TeleType Corp. ASR= Automatic Send/Receive.)

Pressing UPPER CASE to turn the indicator light off return the 'yboard to normal SHIFT key operation.

UPPER CASE and REPEAT (See Section 2.5, "Keyboard Restart".)

LOCAL Key/Indicator

Pressing LOCAL, so that the indicator light goes on, sets the Sol for local operation in which keyboard entries are not transmitted, but they are "looped back" to the Serial Communication Interface (SCI) input for display. When set, the LOCAL key, through internal circuitry, connects the serial output to the serial input and disables serial transmission external to the Sol. That is, the Sol is not "on line." Pressing LOCAL again, so that the light turns off, ends local operation. (This corresponds to the local/line switch on a TTY.)

RETURN

RETURN is a large black key in the upper right corner of the keyboard. The function of the RETURN key is similar to that of the carriage return on a typewriter. (This is the same action as a TTY carriage return.)

In the Command Mode, RETURN is used to enter a command after it is typed; the command is thereupon executed by SOLOS. All characters on he line to the left of the cursor are interpreted as the command. After the command is executed, the cursor is returned to the left margin on the next line. If more than one command line is on the screen, one can execute any one of them as follows: position the cursor to the right of the desired command and press RETURN. (This procedure will work even if the command has already been executed, as long as the command has not scrolled off the screen.)

In Terminal Mode, when RETURN is pressed, an ASCII CR character is sent to the remote computer and the cursor is moved to the beginning of the line on which it resides.

In either mode RETURN also erases all data in the line to the right of the original cursor position.

LINE FEED

Pressing LINE FEED moves the cursor vertically downward one line. (This is the same action as a TTY line feed.) In the Command Mode, LINE FEED function exactly like RETURN, except that it does not erase any data in the line to the right of the original cursor position.

LOAD

The LOAD key character is displayed but causes no other action in Command Mode.

5-6

Sol

DEL (Delete)

The delete key is a small grey key labeled "DEL," located on the right side of the keyboard. The delete key is active when unshifted. When the cursor is positioned over a character and the delete key is pressed, the character is replaced with a space and the cursor moves one space to the left. Used in conjunction with the REPEAT key, DEL can be useful in deleting a string of characters to the left of the cursor.

The DEL key is also a dual character key; when shifted, it generates an underline. It is also a control key. Because the DEL key has aspects of both a character key and a function key it is included in both Table A4-1 and A4-2.

REPEAT

This is a medium-sized black key on the right of the keyboard. When pressed at the same time as another key, it repeats the function of the other key until either key is released. For example, when REPEAT is pressed together with the space bar, spaces will be cleared of characters as the cursor moves to the right; when used with the cursor directional keys, REPEAT moves the cursor continuously until released. With a character key, it repeats the character. The rate of repetition is approximately 15 times per second.

REPEAT is a hardwired function that does not generate a code.

When UPPER CASE and REPEAT are pressed simultaneously, a keyboard restart is executed (SOLOS is re-initialized) As a secondary result, UPPER CASE resets to lower case letters. (See 2.5, "Keyboard Restart.")

CTRL (See special section on control keys, 5.4.)

MODE SELECT

This is the large white key in the lower right corner of the main keyboard. If the MODE SELECT key is pressed, while SOLOS is in either mode, the Sol will be re-initialized to the SOLOS Command Mode and display the prompt character followed by the cursor.

HOME CURSOR (See 5.3.1, "Cursor Control Keys.")

CLEAR

In both modes, pressing CLEAR erases the entire screen and moves the cursor to its "home" position (upper left corner of the screen).

5.4 THE CONTROL KEYS

.1 General Information

CTRL is used with character keys to initiate functions or generate control characters defined in Table A4-1. A control character is an ASCII standard character whose code specifies an operation to be performed, rather than a symbol to be displayed. Usually the operation is to be performed by a peripheral such as a printer. For example, a Line Feed (\emptyset A), when transmitted to a printer, causes the printer, which recognizes the ASCII code, to move the paper platen up one line. If the resident program calls for it, the control character can cause the Sol to produce a graphic symbol representing the control character.

A control character is generated when CTRL is held down while pressing a character key (regardless of the status of UPPER CASE AND SHIFT LOCK). For example, CTRL plus J produces ASCII ØA, Line Feed.

Some control characters overlap some of the function keys. For example, the LINE FEED function key is the same as CTRL/J and CTRL/*. Certain ASCII codes are output by two different control keys; for example: Ø8, Backspace is produced by CTRL/H and CTRL/(.

5.4.2 Transmission and Display of Control Keys

control procedure causes the keyboard to generate a 7-bit code. In a Terminal Mode of SOLOS, with the LOCAL key off, this code is sent to the Serial Communications Interface (SCI) for transmission. Certain function keys which have an eighth bit set by the Sol keyboard are sent directly to the VDM for display and consequently are not transmitted.

When the Sol is in the Terminal Mode and the LOCAL key is activated, the outward bound serial data is connected back to the Serial Interface input and displayed on the video monitor as the corresponding control symbol. In the Command Mode, control characters are not displayed.

The display of control characters can be surpressed by an internal switch setting. (Refer to Appendix 3, "Internal Controls.")

In Table A4-1, the three columns under the heading "CONTROL" give the symbol that can be generated by the corresponding control sequence, the code generated by the keyboard, and the ASCII function.

If you wish to see the control characters displayed at this time, follow Table A4-1 to generate the indicated control characters. Use the following exercise, if helpful.

5-8

Sol

5.4.3 Familiarization with the Control Symbols

This optional exercise requires that a SOLOS Personality Module be stalled in the Sol, and that the control character display option be abled (a switch setting described in Appendix 3, "Internal Controls").

- 1) Turn on the Sol and monitor.
- 2) Enter Terminal Mode as follows:
 - a) Set UPPER CASE.
 - b) Type TERM and press RETURN.

"TERM" will appear on the screen as you type, and the cursor will disappear when you press the RETURN key. The Sol is in Terminal Mode.

- 3) Set for local operation by pressing the LOCAL key so that the indicator light goes on. Local operation enables the keyboard entries to be seen on the display screen. UPPER CASE may be in either state.
- 4) Test the symbol generation of the Terminal Mode by pressing each character key simultaneously with CTRL. As each is pressed, the control character symbol shown in Table A4-1 should appear on the screen.

5.5 ARITHMETIC PAD KEYS

The keys on the numeric pad and the hex codes generated by them are the same as the arithmetic keys on the main keyboard. They are repeated in the standard calculator pad arrangement for convenience in entering large amounts of numerical data.

Except for the division symbol key (\div) , pressing these keys causes the Sol to produce the symbol labeled on the key. The division symbol key enters a forward slash (/) character. UPPER CASE, SHIFT, AND CTRL do not affect these keys.

SECTION 6

UNPACKING AND INSTALLATION

Refer to this section when you need to install or move and reconnect a Sol system. This section contains instructions and procedures.

If your dealer has installed and checked out your system or if you are going to use an already installed system, you can skip this section.

6.1 RECEIVING INSPECTION

- 1) Examine the shipping container(s) for signs of possible damage to the contents during transit.
- 2) Carefully open the container and take out the components. Save the shipping materials for use in returning your Sol unit to your dealer in case he needs to ship it to the factory.
- 3) Inspect the contents for damage. If anything is damaged, please contact the carrier and your dealer immediately. Describe to them the condition of both the container and its contents so that they can take appropriate action.
- 4) Check the contents against Table 6-1, "Sol Systems Component Lists," to make sure you have received everything. Select the list for the system you ordered. If you special-ordered your Sol, you may be able to add or subtract items from the most similar list; otherwise, obtain a list from your dealer. If anything is missing, please contact your dealer at once so that he can take appropriate action. Refer to items by part number and name.
- 5) Fill out the warranty cards and mail them. Be sure to fill out each and every warranty card completely. There should be one card for each product you have received (other than software). When registered with Processor Technology, the warranty cards establish you as the owner of the product, and allow Processor Technology to send you important information.
- 6) When you have unpacked and checked your Sol system, continue reading this section.

6.2 INSTALLATION OF S-100 MODULES

(kefer to Fig. 6-1, "Installing An S-100 Module.")

WARNING

Before reading further, please the warning at Section 7.2.

BEFORE PERFORMING ANY SERVICE, DISCONNECT THE AC LINECORD OF THE Sol FROM THE REAR PANEL.

Before installing your S-100 modules, refer to the appropriate user's manual for instructions and precautions. Set the address switches on the memory modules according to the memory manual module before installing the modules.

S-100 modules(s) are installed in the expansion chassis (the cardcage for the backplane located in left rear three quarters of Sol as viewed from the front).

S-100 modules are installed in the Sol as follows:

(You may install any module in any of the five card slots, except for the Helios Controller modules; see the Helios II User's Manual.)

- red button on the rear panel should be out. Disconnect the AC linecord from the rear panel.
- 2) On the Sol rear panel, unscrew about two turns the two knurled thumbscrews that hold the top cover in place.
- 3) Remove the top cover of the Sol by lifting it carefully from the rear and unhooking it from the back edge of the keyboard cover. Set it aside.
- 4) Being careful not to mar the walnut sides, swing the Sol keyboard cover up, unhook it from the front edge of the main chassis, and set it aside.
- 5) Touch the Sol chassis to discharge any static electricity from your body.
- 6) If you are going to use the Sol as a terminal, or connect the serial port to a SolPrinter, refer to the <u>Sol Technical Manual</u> and the <u>SolPrinter User's Manual</u> or consult your dealer.
- 7) If you want to change the polarity of the display or make the cursor blink, refer to the appendix "Internal Controls."

- 8) With the component side up, insert the edge connector side of module in the card guides. (Refer to Fig. 6-1, "Installing An S-100 Module.")
- 9) Carefully slide the module in until its edge connector is fully seated in the backplane connector. (The backplane is the vertical circuit board on the front side of the expansion chassis.)






Fig. 6-1. Installing An S-100 Module

6.3 BUTTONING UP THE SOL AND INSTALLING THE FUSE

(Refer to Fig. 6-2., "Sol System Interconnections.")

1) Replace the covers on the Sol:

Hook the keyboard cover under the front edge of the main chassis and lower it over the keyboard.

Hook the top cover over the back edge of the keyboard cover and lower the top cover down into place over the rear of the chassis.

Re-install the two knurled thumbscrews fastening the rear panel.

Do not re-install the AC linecord yet.

- 2) Insert one of the two supplied 3.2A Slo-Blo fuses in the fuse cap, push the assembled cap-and-fuse into the fuse holder in the rear panel of the Sol, and turn the cap one-quarter turn clockwise.
- 3) With the AC linecord still disconnected from the 110 VAC outlet, connect the other end of the linecord to AC connector on Sol rear panel.




Fig. 6-2. Sol System Interconnections

6-5

6.4 CONNECTING THE VIDEO

Refer to Fig. 6-2, "Sol System Interconnections.")

- Position your video monitor on top of the Sol's built-in video monitor platform or in a location such that the screen will be conveniently visible from your position at the Sol keyboard.
- 2) From your Sol system components, select the coaxial video cable. This cable is about one meter long with identical male video coaxial connectors on both ends.
- 3) Insert the hollow male prong of the connector on one end of the cable into the mating video output connector on the Sol rear panel and screw on the connector securely.
- 4) In the same manner, connect the other end of the cable to the video input connector on the rear panel of the TV monitor.
- 5) There is a miniature two-position toggle switch on the rear panel of the PT-872 video monitor that is supplied with Sol systems. This toggle switch is just beneath the video cable input connector. It selects the input signal for the monitor from either the TV antenna or from the video input connector. Push the switch's lever in toward the center of the monitor. This position selects the video input.

6.5 THE CASSETTE CONNECTION

(If you have a Helios II floppy disk memory system in place of a cassette recorder, skip this and go to the Helios II User's Manual.)

(Refer to Fig. 6-2, Sol System Interconnections.)

NOTE

Refer to Section 4.2, "Audio Cassette Recorders" and the appendix "Cassette Recorder Supplement" for more detailed information on cassette recorders in a Sol system.

- 1) Place your cassette recorder on a flat accessible surface 1 to 3 feet from your Sol, and at least a foot from any equipment that contains transformers or devices that may generate magnetic fields. The Helios and the Sol do contain such devices.
- 2) Select the two audio cables from your Sol system components. (These have miniature phone plugs at both ends.)

- 3) Let the first audio cable be the "Audio IN" cable. ("IN" is with reference to the computer.) Plug one end of the Audio IN cable into Audio IN jack (J7) on Sol rear panel. Plug the other end into MONITOR or EARPHONE jack on the recorder connector panel.
- 4) Let the second audio cable be the "Audio OUT" cable. Plug one end of the Audio OUT Cable into the Audio OUT jack (J6) on the Sol's rear panel. Plug the other end into the AUX IN (AUXILIARY IN) jack on the recorder.

NOTE

The use of the MICROPHONE input is not recommended.

- (This is thinner than the audio cables, fitted with subminiature phone plugs at both ends.) Let this cable be the "Motor 1" cable. (A second "Motor 2" cable is needed if your system uses two recorders. If you are installing two recorders, refer to the appendix, "Cassette Recorder Supplement.")
- 6) Plug one end of Motor 1 cable into the Motor 1 jack (J8) on Sol rear panel.
- 7) Plug the other end into the REMOTE jack on recorder.

5.6 CONNECTING THE AC POWER

- 1) Be sure the Sol covers are in place.
- 2) Be sure that the AC power switches for the Sol, the video monitor and the recorder are OFF.
- 3) Connect their AC linecords to their rear panel receptacles.
- 4) Plug the linecords into convenient AC outlets.

Your system is now installed and ready. Return to Section 1 of this manual, or if you already read Section 1, please go to Section 2, "At the Controls."

Table 6-1. Sol System Component Lists

ORDER NO.	DESCRIPTION	QUANTITY	(√)
400410	Sol-20 Terminal Computer			
107000 727019 730024 727034 727018 723018 part of 724007 718001	SOLOS Personality Module Extended Cassette BASIC (cassette) Sol Terminal Computer User's Manual SOLOS/CUTER User's Manual Extended Cassette BASIC User's Manual Fuse, 3.2A Slo-Blo Cap, Fuse Holder Cord, AC Power, 3-Wire	1 1 1 1 2 1	•))
400500	Sol-20/16			
400410 214010 730026 730034	Sol-20 Terminal Computer (See list above) 16KRA-1 Memory Module 32KRA-1 User's Manual "16KRA-1 Product Description"	1 1 1	())
400600	Sol-20/32			
400410 214020 730026	Sol-20 Terminal Computer (See list above) 32KRA-1 Memory Module 32KRA-1 User's Manual	1 1 1	())
400700	Sol System I-A			
400500 722016 718005 or 101034	Sol-20/16 Terminal Computer (See list above) PT-872 video monitor (with manual) Video Cable Assembly	1 1 1	())
722019 718006 or	RQ-413A Cassette Recorder Audio Cable Assembly	1 2	())
101041 718007 or 101042	Motor Control Cable Assembly	1	()	,

Table 6-1. Sol System Packing Lists (continued)

C ER #	DESCRIPTION	QUANTITY	(√)
3800	Sol System II-A		
	(Same as I-A, except that the Sol model is:)		
400500	Sol-20/32 Terminal Computer (See list above)	1	()
400310	Sol System III-A		
400410	Sol-20 Terminal Computer		
107015	(See list above) BOOTLOAD Personality Module Memory module(s) containing	1	()
300000	65,536 bytes of memory Helios II, Model 2		
722016 718005 or	(See list in Helios II User's Manual PT-872 video monitor (with manual) Video Cable	1	()
101034	<pre>(alternate video cable) appropriate memory module manual(s)</pre>	1	()
730031 731029	Helios II User's Manual PTDOS User's Manual	1	()
7037	Extended Disk BASIC User's Manual (instead of Cassette BASIC)	1	()
,∠7010	Trek-80 User's Manual	1	()
	of they are much product on all terminals		
400311	Sol System III-B		
	(Same as III-A without video video monitor and cable)		
400350	Sol System IV-A		
	(Same as III-A except that Helios II is double dual drive model:)	a	
304000	Helios II, Model 4	1	()
400351	Sol System IV-B		
	(Same as IV-A without video monitor and cable)		

SECTION 7

TLC FOR YOUR Sol

7.1 SERVICE AND ORDERING PARTS

A convenient and economical way to arrange for preventative maintenance and to be prepared for eventual adjustments as well as unexpected problems, is to purchase a maintenance contract if your dealer has it available to you.

Do not replace devices thought to be defective in a Sol that is still under warranty. To do so may void the warranty. Refer the problem to your factory-authorized dealer, even if the warranty has expired.

Order replacement parts or additional equipment and manuals from your factory-authorized dealer. Be sure to include the Processor Technology order number or part number, the quantity you want to order and a complete description of the item. For example: one (1) Sol Technical Manual, PT-730038. Your dealer has a list of part numbers. He may have a stock of some replacement parts on hand.

7.2 CARE AND EXTERIOR CLEANING OF YOUR Sol

It is recommended that you turn off your Sol if you are not using it for an extended period of time. This practice should help extend the life of certain components. The Sol needs no warmup time.

When required, clean the keyboard and exterior covers of your Sol with a cloth dampened in a mild detergent solution. Be sure to turn off the power first and disconnect the AC linecord from the rear panel.

Once a year, a thin coating of linseed oil applied with a clean cloth will preserve and beautify those famous walnut side panels.

WARNING

Do not remove the cover(s) from the Sol. For your protection the Sol is designed so that the AC linecord must be disconnected before the top cover can be removed. Never reconnect the linecord when the top cover is off.

If you encounter a problem, first reread those parts of this manual which pertain to the operation you were attempting when the problem occurred. If you are still unable to solve the problem or if you have subsequent hardware or software failures, ask help from qualified technical personnel.

WARNING (Continued)

If you yourself are the qualified person finally responsible for the hardware in the system, you may use the following sections to trouble-shoot the problem. If you are still unable to solve the problem, ask your dealer for help. Service on all Processor Technology products, in or out of warranty, is the reponsiblity of the factory-authorized dealer.

The following sections are to be used only by qualified personnel as basic aid in determining whether a problem warrants calling upon the factory-authorized dealer for service.

BEFORE PERFORMING ANY SERVICE, DISCONNECT THE AC LINECORD OF THE Sol FROM THE REAR PANEL.

- 7.3 TROUBLE-SHOOTING the Sol INSTALLATION
- 7.3.1 Checking and Installing the Fuse

(See Figure 6-2, "Sol System Interconnections.")

- 1) Is the fan running? Put your hand at the fan output if you cannot hear the fan running. If the fan is not running, is the AC linecord plugged into a power receptacle? If it is plugged in, the fuse should be checked. The Sol is protected by a 3.2 amp Slo-Blo fuse housed on the rear panel. Check the fuse as follows:
 - a) Turn Sol's AC power switch OFF.
 - b) Disconnect the AC linecord from the rear panel.
 - c) Turn the fuse holder cap one quarter turn counterclockwise; pull straight out and remove the fuse from the cap.
 - d) Inspect the finer fuse element that should be connected to the end of the thicker spiral element; it looks like a small "bobby pin", and it should be in one piece connected all the way to the other end of the fuse. If it is broken in the middle, it is blown. A spare fuse is shipped with each Sol.
 - e) To install a fuse, insert the fuse into the cap, push the cap containing the fuse into the fuse holder and turn one quarter turn clockwise.

- 7.3.2 Removing The Covers Prior to Checkout of the Interior
- 1) Be sure that AC power to the Sol is turned off. The square red button on the rear panel should be out. The fan should be stopped.
 - Disconnect the AC linecord from the Sol rear panel.
- 2) On the Sol rear panel, unscrew the two knurled thumbscrews that hold the top cover in place (about two turns).
- 3) Remove the top cover of the Sol by lifting it carefully from the rear and unhooking it from the back edge of the keyboard cover. Set it aside.
- 4) Being careful not to mar the walnut sides, swing the Sol keyboard cover up, unhook it from the front edge of the main chassis, and set it aside.
- 5) Proceed to the next section.
- 7.3.3 Checkout of Cables, Connectors, Sol-PC and Personality Module
- Touch the Sol chassis to discharge any static electricity from your body.
- 2) Connectors and Cables. The mechanical contacts of connectors must be in proper position. In order to provide versatility and serviceability, a number of connectors are used in the system. Be sure that they are all inserted properly. Secure any loose cable connectors. On the Sol-PC there is a coax connector at the video display circuitry and a ribbon cable connecting the keyboard to the Sol-PC.
 - Helios Cables. If you are using a Helios Disk System, be sure that when the cover is placed on the Sol, the cables are not pulled from their sockets.
- 3) S-100 Cards. Pull the cards back from the backplane and reseat them.
- 4) Personality Module. Grasping its handle, remove and reseat the personality module located on the rear of the main printed circuit board. (Refer to Fig. 2-1, "Sol Rear Panel.")

7.3.4 Buttoning the Sol Back Up

- o replace the covers on the Sol:
- 2) Hook the keyboard cover under the front edge of the main chassis and lower it over the keyboard.
- 2) Hook the top cover over the back edge of the keyboard cover and lower the top cover down into place over the rear of the chassis.
- 3) Re-install the two knurled thumbscrews fastening the cover to the chassis.
- 4) Reconnect the AC linecord to the rear panel.

7.4 TROUBLE-SHOOTING THE VIDEO

- 1) Turn ON the AC power switches of the Sol and video monitor.
- 2) If the monitor display raster is out of sync (a black horizontal bar moves slowly down screen, numerous black lines cut across the raster, or both), adjust monitor vertical and horizontal hold controls for a stable raster.
- 3) You should see the SOLOS Command mode prompt character followed by thu cursor (★) in the upper left corner of the screen. If you don't, recheck the video cable connection as in Section 6, "Unpacking And Installation." If still no cursor, go to 7.3.2, "Removing The Covers" and 7.3.3, the checkout of cables, etc.

If control characters do not appear in the SOLOS Terminal mode, check the setting of the internal switch that controls the display of control characters. (See Appendix 3, "Internal Controls".)

7.5 TROUBLE-SHOOTING CASSETTE OPERATIONS

NOTE

The tape head must be clean in order to read or write a tape reliably.

7.5.1 Problems Encountered When Loading

1) If the tape moves while the cassette is under SOLOS control, there is a malfunction in the remote control circuitry or cabling. The recorder is under SOLOS control when MODE SELECT has been pressed to reset any tape commands. With the Sol power OFF, there should be no continuity between the MOTOR 1 jack on the Sol and the REMOTE plug on the cassette. Check to see that the Motor cable for each recorder is pushed in until you feel the stop in the jack (the detent position for the jack; this is not necessarily all of the way in).

- 2) With certain cassette recorders or cassettes there may be a misreading of the tape when the splice joining the leader to the tape passes the tape head. In this case an ERROR message will appear and the tape will stop. To resume tape loading, position the tape past the leader and retype the command used to load the program.
- 3) If you continue to have difficulty in loading, check the recorder controls for proper settings and make sure you have followed all appropriate instructions and operating tips in Section 4.2, "Audio Cassette Recorders" and 4.3, "Getting Into BASIC." Try different cassette recorder volume settings until a reliable setting is found.
- 4) Usually Processor Technology cassettes have the same program recorded more than once on the same cassette to provide against accidental damage or erasure. If you have difficulty loading a program, try the same procedure with the redundant recording.
- 5) Check all cassette interconnect cables for intermittent connections and shorts. Try substituting cables to detect defective cables.

7.5.2 Possible Faulty Tape?

- Note the exact tape counter reading at the time of the read error.
- 2) Rewind the tape and try to read the same part of the tape in which the error occurred. If there is no read error at the same point, the error was not recorded on the tape. If there is, the error was recorded on the tape.
- 3) Rewind the tape and record a file on the same part of the tape in which the read error occurred. Then read this file. If there is no read error, the original error was generated during the initial recording process. If a read error occurs at the same point, the cassette is faulty.

APPENDIX 1

PRODUCTS AVAILABLE from Processor Technology

Al.1 EQUIPMENT

MEMORY MODULES

Dynamic Read/Write Random Access Memory modules are available from Processor Technology in the following models: (The first two digits give the memory capacity in kilobytes.)

16KRA-1 32KRA-1 48KRA-1 64KRA-1

GENERAL PURPOSE MEMORY MODULE (GPM)

The GPM module is used to store any frequently-accessed programs as firmware in its 10,240 bytes of ROM. The programs thus stored can be ready to accept commands as soon as power is applied to the Sol. Included with this subsystem is 1,024 bytes of RAM for use as scratch-pad memory.

DISKETTE MEMORY SYSTEMS

The Helios II dual diskette drive systems include one or two dual drives, complete with power supply and indicator panel in a single attractive cabinet. An S-100 bus compatible controller is provided in the system. Software includes PTDOS operating system and Extended Disk BASIC. PTDOS operates up to four dual drives. PTDOS contains Extended Disk BASIC, ASSM, DEBUG, EDIT, and TREK-80, plus many other powerful software tools.

The single dual drive model can be upgraded to a double dual drive model. Both models are available in 220/240 VAC 50 Hz versions.

PRINTERS

SolPrinter 2 is a word processing printer by a Diablo (a Xerox company.) It has a changeable metal print wheel. The interface to the Sol parallel port and power supply is included.

SolPrinter 2-E is an impact printer like the SolPrinter 2 but with a plastic print wheel.

Forms tractors are available for the SolPrinter 2 and 2-E.

SolPrinter 3 is a 200 characters per second dot matrix printer with an RS-232 serial interface. This SolPrinter includes a power supply and orms tractor.

The "engineering geniuses" at Processor Technology are continually developing new products for the Sol system. Ask your dealer for the latest releases.




Fig. Al-1. Sol System IV-A

Al.2 SOFTWARE AVAILABLE FROM Processor Technology

PROGRAM DEVELOPMENT SOFTWARE ON CASSETTE

Processor Technology cassette software is designed to run either on a Sol Terminal Computer, with SOLOS, or on another 8080 computer using CUTER software and CUTS format cassette tape.

EDIT

EDIT is a line-oriented text editor that allows the creation or modification of ASCII files such as source files coded in BASIC or assembly language. EDIT allows editing on character, string, line, and page levels; at any of these levels, additions, insertions, substitutions, and deletions of text may be made. Additionally, EDIT offers the option to retain a command string as a macro and execute it repeatedly.

EDIT requires approximately 4K bytes of memory.

ASSM

ASSM is an assembler that translates a symbolic 8080 assembly language program ("source code") into the binary instructions required by the computer to execute the program.

The assembler itself occupies almost 8K bytes of memory; an additional 2K of memory is required for the symbol table. Two cassette recorders are also required.

Also included on the cassette are two other programs, PACK and UNPAC. These programs convert a cassette file from either of the two SOLOS/CUTER file formats (single-block and multiple block) to the other.

DEBUG

DEBUG is an aid for debugging a machine language program. DEBUG permits you to set as many as fifteen "breakpoints" in a program. When that program is executed under control of DEBUG, execution will be interrupted at each breakpoint address so that CPU registers, flags, and specified memory locations may be examined and modified.

DEBUG requires 8K bytes of memory.

ALS-8

ne ALS-8 assembly language development system is an operating system that facilitates the writing, editing, assembling and debugging of your own programs. It includes a resident assembler, simulator, and text editor.

The ALS-8 program requires 8K bytes of memory plus 4K for the symbol tables and system global area. ALS-8 is also available in a ROM on a GPM module (see Al.1). In that form, the system requires a minimum of 2K of RAM.

Software#1

Software #1 is a program development system, more limited than ALS-8, but requiring less memory. Included in the package are an executive to handle memory files, an assembler, and a line-oriented editor.

Software #1 requires at least 6K bytes of memory.

Extended Cassette BASIC

Extended Cassette BASIC is an adaptation of BASIC, a straightforward language combining interactive features and mathematical capabilities. BASIC includes an interactive editor and an interpreter.

xtended Cassette BASIC requires a minimum of 16K bytes of memory. The recommended amount of memory is 24K.

PILOT

PILOT is an interpretive language designed for writing interactive programs. It is suitable for writing educational applications programs, other interactive programs and games.

PILOT requires 16K bytes of memory.

8080 FOCAL

FOCAL is an adaptation of the original FOCAL, a math language written for the PDP-8 mini-computer. "FOCAL" and "PDP-8" are registered trademarks of Digital Equipment Corporation. Many thousands of FOCAL programs exist and can now run in the Sol. A disk version of FOCAL is included on the PTDOS system disk that comes with a Helios II system.

FOCAL requires 10K bytes of memory.

Al-4 Sol

VIDEO GAMES ON CASSETTE

GAMEPAC 1 and GAMEPAC 2 are two anthologies of games including:

Target - an arcade-type "shooting" game.

Hangman - the traditional word game.

QUBIC - a three-dimensional version of TIC-TAC-TOE.

("QUBIC" is a registered trademark of Parker Bros.)

Each game requires 4K bytes of memory.

TREK-80

TREK-80 is a space war game based on the NBC television series Star Trek. This program simulates a real time war with the Klingons. (You can warp through hyperspace and fire phasers, photon torpedos, or experimental rays. If you "just can't make it," you can self-destruct.)

TREK-80 requires 8K bytes of memory.

8080 CHESS

8080 CHESS is the ancient game of pure skill and fathomless variety, adapted to run on the Sol. 8080 CHESS turns your computer into a worthy opponent. A variable difficulty control matches your skill level.

8080 CHESS requires 16K bytes of memory.

FLOPPY DISK SOFTWARE

Extended Disk BASIC

Extended Disk BASIC has all the features of Extended Cassette BASIC and also the advantages of the Helios II floppy disk and PTDOS.

Many dealers offer Optional Precision BASIC, allowing the user to request a version of Extended Disk BASIC with 6, 8, 10, 12, 14, or 16 digits of precision. (Standard BASIC has 8-digit precision.)

Extended Disk BASIC requires 32K bytes of memory, and is supplied on the PTDOS system disk.

Extended Disk FORTRAN

Extended Disk FORTRAN is both a subset and a superset of ANSI standard FORTRAN, a widely used algebraic language. Extended Disk FORTRAN is written to take advantage of the Helios II Disk Memory System and PTDOS.


Extended Disk FORTRAN requires 32K bytes of memory.

WordWizard

WordWizard is an electronic typing program that turns your Sol, Helios, and SolPrinter into a powerful office or home tool for composing, correcting, editing and updating letters and other literature. WordWizard can print a file while you are editing a second file.

WordWizard requires 48K bytes of memory.

New software for the Sol is constantly being developed at Processor Technology. Ask your dealer about the latest releases.



APPENDIX 2

CASSETTE RECORDER SUPPLEMENT

A2.1 SELECTING A CASSETTE RECORDER

Not all audio cassette recorders are suitable for data storage use with the Sol. Two models tested and approved by Processor Technology for such use are the Panasonic RQ-413AS and Realistic CTR-21. (Some users report unsuccessful results with the Panasonic RQ-309 and the J. C. Penney recorder, Catalog #851-0018.) Should you wish to use a different recorder than those approved by Processor Technology, it should have the following features:

Auxiliary Input

Though the Sol can be configured for use with the microphone input, such configuration is no longer recommended.

Digital (Tape) Counter

The counter is needed to locate files on the tape.

Tone Control

The existence of a tone control is one indication of high quality electronics.

Monitor Output in Record Mode

Recorders on which the "monitor" jack is labeled MONITOR usually provide a monitor output in the Record Mode. If the jack is labeled EAR or EAR PHONE, the recorder usually does not provide a monitor output in the record mode.

To determine whether the recorder provides a monitor output in the Record mode:

- 1) Install a blank tape.
- 2) Plug a headset or earphone into the MONITOR jack.
- Plug a microphone into the MICROPHONE jack.
- 4) Set the recorder controls to record.

5) Speak into microphone while listening with the earphone. If you hear yourself through the earphone, the recorder does provide a monitor output in the record mode.

Even if a recorder has the preceding features, there is no guarantee it will work properly with the Sol. Recorders vary greatly in the quality of their electronics. When selecting a "non-approved" recorder, it is recommended that you test it before purchase, if possible, with a long file. Test it in both the record mode (Write) using the SAVE command and in the playback mode (Read) using the GET or XEQ commands. If the recorder is unsatisfactory, you will either:

- 1) Get an error message in the read mode.
- 2) Find the differences, upon playback, in what you recorded in the write mode.
- 3) Both of the above.

A2.2 INTERCONNECT REQUIREMENTS FOR TWO RECORDERS

Your Sol is capable of controlling one or two recorders. (The interconnect requirements for one recorder were previously covered in Section 4.3, "Getting into BASIC.") Since the Sol has only one audio input and one audio output jack, the interconnect requirements for two recorders are somewhat different than for one.

n the case of two recorders, Unit 1 and 2 must be specified in the DAVE command in order to select the desired recorder. A default selects Unit 1.


Reading from One Recorder and Writing to the Second Recorder

- 1) Let recorder 1 be the unit read from; connect the Sol's Audio IN cable to the recorder's MONITOR output. Connect MOTOR 1 cable to the recorder's REMOTE jack.
- 2) Let recorder 2 be the unit written to; connect the Sol's Audio OUT cable to the recorder's AUX input. Connect MOTOR 2 cable to the recorder's REMOTE JACK.

Reading and Writing to Both Recorders

For this setup, you will need two "Y" adapters, one to feed the single Sol audio output to the AUXILIARY input of two recorders and the other to feed the MONITOR output of two recorders to the single Sol audio input. (If you intend to use the Audio In and Out cables described in Section 6.5, "The Cassette Connection," miniature phone jack-to-two miniature phone plug adapters are required.)

Because the recorder outputs should not be connected together directly, it is recommended that you wire a 1000 ohm resistor in series between the MONITOR adapter and the MONITOR output of each recorder.



(A) Miniature Phone Plug
(B) Subminiature Phone Plug
Rl = R2 = 1000 ohms, ¼ watt

Figure Connecting Sol to two cassette recorders.

APPENDIX 3

INTERNAL CONTROLS

A3.1 GENERAL INFORMATION

(First Read the Warning" at 7.2.)

Your Sol will work normally without having to reset the control switches described in this section. They have been set at the factory. If you need to change the functions controlled by these switches, the switches must be accessed when the top cover and keyboard cover of the Sol are removed. They are located on the Sol-PC in DIP switch pack Sl. In this section, the switch controls are described separately by function. They are summarized with their recommended settings in Table A3-1, "Sol Internal Controls in Numerical Order." Internal switch settings for the terminal mode and other internal controls are treated in the Sol Technical Manual.

Refer to Fig. A3-1, "Sol Internal Controls in Numerical Order," for the location of Sl.

WARNING

BEFORE PERFORMING ANY SERVICE, DISCONNECT THE AC LINECORD OF THE Sol FROM THE REAR PANEL.

A3.2 REMOVING THE Sol COVERS

(1

To access Sl, remove the Sol top cover and keyboard cover as instructed in Section 7.3, "Trouble-shooting the Sol Installation."

A3.3 VIDEO DISPLAY SWITCHES

CAUTION

Since each switch lever is extremely small, it may not be practical to use one's finger to set them. As a convenience, you might use the pointed end of a nonconductive tool shaped like a pencil. Do not use a metal object.

Video Display (POLARITY) Switch, S1-4

If you want a normal video display (white characters on a black background), set Sl-4 switch to ON. If the switch is in the OFF position, black characters will be displayed on a white background (reverse video display).

Cursor Display (S1-5 and S1-6)

The cursor that appears in SOLOS as the prompt character is usually a solid, non-blinking cursor.

CAUTION

Never put S1-5 and S1-6 ON at the same time. To do so may damage your Sol.

To make it blink on and off at the rate of approximately twice per second:

- 1) Set the SOLID Switch (S1-6) to OFF.
- 2) Set the BLINK Switch (S1-5) to ON.
- 3) To reset the cursor to a solid display, reverse the above settings.

With both S1-5 and S1-6 in their OFF positions, there will be no cursor display.

Blanking Out the Display of Control Characters (S1-3)

Blank out the display of control characters by setting the BLANK Switch (S1-3) to ON. Any control characters generated should not appear on the screen. To display control characters, set S1-3 to OFF. (Control characters are explained in Section 5, "At the Keyboard.")

A3.4 RESTART (RST) SWITCH, S1-1

This switch permits you to restart your Sol without turning the power off. You should normally leave it in its OFF, or run, position. Set it to ON and then OFF to reset the 8080 and restart the Personality Module program. (A manual restart with this switch performs the same function as turning the power on or pressing a keyboard generated restart: UPPER CASE key with REPEAT key. See "Keyboard Restart" in Section 2.5.)

A3.5 REPLACING THE Sol COVERS

(Refer to 7.3.4, "Buttoning the Sol Back Up.")

A3.6 TERMINAL MODE SWITCH SETTINGS

Instructions for setting the Terminal mode switches are in the <u>Sol</u> <u>Technical Manual</u>. Consult your dealer if you intend to use the <u>Terminal mode</u>.

A3.7 PARALLEL DATA INTERFACE (PDI)

Instruction for connecting devices to the Sol's PDI are in the Sol Technical Manual. Consult your dealer for help.




Fig. A3-1. Sol-PC Internal Control Switches (S1)

Table A3-1. Sol Internal Controls in Numerical Order

CONTROL	FUNCTION	FACTORY PRESET
RST (Restart) S1-1	Permits manual restart of Sol without turning power off. (Useful for test purposes.)	OFF
S1-2	Spare	OFF
BLANK CTRL S1-3	Determines whether control characters are displayed or not.	OFF
POLARITY S1-4	Selects normal (white characters on black background) or reverse video display.	OFF
CURSOR BLINK S1-5	Selects blinking cursor.	OFF
SOLID CURSOR S1-6	Selects solid cursor.	ON

1 EPT 3 - 72 APPENDIX 4

KEYBOARD TABLES

Table A4-1. Sol Keyboard Character and Control Keys (The keys in this table are arranged as found on the keyboard, left to right, top to bottom.)

UNSHIFTED		SHIF	red	CONT	ROL	
KEY/ SYMBOL	HEX. CODE	KEY/ SYMBOL	HEX. CODE	SYMBOL	HEX. CODE	ASCII CONTROL FUNCTION
1	31	!	21	Γ¹	Øl	Start of Heading (SOH)
2	32	**	22	1	Ø2	Start of Text (STX)
3	33	#	23		øз	End of Text (ETX)
4	34	\$	24	4	Ø4	End of Transmission (EOT)
5	35	8	25		ø5	Enquiry (ENQ)
6	36	&	26	\checkmark	ø6	Acknowledge (ACK)
7	37	•	27	Я	ø7	Bell (BEL)
3	38	(28	4	Ø 3	Backspace (BS)
2	39)	29	\rightarrow	ØЭ	Horizontal Tab (HT) 2
Ø	30	Ø 3	20 ²	□"	ØØ	Null (NUL)
-	2D	=	3D	← ⁴	ØD	Return (CR) ²
^	5E	~	7E		lE	Record Separator (RS)
[5B	{	7B	Θ^4	lB	Escape (ESC) ²
	5C		7C	Ð	lC	File Separator (FS)
]	5D	}	7D ⁵	5	lD	Group Separator (GS)
q	71	Q	51	0	11	Device Control 1 (DC1)(X-ON)
W	77	W	57	4	17	End of Transmission Block (ETB)
е	65	E	45		ø5	Enquiry (ENQ)
r	72	, R	52	0	12	Device Control 2 (DC2) (TAPE)
t	74	T	54	0	14	Device Control 4 (DC4)
У	79	Y	59	+	19	End of Medium (EM)
u	75	U	55	*	15	Negative Acknowledge (NAK)

¹SOLOS cursor left. (Symbols shown are displayed by the 6574 character generator.)

²Same as function keys (see Table A4-2).

 $^{^3}$ Space function (SP); \emptyset is not displayed.

[&]quot;Not displayed in SOLOS.

⁵Alternate mode.

Table A4-1. Sol Keyboard Character and Control Keys (Continued)

UNSHIFTED		SHIFTED		CONT	ROL	
SYMBOL	HEX. CODE	KEY/ SYMBOL	HEX. CODE	SYMBOL	HEX. CODE	ASCII CONTROL FUNCTION
i	69	I	49)	ø១	Horizontal Tab (HT) 1
0	6F	0	4F	0	ØF	Shift In (SI)
p	70	P	50	B	lø	Data Link Escape (DLE)
@	40		60	D ²	øø	Null (NUL)
a	61	A	41	L ₃	Øl	Start of Heading (SOH)
s	73	S	53	0	13	Device Control 3 (DC3) (X-OFF)
đ	64	D	44	4	ø4	End of Transmission (EOT)
f	66	F	46	\checkmark	øб	Acknowledge (ACK)
g	67	G	47	£	ø7	Bell (BEL)
h	68	H	48	4	ø8	Backspace (BS)
j	6A	J	4A	≡ 2	ØA	Line Feed (LF) 1
k	6B	K	4 B	+	Ø₿	Vertical Tab (VT)
1	6C	L	4C	#	ØC	Form Feed (FF)
· ;	3B	+	2B	+	ØB	Vertical Tab (VT)
	3A	*	2A	≡ 2	ØA	Line Feed (LF) 1
DEL 4	7 F	2	5F		lF	Unit Separator (US)
Z	7A	Z	5A	۶	· lA	Substitute (SUB)
×	78	X	58	X	18	Cancel (CAN)
С	63	С	43	١	øз	End of Text (ETX)
v	76	V	56	Л	16	Synchronous Idle (SYN)
b	62	В	42	1	Ø2	Start of Text (STX)
n	6E	N	4E	8	ØE	Shift Out (SO)
m	6D	M	4D	← ²	ØD	Return (CR) ¹
1	2C	<	3C	*	ØC	Form Feed (FF)
	2E	>	3E	€	ØE	Shift Out (SO)
/	2F	?	3F	Θ	ØF	Shift In (SI)

¹Same as function keys (see Table A4-2).

²Not displayed (masked off) in SOLOS.

³SOLOS cursor left.

^{*}DEL, 7F, Delete symbol (**) is not displayed in SOLOS. Delete functions in Terminal Mode when shifted.

Table A4-2. Sol Keyboard Function Keys

(The keys are ordered in this table as found on the keyboard in two groups, left and right.)

SHIFTED, UNSHIFTED OR CONTROL

KEY	HEX. CODE		SY	MBOL DISPLAYED
ESCAPE (ESC)	18		Θ	PTDOS Only.
BREAK	_			
TAB (HT)	Ø9		\rightarrow	Both SOLOS and PTDOS.
CTRL	_			
SHIFT LOCK	_			
UPPER CASE	-			
SHIFT	-			
LOCAL	-			
SPACE BAR (SP)	20			
RETURN (CR)	ØD		+	Masked Off in SOLOS.
LINE FEED (LF)	ØA		Ξ	Masked Off in SOLOS.
DELETE (DEL)	7 F	CTRL Only (1F); 7F displays no symbol.		
LOAD	8C		#	Both SOLOS and PTDOS.
REPEAT	-			
CTRL	-			
SHIFT	-			
MODE SELECT	80		\rangle	SOLOS Terminal Mode Prompt is a programmed display of SOLOS.
\bigcap	97		4	L to the control of t
→	81		Γ	
CURSOR CONTROL	93		0	Not transmitted in SOLOS.
↓ (↓	9A		5	PTDOS Only
HOME CURSOR	8E		\otimes	
CLEAR	8B		4_	

(()

¹ See DEL in Table A4-1.

Table A4-3. Names of Graphic Characters on Keytops (The names given here are industry-standard terms.)

SP	Space	<	Less Than
!	Exclamation Point	=	Equals
1	Logical OR (not used in the Sol)	. >	Greater Than
**	Quotation Marks	?	Question Mark
#	Number Sign	@	Commercial At
\$	Dollar Sign	[Opening Bracket
ક	Percent	\	Reverse Slant
&	Ampersand]	Closing Bracket
1	Apostrophe	^	Circumflex
(Opening Parenthesis		Logical NOT
)	Closing Parenthesis		Underline
*	Asterisk	•	Grave Accent
+	Plus	{	Opening Brace
,	Comma	!	Vertical Line (This graphic is
_	Hyphen (Minus)		stylized to distinguish it from Logical OR)
	Period (Decimal Point)	}	Closing Brace
/	Slant	~	Tilde
:	Colon		
:	Semicolon		

APPENDIX 5

Sol SPECIFICATIONS

Keyboard:

85 key upper/lower case with separate numeric keypad. Upper-case shift, shift-lock, cursor control and repeat keys provided. System reset performed by simultaneous depression of control keys. Indicator lights (LED) for local, upper case and shift.

Character set:

96 printable ASCII upper and lower case characters plus 32 optionally displayable control characters.

Cursor:

Switch-selectable blinking. Block video inversion. Program controlled positioning standard. Cursors may occupy at any or all character locations.

CPU:

8080A - Uses same machine language as other 8080 systems. 2 MHz clock cycle time. 78 instructions.

Cassette Interface:

1200 Baud CUTS format or 300 Baud Kansas City format, selected by software. Recorder remote start-stop connector. AGC for level insensitivity. Phase-locked data recovery tracks with speed variations. Software performs CRC data integrity check each 256 characters.

Serial Interface:

RS-232 and 20 mA current loop, 75 to 9600 baud, asynchronous. 25 pin female "D-type" connector on card.

Parallel Interface:

Eight data bits for input and output; output bus is tristate for bidirectional interfaces; levels are standard TTI. 25 pin male "D-type" connector on card.

External memory:

Expandable to 65,536 bytes total ROM, PROM and RAM. (More than 64K with the extended addressing capability of Processor Technology Memory Modules.) Uses S-100 standard modules.

Video Signal Output:

1.0 to 2.5 volts peak-to-peak. Nominal bandwidth is 7 MHz.

Power Requirements:

117 volts AC, 50/60 Hertz, 250 Watts. 220/240 Volt, 50/60 Hertz option available.

READER COMMENTS

Use this postpaid mailer to send your comments on this manual. We will carefully consider your

suggestions for incorpor product, please attach a s		ask questions or comment about the
NAME OF MANUAL		
PUBLICATION DATE	MANU	JAL PART #
Are there specific points paragraph references.	that need clarification or co	prrection? Give details, with page and
		Do you think certain aspects should be ted or was any material unnecessary?
	ation on associated products ramaterial is missing and where	equired to use the product described in should it be placed?
	A A	
Please check the box nex Clerk, Bookkeeper Office Worker Secretary Typist, Stenographer Electronic Typist Small Business Person Manager	Doctor, Dentist Nurse Lawyer Government Worker, Official Programmer Technician Engineer	Scientist Home Personal Computer User Student Teacher Writer Other Professional Other
NAME		DATE
f you want a reply, check	_	

FOLD

FOLD

BUSINESS REPLY MAIL

NO POSTAGE NECESSARY IF MAILED IN THE UNITED STATES

Processor Technology Corporation

7100 Johnson Drive Pleasanton, CA 94566

attn: Technical Publications Dept.

PERMIT NO. 319
PLEASANTON, CALIF.

FIRST CLASS



FOLD